

STANDARD OPERATING PROCEDURE for WEIGH BRIDGE BY WEIGH BRIDGE OPERATION

Weighbridge environment

- **PPE:** Relevant PPE's such as safety helmets and safety shoes are used
- **Inspection** Ensure the weighbridge platform and the surrounding area are clean and free of dirt, debris, mud, or any obstruction that could interfere with the weighing.
- **Clearance:** Verify that the weighing platform is not in contact with its surrounding frame or walls, which can prevent it from settling correctly.

General Checks

- Instruct the driver to approach the weighbridge slowly and to drive onto the center of the platform without turning sharply or braking harshly.
- Ensure the entire vehicle is completely on the platform and all wheels are within the designated area.
- Cleaner or security personnel or weighbridge person need to guide while climbing to weighbridge to avoid vehicle sliding/falling.
- While weighting the weightment of required load vehicle, no person or other than weighing material or second vehicle should not place on weighbridge. Driver or cleaner should not stay in vehicle cabin during weightment. This should be ensured by operator of the weigh bridge.

Instrumentation

- **Power check:** Confirm that the power supply to the weighing terminal, computer, and any peripheral equipment (like cameras and barriers) is active and functioning.
- **Zero balance:** With no vehicles on the bridge, ensure the digital indicator displays a reading of exactly zero. Perform a zero adjustment if necessary.
- **Capture tare weight (empty weight):** If this is the initial weighing of an empty vehicle, capture the stable weight reading.
- **Capture gross weight (loaded weight):** If the vehicle is loaded, capture the stable weight reading. The indicator must show a stable weight before the reading is recorded.
- Check the healthiness/condition of the security seal an controlled & junction box if any breakages of seal notice informed to plant head.

