

STANDARD OPERATING PROCEDURE FOR FLUX BAKING AND HOLDING

1. **Purpose:** To provide guidelines for easy process for Flux Baking

2. **Scope:** This procedure is applicable to applicable to Flux Baking

3. **Responsibility:**

Head Production, Concern Engineers and the Shift In - Charge along with their Operators and the Sub - Contractors are responsible for this activity.

4. Procedure

- a. Operator shall fill the Flux in Flux Tray of Baking Oven whenever required.
- b. Check the unit is working properly and temperature to be " SET " at 2500 Celsius.
- c. For " TWO HOURS " Flux to be heated at 2500 Celsius temperature.
- d. After " TWO HOURS " Flux to be transfer in Holding Oven for Holding the temperature of 1000 Celsius up to Flux uses.

*** Temperature and time shall meet the flux manufacturer recommendation

- e. Operator shall issue the Flux to Saw Welder from Holding Oven.
- f. Operator shall update Flux Baking Register which indicates: -
- g. Baking Temperature, Flux in Time, Out Time, Holding Temperature,
- h. Ensure proper electrical connections with the work piece and ensure good ground.
- i. Ensuring the unit is working and in good condition.
- j. Keep the required quantity of the Flux and Electrodes inside the unit that are to be used for a da
- k. Adjust the appropriate temperature as and when required.
- l. Ensure all the electrical cables are intact and are not damaged.
- m. Maintain the machine in good working condition. He keeps his working area clean.

- n. In case of breakdown of the machine he informs his supervisors who in turn advises the plant maintenance department through the breakdown slip.
- o. Operator is responsible for " Safety Practices " at the time of work.
- p. Use of helmets, safety shoes, goggles and hand gloves is compulsory.
- q. At the time of flux taking from oven, oven should be " OFF ".
- r. DO NOT use TORN hand gloves.
- s. DO NOT touch the flux with bare hand and ensure that hand gloves are worn.
- t. DO NOT touch the coil which is inside the oven.
- u. DO NOT touch any electrical cable near the panel.



SOP NO.: PTC/Fab/PROD/ REV.00