Q MH1 FIDUCIAL ▼ MOUNTING_HOLE_4−40 Sheet: detector_connector_0 Sheet: sheet60A16C98 ♦ FIDUCIAL O MH2 VAA MISO MISO VAA_UVAA MISO MISO MOUNTING_HOLE_4-40 MOSI MOSI INT1 INT1_6 MOSI NT1D INT1_0 FID3 О мнз + FIDUCIAL SCK SCK INT2D INT2_0 SCK_DSCK INT2D_INT2_6 ↓ MOUNTING_HOLE_4-40 CS_6_5 CS CS_0_5 CS FID4 **О**мн4 FIDUCIAL MOUNTING_HOLE_4-40 GND_GND GND_GND TEENSY1 File: detector_connector.sch File: detector_connector.sch TEENSY_4.1 Sheet: sheet60A05B0A Sheet: sheet60A16CB2 GND GND GND Vin_(3.6_to_5.5_V) V_IN VAA MISO MISO VAA MISO MISO × 0 DO/RX1/CRX2/PWM MOSI MOSI INT1 INT1_1 MOSI_DMOSI INT1D_INT1_7 3.3v_(250_mA_max) 3V3_VAA × 1 D1/TX1/CTX2/PWM SCK DSCK INT2D INT2_1 SCK_DSCK INT2D_INT2_7 INT1_2 2 INT2_2 3 D3/LRCLK2/PWM CS_1_b_CS CS_7_b_CS GND GND GND_GND D21/A7/RX5/BCLK1 21 INT2_5 CS_2 4 D4/BCLK2/PWM INT1_1 5 D5/IN2/PWM File: detector_connector.sch File: detector_connector.sch INT2_1 6 D6/OUT1D/PWM D7/RX2/OUT1A/PWM Sheet: sheet60A0810C Sheet: sheet60A16CCC D18/A4/SDA0/PWM 18 INT2_4 VAA MISO MISO VAA MISO MISO INT1_0_8 D8/TX2/IN1/PWM D17/A3/TX4/SDA1 17 INT1_4 MOSI MOSI INT1D INT1_2 MOSI MOSI INT1D INT1_8 INT2_0 9 D9/OUT1C/PWM D16/A2/RX4/SCL1 16 CS_3 SCK_DSCK INT2D_INT2_2 SCK_DSCK INT2D_INT2_8 CS_0 10 D10/CS/MQSR/PWM D15/A1/RX3/SIN/PWM 15 INT2_3 CS_8_CS CS_2_5_CS MOSI 11 D11/MOSI/PWM D14/A0/TX3/SOUT/PWM 14 INT1_3 GND_GND GND_GND D13/LED/SCK/PWM 13 SCK MISO 12 D12/MISO/MQSL/PWM File: detector_connector.sch File: detector_connector.sch D41/A17 41 CS_11 D40/A16 40 INT2_11 D39/A15/MISO1/OUT1A 39 INT1_11 INT1_8 24 D24/A10/TX6/SCL2/PWM Sheet: sheet60A08126 Sheet: sheet60A16CE6 INT2_8 25 D25/A11/RX6/SDA2/PWM VAA MISO MISO VAA_DVAA MISO CS_8 26 D26/A12/MOSI1 INT1_7 27 D27/A13/SCK1 MOSI MOSI INT1D INT1_3 MOSI_MOSI INT1D_INT1_9 D38/A14/CS1/IN1 38 CS_10 SCK SCK INT2D INT2_3 SCK_DSCK INT2D_INT2_9 D37/CS/PWM 37 INT2_10 INT2_7__28 D8/RX7/PWM CS_3_bcs CS_9_bcs D35/CS/PWM 36 INT_10
D35/CS/PWM 35 CS_9
D34/RX8 34 INT_9
D33/MCLK2/PWM 33 INT_9 CS_7_29 D29/TX7/PWM GND_GND GND_GND INT1_6__30__D30/CRX3 INT2_6__31 D31/CTX3 File: detector_connector.sch File: detector_connector.sch CS_6 32 D32/OUT1B Sheet: sheet60A0BEFD Sheet: sheet60A16D00 VAA MISO MISO VAA_UVAA MISO MISO MOSI NT1D INT1_4 MOSI MOSI INT1 INT1_10 SCK SCK INT2D INT2_4 SCK_SCK INT2D_INT2_10 CS_4_bcs CS_10_5 GND GND GND_GND File: detector_connector.sch File: detector_connector.sch Sheet: sheet60A0BF17 Sheet: sheet60A16D1A VAA_UVAA MISO MISO VAA_UVAA MISO MISO MOSI NT1D INT1_5 MOSI NT1D INT1_11 SCK SCK INT2D INT2_5 SCK_DSCK INT2D_INT2_11 CS_5_CS CS_11_5 GND_GND GND_GND File: detector_connector.sch File: detector_connector.sch Janelia Sheet: / File: lick_detector_interface.sch Title: lick_detector_interface Size: A4 Date: Rev: 1.0 KiCad E.D.A. kicad 5.1.10-88a1d61d5888ubuntu20.10.1 ld: 1/13























