Cleanup Methods

- **Method 1**: Wet vacuum (in the case of porous materials, some mold spores/fragments will remain in the material but will not grow if the material is completely dried). Steam cleaning may be an alternative for carpets and some upholstered furniture.
- **Method 2**: Damp-wipe surfaces with plain water or with water and detergent solution (except wood —use wood floor cleaner); scrub as needed.
- Method 3: High-efficiency particulate air (HEPA) vacuum after the material has been thoroughly dried. Dispose of the contents of the HEPA vacuum in well-sealed plastic bags.
- Method 4: Discard remove water-damaged materials and seal in plastic bags while inside of containment, if present. Dispose of as normal waste. HEPA vacuum area after it is dried.

Personal Protective Equipment (PPE)

- Minimum:
- Gloves
- N-95 respirator
- Goggles/eye protection
- Limited:
- Gloves
- N-95 respirator or half-face respirator with HEPA filter
- Disposable overalls
- Goggles/eye protection
- Full:
- Gloves
- Disposable full body clothing
- Head gear
- Foot coverings
- Full-face respirator with HEPA filter

Containment

Limited:

- Use polyethylene sheeting ceiling to floor around affected area with a slit entry and covering flap
- o Maintain area under negative pressure with HEPA filtered fan unit
- o Block supply and return air vents within containment area
- Full:
- Use two layers of fire-retardant polyethylene sheeting with one airlock chamber
- Maintain area under negative pressure with HEPA filtered fan exhausted outside of building
- o Block supply and return air vents within containment area