Kyria × Universal Layout Ortho

Large: EN / RU output on Mac. Small: key sent by Kyria firmware.

BASE · English / Russian

Left half

Tab	Q q / й	W w / ц	E e / у	R r / к	T t / е
Esc	A а / ф	S s / ы	D d / в	F f / а	G g / п
·	Z z / я	X x / ч	C c / с	V v / м	B b / и

Right half

Y у / н	U u / г	I i / ш	O o / з	P p / х	Bksp
H h / р	J j / о	K k / л	L l / д	; ~ / ж	·
N n / т	M m / ь	, & / б	. [/ ю	/] / э	·

next to B: F13 Universal

LCmd | Caps | Space | NAV | ALT

Caps | SYM | Shift | ALT | RCmd

COMMON ACTIONS

Backspace	right of P / NAV+O	Page Up / Down	NAV+M / ,
Forward delete	NAV+P	Digits 1-5	NUM+Q / W / E / R / T
Enter	NAV+G / NAV+H	Digits 6-0	NUM+Y / U / I / O / P
Escape	NAV+T / NAV+Y	SYM: top row	! @ # $ % / ^ ? * ( )
Arrows	NAV+J / K / L / ;	F1-F10	SYM+NAV + lower row
Home / End	NAV+U / I	English / Russian	Caps: second left

NUM = NAV + SYM. F13 next to B selects Universal via Karabiner; NAV+W switches app windows.

NAV, SYM and NUM

Small: BASE position. SYM shows Universal Layout Ortho output; NUM sends keypad digits.

NAV

Hold inner left thumb key

Q	W	E	R	T	Y	U	I	O	P
C+Tab	Cmd+`	C+S+Tab	C+Tab	Esc	Esc	Home	End	Bksp	Del
A	**S**	**D**	**F**	**G**	**H**	**J**	**K**	**L**	**;**
1× Cmd	1× Opt	1× Ctrl	1× Shift	Enter	Enter	←	↓	↑	→
Z	**X**	**C**	**V**	**B**	**N**	**M**	**,**	**.**	**/**
C+M+←	C+M+→	GAME	Print	Tab	Tab	PgUp	PgDn	'	NumLock

NAV + Caps position = CMD. NAV+C activates GAME.

SYM

Hold second left key of right thumb cluster

Q	W	E	R	T	Y	U	I	O	P
!	@	#	$	%	^	?	*	(	)
A	**S**	**D**	**F**	**G**	**H**	**J**	**K**	**L**	**;**
~ / ж	`	'	"	-	+	1× Shift	1× Ctrl	1× Opt	1× Cmd
Z	**X**	**C**	**V**	**B**	**N**	**M**	**,**	**.**	**/**
\	¦	;	,	_	=	.	:	|	/

SYM+Q..P sends symbols. Right of P is Backspace. ~ / ж depends on Caps.

NUM

Hold NAV and SYM together

Q	W	E	R	T	Y	U	I	O	P
KP1	KP2	KP3	KP4	KP5	KP6	KP7	KP8	KP9	KP0
A	**S**	**D**	**F**	**G**	**H**	**J**	**K**	**L**	**;**
1× Cmd	1× Opt	1× Ctrl	1× Shift	F11	F12	1× Shift	1× Ctrl	1× Opt	1× Cmd
Z	**X**	**C**	**V**	**B**	**N**	**M**	**,**	**.**	**/**
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10

Hold NAV+SYM for digits 1-0. Right of P is Backspace; 1× modifies the next key.

Mac, other layers and Studio

Universal Layout Ortho is selected in macOS; Kyria sends firmware keys and saved Studio changes.

MAC: LANGUAGE, WINDOWS AND TABS

English / Russian

With Universal Layout Ortho selected, press the second left thumb key, Caps, to switch EN/RU within the layout. The macOS input source stays the same. Select Polish separately.

Digits and symbols

NAV+SYM activates NUM: the top row sends digits 1-0. On SYM it sends ! @ # $ % ^ ? * ( ). The ; , . / keys also change in Universal; see BASE.

macOS windows and apps

NAV+W sends Command+Grave for the next window. To switch apps: NAV+A, release, then NAV+B or NAV+N sends Command+Tab. The app sequence is not yet verified.

Tabs

NAV+Q or NAV+R sends Control+Tab; NAV+E sends Control+Shift+Tab. These work in apps that support them.

Restore Universal

F13 next to B selects Universal Layout Ortho via Karabiner. The outer LCmd and RCmd thumb keys may select U.S. or Russian.

ZMK STUDIO

Connect to the USB-C dongle through zmk.studio and press Save after editing. Ordinary Backspace is Key Press Keyboard Delete. Keypad Backspace is a different code; Keyboard Delete Forward deletes to the right.

Verified Studio edits are in the source keymap. Later Studio edits take precedence.

GAME

NAV+C activates • second left right-thumb key returns to BASE



Thumbs: Option / Space / GFN | BASE / Space / Print Screen

OTHER LAYERS

GFN

On GAME, hold the NAV position. The first two left thumb keys send Esc and Enter. GFN also has Reset and Bootloader; check their positions in firmware before use.

ALT

Hold the rightmost left thumb key or the second rightmost right thumb key: ALT+T = ё, ALT+I = щ, ALT+M = ъ. ALT+L = « and ALT+; = ». These are Universal characters; Space sends a nonbreaking space.

CMD

Hold NAV and the Caps-position thumb key. U / I / O: volume down / mute / up. J / K / L: previous track / play-pause / next track. The extra key left of Q unlocks Studio. The second left right-thumb key sends left Command.