Download and Install JetPack

This document is intended to help you get familiar with installing JetPack, using the tools, and running sample code.

System Requirements

Host Platform:

Ubuntu Linux x64 v16.04

Note that a valid Internet connection and at least 10GB of disk space is needed for the complete installation of JetPack.

Target Platform:

- One of the following developer kits:
 - Jetson TX2
 - Jetson TX2i
 - o Jetson TX1
- Additional target requirements:
 - USB Micro-B cable connecting Jetson to your Linux host for flashing.
 - (Not included in the developer kit) To connect USB peripherals such as keyboard, mouse, and [optional] USB/Ethernet adapter (for network connection), a USB hub could be connected to the USB port on the letson system.
 - o An HDMI cable plugged into the HDMI port on Jetson Developer Kit, which is connected to an external HDMI display.
 - An Ethernet cable plugged into the on-board Ethernet port, which is connected to either a secondary network card on your Linux host or the same network router providing internet access for the Linux host.

Download the Latest JetPack Version

The latest version of JetPack is available in the NVIDIA Embedded Developer Zone at:

https://developer.nvidia.com/jetson-development-pack

All available JetPack downloads can be found at:

https://developer.nvidia.com/jetpack-archive

Downloading JetPack

- On the host machine running Ubuntu, create a new directory to store installation packages.
- Download JetPack-\$ (VERSION). rum into the new directory on the host Ubuntu machine.

Avoid running or installing JetPack in a path that contains a "." Paths that contain a "." are known to cause installation issues.

Installing JetPack

JetPack runs on the host Ubuntu x86_64 machine and sets up your development environment and Jetson Development Kit target via remote access. Please refer to the System Requirements section for supported hardware configurations.

The following instructions assume you have downloaded the latest JetPack version, JetPack-\$ (VERSION). run, where \$ (VERSION) refers to the version string for the installer you have.


1. Add exec permission for the JetPack-\$ {VERSION}.run


chmod +x JetPack-\$ {VERSION}.run

2. Run JetPack-\$ (VERSION). run in terminal on your host Ubuntu machine.



3. Next, the JetPack installer will indicate the installation directory. In the Privacy Notice section, select whether or not to enable data collection






5. The JetPack installer will pop up a window to ask for permission to use during the installation process; you will need to enter your sudo password here.




6. The Component Manager opens, which allows you to customize which components to install. Select the Jetson Developer Kit you would like to develop for to customize the installation components for each device.





8. The Component Manager will proceed with the installation. Once the host installation steps are completed, click the Next button to continue with the installation of target components.





NOTE: JetPack will now proceed with setting up the Jetson Developer Kit target, if the corresponding components were selected (i.e., flashing the OS and pushing components to the Jetson Developer Kit target).

9. If you de-selected Flash OS in the Component Manager, you will need to enter the IP address, user name, and password to set up an ssh connection to the target device.



After you enter the required information and click Next, JetPack will begin installing components on the target device.


10. If you selected Flash OS in the Component Manager, you will need to select the network layout for your specific environment.



11. If you selected the Device access Internet via router/switch layout, you will be asked to select which interface to use for Internet access.



12. If you selected the **Device get IP assigned by DHCP server on host and access Internet via host machine** layout, you must select which interface is to be used for Internet access, and which is to be used for the target interface.



13. A pop-up window will instruct you to put your device into Force USB Recovery Mode, so you can flash the OS.

```
● ◎ ◎ Postinstallation
Please put your device to Force USB Recovery Mode, when your are ready, press En
ter key
To place system in Force USB Recovery Mode:
```

1. Power down the device. If connected, remove the AC adapter from the device. The device MUST be powered OFF, not in a suspend or sleep state.

2. Connect the Micro-B plug on the USB cable to the Recovery (USB Micro-B) Port on the device and the other end to an available USB port on the host PC.

3. Connect the power adapter to the device.


4. Press and release the POWER button to power on device. Press and hold the FOR CE RECOVERY button, while pressing the FORCE RECOVERY button, press and release the RESET button; wait two seconds and release the FORCE RECOVERY button.;

5. When device is in recovery mode, lsusb command on host will list a line of "N Vidia Corp"

14. Next, you will be prompted to install components on the specific target machine, and to compile samples.



15. After the post installation tasks have been completed, the installation will be complete.



Compiling Samples

JetPack automatically compiles all samples, if Compile Samples was checked during the component selection portion of the installation. CUDA samples can be found in the following directory:

Samples

You can recompile the samples by running:


SMS=53 EXTRA_LDFLAGS=--unresolved-symbols=ignore-in-shared-libs TARGET_ARCH=aarch64 make

Run Sample Code

The CUDA samples directory will be copied to the home directory on your device by JetPack. The built binaries are in the following directory:

 $\begin{tabular}{ll} \hline (home/ubuntu/NWIDIA_CUDA-<\!version>_Samples/bin/aarch64/linux/release/\\ \hline \end{tabular}$

Run them by calling them in terminal, or double-clicking on them in the file browser. For example, when you run the oceanFFT sample, the following screen will be displayed.



NVIDIA® JetPack with Linux for Tegra® Documentation Rev.3.3.180716 ©2018. NVIDIA Corporation. All Rights Reserved.