NSO Sustainability Automation Example

Reaching Network Automation Level 5 **Principles and Practice**

Per Andersson Viktoria Fordos Jan Lindblad

Ulrik Stridsman

NSO Engineering Architects

Learning Objectives and Prerequisites

Once the Adaptive Service Activation Scripts (Network Automation Level 2) are left behind, a world of life-cycle flexibility and stylistic freedom of the services running in our network. What can we use this flexibility for? In this lab, the participant will upgrade a pre-existing Network Services Orchestrator (NSO) service from Network Automation Level 3 to Level 5 by adding service health measurement and make it adapt to changes in the environment.

The vision of the Internet Engineering Task Force (IETF) Application Level Traffic Optimization (ALTO) Working Group (WG) is to optimize the application and network together, so that the delivered service is delivered as well as possible to the collection of users. This might mean delivering this user's service from a data center that is not the closest one, but from another with less load or lower energy prices, and therefore less expensive to the customer. Moving service instances around becomes a natural part of the life-cycle.

Prerequisites:

- Basic programming skills in Python
- Some familiarity with NSO services and YANG modules

Key takeaways:

- Hands-on experience with Network Automation Levels 3-5
- Giddy feeling of power arising from services that adapt to their environment
- Insight into how network orchestration may be used for sustainability

Disclaimer

This training document is to familiarize with Network Services Orchestrator (NSO) and Network Automation Levels. Although the lab design and configuration examples could be used as a reference, it's not a real design, thus not all recommended features are used, or enabled optimally. For the design related questions please contact your representative at Cisco, or a Cisco partner.

Table of Contents


LEARNING OBJECTIVES AND PREREQUISITES	2
DISCLAIMER	2
THE CCENARIO	_
THE SCENARIO	<u> 5</u>
BACKGROUND	5
VIDEO DELIVERY SERVICE	
LAB STARTING-POINT	
PREPARING YOUR RUNTIME ENVIRONMENT	8
THE FIRM OF THE PROPERTY OF TH	
STEP P.4: SELECTING IMPLEMENTATION AND BUILDING THE SYSTEM	8
STEP P.5: GETTING TO THE NSO COMMAND PROMPT	9
STEP P.6: UPDATING THE PROJECT	9
STEP P.7: CONFIGURING A SERVICE INSTANCE	10
STEP P.8: LOOKING AT OPERATIONAL DATA AND THE PLAN	11
STEP P.9: TURNING OFF COMMIT MESSAGES	13
TASK 1 OVERVIEW: GO TO LEVEL 4, ADD MONITORING	13
Overview 1.1 Replace dc/is-active with dc/oper-status/jitter	13
OVERVIEW 1.2 REPLACE EDGE/DC WITH EDGE/OPER-STATUS/CHOSEN-DC	
OVERVIEW 1.3 WRITE A DC SELECTION FUNCTION IN PYTHON	15
Overview 1.4 Configure Skylight	15
Overview 1.5 React to Skylight Notifications	16
OVERVIEW 1.6 BUILD AND DEPLOY	16
Overview 1.7 Test	16
TASK 1 DETAILED INSTRUCTIONS	20
STEP 1.1 REPLACE DC/IS-ACTIVE WITH DC/OPER-STATUS/JITTER	20
STEP 1.2 REPLACE EDGE/DC WITH EDGE/OPER-STATUS/CHOSEN-DC	
STEP 1.3 WRITE A DC SELECTION FUNCTION IN PYTHON	
STEP 1.4 CONFIGURE SKYLIGHT	
STEP 1.5 REACT TO SKYLIGHT NOTIFICATIONS	
STEP 1.6 BUILD AND DEPLOY	
STEP 1.7 TEST	
TASK 2 OVERVIEW: GO TO LEVEL 5, ADD ONGOING OPTIMIZATION	26
OVERVIEW 2.1 ADD EDGE-CAPACITY AND ENERGY-PRICE	
Overview 2.2 Add edge-clients (optional)	
Overview 2.3 Better DC Selection Function	

OVERVIEW 2.4 OPTIMIZATION DOESN'T HAVE TO BE NOTIFICATION BASED	27
OVERVIEW 2.5 KEEP OPTIMIZING	27
OVERVIEW 2.6 BUILD AND DEPLOY	27
Overview 2.7 Test	28
TASK 2 DETAILED INSTRUCTIONS	33
	22
STEP 2.1 ADD EDGE-CAPACITY AND ENERGY-PRICE	
STEP 2.2 ADD EDGE-CLIENTS (OPTIONAL)	
STEP 2.3 BETTER DC SELECTION FUNCTION	
STEP 2.4 OPTIMIZATION DOESN'T HAVE TO BE NOTIFICATION BASED	34
STEP 2.5 KEEP OPTIMIZING	35
STEP 2.6 BUILD AND DEPLOY	35
STEP 2.7 TEST	
SUMMARY	37
RESOURCES FOR NEXT STEPS	37

The Scenario


Background

As an industry, we have been talking for years about "network automation". The exact meaning of that concept has often been rather nebulous. Attempts at defining more specific levels, similarly to how the auto industry defined specified levels of "self driving cars".



Even with the examples showing what the network automation levels mean, however, people did not get very clear and intuitive understanding of what the levels mean.

The purpose of this lab is to give the participants a concrete, hands-on, intuitive feel for the meaning of level 3, level 4 and level 5 network automation.




In this lab we going on a journey, starting at a pre-existing NSO level 3 service. The first stage of the journey will be to upgrade it to a level 4 implementation by adding service monitoring functionality into the service definition. The second stage takes the service to level 5 by adding a mechanism for constant, on-going optimization of all service instances.

You can read more about the network automation levels in this blog post https://community.cisco.com/t5/nso-developer-hub-blogs/network-automation-levels/ba-p/4742665

Video Delivery Service

In this example, we are looking at a video delivery service. The service is implemented by a network of data centers (DCs) and edge devices. Each DC contains an Origin Video Server (this is something we made up for this lab), and a generic firewall. The edge devices are Edge Video Caches (again, this is something we made up for this lab), that are built to work together with the Origin Video Servers. Imagined end-users can then consume their video feeds through the Edge Video Caches.




The NSO service we are talking about here controls how the Edge Video Caches are connected to the DCs. Each Edge Video Cache must be connected to exactly one DC, but which one can vary over time, depending on the DC availability, delivered quality, load and the current energy price at the DC location.

At the starting point of this lab, it is the NSO operators that manually decide through configuration which DCs are considered available and which Edge Video Caches are connected to which DCs. While the service at this level automates the device configuration work for the Origin Video Servers and firewalls, the manual decisions/configurations about DC availability and which Edge device should connect to which DC obviously is not automated to a high level. We call this level 3.


Lab Starting-point

In the lab setup, we have a single NSO instance that controls all the DCs, all the relevant devices in them, and all the Edge devices. All the devices in the DC and the Edge devices are really NSO NETSIM devices. That means they basically only implement the management interfaces as described by their YANG models, but otherwise don't really do anything. We have endowed some of these NETSIMs with a little bit of additional behavior, though, so that they react and respond to a few things. Such functionality will be described later, as needed.



Also, logically part of each DC is an Accedian Skylight monitoring system. In our setup, there is really only one instance of a skylight system, or "device" as NSO tends to think of all managed systems as devices. A single skylight is enough since we think of it as running "in the cloud" outside our DCs.

When we start, the NSO system is already up and running with the level 3 service implementation, and there are Network Element Drivers (NEDs) for all device types installed, and the devices are already listed in the NSO device list.



Preparing your Runtime Environment

The first few preparation steps (Installing development tools, Installing NSO, Cloning the example application repository) are described in the README.md file. Once they are completed, you can continue with the demo/lab preparations here.

Step P.4: Selecting Implementation and Building the System

This lab has a top level Makefile that takes care of building and sets up pretty much everything required to run this project. It even goes so far as to start up the NSO Command Line Interface (CLI) if all the build steps are successful.

At the core of the project you will find the "streaming" NSO service. This project contains three different implementations of the streaming service, referred to as level3, level4 and level5. Level3 is the expected starting point for the lab, but you can switch back and forth between levels any time.

Before your first build, you will need to set the project to use the level3 implementation. Never mind the error message, it's because no implementation was selected previously.

```
$ ./streaming-switch-level.sh level3
rm: ./packages/streaming/current: No such file or directory
ln -s level3 ./packages/streaming/current
Set streaming service implementation to:
level3
$
```

You may edit the code in any of these levelX-directories directly. You may also copy any of the levels into your own directory (but you need to keep that copy in the same package directory). This may be useful if you want to keep the original implementations unchanged, so that you can easily compare your solution with any of them.

OPTIONAL:

```
$ cp -r packages/streaming/level3 packages/streaming/myway
$ ./streaming-switch-level.sh myway
```

Once you have selected which streaming service implementation to use, you can build the project using make.

```
$ make clean all
...
```

If everything goes well, the build ends with a prompt inside the NSO Command Line Interface (CLI). In this case, all NSO NED packages and the streaming service package have been built. An NSO NETSIM network created and started. All devices synced.

```
...
#### Entering NSO Command Line Interface as user admin
ncs_cli -Cu admin
admin connected from 127.0.0.1 using console on ...
admin@ncs#
```

You can now work with the devices and services in the NSO system.

Step P.5: Getting to the NSO Command Prompt

If you dropped out of the NSO CLI and want to get back in from the Linux command line, there are a couple of ways. If your build is working fine, just running make will drop you in there soon enough:

```
$ make all
...
admin connected from 127.0.0.1 using console on ...
admin@ncs#
```

If the build is stopping mid-way, and you still want to get into the NSO CLI, you can also just launch the NSO CLI binary.

```
$ ncs_cli -Cu admin

User admin last logged in ... using cli-console
admin connected from 127.0.0.1 using console on ...
admin@ncs#
```

To drop back out to the Linux command line (or leave any NSO CLI sub mode), use the exit command (or press ctrl+d).

```
admin@ncs# exit $
```

Step P.6: Updating the Project

As you are making changes to the source packages in the project, NSO will **not** automatically pick them up. That's a feature, not a bug. © Updating NSO packages' behavior should only happen when the operator explicitly requests so, and not because some file happened to change.

When using the ./streaming-switch-level.sh command to change which packages are being used, it may be good to do a full clean rebuild of the project. The way the Makefile has been set up, this will also remove all data from the NSO database etc. That would not be normal in a production environment, but makes sense in this lab.

```
$ make clean all
```

If you have not changed the set of packages, but did change the contents of one or more YANG file, an incremental rebuild is what you want. This will not change the set of packages, and the NSO database contents will be kept. Once the build completes, you will need to perform a packages reload command to make the change take effect, and it's a good habit to always check the packages' operational status after a reload. If there isn't an X in the UP column, you have some debugging to do.

```
$ make all
...
User admin last logged in ... using cli-console
admin connected from 127.0.0.1 using console on ...
admin@ncs# packages reload
...
reload-result {
   package streaming
   result true
}
```

admin@ncs# show packages package oper-status												
NAME	UP	PROGRAM CODE ERROR	JAVA UNINITIALIZED	PYTHON UNINITIALIZED	BAD NCS VERSION	PACKAGE NAME	PACKAGE VERSION	CIRCULAR DEPENDENCY	META DATA ERROR	FILE LOAD ERROR	ERROR INFO	WARNINGS
edge-nc-1.0	х	-	-	_	_	-	-	_	-	_	_	-
firewall-nc-1.0	X	-	-	-	-	-	-	-	-	-	-	-
origin-nc-1.0	X	-	-	-	-	-	-	-	-	-	-	-
skylight-nc-1.0	X	-	-	-	-	-	-	-	-	-	-	-
streaming	Х	-	-	-	-	-	-	-	-	-	-	-
admin@ncs#												

For changes to files that do not require compilation, that is python and template files, all you need to do in order for the change to take effect is to reload packages.

```
admin@ncs# packages reload
...
reload-result {
   package streaming
   result true
}
admin@ncs#
```

Step P.7: Configuring a Service Instance

In NSO our service streaming service is called "edge" in the YANG tree. To add edge service instances, you first have to go to configuration mode.

```
admin@ncs# config
Entering configuration mode terminal
```

To then create an edge service instance you type edge and a name for the service instance. Since the streaming service instances are tied 1:1 to the edge video caching devices, the name of the service instance has been locked down to only allow names of edge devices. As the system comes prepared, there are four edge devices, edge0, edge1, edge2 and edge3.

Pressing the TAB-key at any point completes the command or provides possible continuations.

```
admin@ncs(config)# edge edge0 ->
Possible completions:
  check-sync
                       Check if device configuration is according to the service
  dc
  deep-check-sync Check if device configuration is according to the service get-modifications Get the data this service created
 deep-check-sync
  load-from-storage
 log
 plan
               Run/Dry-run the service logic again
 re-deploy
 reactive-re-deploy Reactive re-deploy of service logic
  touch
                        Mark the service as changed
                       Undo the effects of the service
  un-deploy
  <cr>
admin@ncs(config)# edge edge0
```

In the initial (level3) version of the streaming service, you have to manually specify which datacenter the edge service should be connected to. Out of the box this lab has two datacenters, called dc0 and dc1.

```
admin@ncs(config)# edge edge0 dc dc

Possible completions:
dc0 dc1
```

```
admin@ncs(config)# edge edge0 dc dc0
admin@ncs(config-edge-edge0)#
```

To review changes, you can use the show config command (at the top level to see all config changes).

```
admin@ncs(config-edge-edge0) # top
admin@ncs(config) # show config
edge edge0
  dc dc0
!
admin@ncs(config) #
```

To make these pending changes take effect, they need to be committed.

Before we do that, let's take a quick look at the current configuration on the Origin Video Server. This is just to show that currently the content catalogue is empty.

```
admin@ncs(config) # show full-configuration devices device origin0 config origin content % No entries found.
admin@ncs(config) #
```

Now we can commit our edge service instance. We will look at the content catalogue again shortly.

```
admin@ncs(config)# commit
Commit complete.
```

Step P.8: Looking at Operational Data and the Plan

Operational data is the data you can look at, but not change. At least not change directly. The streaming service has some interesting operational data you may want to observe. You can observe this data while you are still in configuration mode, but then you have to put do in front of your show command, to indicate that you want to run an operational mode command.

```
admin@ncs(config) # do show edge edge0
                                                                   POST
        BACK
                                                                   ACTION
TYPE NAME TRACK GOAL STATE
                                                               ref STATUS
                                   STATUS
                                             WHEN
                                   reached
self self false -
                                              2024-01-25T15:34:10 -
                  init.
                   dc dc false -
                   init
                   fw-configured not-reached - ready not-reached -
plan-location /edge[name='edge0']
admin@ncs(config)#
```

At this point in the lab, pretty much all you see is the service's plan. Each NSO nano-service has an associated plan that shows how far the service instance has come in its realization.

As you can see here, this service instance has reached its init state, but is not ready. The datacenter component seems to be waiting on the state fw-configured. Looking in streaming-plan. yang reveals that this stage has a pre-condition associated. It is waiting for the operator to configure the datacenter leaf is-active with value true.

```
admin@ncs(config) # dc dc0 is-active true
admin@ncs(config-dc-dc0)# commit
Commit complete.
admin@ncs(config-dc-dc0)#
System message at 2024-01-25 16:42:13...
Commit performed by admin via console using cli.
admin@ncs(config-dc-dc0)#
System message at 2024-01-25 16:42:21...
Commit performed by admin via system using cli.
admin@ncs(config-dc-dc0)#
System message at 2024-01-25 16:42:21...
Commit performed by admin via system using cli.
admin@ncs(config-dc-dc0)#
System message at 2024-01-25 16:42:21...
Commit performed by admin via console using cli.
admin@ncs(config-dc-dc0)#
```

The commit command changed the datacenter dc0 to is-active. Moments later, there was a second commit performed by the system itself. This is called a re-deploy. It was triggered by the pre-condition for state fw-configured now being true. Seconds later a few more commits happened spontaneously. Other stages of the service plan got into action. Dropping out to operational mode to have a look.

```
admin@ncs(config-dc-dc0)# exit
admin@ncs(config)# exit
admin@ncs# show edge edge0
                BACK
                                                                                                                   POST ACTION
TYPE NAME TRACK GOAL STATE
                                                 reached 2024-01-25T15:34:10 -
reached 2024-01-25T15:42:12 -
reached 2024-01-25T15:34:10 -
self self false - init
dc dc false - init
                                 reached 2024-01-25T15:34:10 -
skylight-configured reached 2024-01-25T15:34:10 -
fw-configured reached 2024-01-25T15:42:12 -
ready reached 2024-01-25T15:42:12 -
init reached 2024-01-25T15:42:12 -
connected-to-dc reached 2024-01-25T15:42:12 -
edge edge false - ready init
                                  connected-to-dc reached 2024-01-25T15:42:12 -
connected-to-skylight reached 2024-01-25T15:42:12 -
                                                                                                                  create-reached
                                                                 reached 2024-01-25T15:42:12 -
                                  ready
 modified devices [ edge0 fw0 origin0 skylight ]
 directly-modified devices [ edge0 fw0 origin0 skylight ]
 plan-location /edge[name='edge0']
admin@ncs#
```

All the service plan states have now been reached. Let's check the Origin Video Server catalogue again.

```
admin@ncs# show running-config devices device origin0 config origin content
devices device origin0
config
  origin content "Blade Runner"
  !
  origin content "Die Hard"
  !
  origin content "Pulp Fiction"
  !
  origin content "The Dark Knight"
  !
  !
  !
  admin@ncs#
```

The service creation has apparently resulted in some device-level configuration changes.

Step P.9: Turning off Commit Messages

If at any point in this lab, you grow tired of the automatic commit messages popping up as soon as something is being committed by the system (or a fellow operator, if you have any), you can turn them off.

```
System message at 2024-01-23 21:46:57...

Commit performed by admin via system using cli.

admin@ncs(config) #

System message at 2024-01-23 21:46:57...

Commit performed by admin via system using cli.

admin@ncs(config) #
```

Open up the ncs.conf NSO configuration file in the project root directory, and look up the commit-message setting.

```
<commit-message>true</commit-message>
```

Change it to false, then save the file.

OPTIONAL:

```
<commit-message>false</commit-message>
```

In order for the change to take effect, you also need to give NSO a reload command (or simply restart it with make clean all) on the Linux command line.

```
$ ncs --reload
$
```

The commit messages were left on by default so that you would see when things are happening.

Task 1 Overview: Go to Level 4, Add Monitoring

The first task in this lab is to extend the existing level3 streaming service so that every service instance created also is monitored, rendering it a level4 service. For monitoring, we are using Accedian Skylight. To do that we have a number of changes in mind.

Here follows a number of steps to implement the level4 service. First each step is described on an overview level. After that follows the same steps one more time, but now on a very detailed level with specific implementation proposals. If you already have a good idea about how to implement the step as described in the overview, you don't need to read the detailed description for that step. If you aren't sure what the overview instructions are trying to say, or would like to verify that your solution is on the right track, you will find one of many possible implementations in the detailed section.

Overview 1.1 Replace dc/is-active with dc/oper-status/jitter

The is-active leaf allows an operator to declare by configuration when s/he judges that a particular DC is ready to be used. This sort of manual health judgement does not feel very automated at all, and needs to go. Instead we would like Skylight to monitor and report the health of each DC, and only advice services to deploy on a particular DC if its health scores

are good. In this lab, we're letting jitter be a proxy for health score, in order not to overcomplicate matters.

Note that the streaming-plan.yang currently refers to dc/is-active, so you will need to update the plan too.

To allow us to track the jitter values, we need to add an operational leaf inside the list of DCs. Operational data is often kept in a container called oper-status to make it super obvious that it's not configuration. Here is a suggested formulation for the jitter leaf.

```
container oper-status {
  config false;
  tailf:info "The actual operational state of the DC.";
  tailf:cdb-oper {
    tailf:persistent true;
  }
  leaf jitter {
    description "The latest reported jitter value for this DC.";
    type decimal64 {
       fraction-digits 3;
    }
    units "ms";
  }
}
```

Overview 1.2 Replace edge/dc with edge/oper-status/chosen-dc

Level3 edge service instances are configured to use a particular dc. This does not feel very automated at all, and on level4, this needs to go. Instead we would like each edge service instance to automatically pick the DC with the best jitter (health score).

Since operators and code in the later stages in the service deployment process will want to know which DC was selected, an operational leaf (a leaf that is not configurable by the operator) in the YANG module should be introduced instead. We suggest also changing the name of the leaf, so that the change is more visible and clear. We recommend placing the operational data in the service under a container called oper-status. Since the data should survive a restart of NSO, it makes sense to mark it as persistent. You could use a YANG structure like this.

```
container oper-status {
  config false;
  tailf:info "The actual operational state of the service.";
  tailf:cdb-oper {
    tailf:persistent true;
  }
  leaf chosen-dc {
    ...
  }
}
```

There are a few templates and one reference in Python to leaf dc that need to be updated to reflect the new location and name.

- python/streaming/main.py (in class LoadFromStoragePostAction)
- templates/edge-servicepoint-dc-fw-configured.xml
- templates/edge-servicepoint-edge-connected-to-dc.xml
- templates/edge-servicepoint-edge-connected-to-skylight.xml

Overview 1.3 Write a DC Selection Function in Python

Since the edge service can no longer rely on operator input when figuring out which DC to connect to, we need to add Python code that makes this choice. We also need to ensure it is invoked at the right time in the nano-service plan, so that coming plan stages that depend on this decision have access to the result of the decision. The decision also needs to be published in such a way that later stages (and operators) can see which DC the service instance decided to use.

The boiler-plate code to insert in main.py in order to handle a particular state might look something like the below. Then add your own decision logic, and update chosen-dc with the result. Replace ComponentStateName with something that reflects which component and state this code pertains to, for your own code navigation.

```
class ComponentStateName(NanoService):
    @NanoService.create
    def cb_nano_create(self, tctx, root, service, plan, component, state, proplist, compproplist):
        self.log.info(f'cb nano create: ComponentStateName for {service.name}')
```

In order for the above state handling code to be called, it also need to be registered in the service's setup method. You do it like this, but remember to replace ComponentName, StateName with the component and states you have chosen that this code should be invoked in, and replace ComponentStateName with the same name you picked for your Python class above.

Overview 1.4 Configure Skylight

The Skylight device needs to be updated with a monitoring session for each edge service instance. Luckily for us, Skylight experts have provided a template with some variables for us to use. You will find this template in edge-servicepoint-edge-connected-to-skylight.xml

This Skylight configuration template sets up a Two-Way Active Measurement Protocol (TWAMP) session between a DC and an Edge device. In addition, the edge device needs to have its TWAMP-reflector function enabled. This is done by adding the following piece of configuration template to the edge device:

Overview 1.5 React to Skylight Notifications

Finally, we need to do something to remedy the situation when Skylight reports changes in jitter (health score). This certainly applies if the jitter (health score) would sky-rocket, but may be equally relevant if the jitter improves markedly.

Overview 1.6 Build and Deploy

As your service changes develop towards a fully-fledged level4 solution, you will likely need to rebuild and re-deploy the service multiple times. If you have changed any YANG module contents, you will need to rebuild on the Linux command line as described previously.

If you only changed Python or template files, packages reload is sufficient to bring in the changes.

Overview 1.7 Test

Something like following behavior is expected once the solution is complete, but it is certainly up to you to decide how closely to recreate this behavior.

First, let's see that we have a good initial state. Packages loaded without error, there is a jitter value per dc, there are no edge services at this point.

```
admin@ncs# show packages package oper-status
                  PROGRAM
              CODE JAVA PYTHON BAD NCS PACKAGE PACKAGE CIRCULAR
UP ERROR UNINITIALIZED UNINITIALIZED VERSION NAME VERSION DEPENDENC
                                                                                                         ERROR
                                                                        VERSION DEPENDENCY ERROR
                                                                                                                WARNINGS
edge-nc-1.0
firewall-nc-1.0 X -
origin-nc-1.0
admin@ncs# show dc
NAME JITTER
dc0 20.0
dc1
       25.0
admin@ncs# show edge
% No entries found.
admin@ncs#
```

Then let's create an edge service instance, and dry-run it to see what it would do with the devices in the network. The output should certainly mention all the devices, edge0, fw0, origin0 and skylight. Note that we abbreviated the fw0 output below with an ellipsis (...), since it is quite long.

```
device fw0
                      config {
                          acl {
                               acl-sets {
                                  acl-set edge0 ACL_IPV4 {
                                      config {
                                          name edge0;
                                           type ACL_IPV4;
                                       acl-entries {
                               }
                      }
                  device origin0 {
                      config {
                          origin {
                               edge 127.0.0.1 {
                              content "Blade Runner" {
                               content "Die Hard" {
                              content "Pulp Fiction" {
                              content "The Dark Knight" {
                      }
                  device skylight {
                              session bd05cfaa-d30d-5560-8f4b-5b88f1e9a0fc agent {
                                  sessiontype twamp;
                                   ifStateful true;
                                      agentId a31e3e45-ec69-4f4a-a479-b2273f8077be;
                                       agentSessionName dc0-agent-to-edge0-twamp;
                                       enable true;
                                      period continuous;
                                  twamp {
                                       senderDscp 0;
                                       reflectorAddr 127.0.0.1;
                                       reflectorPort 4000;
                                       reportInterval 31;
                      }
             +edge edge0 {
admin@ncs(config-edge-edge0)# commit
Commit complete.
admin@ncs(config-edge-edge0)#
```

At this point, the service creation happens, and the configuration changes are sent to all the devices. Since this is a nano-service with multiple stages, the services will re-deploy themselves when a condition they have been waiting for has been fulfilled. We can then show the nano-service plan state for the edge0 service instance.

```
admin@ncs(config-edge-edge0)#
System message at 2024-01-29 16:37:58...
Commit performed by admin via system using cli.
admin@ncs(config-edge-edge0)#
System message at 2024-01-29 16:37:58...
Commit performed by admin via system using cli.
admin@ncs(config-edge-edge0)#
System message at 2024-01-29 16:37:58...
Commit performed by admin via console using cli.
admin@ncs(config-edge-edge0)# exit
admin@ncs(config)# exit
admin@ncs# show edge
                                                                                                                                                                                                                                           POST ACTION
                                 BACK
TYPE NAME TRACK GOAL STATE
                                                                                                                                                                                                                           ref STATUS
                                                                                                                                      STATUS WHEN
                                                                                                 reached 2024-01-29T15:37:50 - reached 2024-01-29T15:37:50 -
self self false - init
                                                                   ready
                                                                    init reached 2024-01-29T15:37:50 -
skylight-configured reached 2024-01-29T15:37:50 -
fw-configured reached 2024-01-29T15:37:50 -
ready reached 2024-01-29T15:37:50 -
dc dc false -
                                                                    init reached 2024-01-29T15:37:50 - connected-to-dc reached 2024-01-20T15:37:50 - connected-to-dc reached 2024-01-2
edge edge false -
                                                                  init
                                                                                                                                      reached 2024-01-29T15:37:50 -
                                                                                                                                                                                                                                           create-reached
                                                                     connected-to-skylight reached 2024-01-29T15:37:50 -
                                                                      ready
                                                                                                                                      reached 2024-01-29T15:37:50 -
  modified devices [ edge0 fw0 origin0 skylight ]
  directly-modified devices [ edge0 fw0 origin0 skylight ]
  plan-location /edge[name='edge0']
   oper-status chosen-dc dc0
admin@ncs#
```

Great, the service creation seems to work. Now, let's change the jitter value for dc1 and create a few more service instances. The long command under devices device skylight reaches out to the skylight device and requests that it sends a notification update about a measured jitter value. Since we have no real devices and no traffic in the network, we use this manual setup to simulate what a Skylight device might have sent.

```
admin@ncs# show dc
NAME JITTER
     20.0
     25.0
dc1
admin@ncs# devices device skylight rpc rpc-send-notification-low-jitter send-notification-low-
jitter device dc1
admin@ncs# show dc
NAME JITTER
dc0 20.0
dc1 1.198
admin@ncs# config
Entering configuration mode terminal
admin@ncs(config)# edge edge1
admin@ncs(config-edge-edge1)# edge edge2
admin@ncs(config-edge-edge2)# edge edge3
admin@ncs(config-edge-edge3)# commit
Commit complete.
admin@ncs(config-edge-edge3)#
```

At this point, three additional service instances are created. They will naturally pick the dc with the best jitter value. As these service instances progress in their nano-service plan, there will be multiple system messages like this.

```
System message at 2024-01-29 16:40:43...
```

```
Commit performed by admin via system using cli.
```

When the service creations are completed, we can have a look at the edge services' operational status. All the new service instances have picked dc1. The previous service instance edge0 remains with dc0.

If we simulate that dc1 suddenly gets a much greater jitter value by sending another Skylight notification, the service instances on dc1 will immediately switch to dc0.

```
admin@ncs# devices device skylight rpc rpc-send-notification-high-jitter send-notification-
high-jitter device dc1 jitter 45.2
admin@ncs#
System message at 2024-01-29 16:45:14...
Commit performed by admin via console using cli.
admin@ncs#
System message at 2024-01-29 16:45:14...
Commit performed by admin via console using cli.
admin@ncs#
System message at 2024-01-29 16:45:14...
Commit performed by admin via console using cli.
admin@ncs# show dc
NAME JITTER
dc0 20.0
dc1
    45.2
admin@ncs# show edge oper-status
      CHOSEN
NAME DC
edge0 dc0
edge1 dc0
edge2 dc0
edge3 dc0
admin@ncs#
```

Task 1 Detailed Instructions

The steps that follow here are detailed implementation proposals for each one of the overview points discussed in the previous chapter.

Step 1.1 Replace dc/is-active with dc/oper-status/jitter

In streaming.yang, look up leaf is-active. Remove it. Remember to remake the package, and issue a packages reload command in NSO afterwards to make the changes take effect.

Remove this from streaming.yang:

```
leaf is-active {
  type boolean;
  default false;
}
```

In streaming-plan.yang, there is a reference to is-active. This blocks edge service instances from using a DC that is not active. Since we will update the selection logic, we won't be needing this block any more. Remove it.

Remove this from streaming-plan.yang:

```
ncs:pre-condition {
  ncs:monitor
   "/streaming:dc[name = $SERVICE/dc]" {
   ncs:trigger-expr "is-active = 'true'";
  }
}
```

To provide a leaf location for the jitter value for each DC, add this to streaming.yang inside, e.g. at the end of the list dc { ... }, where the leaf is-active was.

```
container oper-status {
  config false;
  tailf:info "The actual operational state of the DC.";
  tailf:cdb-oper {
    tailf:persistent true;
  }
  leaf jitter {
    description "The latest reported jitter value for this DC.";
    type decimal64 {
       fraction-digits 3;
    }
    units "ms";
  }
}
```

Step 1.2 Replace edge/dc with edge/oper-status/chosen-dc

Removing a configurable leaf and replacing with an operational leaf is pretty easy,

Replace this in streaming.yang:

```
leaf dc {
  type leafref {
    path "/dc/name";
  }
}
```

... with this:

```
container oper-status {
  config false;
  tailf:info "The actual operational state of the service.";
  tailf:cdb-oper {
    tailf:persistent true;
  }
  leaf chosen-dc {
    type leafref {
       path "/dc/name";
    }
  }
}
```

Because of this change, we have to update several references to edge/dc to go to edge/oper-status/chosen-dc instead. Three such references are in templates, and one in Python.

Replace this in edge-servicepoint-edge-connected-to-skylight.xml, in edge-servicepoint-dc-fw-configured.xml and in edge-servicepoint-edge-connected-to-dc.xml:

```
<?set DC = {./dc}?>
... with this:
    <?set DC = {./oper-status/chosen-dc}?>
```

You will find the reference from Python in class LoadFromStoragePostAction. This action is being called in the service's nano-plan. This action tells the Origin video server to update its content so that it has all the content currently being cached in the Edge video caching devices. Obviously, that command needs to be sent to the right Origin video server; the one in the selected DC. The change is needed due to us renaming leaf dc to leaf oper-status/chosendc.

Replace this in main.py:

```
origin_name = root.dc[service.dc].media_origin
... with this:
    origin_name = root.dc[service.oper_status.chosen_dc].media_origin
```

Step 1.3 Write a DC Selection Function in Python

The DC selection needs to happen very early in the deployment of the edge service, since most other things depend on it. This selection does not depend on anything else being decided in the service instance, so it can very well go first in the DC component nano-plan.

The dc component already has an "init" state that does nothing. We can change that so that it calls a Python method that makes the DC selection, and then writes the decision to the chosen-dc operational leaf.

Replace this in streaming-plan.yang:

```
ncs:component-type "dc" {
  ncs:state "ncs:init";
```

... with this:

```
ncs:component-type "dc" {
  ncs:state "ncs:init" {
    ncs:create {
      ncs:nano-callback;
    }
}
```

Since we chose to implement the DC selection in the DC component's init state, a reasonable class name might be DCInit. This class should have a cb_nano_create method, which will be invoked by NSO when getting to the state in the plan, which will be immediately at service creations with the nano-plan above.

This function should now figure out which DC to use, and write the name of the chosen one to service.oper_status.chosen_dc. As selection logic here, we are just looping over all the DCs and keeping track of which one has the lowest jitter. Yes, if you are a Python wizard you could do this in more or less a single line, but here we prefer to keep to the basics.

```
class DCInit(NanoService):
    @NanoService.create
    def cb_nano_create(self, tctx, root, service, plan, component, state, proplist, compproplist):
        self.log.info(f'cb_nano_create: DCInit for {service.name}'
        # Find the DC with the lowest jitter
        best_jitter = 100000
        best dc = None
        for dc in root.dc:
            if dc.oper_status.jitter is None:
               self.log.info(f'Checking DC {dc.name}: DC is not ready')
                continue # Data not available yet, disregard this option
           dc jitter = float(dc.oper_status.jitter)
            self.log.info(f'Checking DC {dc.name}: jitter {dc_jitter}')
            if dc jitter < best jitter:
               best_jitter = dc_jitter
               best dc = dc
        if best dc is None:
           raise Exception('No DC found')
        self.log.info(f'Found DC {best_dc} with the lowest jitter {best_jitter}')
                                                       # Value goes into operational data, usable
        service.oper status.chosen dc = best dc.name
                                                        # by templates applied at later stages
```

Then, a bit lower down in main.py, make sure the setup method starts like this (but keep the rest of what is in the setup method too), to have the state code registered/associated with the right component and state:

Step 1.4 Configure Skylight

Services usually have to configure devices, or sometimes lower-level services. This generally happens through templates. The contents of these templates are typically received from

experts on the particular devices or services being used. The templates use XML format in order to resolve ambiguity that often arise with other formats. This XML content is usually generated by configuring the device (or lower-level service) manually using CLI or any convenient method, then grabbing the result as NETCONF XML.

The edge-servicepoint-edge-connected-to-skylight.xml template is great when it comes to what needs to be setup on the Skylight device. There are two main problems with it, however, the way it is created. First, the config templates declares a servicepoint, componenttype and state. This means the template will override any Python (or Java) code that implements this state. The code we have in ConnectedToSkylight in main.py isn't getting called, despite being properly registered. The purpose with that code is to create a unique session id, needed by the Skylight configuration. This leads to the second problem, which is that the SESSION_ID variable in the template is hard-coded. The session id would not be unique at all, making all edge service instances overwrite each other's Skylight config.

Fixing these things in the template is easy, just remove a few of the headers, and the Python code will be invoked. The Python code already computes a value for the SESSION_ID, which will then be picked up as the Python code applies the template.

One more thing, leaf dc changed name to oper-status/chosen-dc. This needs to be updated in the template DC variable as well.

Replace this in edge-servicepoint-edge-connected-to-skylight.xml:

Besides configuring the Skylight device, we also need to configure the Edge device to enable its TWAMP reflector. Maybe this should have been a separate step in the nano-plan for super clarity, but here we chose the slightly more lazy option to just piggy back this in the same template as the skylight setup.

So we are back in edge-servicepoint-edge-connected-to-skylight.xml again, and right after the existing configuration for the skylight device:

Insert this:

This will be near the very end of the template, but make sure the </config-template> line still goes last.

Step 1.5 React to Skylight Notifications

Monitoring is great, but if we don't handle most situations automatically, we can't say the network is very automated, can we? Of course, we don't want to raise any alarms for situations that the system is resolving on its own, right? Alarms are for getting the attention of operators, and that's not what we are looking for here. So what do we do?

There will obviously be situations that the automated system can't handle well, but if the Skylight indicates that one of our DCs is giving is trouble, such as high jitter, an obvious solution would be to switch to another. Which one? Well, there is already logic in the service for picking the best DC at the time of creation. So how about simply reusing that? In NSO terms, recomputing the best way to express an existing service in light of new operating conditions, but without changing the intent (i.e. service configuration), is called a re-deploy.

So what we want is to automatically re-deploy services when we get notifications about jitter changes from Skylight. Which services? All of them? While re-deploying all services every time a notification about a change comes in might be optimal in one sense, it does not scale all that well. Doing so would make all service instances always and immediately go to the DC with the best jitter. Also, if you have a lot of service instances (e.g. tens of thousands or millions), the sheer re-computation work could be large.

In the design here, we have chosen to re-deploy all services on the particular DC that the notification concerns. This means the services on this DC will migrate if the jitter values get high, but all edge service instances will not always immediately flock to the best DC. To implement this automatic re-deploy of services, we are using an NSO notification kicker, i.e. a function that will invoke an action when a particular kind of notification is received. Kickers are easily set up with a bit of configuration. We have chosen to, yet again, place this kicker config snippet in the edge-servicepoint-edge-connected-to-skylight.xml since it is applied at the right time.

Add this to edge-servicepoint-edge-connected-to-skylight.xml . You can add it "anywhere" in the template (order between blocks does not matter), but of course not within the existing blocks. How about putting it after the <devices>...</devices> blocks in there?

```
<kickers xmlns="http://tail-f.com/ns/kicker">
  <notification-kicker xmlns="http://tail-f.com/ns/ncs-kicker">
     <id>skylight-notification-kicker</id>
```

This will be near the very end of the template, but make sure the </config-template> line still goes last.

Step 1.6 Build and Deploy

How to build and deploy has been described earlier in this document, but here follows a brief summary of what you need to do after making the changes above.

Every time you make a change to a YANG module (streaming.yang, streaming-plan.yang) or Java module (none in this project) you need to get to the Linux command line and run make like this:

```
$ make all
```

If all goes well, you will end up on the NSO command line again. If there are compilation or build errors, you will need to correct them, then rerun make as above again.

NSO will not automatically use the new versions of your packages. Upgrading your system is a potentially disruptive operation and should always be done very consciously, using packages reload. For changes to templates and Python code, this is sufficient to get those changes into the system. We recommend to always follow up with showing the package status, in order to see more clearly that all packages are running fine.

```
admin@ncs# packages reload
...
admin@ncs# show packages package oper-status
```

Step 1.7 Test

If everything is running fine now, the command sequence described earlier in this chapter under point 0 (see page 16) should work on your system and produce something similar.

During the development work, there are a couple of log files that may come in handy, to see what is going on in the system.

The most useful one is probably going to be the streaming service log file.

```
$ less logs/ncs-python-vm-streaming.log
```

The development log, and XPath trace log may occasionally also be useful.

```
$ less logs/devel.log
$ less logs/xpath.trace
```

Task 2 Overview: Go to Level 5, Add Ongoing Optimization

In the second task in this lab, we are taking the service to level 5. This means we are adding a more advanced optimization, and in particular, ensuring that optimization is always on. We will even go so far as to stop reacting immediately on incoming notifications. In the real world, you would probably keep reacting immediately when you are notified about really bad conditions, but here the point we are trying to make stands out clearer if we don't.

As with the task 1 work, each step is described first on an overview level, then once more in full detail a bit further down.

Overview 2.1 Add edge-capacity and energy-price

In order to have a more complex (more interesting) decision function that takes into account several different parameters when deciding which DC an edge service should connect to, we'll start by adding two leafs to the DC model. Edge-capacity is a configurable leaf where the operator sets the max number of edge clients that the DC can support. Let's give this leaf a default value of 3.

Energy-price is an operational value in each DC that you can set manually to simulate changes. Want to play things scientifically and specify a unit for the leaf? You can use USD/MWh as the unit. We have also provided an action called action/vary-energy-price. If you invoke this action, a background Python thread will go around and adjust the energy-price for a DC every 15 seconds or so. You can turn off the price variations by running the same action again.

```
admin@ncs# actions vary-energy-price
result Started Varying Energy Price
admin@ncs# actions vary-energy-price
result Stopped Varying Energy Price
admin@ncs#
```

The code for this thing is found in skylight_notification_action.py, if you are curious, but we don't expect you to make any changes here.

Overview 2.2 Add edge-clients (optional)

Each edge service instance already has a leaf called oper-status/chosen-dc that operators can have a look at if they are interested to see which DC an edge service instance is connected to.

As it turns out, it will be interesting to have a look at the DC operational status as price and jitter varies. If the list of edge service instances attached to each DC was listed in the same operational status view, that looks cool. This step is entirely optional and only provides information that is already available in one more view.

If you want to do this, add a new leaf-list in the DC list as oper-status/edge-clients. Add and remove the name of the edge client to this list as it moves around.

You may be interested to know that the Python MAAGIC methods to remove and add elements from a leaf-list are

```
myleaflist.remove(somename)
myleaflist.create(somename)
```

Overview 2.3 Better DC Selection Function

Now that we have a few more parameters to look at besides jitter, namely edge-capacity and energy-price, you should devise an optimization function that selects the best DC by taking all of these into account in some way. We will leave exactly how up to you, but we are very interested in hearing your thoughts about what you chose to do, and also what you would have liked to do if you had more time to implement something grander.

In our opinion, the optimization function should not allow more edge service instances to join a particular DC than specified in edge-capacity for that DC.

Overview 2.4 Optimization doesn't have to be Notification Based

You probably remember from your work on task 1 that when a jitter change notification is received from Skylight, that triggers an invocation of the action class SkylightNotificationAction. This callback updates the DC jitter operational data value, and also calls reactive_re_deploy() on the service instances that are connected to the particular DC. It's time to remove the re-deploy part of this code now.

Not that this behavior is bad, but it makes it harder to see what's going on once we get to level5, so for now, let's take it out. In a real system, keeping something that re-deploys services that got into trouble is a good thing, but typically some more thought needs to go into the solution than just immediately re-deploying large number of service instances.

Overview 2.5 Keep Optimizing

Remember that vary-energy-prices action mentioned earlier? We have one more Python background thread that can be started and stopped at will with a similar command.

admin@ncs# actions optimize result Stopped Optimizer admin@ncs# actions optimize result Stopped Optimizer admin@ncs#

The idea with the optimizer thread is that it picks one of the edge service instances every 15 seconds in a round-robin fashion and optimizes it with respect to the current DC capacity, jitter and energy price.

This action is already implemented in keep_optimizing_action.py, but there is one problem. The code that actually does the optimization of the edge service instance is missing, and you have to provide it.

Overview 2.6 Build and Deploy

The commands to rebuild and deploy your solution are exactly the same as before. For YANG changes you first need to run make on the Linux command line.

\$ make all

After the make went through fine, or if you only did Python or template changes, you need to load the new package versions with packages reload. We recommend to also taking a look at the package oper-status afterwards.

```
admin@ncs# packages reload
...
admin@ncs# show packages package oper-status
```

Overview 2.7 Test

Something like following behavior is expected once the solution is complete, but it is certainly up to you to decide how closely to recreate this behavior.

First, let's see that we have a good initial state. Packages loaded without error, there is a jitter value per dc as before, but now also energy-price and edge-clients. There are no edge services at this point.

```
admin@ncs# show packages package oper-status
                                                                                      PACKAGE
                PROGRAM
             CODE JAVA PYTHON BAD NCS PACKAGE PACKAGE CIRCULAR
UP ERROR UNINITIALIZED UNINITIALIZED VERSION NAME VERSION DEPENDENCY
edge-nc-1.0
firewall-nc-1.0 X
origin-nc-1.0 X
skylight-nc-1.0 X
streaming
admin@ncs# show dc
                ENERGY EDGE
NAME JITTER PRICE CLIENTS
dc0 20.0 100 -
dc1 25.0
              75
admin@ncs# show edge
% No entries found.
admin@ncs#
```

Let's go and create all four edge service instances right away. A commit dry-run shows what configuration would be sent to the various devices. The output is actually quite substantive now, so we have shortened it a bit, in order to keep you from flipping too many pages.

Worth noting is that there is some twamp reflector config for all edge devices. A bunch of (different) firewall rules are provided for both fw0 and fw1. Both Origin video servers get their content catalogs updated with (different) content, depending on what titles are needed for each Edge video cache device. The skylight configuration gets a bunch of twamp sessions to set up. Finally the edge services themselves are also mentioned, but have no configuration data.

```
admin@ncs# config
Entering configuration mode terminal
admin@ncs(config)# edge edge0
admin@ncs(config-edge-edge0)# edge edge1
admin@ncs(config-edge-edge1)# edge edge2
admin@ncs(config-edge-edge2)# edge edge3
admin@ncs(config-edge-edge3)# commit dry-run
   local-node {
       data devices {
                 device edge0 {
                    config {
                       edge {
                            streaming-port 554;
                             origin-server 127.0.0.1;
                         twamp {
                           session-reflector {
                                admin-state true;
```

```
}
   }
device edge1 {
device edge2 {
device edge3 {
device fw0 {
   confiq {
       acl {
           acl-sets {
                acl-set edge3 ACL IPV4 {
                   config {
                       name edge3;
                       type ACL_IPV4;
                    acl-entries {
                       acl-entry 10 {
           }
       }
   }
device fw1 {
device origin0 {
   config {
       origin {
           streaming-port 554;
            edge 127.0.0.1 {
                streaming-port 554;
            content "Apollo 13" {
            content "Some Like it Hot" {
            content "Terminator 2: Judgement Day" {
            content "The Matrix" {
        }
   }
device origin1 {
   config {
        origin {
            streaming-port 554;
            edge 127.0.0.1 {
               streaming-port 554;
            content Alien {
            content "Blade Runner" {
            content "Die Hard" {
            content "Don't Look Up" {
            content Ghostbusters {
            content "Pulp Fiction" {
            content "Terminator 2: Judgement Day" {
            content "The Dark Knight" {
            content "The Matrix" {
```

```
}
                  device skylight {
                     config {
                         sessions {
                              session 2848df3f-f27c-53ce-9373-ab64036d1f0b agent {
                                  sessiontype twamp;
                                  ifStateful true;
                      }
             +edge edge0 {
             + }
             +edge edge1 {
             +}
             +edge edge2 {
             + }
             +edge edge3 {
admin@ncs(config-edge-edge3)#
```

Ok, let's commit that.

```
admin@ncs(config-edge-edge3)# commit
Commit complete.
admin@ncs(config-edge-edge3)# exit
admin@ncs(config)# exit
admin@ncs#
System message at ...
```

At this point a whole bunch of system messages drop into the CLI. After some seconds a few more land there. This is because the Origin video server requires some time to load the titles needed by the Edge video caches, and the DC switch won't complete until they are available at the new DC.

Now, let's observe the edge state.

```
admin@ncs# show edge
                                                     BACK
                                                                                                                                                                                                                                                                                                                                                                                POST ACTION
TYPE NAME TRACK GOAL STATE
                                                                                                                                                                                                                    STATUS WHEN
                                                                                                                                                                                                                                                                                                                                                         ref STATUS
                                                                                                                                                                                         reached 2024-01-31T15:43:00 - reached 2024-01-31T15:43:00 - reached 2024-01-31T15:43:00 -
self self false -
                                                                                                            skylight-configured reached 2024-01-31T15:43:00 - fw-configured reached 2024-01-31T15:43:00 - re
                                                                                                             ready reached 2024-01-31T15:43:00 -
reidy reached 2024-01-31T15:43:00 -
init reached 2024-01-31T15:43:00 -
connected-to-dc reached 2024-01-31T15:43:00 -
                                                                                                            ready
edge edge false -
                                                                                                         init
                                                                                                                                                                                                                  reached 2024-01-31T15:43:00 -
                                                                                                                                                                                                                                                                                                                                                                               create-reached
                                                                                                            connected-to-skylight reached 2024-01-31T15:43:00 -
                                                                                                                                                                                                                  reached 2024-01-31T15:43:00 -
                                                                                                            readv
   modified devices [ edge0 fw1 origin1 skylight ]
    directly-modified devices [ edge0 fw1 origin1 skylight ]
   plan-location /edge[name='edge0']
   oper-status chosen-dc dc1
```

Similar information follows for the other edge service instances. We can see edge0 reached state ready and selected dc1 as its DC. At this point, the show dc view gives a pretty good overview.

```
admin@ncs# show dc
ENERGY
NAME JITTER PRICE EDGE CLIENTS

dc0 20.0 100 [ edge3 ]
dc1 25.0 75 [ edge0 edge1 edge2 ]

admin@ncs#
```

Now we immediately see that three edge service instances (edge0 .. 2) selected dc1, and we can see why – the energy price is considerably lower, even if the jitter is a bit higher than dc0. The edge3 service instance had to pick dc0 because dc1 had already reached its edge-capacity of 3 edge clients.

We can now play around with the jitter, energy-price and edge-capacity values. As before, we can order the skylight device to "detect" a jitter change and send a notification to NSO.

This immediately updates the jitter value for dc0, but nothing happens when it comes to moving edge service instances around. To do that, we can turn on the optimizer.

```
admin@ncs# actions optimize
result Started Optimizer
admin@ncs#
System message at 2024-01-31 16:57:16...
Commit performed by admin via console using cli.
admin@ncs# show dc
          ENERGY
NAME JITTER PRICE EDGE CLIENTS
_____
dc0 1.951 100 [ edge0 edge3 ] dc1 25.0 75 [ edge1 edge2 ]
admin@ncs#
System message at 2024-01-31 16:57:31...
Commit performed by admin via console using cli.
admin@ncs# show dc
         ENERGY
NAME JITTER PRICE EDGE CLIENTS
_____
dc0 1.951 100 [ edge0 edge1 edge3 ] dc1 25.0 75 [ edge2 ]
admin@ncs#
```

The optimizer takes one edge service instance every 15s and re-deploys it. That makes the service instance implement itself on the best DC under the current circumstances. The first service instance to move from dc1 to dc0 was edge0. Apparently that very low jitter value is more attractive than the energy-price difference. Edge1 soon follows. Edge2 is stuck on dc1 because dc0 is now at capacity.

To make this a little more interesting, we can start to vary the energy prices in the background too, and display the dc status on repeat.

```
admin@ncs# actions vary-energy-price
result Stopped Varying Energy Price
admin@ncs# show dc | repeat
```

The show on repeat gives a display like this.

```
ENERGY

NAME JITTER PRICE EDGE CLIENTS

dc0 1.951 97 [ edge0 edge1 edge3 ]
dc1 25.0 75 [ edge2 ]
```

That high jitter on dc1 really keeps service instances away. Press Ctrl+C to interrupt and get back to the command prompt again. Let's give dc1 a little lower jitter. We can specify the exact value if we want (doing so on either rpc-send-notification-low-jitter or -high-jitter commands has the same effect).

```
admin@ncs# devices device skylight rpc rpc-send-notification-low-jitter send-notification-low-jitter device dc1 jitter 3.5
admin@ncs# show dc | repeat
```

After a little while, the DC status might look like this instead.

Once you get to this point, you have completed the lab and implemented a level5 service. Congratulations! ©

Task 2 Detailed Instructions

The steps that follow here are detailed implementation proposals for each one of the overview points discussed in the previous chapter.

Step 2.1 Add edge-capacity and energy-price

Since edge-capacity in meant to be a configurable item the list dc, you can add this after leaf skylight-agent-id and before container oper-status. The exact placement is not particularly important, but it needs to be inside list dc and outside the oper-status container, and not within any of the other leaf declarations.

```
leaf edge-capacity {
  description "The number of edge services this DC can handle.";
  type uint32;
  default 3;
}
```

Leaf energy-price is meant to be an operational status value, so it should go inside container oper-status of the list dc.

```
leaf energy-price {
  description "The latest reported energy-price value for this DC.";
  type uint32;
  units USD/MWh;
}
```

Remember to run make when you have YANG module changes, before you do the packages reload.

Step 2.2 Add edge-clients (optional)

So you want to be a hero and do all the optional work as well?! © Nice, don't worry, this step won't take long. There's really only a couple of small things here. Inside the container oper-status in list dc, add a leaf-list like this.

```
leaf-list edge-clients {
  description "The edge service instances currently depending on this DC.";
  type leafref {
    path /edge/name;
  }
}
```

In the next step (the DC selection function), there are a couple of more Python lines to add and remove edge service instance names to this leaf-list.

Step 2.3 Better DC Selection Function

There really isn't any right answer for how to write this function, so I would be shocked if you came up with a very similar solution. I will definitely conclude you had a peek at this solution, if that happens. ©

So here is our thinking. We have the existing optimization function from level4, which talks about jitter. Since we'll be combining multiple variables here, let's not call it best_jitter anymore, but best_score, and base that score on jitter and energy_price in some way.

How to weigh jitter and energy_price against each other? Well, if you are more concerned about energy price than jitter, giving it a higher weight might make sense (see

JITTER_WEIGHT and PRICE_WEIGHT). How do you compare values that have different units of measurement and are of totally different magnitudes? As an engineer, let me propose using logarithms. This way a change of one value from 0.26 to 0.35 will show as a relatively larger change than a change in another from 1000 to 1200. But let's not relive algebra class here, I'm sure whatever you pick will do.

```
class DCInit(NanoService):
   JITTER WEIGHT = 1
   PRICE_WEIGHT = 2
    @NanoService.create
    def cb_nano_create(self, tctx, root, service, plan, component, state, proplist, compproplist):
        self.log.info(f'cb_nano_create: DCInit for {service.name}')
        # Find the DC with the lowest score (based on jitter, energy-price and DC capacity)
        best score = 100000
        best dc = None
        for dc in root.dc:
            if dc.oper status.jitter is None or dc.oper status.energy price is None:
                self.log.info(f'Checking DC {dc.name}: DC is not ready
                continue # Data not available yet, disregard this option
            if len(dc.oper status.edge clients) >= dc.edge capacity and service.name not in
dc.oper status.edge clients:
               self.log.info(f'Checking DC {dc.name}: DC is full')
                continue # Already full, not an option
            dc jitter = float(dc.oper status.jitter)
            dc price = int(dc.oper status.energy price)
            dc_score = DCInit.JITTER_WEIGHT * math.log10(dc_price)
            self.log.info(f'Checking DC {dc.name}: jitter {dc_jitter} price {dc_price} -> score
{dc score}')
            if dc score < best_score:</pre>
               best_score = dc_score
        best_dc = dc
if best_dc is None:
           raise Exception ('No DC found')
                                                         # Value goes into operational data, usable
        service.oper status.chosen dc = best dc.name
                                                         # by templates applied at later stages
        self.log.info(f'Using DC {root.dc[service.oper_status.chosen_dc].name}')
```

If you chose to do the optional step with edge-clients above, then revise the tail end of the code to the thing below instead. That will remove the edge service instance name from the previous DC's leaf-list edge-clients and add it to the newly selected one.

```
if best_dc is None:
    raise Exception('No DC found')
if service.oper_status.chosen_dc:
    self.log.info(f'Leaving DC {root.dc[service.oper_status.chosen_dc].name}')
    # This is just to keep operators informed, not affecting the service logic
    root.dc[service.oper_status.chosen_dc].oper_status.edge_clients.remove(service.name)

service.oper_status.chosen_dc = best_dc.name  # Value goes into operational data, usable
    # by templates applied at later stages

self.log.info(f'Using DC {root.dc[service.oper_status.chosen_dc].name}')
# This is just to keep operators informed, not affecting the service logic
root.dc[service.oper_status.chosen_dc].oper_status.edge_clients.create(service.name)
```

Step 2.4 Optimization doesn't have to be Notification Based

In order not to re-deploy service instances as Skylight notifications are flowing in, just delete the following lines from skylight notification action.py.

```
# Automatically re-deploy services that are on the DC in the notification,
# but let all other services stay as they are
for edge in r.streaming__edge:
    if edge.oper_status.chosen dc == notification.device:
        self.log.info(f'Re-deploying service {edge.name}')
        edge.reactive_re_deploy()
    else:
        self.log.info(f'Leaving service {edge.name} on {edge.oper_status.chosen dc} as is')
```

Step 2.5 Keep Optimizing

What do you need to do to make a service instance optimize itself in the context of the current environment? We have said it, we have done it so many times already in this lab: redeploy the service. The missing piece of code is really a one-liner.

```
edge.reactive re deploy()
```

We will show where to insert it below. To hide this simple fact a bit, we also changed the comments in the module to say <optimize> etc. when we actually mean re-deploy.

The comment at the top of the module should read

This module implements an NSO action callback that is used to optimize the running services. When this action is invoked, it will start a background thread that reads the list of edge services and re-deploys them one by one at regular intervals (see INTERVAL_TIME below). Invoking the same action again will make the thread terminate.

The worker thread comment should read

```
# worker_thread
# Reactively re-deploys edge service instances, one at a time.
# The thread runs every few seconds (INTERVAL TIME) until requested to stop.
```

The log message and actual re-deploy function call should, near the bottom, just before the exception handling stuff, should read

```
edge = r.streaming__edge[edge_names.pop(0)]
self.log.info(f'Optimizer re-deploying service {edge.name}')
edge.reactive re deploy()
```

If you have eagle-eyes, you may have noticed that the code is calling reactive_re_deploy() rather than just re_deploy(). The difference is small but sometimes crucial. The reactive-variant invokes the service instance re-deploy as the same user that created the service, rather than the one launching the re_deploy call. In this lab, we're using the same NSO user in both situations, so it doesn't matter. We just want this code to do the right thing.

Step 2.6 Build and Deploy

This has been described many times now, and the commands to rebuild and deploy your solution are exactly the same as before. For YANG changes you first need to run make on the Linux command line.

```
$ make all
```

After the make went through fine, or if you only did Python or template changes, you need to load the new package versions with packages reload. We recommend to also taking a look at the package oper-status afterwards.

```
admin@ncs# packages reload
...
admin@ncs# show packages package oper-status
```

Step 2.7 Test

If everything is running fine now, the command sequence described earlier in this chapter in section Overview 2.7 should work on your system and produce something similar.

During the development work, there are a couple of log files that may come in handy, to see what is going on in the system.

The most useful one is probably going to be the streaming service log file.

```
$ less logs/ncs-python-vm-streaming.log
```

The development log, and XPath trace log may occasionally also be useful.

```
$ less logs/devel.log
```

^{\$} less logs/xpath.trace

Summary

Thank you for staying with us all the way till the end! We hope you have enjoyed the lab, and we are sincerely interested in any feedback you may have.

This lab was developed in order to give the network automation levels a concrete form. Hopefully you now have a good intuitive feel for what level 3 means, and how that is different from level 4. The system behavior at level 5 is qualitatively different from level 4, but did you notice how small the code-wise differences between a level 4 system and a level 5 system can be?

The NSO development team is trying hard to enable you to design the system behavior you need with good performance at a minimum amount of modeling and coding work. The DC selection function in the level 5 service implementation shows where we are on this journey.

The lab is publicly available at github and gitlab for anyone to go through, or to file suggestions or questions. You will find it at

- https://github.com/janlindblad/nso-sustainability-automation-example
- https://gitlab.com/nso-developer/nso-automation-levels-example

Resources for Next Steps

- Discussion: NSO Developer Hub
- CiscoLive: <u>Network Automation in Theory and Practice</u>. A journey from YANG modelling to monitored and adaptive services
- LinkedIn: Cisco Automation Developer Community
- YouTube: Cisco Automation Developer Hub
- Book: Network Programmability with YANG
 @Pearson/Addison-Wesley @O'Reilly @Amazon