

33 KV Line Pole Numbering on Database

Grid Name+ PBS Name+ Feeder Name+ Pole No.

11 KV Line Pole Numbering on Database

S/S Name + PBS Name+ Feeder Name+ Pole No.

33 KV Line Pole Numbering on Pole

Starting Pole= Grid Name+ PBS Name+ Feeder Name+ Pole No.

Border Area= Grid Name + PBS Name+ Feeder Name+ Pole No.

Key Pole= Grid Name + ~~PBS Name~~+ Feeder Name+ Pole No.

General Pole= ~~Grid Name~~ + ~~PBS Name~~+ Feeder Name+ Pole No.

11 KV Line Pole Numbering on Pole

Starting Pole= S/S Name + PBS Name+ Feeder Name+ Pole No.

Border Area= S/S Name + PBS Name+ Feeder Name+ Pole No.

Key Pole= S/S Name + ~~PBS Name~~+ Feeder Name+ Pole No.

General Pole= ~~S/S Name~~ + ~~PBS Name~~+ Feeder Name+ Pole No.