ECE 230L - LAB 2

SILICON WAFER CHARACTERIZATION RESISTIVITY, CARRIER CONCENTRATION, MOBILITY

Note: The pre-lab for this lab should be completed before the FIRST lab section occurring the week of your scheduled lab. This pre-lab consists of entering your average measured 4-point probe sheet resistance, sample thickness, and resistivity values for each of the 3 samples probed in the SMIF. To complete this laboratory, the entire class data set will be used. Type in your data at the link provided on the ECE 230L Sakai site by the due date, above using the online data entry link provided on Sakai.

Contents

| Pre-Lab | | 2 |
|--------------|---|---|
| 1 | Objectives of this Laboratory | 3 |
| 2 | Determining Carrier Concentration for Resistivity Data | 4 |
| 3 | Plot of Resistivity vs. Impurity Concentration | 4 |
| 4 | Estimating expected Resistivity given a Carrier Concentration | 5 |
| 5 | Device Performance based on Doping and Sample Data | 5 |
| \mathbf{G} | Grading Rubric | |

Pre-Lab: Calculate Resistivity from Probe Measurement

The goal of this portion of the laboratory is to determine, from the sheet resistance data measured for the Silicon wafers in the SMIF, the resistivity of each of the wafers.

The four-point probe Van der Pauw method that was used in the SMIF provided a sheet resistance value. This value was calculated by the instrument by providing a small current (I) through the 4 probes which are equally spaced on the sample and measured the voltage (V) across the two inner probes. The V/I values reported by the instrument are in units of Ohms (Ω) . These values are called the sample's sheet resistance. For thick semiconductor samples like the ones measured in the SMIF—where the thickness of the wafer (W) is much smaller than the width and length of the sample—the resistivity of the sample is given by the equation

$$\rho = \frac{V}{I}t\tag{1}$$

where V/I is the sample's sheet resistance (Ω) and t is the sample's thickness (cm).

Calculate the resistivity of each of the wafers that you measured in the SMIF using the above equation. Enter these values along with the sheet resistance and sample thickness for each of the wafers that you measured in the SMIF. Enter your values by clicking here or going to the url https://duke.qualtrics.com/jfe/form/SV_bkjCbShas8s2N13.

1 Objectives of this Laboratory

The objectives of this laboratory session are as follows:

• Measure the sheet resistance of several Silicon wafers using a 4-point probe Van der Pauw measurement tool

- Using wafer thickness, determine the resistivity of Silicon wafers
- Determine Carrier Concentration of Silicon Wafers
- Determine μ of Silicon Wafers
- Obtain class data and average class values
- Determine number and values of doped wafers used—determine σ of each

Below, we have included a table with all of the symbols used in this lab manual and their definitions for your convenience.

Table 1: Relevant notation used throughout lab manual

| Symbol | Definition | Unit |
|---------|------------------------------------|---------------------|
| R | Resistance | Ω |
| L | Length | cm |
| A | Area | cm^2 |
| t | Thickness | cm |
| I | Current | A |
| V | Voltage | V |
| ρ | Sample resistivity | Ω-cm |
| e | Magnitude of the electronic charge | С |
| μ_p | Hole mobility | cm^2/V_s |
| μ_n | Electron mobility | cm^2/V_s |
| n, p | Carrier concentration | cm^{-3} |
| N_A | Acceptor Concentration | cm^{-3} |
| N_D | Donor Concentration | cm^{-3} |
| N_I | Impurity Concentration | cm^{-3} |

2 Determining Carrier Concentration for Resistivity Data

All of the samples measured in the SMIF were p-type Boron doped. To determine the carrier concentration, N_A , a few assumptions need to be made.

Assumptions:

- 1. $\mu_p = 480 \text{ cm}^2/V_s$ (see Table 5.1, pp. 158 in Neaman text)
- 2. $N_D = 0$
- 3. Complete ionization

Along with these assumptions, we can use

$$\rho = \frac{1}{e(\mu_n n + \mu_p p)} \tag{2}$$

to determine carrier concentration. Here, e is the magnitude of the electronic charge, which is always 1.6×10^{-19} C.

Given the above assumptions, the equation for ρ reduces to

$$\rho = \frac{1}{e\mu_p N_A}.\tag{3}$$

 \square Calculate the carrier concentration, N_A , for the entire class data set. Since we are assuming that $N_D = 0$, the N_A value is exactly the impurity concentration, N_I .

3 Plot of Resistivity vs. Impurity Concentration

Plots of resistivity, ρ versus impurity concentration, N_I are called Irwin curves. They are used to estimate the carrier concentrations of samples once the sample's resistivity is known.

- \square Plot on a log-log scale the resistivity, ρ versus impurity concentration, N_I (in this case, the same as the carrier concentration, N_A) for the class data set. Your plot should resemble Figure 5.4 on pp. 165 of the Neamen text. Remember that the SMIF samples were all p-type (Boron) doped. This plot should have many values of ρ and N_I based on the class data.
- \square Determine a curve-fit to this data from the above plot including \pm error ranges. Justify the \pm error ranges used. Does the expected error range vary with carrier concentration?

4 Estimating expected Resistivity given a Carrier Concentration

With a plot of resistivity, ρ , versus impurity concentration, N_I , it should be possible to extract either ρ or N_I given the other.

 \square For a Si p-type (Boron) doped Carrier Concentration, N_A of 1×10^{17} cm³, what range of Resistivity, ρ , values would you expect to obtain from this sample? Use your class averaged data plot and curve-fit from Section 3 to answer this question. Note that a range of resistivity is specified, so the \pm error range must be used.

5 Device Performance based on Doping and Sample Data

The resistance, R, of a sample can be determined based on its resistivity, ρ , given the sample cross-sectional area, A, and length, L. The equation for determining Resistance from resistivity is the following (see Neaman Section 5.1.3 pp. 164):

$$R = \frac{\rho L}{A} \tag{4}$$

□ For a die-sized portion of a wafer just like the ones measured in class, with cross-sectional area $A = 10^{-6}$ cm² and length L = 0.001 cm of the Si p-type (Boron) doped sample above—with Carrier Concentration N_A of 1×10^{15} cm³ and a resistivity range as determined in Section 4 based on class-measured data—in an applied voltage of 5 V, determine the range of expected currents that would flow through this die.

Submit the answers to the questions marked by a square (\Box) along with all of the other below-listed items in the rubric in your Lab X write-up.

Table 2: ECE 230L Laboratory 2 Grading Rubric

| Criteria | Points Possible |
|--|-----------------|
| Pre-Lab | 15 |
| Sheet resistances (x 3) reported | 5 |
| Sample thicknesses (x 3) reported | 5 |
| Resistivities calculated (x 3) | 5 |
| Determining Carrier Concentration for Resistivity Data | 10 |
| Data set | 10 |
| Plot of Resistivity vs. Impurity Concentration (Irwin curve) | 45 |
| Plot | 10 |
| Curve-fit | 10 |
| \pm error range specified | 10 |
| Justification for error range | 15 |
| Estimating expected Resistivity given Carrier Concentration | 15 |
| Range of resistivities specified | 15 |
| Device Performance based on Doping and Sample Data | 15 |
| Current range specified from data | 15 |
| Total | 100 |