

TechNova TN-3000 Smart Wi-Fi Router

Product User Manual & Troubleshooting Guide

Model: TN-3000 | Category: Networking Equipment / Wireless Router

The TN-3000 is a dual-band Wi-Fi 6 router designed for home and small-office networks. It provides 2.4 GHz and 5 GHz wireless connectivity, one Gigabit WAN port, four Gigabit LAN ports, a WPS button, and a 12V DC power input.

1. Product Specifications

Specification	TN-3000
Wireless Standard	IEEE 802.11ax (Wi-Fi 6)
2.4 GHz Speed	Up to 574 Mbps
5 GHz Speed	Up to 2402 Mbps
WAN Port	1 × Gigabit Ethernet (RJ-45)
LAN Ports	4 × Gigabit Ethernet (RJ-45)
Security	WPA3 / WPA2
Antennas	4 external omnidirectional antennas
Power Input	12V DC barrel jack
WPS	Hardware WPS button

2. Package Contents

The package contains one TN-3000 router, one 12V DC power adapter, one Ethernet cable, a quick-start guide, and the product warranty card.

3. Hardware Overview

The front panel contains status indicators for Power, Internet, 2.4G, 5G, and WPS. The rear panel contains one blue WAN port, four yellow LAN ports, a DC power jack, and the WPS button. Four external antennas provide wireless coverage.

4. Setup Instructions

1. Connect the 12V DC power adapter to the router and switch on the power.
2. Connect the Internet/modem Ethernet cable to the blue Gigabit WAN port.
3. Connect wired devices to any of the four yellow Gigabit LAN ports when required.
4. Wait for the Power and Internet indicators to become stable.
5. Connect your phone or computer to the TN-3000 Wi-Fi network.
6. Open the router configuration page and follow the setup wizard.
7. Create a secure Wi-Fi password and select WPA3 or WPA2 security.

5. LED Indicator Guide

LED	Meaning
Power	Solid: router is powered and operating normally.
Internet	Solid: Internet connection is available. Blinking: network traffic is active.
2.4G	Indicates 2.4 GHz wireless activity.
5G	Indicates 5 GHz wireless activity.
WPS	Indicates WPS pairing activity.

6. Network Configuration Tips

For normal operation, place the router in an open central location. Keep the antennas upright. Use the 5 GHz band for higher-speed devices located near the router and the 2.4 GHz band for longer-range connectivity. Use WPA3 when supported by client devices; otherwise use WPA2.

7. Troubleshooting Guide

Problem	Recommended Action
No power	Check the 12V DC adapter, power connection, and wall outlet.
No Internet	Check the blue WAN cable and confirm that the modem/ISP connection is active.
Slow Wi-Fi	Move closer to the router, reduce interference, or switch between 2.4 GHz and 5 GHz.
Cannot connect to Wi-Fi	Verify the Wi-Fi password and confirm that the correct SSID is selected.
WPS pairing fails	Place the devices closer together and retry WPS. Check that WPS is enabled.

8. Error Code E-04

Meaning: WAN connection unavailable or the router cannot detect an active Internet link.

Resolution: Verify that the Ethernet cable is connected to the blue WAN port. Restart the modem and TN-3000, wait two minutes, and check the Internet LED. If the issue remains, verify the service status with the Internet provider.

9. Product Identification

Product ID / Model: TN-3000. Brand: TechNova. Use the model string TN-3000 when associating this manual with the product knowledge base.