Xbox One Voice Guide

Voice Command

Stop Listening.

Xbox,

General Commands

Media Commands

on. turn off. sign in. sign out. sign in as person. go Home. go to game, app, or activity.

show menu. go back. snap app.

unsnap. switch. record that. start a party.

watch TV. watch channel.

One Guide. | Show Guide. What's on channel.

Watch this channel. App Channels.

play | stop | pause | fast forward | rewind next song | previous song faster | slower | skip forward | skip backward Description

stop listening, or cancel a command

show menu of voice commands

turn on the Xbox turn off the Xbox use the user to sign in to system sign in as specified user open the Home screen open any game, app, or activity go to Netflix | Forza Motorsport Five open game or app menu return to the previous screen dock an app to the right side of screen snap Netflix | TV | Internet Explorer close the docked app switch between fullscreen and docked app record the last 30 seconds of game play launch and snap the Party app

open the TV app open the TV app and watch a channel watch ESPN | Discovery Channel open channel listings open guide for selected channel what's on ESPN | Discovery Channel watch current channel in listings view apps like ESPN or Netflix

transport controls for viewing media

Skype person. call person. answer (without video). hang up. send a message.

Bing topic. help. select. show notifications.

use a code.

use Skype to video call a person call a person using the Skype phone answer an incoming Skype (without video) hang up Skype or phone call send a message using Sktype

use Bing to search for a topic open the help screen show supported voice commands or shortcuts show notification feed open the Kinect QR code reader