# **Pipeline Data Hazards**



Caiwen Ding
Department of Computer Science and Engineering
University of Connecticut

CSE3666: Introduction to Computer Architecture

### **Troubles from Pipelining**

### Pipeline hazards

- Structural hazards: attempt to use the same resource by two different instructions at the same time
- Data hazards: attempt to use data before it is ready
  - An instruction's source operand(s) are produced by a prior instruction still in the pipeline
- Control hazards: attempt to make a decision about program control flow before the condition has been evaluated and the new PC target address calculated
  - branch and jump instructions, exceptions
- Pipeline control must detect and take action to resolve hazards

#### **Data Hazards**


- Data dependency may cause data hazard
  - Data dependency: an instruction depends on data produced by a previous instruction
  - Data hazard: an instruction cannot get its data in time

Example: Read after write (RAW) dependency/hazard

```
# SUB and AND depend on ADD
# read x1 after write x1
add x1, x1, x1
sub x4, x1, x5
and x6, x1, x7
```

### **Data Dependency Can Cause Data Hazards**

• Later instructions are dependent on ADD



### **Dealing with Data Hazards**

- We can usually resolve hazards by waiting, but we will try to find ways to reduce time on waiting
- Data hazards
  - Stalling (waiting)
  - Forwarding

Reading: Section 4.6 (on data hazards) and Section 4.8

# Software approach

• Wait by inserting NOPs. Increase instruction count


NOP

NOP

sub x4, x1, x5

		1	2	3	4	5	6	7	8
add	x1,x2,x3	IF	ID	EX	MEM	WB			
NOP			IF	ID	EX	MEM	WB		
NOP				IF	ID	EX	MEM	WB	
sub	x4, <mark>x1</mark> ,x5				IF	ID	EX	MEM	WB
and	x6,x1,x7					IF	ID	EX	MEM

### Hardware can detect data hazards and wait



### **Stalls Shown in Pipeline Diagram**


Register 1 is not updated by ADD until the first half of cycle 5

The SUB instruction cannot get the correct data until the second half of cycle 5 It waits in the ID stage in cycles 4 and 5

The AND instruction cannot get into ID stage. It stays in IF in cycles 4 and 5.


Two instructions cannot be in the same stage!							or two s "same	cycles e stage"	
		1	2	3	4	5	6	7	8
add	x1,x2,x3	IF	ID	EX	MEM	WB			
sub	x4, <mark>x1</mark> ,x5		IF	ID	-	-	EX	MEM	WB
and	x6,x1,x7			IF	-	-	ID	EX	MEM

### Another (better) Way to "Fix" a Data Hazard



# Forwarding (aka Bypassing)

- Use result if it is already computed and available
  - Don't wait for it to be stored in a register
  - Require extra connections in the datapath



Stale data in ID/EX However, EX/MEM has the correct one

# **Pipeline Diagram Showing Forwarding**

x1 is not updated in register file until the first half of cycle 5, but it is available at the end of cycle 3

The SUB instruction can get the correct value through forwarding in cycle 4


Can AND be executed without stall? Can it get the correct value in ID?

		1	2	3	4	5	6	7	8
add x	1,x2,x3	IF	ID	EX	MEM	WB			
sub x	4, <mark>x1</mark> ,x5		IF	ID	EX	MEM	WB		
and x	6,x7, <mark>x1</mark>			IF	ID	EX	MEM	WB	

### Adding forwarding paths

Where would you add the path for SUB?

In previous cycle: ADD was in EX, computing  $x^2 + x^3$ . SUB was in ID, reading  $x^1$  from register file



### What about AND?


x1 is not updated in register file until the first half of cycle 5, but it is available at the end of cycle 3

The AND instruction cannot the correct value in ID (cycle 4) It can get the correct value through forwarding in cycle 5

	1	2	3	4	5	6	7	8
add x1,x2,x3	IF	ID	EX	MEM	WB			
sub x4, <b>x1</b> ,x5		IF	ID	EX	MEM	WB		
and x6,x7,x1			IF	ID	EX	MEM	WB	

### Adding forwarding paths - 2


• Where would you add the path for AND?



### **Forwarding Paths to ALU**

ALU result is stored in EX/MEM and MEM/WB,

Data loaded from data memory can also be forwarded via Write Data.



b. With forwarding

### **MUX Added before ALU input**

A MUX is added before each input to ALU

00: Take the value from the register file, stored in ID/EX

10: Take the value from EX/MEM


01: Take the value from MEM/WB

- A forwarding unit needs to generate the control signals
  - ForwardA and FowardB, each having 2 bits

When should we forward from EX/MEM to EX? When should we forward from MEM/WB to EX?

### **Detecting the Need to Forward from EX/MEM to EX**

When should we forward from EX/MEM to EX? Describe the logic in English.



b. With forwarding

### Forwarding from EX/MEM to EX

```
Logic
Only R-type computes new result in EX


if EX/MEM.RegWrite and (not EX/MEM.MemRead) and
EX/MEM.rd != 0 and
EX/MEM.rd == ID/EXE.rs1

then
ForwardA = 0b10
```

Similar for ForwardB

# Detecting the Need to Forward from MEM/WB to EX

When should we forward from MEM/WB to EX? Describe the logic in English.



b. With forwarding

### Forwarding from MEM/WB to EX

### Logic

Similar for ForwardB

# **Yet Another Complication!**

What if we change the SUB instruction a little?

Which x1 should AND use? Which forwarding path?

	1	2	3	4 5	6	7	8
add x1,x1,x2	IF	ID	EX .	MEM WB			
sub <b>x1</b> ,x1,x3		IF	ID	EX MEM	WB		
and x1,x4,x1			IF	ID EX	MEM	WB	

### Forwarding from MEM/WB to EX (corrected)

### Logic

```
if MEM/WB.RegWrite and
    MEM/WB.rd != 0 and
    MEM/WB.rd == IE/EXE.rs1 and
    not (forward from EX/MEM)
then
ForwardA = 0b01
Corrected!
```


Similar for ForwardB

# Data Forwarding (aka Bypassing)

- Take data where it is available in any of the pipeline registers and forward it to the units (e.g., the ALU) that need it
- For ALU: the inputs can come from any pipeline register rather than just from ID/EX
  - Add multiplexors to the both inputs of the ALU
  - Connect ALU result in EX/MEM and Write data in WB to the MUXes
  - Add the proper forwarding logic for the MUXes
  - Pass register numbers along the pipeline and send to forwarding logic
- Other units may need similar forwarding logic (e.g., the D-Mem)


# **MEM/WB** to **MEM** forwarding

- Loads that immediately followed by stores (memory-to-memory copies) can avoid a stall via forwarding
  - From the MEM/WB register to the data memory input
  - MUX and forwarding logic are added in MEM stage




### **Load-Use Data Hazard**

- Cannot always avoid stalls by forwarding
  - The value needed is not computed/loaded yet



SUB cannot get in Ex and use x1 in this cycle Wait in ID (not in EX!)

### Stall/Bubble in the Pipeline



### Another view: Stall/Bubble in the Pipeline

- Cycle 3: hazard is detected (in ID)
- Cycle 4: IF and ID repeat. EX has a NOP. LW continues
- Cycle 5: all instructions move to the next stage

#### How does AND get x2 in cycle 5?

Cycle	IF	ID	EX	MEM	WB
3	or x8,x2,x6	and x4,x2,x5	lw x2,20(x1)		
4	or x8,x2,x6	and x4,x2,x5	NOP	lw x2,20(x1)	
5	add x9,x4,x2	or x8,x2,x6	and x4,x2,x5	NOP	lw

# Yet another one, with pipeline diagram

The result of lw is not available until the end of cycle 4

The AND instruction cannot enter the EX stage in cycle 4.

In cycle 3:

The hazard is detected in ID

A bubble (NOP) is inserted in the pipeline (stored in ID/EX)

In cycle 4:


The EX stage does NOP (the inserted bubble)

The AND instruction stays in the ID stage in cycle 4

The OR instruction stays in the IF stage

	1	2	3	4	5	6	7	8
lw x2,20(x1)	IF	ID	EXE	MEM	WB			
and $x4, x2, x5$		IF	ID	-	EXE	MEM	WB	
or x8,x2,x6			IF	-	ID	EXE	MEM	WB

# **Datapath with Hazard Detection**



### **Performance impact - 1**

One cycle is wasted for each load-use hazard.

If 50% of the load instructions cause load-use hazard, what is the average number of stall cycles per each load instruction?

### Performance impact - 2

One cycle is wasted for each load-use hazard

The ideal CPI is 1.

Suppose 30% of the instructions are load and 60% of them cause load-use hazard.

What is the average CPI of all instructions?


### **Code Scheduling to Avoid Stalls**

• Reorder code to avoid use of load result in the next instruction Consider code:

$$A = B + E; C = B + F;$$

Instructions are

Load B, load E, compute A, store A. Load F, compute C, store C.



### **Summary – Handling Data Hazards**

One of the reasons we cannot achieve the ideal speedup is hazards

Handling data hazards (RAW in 5-stage MIPS pipeline)

- Forwarding can eliminate many hazards
  - ALU-to-ALU (to both ALU input ports)
  - Memory-to-ALU (to both ALU input ports)
  - Memory-to-Memory (to the memory Write Data port)
    - Load followed by store
- Still, pipeline needs to support stall
  - Not all hazards can be avoided by forwarding (Load-use)
- Code scheduling can avoid some stalls

• Study the remaining slides yourself

# Summary of forwarding to the next instruction

Where data is generated	Where data is consumed	Forwarding paths
EX	EX	EX/MEM to EX
EX	MEM	EX/MEM to EX
MEM	EX	Stall
MEM	MEM	MEM/WB to MEM


For each case, find an example consisting of two instructions. Explain the execution of the instructions.

- 1. On processors without forwarding, how many stall cycles are needed?
- 2. On processors with forwarding, how does the second instruction get the operand?

# Writing pipeline diagram

- Recognize and handle data dependence
  - Understand when data are generated and when they are used
- Two instructions cannot be in the same stage in the same cycle
- Detect hazard and wait, if necessary, in ID stage
  - Once an instruction enters EX, it does not stop until it's completed
  - IF only fetches instructions. It does not check instructions
- Do not stall unnecessarily

### **Common mistakes**



I4 is not fetched until cycle 5 '-' means repeat

No stalls in EX, MEM, WB

• If there is no forwarding, how many stall cycles does the following instructions have?

• With forwarding, which forwarding path does the sub instruction use?

- A. EX/MEM to EX
- B. MEM/WB to EX
- C. MEM/WB to MEM
- D. None

• With forwarding, which forwarding path does the sw instruction use?

- A. EX/MEM to EX
- B. MEM/WB to EX
- C. MEM/WB to MEM
- D. None

• With forwarding, which forwarding path does the sw instruction use?

```
sub x2, x1, x4
nop
sw x2, (x10)
```

- A. EX/MEM to EX
- B. MEM/WB to EX
- C. MEM/WB to MEM
- D. None

• With forwarding, which forwarding path does the sub instruction use?

- A. EX/MEM to EX
- B. MEM/WB to EX
- C. MEM/WB to MEM
- D. None

#### Forward from MEM/WB to MEM

#### From MEM/WB to MEM

ADD a MUX to select data going to D-MEM.WriteData EX/MEM.ReadData2 or MEM/WB.WriteData?

### rs2 only

```
if MEM/WB.rd != 0 and
    MEM/WB.rd == EX/MEM.rs2 and
    MEM/WB.MemRead and
    EX/MEM.MemWrite
then
    forward from MEM/WB to MEM
```

### **Load-use Hazard Detection Unit in ID**

Detect Hazard in ID.

```
The logic is
```

#### Hazard/Stall Hardware

Along with the Hazard Unit, we have to implement the stall.

- Prevent the instructions in the IF and ID stages from progressing down the pipeline.
  - This is done by preventing the PC register and the IF/ID pipeline register from changing
  - Hazard detection Unit controls the writing of the PC (PC.write) and IF/ID (IF/ID.write) registers
    - The instruction in IF will be fetched again
    - The instruction in ID will be decoded and read RF again
- Insert a "bubble" (a NOP instruction) between the 1w instruction (in the EX stage) and the load-use instruction (in the ID stage)
  - Set the control bits in the EX, MEM, and WB control fields of the ID/EX pipeline register to 0 (a NOP). The Hazard Unit controls the MUX that chooses between the real control values and the 0's
- Let load and earlier instructions proceed normally down the pipeline