USB BT Joystick Center 6

USB BT Joystick Center

for use with USB BT Joystick Center and Joy2Touch Server.

Edition 1



poke 64738 Lead Developer poke64738@gmail.com

Jared Morgan
Volunteer Technical Writer
jaredleonmorgan@gmail.com

Abstract

This guide will help you initially set up USB BT Joystick Center and Joy2Touch Server on your Android device. After initially setting up the product, further instructions about configuring both products are discussed in detail.

Table of Contents

- 1. Introduction
- 2. Main Screen
- 3. Connect a Controller
- A. Revision History

Chapter 1. Introduction

Thank you for downloading USB/BT Joystick Centre.

Chapter 2. Main Screen

When you start the application for the first time, the main screen is displayed.



Chapter 3. Connect a Controller

Procedure 3.1. Configuring Input Methods

Before using USB BT Joystick Center to control an application for the first time, you need to authorize the application as a valid input method (IME).

Follow these steps to authorize USB BT Joystick Center as an input method on the device.

- 1. Tap the **IME** slider to open the Android Language and Input settings.
- 2. In the Keyboard & Input Methods group, tap the USBJoyIME checkbox.
- 3. In the Attention dialog box, read and accept the warning and tap **OK**.
- Exit the Android Language and Input settings screen.
 USB BT Joystick Center is now configured as an IME

Procedure 3.2. Select Input Method

- 1. Tap the **IME** Button to open the Input Method menu.
- 2. Select USBJoyIME to set USB BT Joystick Center as the input method, until the application is closed.



Note

Once this setting is activated, you will not be able to use other input methods, such as on-screen keyboards.

Procedure 3.3. Connect USB Device

Follow this procedure to connect a USB device and detect it using USB BT Joystick Center

- 1. Plug the cable into the device.
- 2. Tap SEARCH to detect the device.
- 3. The controller is detected, and it's name is displayed as a button in the main screen.

Procedure 3.4. Connect Bluetooth Device

Follow this procedure to pair and detect a Bluetooth controller with USB BT Joystick Center.

- 1. Tap the **BT** slider to turn on Bluetooth.
- 2. Tap Yes on the Bluetooth permission request menu to activate Bluetooth on the device.
- 3. On the controller, activate Bluetooth pairing mode.
- 4. On the device, tap SEARCH.
- 5. The controller is detected, and it's name is displayed as a button in the main screen.

Revision History

Revision 6.1-1 Mon Nov 5 2012 Jared Morgan.

First Draft for community review.