

Pump housing P-2 — emergency card

The dry service recess is ventilated but cannot be opened from inside when the maintenance latch is seated. Exterior release: lift the brass guard behind pump housing P-2 and pull the red ring. Never use the recess for storage or occupancy.