



2.06 Lock out / Tag Out of Trucks and Trailers

1. Purpose

The purpose of this Lockout and Tagout Procedure is to identify the hazards and define the steps in locking out vacuum truck and well site trailers

2. Scope

This procedure is intended for use by all Silverpoint employees .

3. Hazard Identification

- Physical Stress -Personal Injury
- Electrical
- Hydraulic
- Pneumatic
- Gravity
- Mechanical

4. EHS Requirements

- Fire retardant Coveralls
- Steel Toed Boots
- Safety Glasses
- Hearing Protection
- Gloves
- Hardhat

5. References

- Silverpoint Corporate Codes of Practice
- Alberta OH&S
- Silverpoint Task List
- Silverpoint THA 2.06

6. Procedure



Safety Alert

Any Vacuum /Water Truck or Well Site Trailer that is inside the Medicine Hat shop should be considered Out of Service until the Maintenance Staff has been consulted or prior authorization has been given to use a particular unit.

LOTO tags and zap strap/pull ties can be found in the front cover of the Operations Manual , please inform you supervisor if the binder needs to be restocked .

6.1. Vacuum / Water Trucks , when a unit is parked in the shop .

- 6.1.1. Put transmission in neutral and set the parking brake, turn off the engine and remove the keys.
- 6.1.2. Place chock blocks under the rear tires to prevent roll away.
- 6.1.3. Complete a LOTO tag indicating why the equipment is being locked out, your name and the date.
- 6.1.4. Attach the LOTO tag and keys to a carabineer ; attach the carabineer to the center console hook.

6.2. When unit is parked outside of the shop .

- 6.2.1. Leave the original LOTO tag on the center console hook.
- 6.2.2. Remove the keys from center console hook and lock the unit.
- 6.2.3. Attach another LOTO tag to the keys and put them in the key box located in the shop.

6.3. When a unit is to be parked in the field .

- 6.3.1. Park the equipment on level/clear surface away from other activities . Ask the consultant if you are unsure where to park.
- 6.3.2. Turn off the engine and remove the keys.
- 6.3.3. Place chock blocks under the tires to prevent unit from moving .
- 6.3.4. Complete a LOTO tag indicating why the equipment is being locked out, your name and date.
- 6.3.5. Lock the unit and place the keys on the engine oil dip stick.

6.4. Well Site Trailers .

- 6.4.1. Park the equipment on level/clear surface away from other activities . Ask the consultant if you are unsure where to park.
- 6.4.2. Place chock blocks under the tires to prevent unit from moving .



6.4.3. Complete a LOTO tag indicating why the equipment is being locked out, your name and date.

6.4.4. Attach the LOTO tag to the pintle eye of the trailer using a zap strap / pull tie.

6.5. Onsite Maintenance .

6.5.1. Remove keys from ignition , complete a DO NOT OPERATE tag and hang it from the center console hook and put the keys in your pocket .

6.5.2. If equipped , turn the battery disconnect switch to the off position , if equipped with a lock out on the battery disconnect and use the lock provided to secure it. Put the lock key in your pocket .

6.5.3. If required a battery cable lock out bag can be used in place of locking out the battery disconnect .

Remember : if you are in doubt about what to do, call your Supervisor