



3.03 Parking Truck for Shut Down

1. Purpose

The purpose of the Standard Operating Procedure is to identify the hazards and define the steps in parking a vacuum truck for shutdown .

2. Scope

This procedure is intended for use by all Silverpoint employees .

3. Hazard Identification

- Equipment Damage .
- Personal Injury .
- Splashing Fuel .
- Pinch Points .
- Slips, Trips and Falls .
- Strains .
- Backing into Objects .
- Physical Stress

4. EHS Requirements

- Fire Retardant Coveralls .
- Steel Toed Boots .
- Safety Glasses .
- Gloves .
- Hard Hat .
- Hearing Protection .
- Spotter for Backing Up .
- Chock Blocks
- Stretching and Frequent Rests .
- Stay Focused on Task .



5. References

- Silverpoint Corporate Codes of Practice
- Alberta OH&S
- Silverpoint Task List
- Silverpoint THA 3.0

• • **One Meter Rule - a spotter will be required whenever a piece of equipment is going to be driven within one meter of any stationary object .**

- Always keep as much distance as possible between your equipment and all stationary objects .
- If the task or job changes , stop and reevaluate your route . Realignment is a simple task that can be easily completed to reduce the risks .
- If realignment or a different route is not possible , and the distance will be closer than one meter a spotter will be mandatory .

6. Procedure

- 6.1. In the event of a shut down in which you are bringing the truck and trailer back to the shop, contact your supervisor or call the after hour's number and let them know you are shutting down .
 - 6.1.1. Be sure vacuum tank is shaled out, Water truck tank and pumps drained and load all hoses , screens , fittings , shovels , trailer hitch , flock rod , etc. then follow these steps . Make sure the full inventory list in the PMI is complete , before leaving location – the vacuum truck should be ready to work if it is needed .
 - 6.1.2. All well site trailers are to be winterized between October 1st and April 30th regardless of temperature when not in use .
 - 6.1.3. Make sure the shacks propane level is above 60%; if not then fill it up, if you can't fill it up be sure to write it in your trailer PMI and notify your supervisor that the propane level is low, they will make arrangements to have it filled .
 - 6.1.4. **Fill the fuel tanks** and diesel flush tank – All parked trucks should be left with a full fuel tank in case the truck is needed in an emergency .
 - 6.1.5. Diesel flush Hibon pump for 1 to 2 seconds .
 - 6.1.6. Remove all personal items from truck and well site trailer unless you have been given approval from your supervisor to leave your belongings in the trailer .
 - 6.1.7. **Make sure the truck and shack are clean , inside , and out** . Do not leave food in fridge or cupboards .



- 6.1.8. Pressure wash the outside of the truck and trailer .
- 6.1.9. Make sure all the lights are off and the windows are closed .
- 6.1.10. Park unit in the yard or storage area in a manner that does not block traffic and allows for as much free space as is safely possible . Don't attempt to back up with out a spotter .
- 6.1.11. Use Tire Boss System to inflate all rear tires to highest setting and then close all tire valves and turn off control box .
- 6.1.12. **Make sure that the truck and shack are both locked** . Leave keys in the key box in the shop (If accessible) . If access to shop is not available , phone the "on call" 1-403-548-8132 number for instructions .

6.2 You are not done your job until all this is completed . If finishing up late, then you are required to come in the next working day to finish all of the above .

6.3 In the event that you are leaving the vacuum truck /Water truck and well site trailer on the drilling rig location , follow these steps .

- 6.3.1 Fill the fuel tank and diesel flush tank – All parked trucks should be left with a full fuel tank in case the truck is needed in an emergency .
- 6.3.2 Be sure vacuum tank is shaled out, Water truck tank and pump drained .
- 6.3.3 Diesel flush Hibon pump for 1 or 2 seconds .
- 6.3.4 Always bring home your PPE in case you are sent to another job .
- 6.3.5 Remove all personal items from truck and well site trailer unless you have been given approval from your supervisor to leave your belongings in the truck and trailer .
- 6.3.6 Make sure the full inventory list in the PMI is complete , before leaving location – the vacuum /water truck should be ready to leave location if needed . Load all inventory items , hoses , fittings , hitch , etc .
- 6.3.7 Clean out all trash and clean the inside of the truck and well site trailer .
- 6.3.8 **All well site trailers are to be winterized October 1st and April 30th regardless of temperature .**
- 6.3.9 Use Tire Boss system to inflate all rear tires to highest setting and than close all tire valves and turn off control box .
- 6.3.10 Place chock block between the wheels to prevent any movement of the unit .
- 6.3.11 Make sure all the lights are off and the windows are closed .
- 6.3.12 Park truck on lease where it is out of the way and will not interfere with rig move or rig operations . If you are shutting down in the winter plug the truck block heater in .
- 6.3.13 Lock the truck and put keys on oil dipstick . For the trailer, put keys in the trailer tube .
- 6.3.14 If truck is equipped , shut off battery power disconnect .



3.03 Parking Truck for Shut Down

Remember : if you are in doubt about what to do, call your Supervisor