



3.04 Switching Out Trucks

1. Purpose

To provide Standard Operating Procedures and safe practices for employees performing truck switch outs on well sites and company facilities .

2. Scope

This procedure is intended for use by all Silverpoint employees .

3. Hazard Assessment & Identification

- Strains
- Sprains
- Slips, Trips, Falls
- Physical Stress
- Personal Injury
- Pinch Points

4. EHS Requirements

- Hard hat
- Hearing protection
- Eye protection
- F/R Coveralls
- Gloves
- Steel toed boots

5. References

- Silverpoint Corporate Codes of Practice
- Alberta OH&S
- Silverpoint Task List
- Silverpoint THA 3.04

6. Procedure

- 6.1. Complete PMI Inventory Checklist .
- 6.2. Complete a Pre-Trip. See Pre-Trip SOP 2.08
- 6.3. Check that all the proper documentation is in the truck .
 - 6.3.1 Insurance



- 6.3.2 Registration
- 6.3.3 CVIP
- 6.3.4 PMI
- 6.3.5 Pre/Post-Trip Book
- 6.3.6 Ticket Book
- 6.3.7 Operations Manual
- 6.3.8 Fuel Cards and Pin Numbers

6.4. Take all personal documentation and PPE with you to the field

- 6.4.1 Drivers License
- 6.4.2 First Aid
- 6.4.3 Confined Space
- 6.4.4 H2S
- 6.4.5 WHIMIS
- 6.4.6 TDG
- 6.4.7 PST/CSO
- 6.4.8 Logbook

6.5. Complete a Vacuum Test

- 6.5.1 Engaging the PTO
- 6.5.2 Turning the 4-way valve to Vacuum
- 6.5.3 Build vacuum
- 6.5.4 Make sure the system holds vacuum /leak down test

6.6. Make sure the truck is fueled up before you leave town.

- 6.6.1 Make sure it is as full as possible when you arrive on lease, stop and fuel it before arriving at you destination if possible.

6.7. Obey all rules of the road on your way to switch out trucks

6.8. Complete a Post-Trip

6.9. Fill Out your logbook



6.10. When you arrive on location to switch out trucks

6.10.1 Make sure everything is loaded onto the exiting truck

- 2,3- and 4-inch Hoses
- T-Bar
- Hitch
- Shovels and Squeegees
- Fittings
- Ratchet Straps and Tie Downs

6.10.2 You must also make sure that a PMI inventory is done, and all defects are noted in the PMI.

6.10.3 Move 2-way radio, antenna, and outside speaker to in-coming truck if necessary.

6.10.4 Put gas monitor kit into in-coming truck.

6.10.5 If possible, make sure that the vacuum truck has been shaled out before it leaves the lease.

6.10.6 Make sure the water truck tank is empty and pump drained.

6.10.7 Do a Pre-Trip on the truck you are bringing home.

6.10.8 The exiting operator must complete a Post-Trip Inspection.

6.10.9 Fuel up truck before parking at the shop

6.10.10 Upon arrival back to the shop complete your post-Trip, fill out your Logbook, park the truck, lock truck, and put keys in the key box in the shop. (SOP 3.03)

Remember : if you are in doubt about what to do, call your supervisor