

**1. Purpose**

The purpose of the Standard Operating Procedure is to identify the hazards and define the steps for the use of a: **High Pressure Hot Water/Steam Wand System: "Safety Guidelines."**

2. Responsibilities

This procedure is intended for use by all Silverpoint employees for the safe operation of using a: **High Pressure Hot Water/Steam Wand System.**

All employees using the Pressure Washer must be trained and certified in the safe operation of the equipment and familiar with all controls.

Untrained personnel are not permitted to operate this equipment.

3. Hazard Identification

- **Equipment Damage and Failure.**
- **Personal Injury.**
- **Physical Stress.**
- **Mental Stress.**
- **Restricted Visibility.**
- **Pinch Points.**
- **Diesel Fumes.**
- **Slips, Trips and Falls.**
- **Burns.**
- **Hot Pipe Surfaces.**
- **Extreme Noise.**
- **Proper Labeling of Valves.**

4. EHS Requirements

- **Fire Retardant Coveralls.**
- **Steel Toed Boots.**
- **Body Armor: top of foot & front of shin**
- **Gloves.**
- **Hard Hat.**
- **Hearing Protection.**
- **Safety Glasses.**

5. References

- **Silverpoint Corporate Codes of Practice.**
- **Alberta OH&S.**
- **Silverpoint Task List.**

6. Procedure**Safety Guidelines**

- Always operate pressure washer in a well-ventilated area free of flammable vapors, combustible dust, gases, or other combustible materials.
- Do not use this pressure washer to spray flammable material.
- Do not smoke while filling fuel tanks.



- Do not operate the unit if fuel is spilled. Wipe the pressure washer clean and move it away from the spill. Avoid creating any ignition until the gasoline or diesel fuel has evaporated.
- The pressure washer has a Safety Relief Valve which should never be altered, modified, or made inoperative. If the device fails, replace immediately with genuine manufacturer replacement part.
- Never operate the pressure washer in an enclosed area. Always make certain there is adequate ventilation (fresh outside air) for breathing and combustion.
- Follow all safety instructions provided with the materials you are spraying. Use of a respirator may be required when working with some materials. Do not use the pressure washer to dispense hazardous detergents.
- **Keep clear of nozzle and spray! Never put your hand, fingers, or body directly over the spray nozzle;**
- **Never point the high-pressure discharge spray at yourself or anyone else. Always keep operating area clear of all persons.**
- **Seek emergency medical care if the spray appears to have penetrated the skin! Do not treat as a simple cut.**
- High pressure hoses and fuel lines should be inspected before each use for signs of wear. If evidence of failure exists, promptly replace all suspect hoses and fuel lines to prevent the possibility of injury from the high-pressure spray. If a hose or fitting is leaking never place your hand directly on the leak.
- Never operate the gun with the trigger wired in the open position.
- Before removing the spray nozzle or servicing the unit, always shut off the unit and trigger the gun to release trapped pressure. (Even after you shut off the unit there is high pressure water left in the pump, hose, and gun until you release it by triggering the gun.)
- Do not direct spray on or into electrical installations of any kind. This includes electrical outlets, light bulbs, fuse boxes, transformers, the unit itself, etc.
- Do not allow metal components of the pressure washer to come in contact with live electrical components.
- Never allow any part of your body to contact the engine, muffler, or heat exchanger.
- Never make adjustments to factory set pressures.
- Never exceed manufactures maximum allowable pressure rating of attachments.
- Do not allow any hoses to make contact with the engine, muffler, or heat exchanger to prevent the possibility of bursting. Avoid dragging the hoses over abrasive surfaces such as cement.
- In freezing temperatures, the unit must always be warm enough to ensure there is no ice formation in the pump. Do not start the pressure washer if it has been transported in an open or non-heated vehicle without first allowing the entire unit to thaw.
- Do not operate the unit without all protective covers in place.



Remember : If you are in doubt about what to do, call your supervisor