

**1. Purpose**

The purpose of the Standard Operating Procedure is to identify the hazards and define the steps for the use of a: **High Pressure Hot Water/Steam Wand System: "Start-up/Cold Water."**

2. Responsibilities

This procedure is intended for use by all Silverpoint employees for the safe operation of using a:

- High Pressure Hot Water/Steam Wand System .
- All employees using the Pressure Washer must be trained and certified in the safe operation of the equipment and familiar with all controls .
- Untrained personnel are not permitted to operate this equipment .

3. Hazard Identification

- Equipment Damage and Failure.
- Personal Injury.
- Physical Stress.
- Mental Stress.
- Restricted Visibility.
- Pinch Points.
- Diesel Fumes.
- Slips, Trips and Falls.
- Burns.
- Hot Pipe Surfaces.
- Extreme Noise.

4. EHS Requirements

- Fire Retardant Coveralls;
- Steel Toed Boots;
- Safety Glasses;
- Gloves;
- Hard Hat;
- Hearing Protection;
- Proper Labeling of Valves.

5. References

- Silverpoint Corporate Codes of Practice;
- Alberta OH&S;
- Silverpoint Task List.

6. Procedure:**Start-up/Cold Water**

- 1) Refer to the Operating Instructions before starting the pump;**
- 2) Locate the Safety Decals on the unit and understand and follow their warnings;**
- 3) Ensure the Burner Switch is in the OFF position;**



4) Engage the power take off;

5) Once the pump has started, perform the following procedures with the gun open:

a) Inspect for system water leaks, oil leaks, and fuel leaks.

If a fuel leak is found,

SHUT DOWN THE PUMP IMMEDIATELY!

Be sure that all damaged parts are replaced and that all mechanical problems have been corrected prior to the operation of the unit.

b) Inspect high pressure hoses for kinks, cuts, and leaks. If a cut or leak is found;

SHUT DOWN THE PUMP IMMEDIATELY!

Replace hose before starting the machine.

6) The unit is now operating as a cold-water pressure washer.

Trigger the gun several times. Rotate adjustable grip on the dual lance for high- and low-pressure application. **NEVER** place hands or fingers in front of the nozzle or look directly into the nozzle;

7) Do not allow the pump to operate in the bypass mode (with the trigger gun closed) for more than three minutes without triggering the gun. Failure to follow this simple rule can cause premature failure of the pump.

Remember : If you are in doubt about what to do, call your supervisor.