



5.01 Viewing Cement Pits, Sumps and Spread Fields

1. Purpose

The purpose of the Standard Operating Procedure is to identify the hazards and define the steps in viewing cement pits and spread fields on start up of new and existing projects .

2. Scope

This procedure is intended for use by the Silverpoint Employees .

3. Hazard Identification

- Physical Stress .
- Personal Injury .
- Equipment Damage .
- Driving .
- Weather .
- Obstacles in Field .
- Spread Drilling Fluid in Wrong Area .
- Overspread .
- Water Bodies .
- Slopes .

4. EHS Requirements

- FR Coveralls .
- Steel Toed Boots .
- Safety Glasses .
- Rubber gloves .
- Hard Hat .
- Hearing Protection .
- Seat belts .
- Pylons .



5. References

- Silverpoint Corporate Codes of Practice
- Alberta OH&S
- Land Spreading Guidelines in the Jurisdiction That Work Occurs .
- High-way Traffic Act .
- Silverpoint Task List
- Silverpoint THA 5.01

NOTE: Not all environmental technicians we work with will mark fields and out of bounds areas , some company's use survey stakes /Pylons or in some cases once you are shown the water body /boundary's there are no markers used at all. We cannot guarantee that all companies will use the same system . It is always a good idea to ask for a map .

It will be up to each operator to determine what system technicians are using to mark the spread fields and water bodies .

6. Procedure

- 6.1. When driving to and from the cement pit, Water source and spread field take extra caution for this is one most hazardous part of the job . Drive carefully and obey the rules of the road .
 - 6.1.1. All operators (both Silverpoint and third party) are to be shown their cement pit, Water source and spread field during daylight hours , if possible , by the technician or out going operator . In the event of a job starting up past dusk then the Technician will still accompany the operator to the locations and put-up flagging or markings to assist the operator . You should also put flagging up if you see hazards .
 - 6.1.2. Day shift operators will be required to show the night shift operator or relieving driver the Water source , cement pit and spread field in daylight hours when lighting permits . Silverpoint will strive to have second operators or relief drivers on location with time to be shown the locations in the daylight . Try to show these things during daylight hours whenever possible .
- 6.2. If requested by the operator trails will be marked to ensure that proper routes are followed . Flagging will be given to each vacuum truck so operators can mark hazards and trails .

Remember : if you are in doubt about what to do, call your supervisor



5.01 Viewing Cement Pits, Sumps...