


Applications:

Model EPR
Truck Scale







Application compliments of:

Advance Scale

Clementon, New Jersey

EPR In / Out Truck Scale Installation

ON THE JOB: Marpal Disposal, New Jersey, utilizes two 70' EPR's for in and out weighing. The EPR truck scale incorporates a double link suspension and hermetically sealed stainless steel load cells, resulting in accurate and dependable weight truck after truck. As the EPR is a "no-bolt" design, maintenance and wear and tare are held to a minimum. All of the electronics are located in sealed, NEMA 4 stainless steel boxes to insure that all of the key components are protected in a harsh environment.

The two truck scales are connected to Cardinal's model 220 weight indicators. The weight indicators

Equipment Used:

- (2) EPR Truck Scales
- (2) 220 Weight Indicators

include water tight, stainless enclosures for maximum protection. The 220's back lit LCD display has brightness controls for high visibility day or night.

With the Marpal Disposal installation, the weight indicators are sending the weight data to a PC for immediate processing of the weight transaction. The model 220 indicator has two serial ports for interfacing to PC's and other peripheral devices such as remote displays and printers.

