1 Playing

1. **Play / pause**
2. **Skip.** Hold ⏮ to start again
3. **Volume.** – and +
4. **Library:** pick something
5. **Tracks:** every song or chapter
6. **Cog:** grown-ups only
7. **Drag** to move through a song

Swipe the picture to skip. Swipe up for the tracks.

2 Pick something

Tap a picture to play it.

Tabs along the bottom: All, Music, Podcasts, Books, Radio.

Books and podcasts carry on where they stopped. The bar shows how far, and the latest ones come first.

Search at the top finds anything.

3 Bedtime

Orange: stay in bed Green: OK to get up!

The **night light** glows through the night and turns **green at wake-up time**. Keep it on the charger.

Sleep Sounds folder: rain, ocean, white noise and a heartbeat. They loop until stopped.

4 Grown-ups

Hold the cog (top right) for 2 seconds, then answer the sum or your grown-up PIN.

Settings are grouped: **Listening, Family, Night** and **Phone and safety**.

Search finds any setting. Try "volume" or "pin".

Music time: a daily listening limit.

5 The remote

1. Put your phone on the **same Wi-Fi**.
2. On the player: **Grown-ups → Remote control** shows its address and PIN.
3. Type the address, like **192.168.1.50:8480**, into Safari or Chrome.
4. Enter the **PIN**.
5. Share → **Add to Home Screen**.

Play, pause, volume, add music and change settings from the sofa.

6 Messages

Type a message on the remote, like "Dinner's ready!", and it pops up on their screen.

Voice messages: Message → **Record a voice message**, then hold the red button: "Goodnight, love you!"

It plays on the player and stays in the **Messages** folder.

Good to know

Cards: link a card to a folder in grown-up settings, then tap it on the back of the phone to play (Android).

Charging: leave it on the charger overnight for the night light.

Updates: Grown-ups → About → **Check for updates**.

Lost the PIN? Grown-ups → Remote control shows it.

github.com/jaso1000/walkie-tales

WalkieTales


MUSIC AND STORIES FOR LITTLE HANDS

Quick guide


How to play, bedtime, grown-up settings and the remote on your phone

How to fold your WalkieTales quick guide


One A4 sheet, one cut, no stapling. It folds into a little 7.4 × 10.5 cm booklet that fits in a phone box.




1. Print page 1 at **actual size** (100%), one side. Fold in half, long edge to long edge, then open.



2. Fold in half the other way, then open. Fold each end in to the middle, then open.



3. Fold in half **short edge to short edge**. Starting at the folded edge, **cut along the middle crease** as far as the next crease, then stop.



4. Open it. Fold long edge to long edge (pictures outside), then push the two ends towards each other so the slit opens into a diamond. Flatten it into a booklet with the cover on the front.