

學習

arduino

Free unaffiliated eBook created from **Stack Overflow contributors.**

#arduino

1: arduino	2
	2
Arduino	2
Arduino	2
	2
Examples	
Lampio	
LED	4
2: Arduino IDE	5
Examples	5
Windows	5
Windows	
Fedora	5
Ubuntu	
macOS	5
3: I2C	6
	6
Examples	6
	6
4: MIDI	9
	9
Examples	9
MIDI THRU	9
MIDI	9
MIDI	10

MIDI	12
5: PWM	15
Examples	15
PWM	15
	15
	15
	15
	16
PWMTLC5940	
6: PythonArduino Uno	
Examples	
ArduinoPython	
7: SPI	
	20
	20
SPI	20
Examples	21
SPI1	21
8:	22
	22
	22
	22
Examples	22
	22
9:	24
	24
	24

24
Examples
24
Base64
25
Python
Arduino
10:
27
Examples
27
11:
Examples
28
28
12:
30
Examples
30
31
13: EEPROM
33
33
Examples
EEPROM
14: ArduinoAtmel Studio 7
34

		. 34
		. 36
		. 38
		. 38
		. 39
		. 39
Е	Examples	39
	Atmel Studio 7	. 39
15	•	40
		. 40
		. 40
E	Examples	
		40
		. 40
		41
		41
16	.	. 43
		. 43
		. 43
		. 43
E	Examples	43
		. 43
17	:	. 45
		. 45
E	xamples	
	.	
Е	xamples	
	cardInfo	
	SD	48

	SD	49
	SD	50
	Listfiles	51
	SD/	53
19):	. 55
		. 55
		. 55
		. 55
		. 55
	Examples	55
		55
	elapsedMilliselapsedMillis	. 56
	millis	56
	elapsedMilliselapsedMicros	57
	1	57
20):	. 60
		. 60
		. 60
	Examples	60
		. 60
		. 60
21	:	. 62
		. 62
		. 62
		. 62
	Examples	62
		. 62
22	:	. 64
	Examples	64
	Arduino Uno R3	64
23	3:	. 67
		67

	€	7
Exa	amples6	5 7
	6	3 7
24: .	6	9
Exa	amples6	9
	ε	39
	6	9
	6	9
25: .	7	0
	7	'0
	7	0'
	7	0'
Exa	amples	0'
		'0
	7	'0
26: .	7	2
	7	'2
Exa	amples	'2
		'2
	7	3

You can share this PDF with anyone you feel could benefit from it, downloaded the latest version from: arduino

It is an unofficial and free arduino ebook created for educational purposes. All the content is extracted from Stack Overflow Documentation, which is written by many hardworking individuals at Stack Overflow. It is neither affiliated with Stack Overflow nor official arduino.

The content is released under Creative Commons BY-SA, and the list of contributors to each chapter are provided in the credits section at the end of this book. Images may be copyright of their respective owners unless otherwise specified. All trademarks and registered trademarks are the property of their respective company owners.

Use the content presented in this book at your own risk; it is not guaranteed to be correct nor accurate, please send your feedback and corrections to info@zzzprojects.com

1: arduino

Arduino

Arduino_o

Arduino

- 0 0
- •
- •
- •

1.0.0 201658

Examples

"Arduino File > Examples > 01. Basics > Bare MinimumArduino IDEFile > Examples > 01. Basics > Bare Minimum •

```
void setup() {
  // put your setup code here, to run once
}

void loop() {
  // put your main code here, to run repeatedly
}
```

setup() · I/O · loop() Arduino · Arduino

```
void setup() {
  // put your setup code here, to run once
}

void loop() {
  // put your main code here, to run repeatedly
}
```

Arduino . .

```
\texttt{setup()loop()} \circ \texttt{File} > \texttt{Examples} > \texttt{01. Basics} > \texttt{Blink} \\ \textbf{Arduino IDE} \circ \\ \textbf{ArduinoLED13LED} \circ \\ \textbf{ArduinoLED13LED2} \circ \\ \textbf{ArduinoLED2} \circ \\ \textbf{ArduinoLED2
```

```
// the setup function runs once when you press reset or power the board void setup() \{
```

1. setup() · Arduinosetup() ·

1.13∘

LED;∘

- **2.** loop() · loop() ·
 - 1. digitalWrite(13, HIGH); LED.
 - 2. delay(1000);1000°
 - 3. digitalWrite(13, LOW); LED.
 - **4.** delay(1000);**1000**°

loop() LED211. Arduino UnoLED13. LED.

Arduino IDE

Bestand Bewerken Schets Hulpmiddelen Help

```
smartbox
         DataPacket.cpp | DataPacket.h | EnCoPacket.cpp | EnCoPacket.h | InstrumentationPacket.cpp
   #include "keys.h"
   #include "device.h"
   #include "LowPower.h"
   #include "instrumentationParamEnum.h"
 5
   #include "sensor.h"
   // #include "Sensor.h"
 6
   #include <SoftwareSerial.h>
 8
 9
   #include <avr/wdt.h>
10 #include <avr/sleep.h>
11
   // Console
12
13 #define SERIAL BAUD 9600
14
   #define debugSerial Serial
15
   // Button to send msg on which pin ?? 2 OR 3
16
   // Pin change interrupt possible on other pins if needed ....
17
18 #define BTN SEND PIN 2
19
   // PIN 2 => IRQ0 // 3 => IRQ1
20
   #define IRQ 0
21
22
   #define PIN TX RN2483 8
23 #define PIN RX RN2483 9
24
25
   // Arduino's
   #if defined (__AVR_ATmega328P__)
26
       // Serial setup to connect Modem
27
28
        #define PIN PWR RN2483 12
```

"LoRaModem.h" contains unrecognized characters. If this code was created with an older version

2: Arduino IDE

Examples

Windows

- 1. https://www.arduino.cc/en/Main/Software
- 2. "Windows Installer"
- 3.

Windows

WindowsArduino IDE

- 1. https://www.arduino.cc/en/Main/Software
- 2. "Windows ZIP"
- 3
- 4. Arduino.exe

Fedora

- 1. sudo dnf install arduino
- 2. Arduino arduino

Ubuntu

- sudo apt-get install arduino
- 2. Arduino arduino

macOS

- 1. https://www.arduino.cc/en/Main/Software
- 2. Mac OS Xº
- 3. .zipº
- **4.** ArduinoApplications •

Arduino IDE https://riptutorial.com/zh-TW/arduino/topic/3790/arduino-ide

3: I2C

I2CArduino - SDASCL Arduino I2CArduino VCC

Examples

· · · 24.3 · 10 ·

```
#include <Wire.h>
#define BUFFER_SIZE 4
#define MAX_NUMBER_OF_SLAVES 24
#define FIRST_SLAVE_ADDRESS 1
#define READ_CYCLE_DELAY 1000
byte buffer[BUFFER_SIZE];
void setup()
 Serial.begin(9600);
 Serial.println("MASTER READER");
 Serial.println("*********");
                 // Activate I2C link
 Wire.begin();
void loop()
  for (int slaveAddress = FIRST_SLAVE_ADDRESS;
      slaveAddress <= MAX_NUMBER_OF_SLAVES;</pre>
      slaveAddress++)
   Wire.requestFrom(slaveAddress, BUFFER_SIZE); // request data from the slave
    if(Wire.available() == BUFFER_SIZE)
     { // if the available data size is same as I'm expecting
        // Reads the buffer the slave sent
        for (int i = 0; i < BUFFER_SIZE; i++)</pre>
         buffer[i] = Wire.read(); // gets the data
        // Parse the buffer
        // In order to convert the incoming bytes info short, I use union
        union short_tag {
         byte b[2];
         short val;
        } short_cast;
        // Parse the temperature
        short_cast.b[0] = buffer[0];
        short_cast.b[1] = buffer[1];
        float temperature = ((float)(short_cast.val)) / 10;
        // Parse the moisture
        short_cast.b[0] = buffer[2];
        short_cast.b[1] = buffer[3];
```

```
#include <Wire.h>
#define BUFFER_SIZE 4
#define MAX_NUMBER_OF_SLAVES 24
#define FIRST_SLAVE_ADDRESS 1
#define READ_CYCLE_DELAY 1000
byte buffer[BUFFER_SIZE];
void setup()
 Serial.begin(9600);
 Serial.println("MASTER READER");
 Serial.println("*********");
 Wire.begin(); // Activate I2C link
void loop()
  for (int slaveAddress = FIRST_SLAVE_ADDRESS;
      slaveAddress <= MAX_NUMBER_OF_SLAVES;</pre>
      slaveAddress++)
   Wire.requestFrom(slaveAddress, BUFFER_SIZE); // request data from the slave
   if(Wire.available() == BUFFER_SIZE)
      { // if the available data size is same as I'm expecting
       // Reads the buffer the slave sent
       for (int i = 0; i < BUFFER_SIZE; i++)
         buffer[i] = Wire.read(); // gets the data
        // Parse the buffer
       // In order to convert the incoming bytes info short, I use union
       union short_tag {
         byte b[2];
         short val;
        } short_cast;
        // Parse the temperature
        short_cast.b[0] = buffer[0];
        short_cast.b[1] = buffer[1];
```

```
float temperature = ((float)(short_cast.val)) / 10;
       // Parse the moisture
       short_cast.b[0] = buffer[2];
       short_cast.b[1] = buffer[3];
       short moisture = short_cast.val;
       // Prints the income data
       Serial.print("Slave address ");
       Serial.print(slaveAddress);
       Serial.print(": Temprature = ");
       Serial.print(temprature);
       Serial.print("; Moisture = ");
       Serial.println(moisture);
     }
   }
   Serial.println("**************************);
   delay(READ_CYCLE_DELAY);
}
```

I2C https://riptutorial.com/zh-TW/arduino/topic/9092/i2c

4: MIDI

MIDI_°

Examples

MIDI THRU

MIDI Thru. MIDIArduinoMIDI INMIDI OUT. .

```
// This is a simple MIDI THRU. Everything in, goes right out.
// This has been validate on an Arduino UNO and a Olimex MIDI Shield
boolean byteReady;
unsigned char midiByte;
void setup() {
    // put your setup code here, to run once:
    // Set MIDI baud rate:
   Serial.begin(31250);
   byteReady = false;
   midiByte = 0;
// The Loop that always gets called...
void loop() {
  if (byteReady) {
       byteReady = false;
       Serial.write(midiByte);
   }
// The little function that gets called each time loop is called.
// This is automated somwhere in the Arduino code.
void serialEvent() {
 if (Serial.available()) {
   // get the new byte:
   midiByte = (unsigned char)Serial.read();
   byteReady = true;
```

MIDI

```
// This is a more complex MIDI THRU. This version uses a queue. Queues are important because
some
// MIDI messages can be interrupted for real time events. If you are generating your own
messages,
// you may need to stop your message to let a "real time" message through and then resume your
message.

#define QUEUE_DEPTH 128
```

```
// Queue Logic for storing messages
int headQ = 0;
int tailQ = 0;
unsigned char tx_queue[QUEUE_DEPTH];
void setup() {
    // put your setup code here, to run once:
    // Set MIDI baud rate:
   Serial.begin(31250);
}
\ensuremath{//}\xspace getQDepth checks for roll over. Folks have told me this
// is not required. Feel free to experiment.
int getQDepth() {
int depth = 0;
   if (headQ < tailQ) {</pre>
        depth = QUEUE_DEPTH - (tailQ - headQ);
        depth = headQ - tailQ;
    return depth;
}
void addQueue (unsigned char myByte) {
   int depth = 0;
    depth = getQDepth();
    if (depth < (QUEUE_DEPTH-2)) {</pre>
        tx_queue[headQ] = myByte;
        headQ++;
        headQ = headQ % QUEUE_DEPTH; // Always keep the headQ limited between 0 and 127
    }
}
unsigned char deQueue() {
   unsigned char myByte;
   myByte = tx_queue[tailQ];
   tailQ++;
    tailQ = tailQ % QUEUE_DEPTH; // Keep this tailQ contained within a limit
    // Now that we dequeed the byte, it must be sent.
   return myByte;
}
void loop() {
   if (getQDepth>0) {
       Serial.write(deQueue());
    }
// The little function that gets called each time loop is called.
// This is automated somwhere in the Arduino code.
void serialEvent() {
 if (Serial.available()) {
   // get the new byte:
   addQueue((unsigned char)Serial.read());;
  }
}
```

MIDI

```
// This is a MiDI clk generator. This takes a \#defined BPM and
// makes the appropriate clk rate. The queue is used to let other messages
// through, but allows a clock to go immediately to reduce clock jitter
#define QUEUE_DEPTH 128
#define BPM 121
#define MIDI_SYSRT_CLK 0xF8
// clock tracking and calculation
unsigned long lastClock;
unsigned long captClock;
unsigned long clk_period_us;
// Queue Logic for storing messages
int headQ = 0;
int tailQ = 0;
unsigned char tx_queue[QUEUE_DEPTH];
void setup() {
    // Set MIDI baud rate:
    Serial.begin(31250);
   clk_period_us = 60000000 / (24 * BPM);
   lastClock = micros();
}
// getQDepth checks for roll over. Folks have told me this
// is not required. Feel free to experiment.
int getQDepth() {
int depth = 0;
   if (headQ < tailQ) {</pre>
       depth = QUEUE_DEPTH - (tailQ - headQ);
    } else {
       depth = headQ - tailQ;
    return depth;
}
void addQueue (unsigned char myByte) {
   int depth = 0;
   depth = getQDepth();
    if (depth < (QUEUE_DEPTH-2)) {
       tx_queue[headQ] = myByte;
       headQ++;
       headQ = headQ % QUEUE_DEPTH; // Always keep the headQ limited between 0 and 127
}
unsigned char deQueue() {
   unsigned char myByte;
   myByte = tx_queue[tailQ];
   tailQ++;
   tailQ = tailQ % QUEUE_DEPTH; // Keep this tailQ contained within a limit
    // Now that we dequeed the byte, it must be sent.
   return myByte;
}
void loop() {
   captClock = micros();
    if (lastClock > captClock) {
```

```
// we have a roll over condition - Again, maybe we don't need to do this.
        if (clk\_period\_us \le (4294967295 - (lastClock - captClock))) {
           // Add a the ideal clock period for this BPM to the last measurement value
           lastClock = lastClock + clk_period_us;
            // Send a clock, bypasing the transmit queue
            Serial.write(MIDI_SYSRT_CLK);
    } else if (clk_period_us <= captClock-lastClock) {</pre>
        // Basically the same two commands above, but not within a roll over check
        lastClock = lastClock + clk_period_us;
        // Send a clock, bypasing the transmit queue
       Serial.write(MIDI_SYSRT_CLK);
   if (getQDepth>0) {
       Serial.write(deQueue());
   }
// The little function that gets called each time loop is called.
// This is automated somwhere in the Arduino code.
void serialEvent() {
 if (Serial.available()) {
   // get the new byte:
   addQueue((unsigned char)Serial.read());;
}
```

MIDI

MIDI""。 4

- •
- •
- •

0x80° 0x7F° 127MIDI° MIDI°

... EXCEPT

D7D0		
1000nnnn	Okkkkkk Ovvvvvv	。。kkkkkk。vvvvvv。
1001nnnn	Okkkkkk Ovvvvvv	。。 kkkkkkk。 vvvvvv
1010nnnn	Okkkkkk Ovvvvvv	。 ""。 kkkkkk。 vvvvvv
1011nnnn	Occccc Ovvvvvv	。。。 120-127""。 cccccc0-119。 vvvvvvv0-127。
1100nnnn	Оррррррр	· · ppppppp
1101nnnn	0vvvvvv	° "° ° ° VVVVVV°

D7D0							
1110nnnn	Ollllll Ommmmmmm	0 0	0	2000H∘	RPN 0°	7°	mmmmmm7°

D7D0		
1011nnnn	Occccc Ovvvvvv	。 Control Change120-127∘
		∘ ∘ c = 120v = 0
		(691 0 0 0
		c = 121v = x∘
		MIDI
		c = 122v = 0
		c = 122v = 127
		。 All Notes Off∘
		c = 123v = 0∘
		c = 124v = 00mni Mode Off
		c = 125v = 00mni Mode On
		c = 126v = MPoly OffMOmni Off0Omni On
		c = 127v = 0Poly

D7D0		
11110000	Oiiiiiii [Oiiiiiii Oiiiiiii] Oddddddd Oddddddd 11110111	 MIDI。 IDMMAAMEI10iiiiii30iiiiii 0iiiiiii 0iiiiiii 1ID。 ID0dddddddd。 System Exclusive。
11110001	Onnndddd	MIDI。 nnn =dddd =
11110010	Ollillii Ommmmmm	∘ 14MIDI1= 6MIDI∘ ILSBMSB∘
11110011	Osssssss	0 0
11110100		0
11110101		О
11110110		o o

D7D0	
11110111	System Exclusive

D7D0	
11111000	∘ 24∘
11111001	٥
11111010	0 0 0
11111011	0 0
11111100	0 0
11111101	o
11111110	。。。300msActive Sensing。。
11111111	0 0 0

MIDI https://riptutorial.com/zh-TW/arduino/topic/9406/midi


5: PWM -

Examples

PWM

Arduino analogWrite()Serial PWM∘

PWM_○ 15V0,0VD



 $Arduino \verb"analogWrite" (pin, value") pinvalue \circ pinvalue 00V2555V \circ \circ$


Arduino Arduino PWM .

MOSFET. <1mA"". ArduinoPWM PWMMOSFETArduino.

- MOSFETBUZ11
- SB320
- 10K~1M
- 12V
- •
- •
- Arduino_°

MOSFET MOSFET MOSFET PWM10MOSFET

0 0



Arduino 0255 · · ·

```
int in = 0;
                            // Variable to store the desired value
byte pinOut = 10;
                            // PWM output pin
void setup() {
                            // This executes once
 Serial.begin(9600);
                                // Initialize serial port
                                // Prepare output pin
 pinMode(pinOut, OUTPUT);
                            // This loops continuously
void loop() {
                           // Check if there's data
 if(Serial.available()){
                               // Read said data into the variable "in"
   in = Serial.read();
                             // Pass the value of "in" to the pin
   analogWrite(pinOut, in);
}
```

ArduinoPWM_o

PWMTLC5940

ArduinoPWM TLC5940。 16120-4095。 http://playground.arduino.cc/Learning/TLC5940。 RGB LED。 PWM。

```
// Include the library
#include <Tlc5940.h>

void setup() {
    // Initialize
    Tlc.init();
    Tlc.clear();
}

unsigned int level = 0;
void loop() {
    // Set all 16 outputs to same value
    for (int i = 0; i < 16; i++) {</pre>
```

```
Tlc.set(i, level);
}
level = (level + 1) % 4096;
// Tell the library to send the values to the chip
Tlc.update();
delay(10);
}
```

PWM - https://riptutorial.com/zh-TW/arduino/topic/1658/pwm----

6: PythonArduino Uno

- Serial.begin(baudrate) // Set baud rate (bits per second) for serial data transmission
- Serial.println(value) // Print data to serial port followed by Carriage Return \r and Newline character \n
- serial.Serial((port=None, baudrate=9600, bytesize=EIGHTBITS, parity=PARITY_NONE, stopbits=STOPBITS_ONE, timeout=None, xonxoff=False, rtscts=False, write_timeout=None, dsrdtr=False, inter_byte_timeout=None) // Initialize serial port with all parameters
- $^{\bullet}$ serial.readline() // Read serial data which contains Carriage Return \r and Newline character \n



Arduino UnoArduino IDE 1.6.9Windows 10Python 2.7.12

Examples

ArduinoPython

Arduino_o

```
void setup() {
  // put your setup code here, to run once:
  Serial.begin(9600);
}

void loop() {
  // put your main code here, to run repeatedly:
  Serial.println("Hello World!");
  delay(100);
}
```

```
setup() Serial.begin(9600) · 9600 · Arduino Serial.begin
```

loop() "Hello World" Serial.println("Hello World!") ASCII (\n) (CR, \r) (\n) 000

COMArduinoCOMPython_o

ArduinoPython

```
void setup() {
  // put your setup code here, to run once:
  Serial.begin(9600);
}

void loop() {
  // put your main code here, to run repeatedly:
  Serial.println("Hello World!");
```

```
delay(100);
}
```

pyserial Windowspyserial Pythonpyserial COM Arduino

readline() while • 100Arduino • pyserial readline() pyserial documentation PySerial ReadLine •

PythonArduino Uno https://riptutorial.com/zh-TW/arduino/topic/6722/pythonarduino-uno

7: SPI

0

```
#define CSPIN 1 // or whatever else your CS pin is
// init:
pinMode(CSPIN, OUTPUT);
digitalWrite(CSPIN, 1); // deselect

// use:
digitalWrite(CSPIN, 0); // select
... perform data transfer ...
digitalWrite(CSPIN, 1); // deselect
```

MISO. MISO. MISO.

- SPI
- SPI

SPI SPISPI SPI.beginTransactionSPISettingsSPI

```
#define CSPIN 1 // or whatever else your CS pin is
// init:
pinMode(CSPIN, OUTPUT);
digitalWrite(CSPIN, 1); // deselect

// use:
digitalWrite(CSPIN, 0); // select
... perform data transfer ...
digitalWrite(CSPIN, 1); // deselect
```

SPISettings

```
#define CSPIN 1 // or whatever else your CS pin is
// init:
pinMode(CSPIN, OUTPUT);
digitalWrite(CSPIN, 1); // deselect

// use:
digitalWrite(CSPIN, 0); // select
... perform data transfer ...
digitalWrite(CSPIN, 1); // deselect
```

 $\texttt{beginTransaction()endTransaction()SPI-} \circ$

ArduinoSPISettings



```
ISRSPI \circ SPI using Interrupt (interrupt\_number) \circ begin Transaction () begin Transaction () end Transaction () \circ
```

ArduinoSPlusingInterrupt

Examples

SPI1

```
#include <SPI.h>
#define CSPIN 1
void setup() {
 pinMode(CSPIN, OUTPUT); // init chip select pin as an output
 digitalWrite(CSPIN, 1); // most slaves interpret a high level on CS as "deasserted"
 SPI.begin();
 SPI.beginTransaction(SPISettings(1000000, MSBFIRST, SPI_MODE0));
 digitalWrite(CSPIN, 0);
 unsigned char sent = 0x01;
 unsigned char received = SPI.transfer(sent);
 // more data could be transferred here
 digitalWrite(CSPIN, 1);
 SPI.endTransaction();
 SPI.end();
void loop() {
 // we don't need loop code in this example.
}
```

- SPI
- SPI。。

SPI https://riptutorial.com/zh-TW/arduino/topic/4919/spi

8:

- digitalPinToInterrupt; //IDIDattachInterrupt()detachInterrupt() o
- attachInterruptdigitalPinToInterruptpinISRmode; //
- attachInterruptISR; //
- detachInterruptdigitalPinToInterrupt;
- detachInterrupt;
- noInterrupts; //
- ; //noInterrupts() •

```
ID。。
ISR 。。
LOWCHANGERISINGFALLING。HIGH。
```

ISR. ISR.

ISRdelay()millis() •

Examples

2GND2_°

```
const int LED_PIN = 13;
const int INTERRUPT_PIN = 2;
volatile bool ledState = LOW;

void setup() {
    pinMode(LED_PIN, OUTPUT);
    pinMode(INTERRUPT_PIN, INPUT_PULLUP);
    attachInterrupt(digitalPinToInterrupt(INTERRUPT_PIN), myISR, FALLING); // trigger when button pressed, but not when released.
}

void loop() {
    digitalWrite(LED_PIN, ledState);
}

void myISR() {
    ledState = !ledState;
    // note: LOW == false == 0, HIGH == true == 1, so inverting the boolean is the same as switching between LOW and HIGH.
```


}

 $\circ \ \circ \ \text{LED} \circ$

https://riptutorial.com/zh-TW/arduino/topic/2913/

9:

- Serial.begin(speed) //Serial.begin(speed, config)
- Serial[1-3].begin(speed) // Arduino Mega1-3130
- Serial[1-3].begin(speed, config) // Arduino Mega1-313.
- Serial.peek() //
- Serial.available() //
- Serial.print(text) //
- Serial.println(text) //Serial.print()



Arduino Mega.

```
Serial.begin(9600);
Serial1.begin(38400);
Serial2.begin(19200);
Serial3.begin(4800);
```

Arduino config.

81 - SERIAL_8E1

62 - SERIAL_602

71 - SERIAL_7N1

Examples

0

```
byte incomingBytes;

void setup() {
   Serial.begin(9600); // Opens serial port, sets data rate to 9600 bps.
}

void loop() {
   // Send data only when you receive data.
   if (Serial.available() > 0) {
        // Read the incoming bytes.
        incomingBytes = Serial.read();
}
```

```
// Echo the data.
Serial.println(incomingBytes);
}
```

Base64

```
byte incoming;
String inBuffer;
void setup() {
    Serial.begin(9600); // or whatever baud rate you would like
void loop(){
   // setup as non-blocking code
   if(Serial.available() > 0) {
        incoming = Serial.read();
        if(incoming == '\n') { // newline, carriage return, both, or custom character
            // handle the incoming command
           handle_command();
            // Clear the string for the next command
            inBuffer = "";
        } else{
           // add the character to the buffer
            inBuffer += incoming;
        }
    }
    // since code is non-blocking, execute something else . . . .
void handle_command() {
   // expect something like 'pin 3 high'
   String command = inBuffer.substring(0, inBuffer.indexOf(' '));
    String parameters = inBuffer.substring(inBuffer.indexOf(' ') + 1);
```

```
if(command.equalsIgnoreCase('pin')) {
    // parse the rest of the information
    int pin = parameters.substring("0, parameters.indexOf(' ')).toInt();
    String state = parameters.substring(parameters.indexOf(' ') + 1);

    if(state.equalsIgnoreCase('high')) {
        digitalWrite(pin, HIGH);
    }else if(state.equalsIgnoreCase('low)) {
        digitalWrite(pin, LOW);
    }else {
        Serial.println("did not compute");
    }
} // add code for more commands
}
```

Python

ArduinoRaspberry PiArduinoPC

Arduino

```
void setup() {
   // Opens serial port, sets data rate to 9600 bps:
   Serial.begin(9600);
}

void loop() {
   // Sends a line over serial:
   Serial.println("Hello, Python!");
   delay(1000);
}
```

```
void setup() {
   // Opens serial port, sets data rate to 9600 bps:
   Serial.begin(9600);
}

void loop() {
   // Sends a line over serial:
   Serial.println("Hello, Python!");
   delay(1000);
}
```

https://riptutorial.com/zh-TW/arduino/topic/1674/

10:

- • Arduino Servo.hServo.h
 - #include <Servo.h> //
 - Servo.attach//。 Servo
 - Servo.write//0 180
 - Servo.read//

Examples

```
#include <Servo.h>
Servo srv;

void setup() {
    srv.attach(9); // Attach to the servo on pin 9
}
```

attach() • PWM• Arduino MegaServo910analogWritePWM•

```
#include <Servo.h>
Servo srv;

void setup() {
    srv.attach(9); // Attach to the servo on pin 9
}
```

https://riptutorial.com/zh-TW/arduino/topic/4920/

11:

```
C / C ++Arduino IDE.

.cpp.
.inoArduino IDE.

Arduino - -

Examples
```

```
int squareNum (int a) {
    return a*a;
}
int
squareNum
int a
return a*a
```

Anatomy of a C function

```
Datatype of data returned,
any C datatype.

Parameters passed to
function, any C datatype.

Function name

int myMultiplyFunction(int x, int y) {

int result;

Return statement,
datatype matches
result = x * y;
return result;

Curly braces required.
```

```
void setup(){
   Serial.begin(9600);
}

void loop() {
   int i = 2;

   int k = squareNum(i); // k now contains 4
   Serial.println(k);
```

```
delay(500);
}
int squareNum(int a) {
   return a*a;
}
```

https://riptutorial.com/zh-TW/arduino/topic/2380/


- Arduino IDE

_

Examples


Arduino IDE

• "">"">""°




0

• ""



• "">""



IDE_°

```
sketch_jan24a | Arduino 1.8.1 (Windows Store 1.8.1.0) — X

File Edit Sketch Tools Help

sketch_jan24a §

#include <Audio.h>
#include <DAC.h>

void setup() {
    // put your setup code here, to run once:
}

void loop() {
    // put your main code here, to run repeatedly:
}
```

https://riptutorial.com/zh-TW/arduino/topic/8896/

13: EEPROM

- EEPROM.write; //EEPROM
- EEPROM.read; //EEPROMEEPROM

EEPROM.write	
	EEPROM
	EEPROM: uint_8 - · EEPROM.put·
EEPROM _°	

0

- ATMega328UnoPro Mini0-1023
- ATMega1680-511
- ATMega12800-4095
- ATMega25600-4095

Examples

EEPROM

<EEPROM.h>

#include <EEPROM.h>

#include <EEPROM.h>


EEPROM https://riptutorial.com/zh-TW/arduino/topic/5987/eeprom

14: ArduinoAtmel Studio 7

- Atmel Studio 7.
- • ISPAtmel Studio Atmel ICE AVRarduinosUnopro miniARMArduinosZeroDue •
- Uno6ICSP Uno AVR •




Arduino Pro Mini AVR



UnoArduino IDE



Pro MiniFTDIDTRAtmelSWD。 TxRx。 ArduinoRxTxFTDITxRx。 FTDIRxTx。



Arduino FTDIPro MiniUnoUSBAC

Atmel ICEAtmel StudioArduino.

Atmel Studio - > - > "Arduino sketch" . . .

Project - > yourProjectName PropertiesTooldebugger / programmerAtmel ICEdebugWire。 Debug - > Start debugging and break。 DWEN。 Arduino。 ArduinoArduino IDEDebug - > disable debugWIRE。

Atmel StudioAtmel Studio

Arduino 1.6.6C ++ 11 $^{\circ}$ C ++Arduinio $^{\circ}$ Atmel Studio 7C ++ 11ToolChainAVR / GNU C ++-std=c++11 $^{\circ}$

.CDDC:\Users\YourUserName\Documents\Atmel

Studio\7.0\YourSolutionName\YourProjectName\ArduinoCore\src\core Atmel StudioSolution Explorer Arduino Core / src / - > .hYourProjectName / Dependancies .

Android IDEAtmel Studio - > Atmel Studio - > .

Atmel Studio 7IDEArduinoArduino IDE/

```
->->->
```

- Edit.CommentSelectionEdit.UncommentSelection
- View.NavigateForwardView.NavigateBackward
- Edit.MoveSelectedLinesUpEdit.MoveSelectedLinesDown
- Edit.GoToDefinition

Examples

Atmel Studio 7

ArduinoAtmel Studio Atmel Studio Arduino Ardui

```
/* Begining of Auto generated code by Atmel studio */
#include <Arduino.h>
/* End of auto generated code by Atmel studio */

// Beginning of Auto generated function prototypes by Atmel Studio
void printA();
// End of Auto generated function prototypes by Atmel Studio

void setup() {
    Serial.begin(9600);
}

void loop() {
    printA();
}

void printA() {
    Serial.println("A");
}
```

ArduinoAtmel Studio 7 https://riptutorial.com/zh-TW/arduino/topic/2567/arduinoatmel-studio-7

- for{}
- {}

_

```
General Remark osetuploop osetupl
```

Examples

whiletrue o true whileo

100num1

```
int num = 0;
while (num < 100) {
    // do something
    num++;
}</pre>
```

for

```
int num = 0;
while (num < 100) {
    // do something
    num++;
}</pre>
```

```
int num = 0;
while (num < 100) {
    // do something
    num++;
}</pre>
```

for

```
int num = 0;
while (num < 100) {
    // do something
    num++;
}</pre>
```

forwhile

for 100°

```
for (int i = 0; i < 100; i++) {
    // do something
}</pre>
```

while

```
for (int i = 0; i < 100; i++) {
    // do something
}</pre>
```

0

```
for (int i = 0; i < 100; i++) {
    // do something
}</pre>
```

while

```
for (int i = 0; i < 100; i++) {
    // do something
}</pre>
```

do whilewhile o

100°

```
int i = 0;
do {
    i++;
} while (i < 100);</pre>
```

1。

```
int i = 0;
do {
    i++;
} while (i < 100);</pre>
```

 $\mathtt{while} \mathbf{0} \mathtt{false} \, \circ \, \, \, \mathtt{do} \, \, \mathtt{while} \circ$

0

break; o

continue; °

break 101i = 0,1...1001000

```
for (int i = 0; i < 1000; i++) {
    // execute this repeatedly with i = 0, 1, 2, ...
    if (i >= 100) {
        break;
    }
}
```

continuej50100

```
for (int i = 0; i < 1000; i++) {
    // execute this repeatedly with i = 0, 1, 2, ...
    if (i >= 100) {
        break;
    }
}
```

https://riptutorial.com/zh-TW/arduino/topic/2802/


- pinMode(pin, pinMode) //o
- digitalRead(pin); //



∘ 10∘ ∘

Examples

/LED_°



Arduino.cc •

https://riptutorial.com/zh-TW/arduino/topic/1662/

• digitalWrite(pin, value)

Examples

Arduino.cc.

https://riptutorial.com/zh-TW/arduino/topic/2477/

Examples

cardInfo

```
SD card test
This example shows how use the utility libraries on which the'
SD library is based in order to get info about your SD card.
Very useful for testing a card when you're not sure whether its working or not.
The circuit:
 * SD card attached to SPI bus as follows:
 ** MOSI - pin 11 on Arduino Uno/Duemilanove/Diecimila
 ** MISO - pin 12 on Arduino Uno/Duemilanove/Diecimila
 ** CLK - pin 13 on Arduino Uno/Duemilanove/Diecimila
 ** CS - depends on your SD card shield or module.
          Pin 4 used here for consistency with other Arduino examples
 created 28 Mar 2011
by Limor Fried
modified 9 Apr 2012
by Tom Igoe
*/
// include the SD library:
#include <SPI.h>
#include <SD.h>
// set up variables using the SD utility library functions:
Sd2Card card;
SdVolume volume;
SdFile root;
// change this to match your SD shield or module;
// Arduino Ethernet shield: pin 4
// Adafruit SD shields and modules: pin 10
// Sparkfun SD shield: pin 8
const int chipSelect = 4;
void setup()
 // Open serial communications and wait for port to open:
 Serial.begin(9600);
 while (!Serial) {
    ; // wait for serial port to connect. Needed for Leonardo only
 Serial.print("\nInitializing SD card...");
 // we'll use the initialization code from the utility libraries
 // since we're just testing if the card is working!
 if (!card.init(SPI_HALF_SPEED, chipSelect)) {
    Serial.println("initialization failed. Things to check:");
    Serial.println("* is a card inserted?");
```

```
Serial.println("* is your wiring correct?");
   Serial.println("* did you change the chipSelect pin to match your shield or module?");
  } else {
   Serial.println("Wiring is correct and a card is present.");
  // print the type of card
 Serial.print("\nCard type: ");
 switch (card.type()) {
   case SD_CARD_TYPE_SD1:
     Serial.println("SD1");
     break;
   case SD_CARD_TYPE_SD2:
     Serial.println("SD2");
     break;
   case SD_CARD_TYPE_SDHC:
     Serial.println("SDHC");
     break:
   default:
      Serial.println("Unknown");
 // Now we will try to open the 'volume'/'partition' - it should be FAT16 or FAT32
 if (!volume.init(card)) {
   Serial.println("Could not find FAT16/FAT32 partition.\nMake sure you've formatted the
card");
   return;
 // print the type and size of the first FAT-type volume
 uint32_t volumesize;
 Serial.print("\nVolume type is FAT");
 Serial.println(volume.fatType(), DEC);
 Serial.println();
 volumesize = volume.blocksPerCluster();
                                            // clusters are collections of blocks
 volumesize *= volume.clusterCount();
                                             // we'll have a lot of clusters
 volumesize *= 512;
                                                // SD card blocks are always 512 bytes
 Serial.print("Volume size (bytes): ");
 Serial.println(volumesize);
 Serial.print("Volume size (Kbytes): ");
 volumesize /= 1024;
 Serial.println(volumesize);
 Serial.print("Volume size (Mbytes): ");
 volumesize /= 1024;
 Serial.println(volumesize);
 Serial.println("\nFiles found on the card (name, date and size in bytes): ");
 root.openRoot(volume);
 // list all files in the card with date and size
 root.ls(LS_R | LS_DATE | LS_SIZE);
void loop(void) {
```

```
SD card datalogger
This example shows how to log data from three analog sensors
 to an SD card using the SD library.
The circuit:
 ^{\star} analog sensors on analog ins 0, 1, and 2
 * SD card attached to SPI bus as follows:
 ** MOSI - pin 11
 ** MISO - pin 12
 ** CLK - pin 13
 ** CS - pin 4
 created 24 Nov 2010
modified 9 Apr 2012
by Tom Igoe
This example code is in the public domain.
 */
#include <SPI.h>
#include <SD.h>
const int chipSelect = 4;
void setup()
  // Open serial communications and wait for port to open:
  Serial.begin(9600);
  while (!Serial) {
    ; // wait for serial port to connect. Needed for Leonardo only
  Serial.print("Initializing SD card...");
  // see if the card is present and can be initialized:
 if (!SD.begin(chipSelect)) {
   Serial.println("Card failed, or not present");
   // don't do anything more:
   return;
  Serial.println("card initialized.");
void loop()
  // make a string for assembling the data to log:
  String dataString = "";
  // read three sensors and append to the string:
  for (int analogPin = 0; analogPin < 3; analogPin++) {</pre>
   int sensor = analogRead(analogPin);
   dataString += String(sensor);
   if (analogPin < 2) {
     dataString += ",";
```

```
// open the file. note that only one file can be open at a time,
// so you have to close this one before opening another.
File dataFile = SD.open("datalog.txt", FILE_WRITE);

// if the file is available, write to it:
if (dataFile) {
  dataFile.println(dataString);
  dataFile.close();
  // print to the serial port too:
  Serial.println(dataString);
}

// if the file isn't open, pop up an error:
else {
  Serial.println("error opening datalog.txt");
}
```

SD

```
SD card file dump
This example shows how to read a file from the SD card using the
SD library and send it over the serial port.
The circuit:
 * SD card attached to SPI bus as follows:
 ** MOSI - pin 11
 ** MISO - pin 12
 ** CLK - pin 13
 ** CS - pin 4
 created 22 December 2010
by Limor Fried
modified 9 Apr 2012
by Tom Igoe
This example code is in the public domain.
 * /
#include <SPI.h>
#include <SD.h>
const int chipSelect = 4;
void setup()
  \ensuremath{//} Open serial communications and wait for port to open:
 Serial.begin(9600);
  while (!Serial) {
   ; // wait for serial port to connect. Needed for Leonardo only
  Serial.print("Initializing SD card...");
```

```
// see if the card is present and can be initialized:
 if (!SD.begin(chipSelect)) {
   Serial.println("Card failed, or not present");
   // don't do anything more:
   return;
 Serial.println("card initialized.");
 // open the file. note that only one file can be open at a time,
 // so you have to close this one before opening another.
 File dataFile = SD.open("datalog.txt");
 // if the file is available, write to it:
 if (dataFile) {
   while (dataFile.available()) {
     Serial.write(dataFile.read());
   dataFile.close();
 // if the file isn't open, pop up an error:
   Serial.println("error opening datalog.txt");
void loop()
```

SD

```
SD card basic file example
This example shows how to create and destroy an SD card file
The circuit:
 * SD card attached to SPI bus as follows:
 ** MOSI - pin 11
 ** MISO - pin 12
 ** CLK - pin 13
 ** CS - pin 4
created Nov 2010
by David A. Mellis
modified 9 Apr 2012
by Tom Igoe
This example code is in the public domain.
*/
#include <SPI.h>
#include <SD.h>
File myFile;
void setup()
  // Open serial communications and wait for port to open:
```

```
Serial.begin(9600);
 while (!Serial) {
   ; // wait for serial port to connect. Needed for Leonardo only
 Serial.print("Initializing SD card...");
 if (!SD.begin(4)) {
   Serial.println("initialization failed!");
   return;
 Serial.println("initialization done.");
 if (SD.exists("example.txt")) {
   Serial.println("example.txt exists.");
 else {
   Serial.println("example.txt doesn't exist.");
 // open a new file and immediately close it:
 Serial.println("Creating example.txt...");
 myFile = SD.open("example.txt", FILE_WRITE);
 myFile.close();
 // Check to see if the file exists:
 if (SD.exists("example.txt")) {
   Serial.println("example.txt exists.");
 else {
   Serial.println("example.txt doesn't exist.");
 // delete the file:
 Serial.println("Removing example.txt...");
 SD.remove("example.txt");
 if (SD.exists("example.txt")) {
   Serial.println("example.txt exists.");
 else {
   Serial.println("example.txt doesn't exist.");
}
void loop()
 // nothing happens after setup finishes.
```

Listfiles

```
/*
Listfiles

This example shows how print out the files in a directory on a SD card

The circuit:
```

```
* SD card attached to SPI bus as follows:
 ** MOSI - pin 11
 ** MISO - pin 12
 ** CLK - pin 13
 ** CS - pin 4
 created
         Nov 2010
by David A. Mellis
modified 9 Apr 2012
by Tom Igoe
modified 2 Feb 2014
by Scott Fitzgerald
This example code is in the public domain.
#include <SPI.h>
#include <SD.h>
File root;
void setup()
  \ensuremath{//} Open serial communications and wait for port to open:
 Serial.begin(9600);
  while (!Serial) {
   ; // wait for serial port to connect. Needed for Leonardo only
  Serial.print("Initializing SD card...");
  if (!SD.begin(4)) {
   Serial.println("initialization failed!");
   return;
  Serial.println("initialization done.");
 root = SD.open("/");
  printDirectory(root, 0);
 Serial.println("done!");
void loop()
  // nothing happens after setup finishes.
void printDirectory(File dir, int numTabs) {
   while(true) {
     File entry = dir.openNextFile();
     if (! entry) {
      // no more files
      break;
     for (uint8_t i=0; i<numTabs; i++) {</pre>
      Serial.print('\t');
     Serial.print(entry.name());
```

```
if (entry.isDirectory()) {
    Serial.println("/");
    printDirectory(entry, numTabs+1);
} else {
    // files have sizes, directories do not
    Serial.print("\t\t");
    Serial.println(entry.size(), DEC);
}
entry.close();
}
```

SD/

```
SD card read/write
This example shows how to read and write data to and from an SD card file
The circuit:
 * SD card attached to SPI bus as follows:
 ** MOSI - pin 11
 ** MISO - pin 12
 ** CLK - pin 13
 ** CS - pin 4
created Nov 2010
by David A. Mellis
modified 9 Apr 2012
by Tom Igoe
This example code is in the public domain.
 */
#include <SPI.h>
#include <SD.h>
File myFile;
void setup()
  // Open serial communications and wait for port to open:
 Serial.begin(9600);
 while (!Serial) {
   ; // wait for serial port to connect. Needed for Leonardo only
 Serial.print("Initializing SD card...");
 if (!SD.begin(4)) {
   Serial.println("initialization failed!");
   return;
 Serial.println("initialization done.");
 // open the file. note that only one file can be open at a time,
 // so you have to close this one before opening another.
 myFile = SD.open("test.txt", FILE_WRITE);
```

```
// if the file opened okay, write to it:
 if (myFile) {
   Serial.print("Writing to test.txt...");
   myFile.println("testing 1, 2, 3.");
   // close the file:
   myFile.close();
   Serial.println("done.");
  } else {
   // if the file didn't open, print an error:
   Serial.println("error opening test.txt");
 // re-open the file for reading:
 myFile = SD.open("test.txt");
 if (myFile) {
   Serial.println("test.txt:");
   // read from the file until there's nothing else in it:
   while (myFile.available()) {
     Serial.write(myFile.read());
   // close the file:
   myFile.close();
 } else {
   // if the file didn't open, print an error:
   Serial.println("error opening test.txt");
}
void loop()
 // nothing happens after setup
```

https://riptutorial.com/zh-TW/arduino/topic/6584/

- · unsigned long millis
- unsigned long micros
- · void delayunsigned long milliseconds
- void delayMicrosecondsunsigned long microseconds
- elapsedMillis •

```
elapsedMillis elapsedMillisObject;
```

- elapsedMillisObject = 0; ""
- unsigned long deltaT = elapsedMillisObject;
- elapsedMillisObject + = =

```
delay()delayMicroseconds() · ·
```

- CPULEDCPU
- delay() o
- 100delay(500)°

```
\label{eq:millis} \begin{split} &\text{millis()} \; 1 \; kHz \circ \; &\text{millis()} \; \circ \; &\text{````} \circ \; &\text{millis()} \circ \; &\text{micros()} \; \circ \\ &\text{elapsedMillismillis()} \circ \; &\text{elapsedMicroselapsedMicros} \; \circ \end{split}
```

Examples

LED

CPU millis()elapsedMillis - \circ

elapsedMillis

elapsedMillis

```
#include <elapsedMillis.h>
#define OUTPIN LED_BUILTIN
#define PERIOD 500

elapsedMillis ledTime;

bool ledState = false;

void setup()
{
    // initialize the digital pin as an output.
    pinMode(OUTPIN, OUTPUT);
}

void loop()
{
    if (ledTime >= PERIOD)
    {
        ledState = !ledState;
        digitalWrite(OUTPIN, ledState);
        ledTime = 0;
    }
    // do other stuff here
}
```

LED ledTime •

 $\texttt{ledTimePERIOD} 750 \circ \texttt{ledTime} \texttt{""} 250 \circ \texttt{ledTimePERIOD} \ \textbf{LED} \circ$

millis

arduino

```
// set constants for blinking the built-in LED at 1 Hz
#define OUTPIN LED_BUILTIN
#define PERIOD 500 // this is in milliseconds
int ledState = LOW;

// millis() returns an unsigned long so we'll use that to keep track of time unsigned long lastTime = 0;

void setup() {
    // set the digital pin as output:
    pinMode(OUTPIN, OUTPUT);
}

void loop() {
    unsigned long now = millis();
```

```
if (now - lastTime >= PERIOD) // this will be true every PERIOD milliseconds
{
    lastTime = now;
    if (ledState == LOW)
    {
        ledState = HIGH;
    }
    else
    {
        ledState = LOW;
    }
    digitalWrite(OUTPIN, ledState);
}

// now there's lots of time to do other stuff here
}
```

millis() - - elapsedMillis o

elapsedMilliselapsedMicros

```
#include <elapsedMillis.h>

void setup() {
    Serial.begin(115200);
    elapsedMillis msTimer;
    elapsedMillis msTimer;
    elapsedMicros usTimer;

    long int dt = 500;
    delay(dt);

    long int us = usTimer;
    long int ms = msTimer;

    Serial.print("delay("); Serial.print(dt); Serial.println(") took");
    Serial.print(us); Serial.println(" us, or");
    Serial.print(ms); Serial.println(" ms");
}

void loop() {
}
```

elapsedMilliselapsedMicros · ·

1

```
if(now-last[0]>=intervals[0]){ last[0]=now; firstTask(); }
if(now-last[1]>=intervals[1]){ last[1]=now; secondTask(); }

//do other things here
}

void firstTask(){
    //let's toggle the built-in led
    digitalWrite(LED_BUILTIN, digitalRead(LED_BUILTIN)?0:1);
}

void secondTask(){
    //say hello
    Serial.println("hello from secondTask()");
}
```

15intervalslast

```
unsigned long intervals[] = {250,2000}; //this defines the interval for each task in
milliseconds
unsigned long last[] = \{0,0\};
                                       //this records the last executed time for each task
void setup() {
 pinMode(LED_BUILTIN, OUTPUT); //set the built-it led pin as output
  Serial.begin(115200);
                              //initialize serial
void loop() {
  unsigned long now = millis();
  if(now-last[0]>=intervals[0]) { last[0]=now; firstTask(); }
  if(now-last[1]>=intervals[1]) { last[1]=now; secondTask(); }
  //do other things here
void firstTask() {
 //let's toggle the built-in led
  digitalWrite(LED_BUILTIN, digitalRead(LED_BUILTIN)?0:1);
void secondTask() {
  //say hello
  Serial.println("hello from secondTask()");
```

if∘ thirdTask∘

```
if(now-last[1]>=intervals[1]){ last[1]=now; secondTask(); }

//do other things here
}

void firstTask(){
   //let's toggle the built-in led
   digitalWrite(LED_BUILTIN, digitalRead(LED_BUILTIN)?0:1);
}

void secondTask(){
   //say hello
   Serial.println("hello from secondTask()");
}
```

```
unsigned long intervals[] = {250,2000}; //this defines the interval for each task in
unsigned long last[] = {0,0};
                                      //this records the last executed time for each task
void setup() {
 pinMode(LED_BUILTIN, OUTPUT); //set the built-it led pin as output
 Serial.begin(115200); //initialize serial
void loop() {
 unsigned long now = millis();
 if(now-last[0]>=intervals[0]) { last[0]=now; firstTask(); }
 if(now-last[1]>=intervals[1]) { last[1]=now; secondTask(); }
 //do other things here
}
void firstTask() {
 //let's toggle the built-in led
 digitalWrite(LED_BUILTIN, digitalRead(LED_BUILTIN)?0:1);
void secondTask() {
 //say hello
 Serial.println("hello from secondTask()");
```

https://riptutorial.com/zh-TW/arduino/topic/4852/

analogRead(pin) //∘

```
Serial.println(val)
```

Examples

AREFarduino

```
//A0 (uno)
#define analogPin 14
#define AREFValue 5
                //Standard for 5V Arduinos
int ADCValue = 0;
float voltage = 0;
void setup()
  Serial.begin(9600);
void loop()
  readADC();
  Serial.print(voltage); Serial.println("V");
void readADC()
  ADCValue = analogRead(analogPin);
  float, devide by the ADC resolution and multiply by the AREF voltage
```

}

https://riptutorial.com/zh-TW/arduino/topic/2382/

ArduinoLiquid Crystal LibraryHitachi HD44780LCD16。 16I2C。 5x7。 16216x2160220420x4 2004。

- #include <LiquidCrystal.h> //
- LiquidCrystalrsenabled4d5d6d7//
- LiquidCrystalrsrwenabled4d5d6d7
- LiquidCrystalrsenabled0d1d2d3d4d5d6d7
- LiquidCrystalrsrwenabled0d1d2d3d4d5d6d7

RS	LCDRSArduino	
RW	LCDRWArduino	
	LCDArduino	
d0 - d7	LCDArduino。 d0d1d2d3;d4d5d6d7LCD。	

Examples

```
Wiring:
  LCD pin 1 (VSS) -> Arduino Ground
  LCD pin 2 (VDD) -> Arduino 5V
  LCD pin 3 (VO) -> Arduino Ground
  LCD pin 4 (RS) -> Arduino digital pin 12
  LCD pin 5 (RW) -> Arduino Ground
  LCD pin 6 (E) -> Arduino digital pin 11
  LCD pin 11 (D4) -> Arduino digital pin 5
  LCD pin 12 (D5) -> Arduino digital pin 4
  LCD pin 13 (D6) -> Arduino digital pin 3
  LCD pin 14 (D7) -> Arduino digital pin 2
#include <LiquidCrystal.h> // include the library
// initialize the library with the numbers of the interface pins
LiquidCrystal lcd(12, 11, 5, 4, 3, 2);
void setup() {
 // set up the LCD's number of columns and rows:
 lcd.begin(16, 2);
 // start writing on the first row and first column.
 lcd.setCursor(0, 0);
 // Print a message to the LCD.
 lcd.print("hello, world!");
void loop() {
```


```
// No need to do anything to keep the text on the display
}
```

https://riptutorial.com/zh-TW/arduino/topic/9395/

Examples

Arduino Uno R3

∘ /vin∘ I / OI / O∘ Arduino R3 Uno∘



PWM

PWM∘ ""∘

PWM3,5,6,9,10,11

PWMArduino Uno R3. . analogWrite - PWM.

ADCA0A1A2A3A4A5

SPII2C

Arduino Uno R3USBUSB。 SerialTx on 0Rx on 1

SPII2CArduino.....

SPIMOSI 11MISO 12SCLK 13SS 10

I2CA5SCLA4SDA

LED

Arduino Uno R3LED13.LED13LED. ""LED.

Arduino

 $13 LED \tiny{\bullet} \quad 20 k1.7 V5 VLEDLOW \tiny{\bullet} \quad 13 pin Model NPUT \tiny{\bullet}$

LED13

https://riptutorial.com/zh-TW/arduino/topic/4386/

SoftwareSerial.h	
SoftwareSerial rxPintxPin inverse_logic	。 rxPin 0. txPin 1. inverse_logic trueLOWHIGHHIGHLOW。 false。
	° 300,600,1200,2400,4800,9600,14400,19200,28800,31250,38400,57600 115200°
isListening	o
	∘ false∘ 64∘
	RX。read。SoftwareSeriallisten()。
	∘ Serial.print()∘
println	∘ Serial.println()∘
	∘ ; ∘ listen() ∘
	∘ Serial.write()∘

rxtx01SoftwareSerialtxrx。

Examples

```
#include <SoftwareSerial.h>
// its always better to change the default tx and rx as the may interfere with other process in future.

// configure tx , rx by defualt they will be 0 and 1 in arduino UNO
SoftwareSerial blue(3,2);
void setup() {
    // preferred baud rate/data transfer rate in general is 38400
        blue.begin(38400);
    // do initialization or put one time executing code here
}

void loop() {
    // put code that you want it to run every time no matter what
    if(blue.available()) {
```

```
// put only that code which needsd to run when there is some data
// This means that the their is some data sent over the bluetooth
// You can do something with the data
int n;
// consider that the data received to be integer, read it by using blue.parseInt();
n = blue.parseInt();
}
```

https://riptutorial.com/zh-TW/arduino/topic/2543/

Examples

```
variableType variableName;

variableType variableName;

variableType variableName;

int a; // declared previously a = 2;

int a; // declared previously a = 2;
```

- char 1
- byte 8
- int 16ATMEGA32Arduino Due
- unsigned int 16ATMEGA32Arduino Due
- long **32**
- unsigned long 32
- float 4
- double 4ATMEGA8Arduino Due

```
char a = 'A';
char a = 65;

byte b = B10010;
int c = 2;
unsigned int d = 3;
long e = 186000L;
unsigned long f = millis(); // as an example
float g = 1.117;
double h = 1.117;
```

https://riptutorial.com/zh-TW/arduino/topic/2565/

- randommax//0max
- randomminmax//minmax
- randomSeedseed//de

```
random() o random() o
```

randomSeed() randomSeed(5) · ·

Examples

random()

```
void setup() {
    Serial.begin(9600);
}

void loop() {
    long randomNumber = random(500); // Generate a random number between 0 and 499
    Serial.println(randomNumber);

    randomNumber = random(100, 1000); // Generate a random number between 100 and 999
    Serial.println(randomNumber);

    delay(100);
}
```

random()randomSeed()

```
void setup() {
    Serial.begin(9600);

    // If analog pin 0 is left unconnected, analogRead(0) will produce a
    // different random number each time the sketch is run.
    randomSeed(analogRead(0));
}

void loop() {
    long randomNumber = random(500); // Generate a random number between 0 and 499
    Serial.println(randomNumber);

    delay(100);
}
```

os://riptutorial.com/zh-TW/arduino/topic/2238/					



Examples

```
#define NOTE_C4 262 //From pitches.h file defined in [Arduino Tone Tutorial][1]
int Key = 2;
int KeyVal = 0;

byte speaker = 12;

void setup()
{
    pinMode(Key, INPUT); //Declare our key (button) as input
    pinMode(speaker, OUTPUT);
}

void loop()
{
    KeyVal = digitalRead(Key);
    if (KeyVal == HIGH) {
        tone(speaker, NOTE_C4); //Sends middle C tone out through analog speaker
    } else {
        noTone(speaker); //Ceases tone emitting from analog speaker
    }

    delay(100);
}
```

[1] https://www.arduino.cc/en/Tutorial/toneMelody

https://riptutorial.com/zh-TW/arduino/topic/2384/

S. No		Contributors
1	arduino	Abhishek Jain, Christoph, Community, Danny_ds, Doruk, geek1011, gmuraleekrishna, H. Pauwelyn, jleung513, Martin Carney, Mizole Ni, Shef, uruloke, Wolfgang
2	Arduino IDE	geek1011, Jeremy, jleung513, sohnryang, uruloke
3	I2C	Asaf
4	MIDI	Rich Maes
5	PWM -	Danny_ds, Johnny Mopp, JorgeGT, Martin Carney
6	PythonArduino Uno	Danny_ds, Peter Mortensen, Stark Nguyen
7	SPI	Christoph
8		DavidJ, Martin Carney
9		blainedwards8, Danny_ds, geek1011, Leah, Martin Carney, MikeS159, Morgoth, Nufail Achath, Peter Mortensen, uruloke
10		geek1011, mactro, Morgoth
11		datafiddler, Leah, MikeCAT
12		Oscar Lundberg
13	EEPROM	AZ Vcience, Chris Combs, Danny_ds, Jeremy, Peter Mortensen , RamenChef
14	ArduinoAtmel Studio 7	Danny_ds, Nate
15		datafiddler, Martin Carney, MikeCAT
16		Martin Carney, uruloke
17		uruloke
18		Danny_ds, robert
19		Christoph, Rei
20		Jake Lites, MikeS159, Ouss4, uruloke
21		Morgoth

22	Jeremy, Martin Carney
23	Girish, Martin Carney
24	Leah, MikeCAT
25	Danny_ds, Javier Rizzo Aguirre, MikeCAT
26	Jake Lites, MikeCAT