

PAVEMENT STRIPER SAFE JOB PROCEDURE

APPROVED AUGUST 10 2015

- 1. Prep area by sweeping area to be painted to keep free of dust and debris. Older parking areas need to be cleaned of grease.
- 2. Using nails and hammer and chalk lines mark off what and where paint needs to be applied.
- 3. Pre-inspect machine especially airlines.
- 4. Paint Preparation: Mix, thin & strain
 - a. Mix and use viscosity cup to arrive at the correct consistency. Spray tips comes in two sizes.
- 5. Operating pressure
- 6. Striping
- 7. Cleanup discharge system completely of paint including washing the paint drum with a soapy brush Electric Air Compressor