## Reusable Blood Transfusion User Guide



## **Assembly**

- 1. Obtain components listed above
- 2. Thread the bottom of the tubing (6) through the flow regulator (large part of flow regulator upright) (5)
- 3. Place filter (3) into drip chamber bottom (4)
- 4. Screw in the drip chamber top (2.2) to the drip chamber bottom (4)
- 5. Screw in the spike (1) to the drip chamber (2.1)
- 6. Attach the needle connection (7) to the bottom of the tubing (6)

## Disassembly/ Sterilization

- 1. Deconstruct the transfusion set, throwing away the needle
- 2. Place the \_\_ separate components into the wash prior to autoclave
- 3. Transfer the components into the autoclave
- 4. Start autoclave cycle
- 5. Remove components when the cycle is finished