1	glow plugs relay	27	5V	53	throttle pos	79	nc
2	nc	28	nc		nc	80	glow plugs lamp
3	(sck)	29	nc	55	+12V / ATT		nc
4	(sda)	30	nc	56	nc	82	nc
5	(a0)	31	turbo pressure	57	oil temp	83	3.3V
6	(cpu reset)	32	H glass button	58	coolant temp	84	nc
7	(cs)	33	nc	59	nc	85	nc
8	(3.3v)	34	misc 1	60	nc	86	nc
9	nc	35	EGR	61	nc	87	nc
10	nc	36	nc	62	nc	88	nc
11	nc	37	nc	63	air temp	89	nc
12	heater hi	38	nc	64	nc	90	
13	heater lo	39	DPF START	65	nc	91	
14	EGT	40	nc	66	FUEL POS	92	+12V / ignition
15		41	misc 2	67	nc		nc
16		42	turbo	68	FAN	94	nc
17	heated glass	43	nc'	69	idle	95	nc
18		44	nc	70	PPP SIGN	96	
19	heated glass	45	nc	71	+12V / ignition	97	+12V / ignition
20	nc	46		72	nc	98	200
21	hall sign	47	nc	73	nc	99	nc
22	hall gnd	48	nc	74	nc	100	
23	nc	49	SDA	75	nc	101	nc
24	nc	50	SCL	76	gnd	102	nc
25	gnd	51	gnd		gnd	103	
26	nc	52	nc	78		104	