Computer Organization and Architecture

Module 2

Basic Operation of Computer Systems, Instruction Set & Addressing Modes, Instruction Encoding

Prof. Indranil Sengupta

Dr. Sarani Bhattacharya


Department of Computer Science and Engineering

IIT Kharagpur

Basic Block Diagram of a Computer System

Simplified Block Diagram


- All instructions and data are stored in memory.
- An instruction and the required data are brought into the processor for execution.
- Input / Output devices interface with the outside world.
- Referred to as von-Neumann architecture.



PROCESSOR CONTROL ARITHMETIC LOGIC UNIT (ALU) MEMORY PRIMARY MEMORY PRIMARY MEMORY SECONDARY MEMORY


• Inside the Processor

- Also called Central Processing Unit (CPU).
- Consists of a *Control Unit* and an *Arithmetic Logic Unit* (ALU).
 - All calculations happen inside the ALU.
 - The Control Unit generates sequence of control signals to carry out all operations.
- The processor fetches an instruction from memory for execution.
 - An instruction specifies the exact operation to be carried out.
 - It also specifies the data that are to be operated on.




What is the role of ALU?

- It contains several registers, some general-purpose and some special-purpose, for temporary storage of data.
- It contains circuitry to carry out logic operations, like AND, OR, NOT, shift, compare, etc.
- It contains circuitry to carry out arithmetic operations like addition, subtraction, multiplication, division, etc.
- During instruction execution, the data (operands) are brought in and stored in some registers, the desired operation carried out, and the result stored back in some register or memory.



What is the role of control unit?

- Acts as the nerve center that senses the states of various functional units and sends control signals to control their states.
- To carry out a specific operation (say, R1 ← R2 + R3), the control unit must generate control signals in a specific sequence.
 - Enable the outputs of registers R2 and R3.
 - Select the addition operation.
 - Store the output of the adder circuit into register R1.
- When an instruction is fetched from memory, the operation (called *opcode*) is decoded by the control unit, and the control signals issued.



Inside the Memory Unit

- Two main types of memory subsystems:
 - *Primary or Main memory*, which stores the active instructions and data for the program being executed on the processor.
 - Secondary memory, which is used as a backup and stores all active and inactive programs and data, typically as files.
- The processor only has direct access to the primary memory.
- In reality, the memory system is implemented as a hierarchy of several levels.
 - L1 cache, L2 cache, L3 cache, primary memory, secondary memory.
 - Objective is to provide faster memory access at affordable cost.


- Various different types of memory are possible.
 - a) Random Access Memory (RAM), which is used for the cache and primary memory sub-systems. Read and Write access times are independent of the location being accessed.
 - b) Read Only Memory (ROM), which is used as part of the primary memory to store some fixed data that cannot be changed.
 - c) Magnetic Disk, which uses direction of magnetization of tiny magnetic particles on a metallic surface to store data. Access times vary depending on the location being accessed, and is used as secondary memory.
 - d) Flash Memory or Solid-State Drives (SSD), which is replacing magnetic disks as secondary memory devices. They are faster, but smaller in size as compared to disk.















Input Unit

- Used to feed data to the computer system from the external environment.
 - Data are transferred to the processor/memory after appropriate encoding.
- Common input devices:
 - Keyboard
 - Mouse
 - Joystick
 - Camera













Output Unit

- Used to send the result of some computation to the outside world.
- Common output devices:
 - LCD/LED screen
 - Printer and Plotter
 - Speaker / Buzzer
 - Projection system














Basic Operation of a Computer


Introduction

- The basic mechanism through which an instruction gets executed shall be illustrated.
- May be recalled:
 - ALU contains a set of registers, some general-purpose and some specialpurpose.
 - First we briefly explain the functions of the special-purpose registers before we look into some examples.

For Interfacing with the Primary Memory

- Two special-purpose registers are used:
 - Memory Address Register (MAR): Holds the address of the memory location to be accessed.
 - Memory Data Register (MDR): Holds the data that is being written into memory, or will receive the data being read out from memory.
- Memory considered as a linear array of storage locations (bytes or words) each with unique address.






- To read data from memory
 - Load the memory address into MAR.
 - Issue the control signal READ.
 - The data read from the memory is stored into MDR.
- To write data into memory
 - Load the memory address into MAR.
 - Load the data to be written into MDR.
 - Issue the control signal WRITE.

For Keeping Track of Program / Instructions

- Two special-purpose registers are used:
 - Program Counter (PC): Holds the memory address of the next instruction to be executed.
 - Automatically incremented to point to the next instruction when an instruction is being executed.
 - Instruction Register (IR): Temporarily holds an instruction that has been fetched from memory.
 - Need to be decoded to find out the instruction type.
 - Also contains information about the location of the data.

Overall Architecture of a Simple Processor



Example Instructions

 We shall illustrate the process of instruction execution with the help of the following two instructions:

a) ADD R1, LOCA

Add the contents of memory location LOCA (i.e. address of the memory location is LOCA) to the contents of register R1.

$$R1 \leftarrow R1 + Mem[LOCA]$$

b) ADD R1, R2

Add the contents of register R2 to the contents of register R1.

Execution of ADD R1,LOCA

- Assume that the instruction is stored in memory location 1000, the initial value of R1 is 50, and LOCA is 5000.
- Before the instruction is executed, PC contains 1000.
- Content of PC is transferred to MAR.
- READ request is issued to memory unit.
- The instruction is fetched to MDR.
- Content of MDR is transferred to IR.
- PC is incremented to point to the next instruction.
- The instruction is decoded by the control unit.

MAR ← PC

MDR ← Mem[MAR]

IR ← MDR

 $PC \leftarrow PC + 4$

ADD R1 5000

- LOCA (i.e. 5000) is transferred (from IR) to MAR.
- $MAR \leftarrow IR[Operand]$

- READ request is issued to memory unit.
- The data is fetched to MDR.
- The content of MDR is added to R1.

```
MDR \leftarrow Mem[MAR]
```

 $R1 \leftarrow R1 + MDR$

```
The steps being carried out are called micro-operations:
```

```
MAR ← PC
```

MDR ← Mem[MAR]

IR ← MDR

 $PC \leftarrow PC + 4$

MAR ← IR[Operand]

MDR ← Mem[MAR]

R1 \leftarrow R1 + MDR

R1 125

Address	Content
1000	ADD R1, LOCA
1004	•••

5000	75
------	----

LOCA

1. PC = 1000

2. MAR = 1000

3. PC = PC + 4 = 1004

4. MDR = ADD R1, LOCA

5. IR = ADD R1, LOCA

6. MAR = LOCA = 5000

7. MDR = 75

8. R1 = R1 + MDR = 50 + 75 = 125

Execution of ADD R1,R2

 Assume that the instruction is stored in memory location 1500, the initial value of R1 is 50, and R2 is 200.

ADD R1, R2

- Before the instruction is executed, PC contains 1500.
- Content of PC is transferred to MAR.
- READ request is issued to memory unit.
- The instruction is fetched to MDR.
- Content of MDR is transferred to IR.
- PC is incremented to point to the next instruction.
- The instruction is decoded by the control unit.
- R2 is added to R1.

$$MDR \leftarrow Mem[MAR]$$

$$PC \leftarrow PC + 4$$

$$R1 \leftarrow R1 + R2$$

R2 200

Address	Instruction
1500	ADD R1, R2
1504	•••

1.
$$PC = 1500$$

2.
$$MAR = 1500$$

3.
$$PC = PC + 4 = 1504$$

4.
$$MDR = ADD R1, R2$$


5.
$$IR = ADD R1, R2$$

6.
$$R1 = R1 + R2 = 250$$


Bus Architecture

- The different functional modules must be connected in an organized manner to form an operational system.
- Bus refers to a group of lines that serves as a connecting path for several devices.
- The simplest way to connect the functional unit is to use the single bus architecture.
 - Only one data transfer allowed in one clock cycle.
 - For multi-bus architecture, parallelism in data transfer is allowed.

System-Level Single Bus Architecture




System-Level Two-Bus Architecture



Single-Bus Architecture Inside the Processor

- There is a single bus inside the processor.
 - ALU and the registers are all connected via the single bus.
 - This bus is internal to the processor and should not be confused with the external bus that connects the processor to the memory and I/O devices.
- A typical single-bus processor architecture is shown on the next slide.
 - Two temporary registers Y and Z are also included.
 - Register Y temporarily holds one of the operands of the ALU.
 - Register Z temporarily holds the result of the ALU operation.
 - The multiplexer selects a constant operand 4 during execution of the micro-operation: $PC \leftarrow PC + 4$.

Internal Processor Bus



Multi-Bus Architectures

- Modern processors have multiple buses that connect the registers and other functional units.
 - Allows multiple data transfer micro-operations to be executed in the same clock cycle.
 - Results in overall faster instruction execution.
- Also advantageous to have multiple shorter buses rather than a single long bus.
 - Smaller parasitic capacitance, and hence smaller delay.

Memory Addressing Concepts

Overview of Memory Organization

- Memory is one of the most important sub-systems of a computer that determines the overall performance.
- Conceptual view of memory:
 - Array of storage locations, with each storage location having a unique address.
 - Each storage location can hold a fixed amount of information (multiple of bits, which is the basic unit of data storage).
- A memory system with M locations and N bits per location, is referred to as an M x N memory.
 - Both M and N are typically some powers of 2.
 - Example: 1024 x 8, 65536 x 32, etc.

Some Terminologies

• Bit: A single binary digit (0 or 1).

• Nibble: Collection of 4 bits.

• Byte: Collection of 8 bits.

• Word: Does not have a unique definition.

• Varies from one computer to another; typically 32 or 64 bits.


How is Memory Organized?

- Memory is often byte organized.
 - Every byte of the memory has a unique address.
- Multiple bytes of data can be accessed by an instruction.
 - Example: Half-word (2 bytes), Word (4 bytes), Long Word (8 bytes).
- For higher data transfer rate, memory is often organized such that multiple bytes can be read or written simultaneously.
 - Necessary to bridge the processor-memory speed gap.
 - Shall be discussed later in detail.

How do we Specify Memory Sizes?

Unit Bytes		In Decimal
8 bits (B)	1 or 2 ⁰	10 ⁰
Kilobyte (KB)	1024 or 2 ¹⁰	10 ³
Megabyte (MB)	1,048,576 or 2 ²⁰	10 ⁶
Gigabyte (GB)	1,073,741,824 or 2 ³⁰	10 ⁹
Terabyte (TB)	1,099,511,627,776 or 2 ⁴⁰	10 ¹²
Petabyte (PB)	2 ⁵⁰	10 ¹⁵
Exabyte (EB)	2 ⁶⁰	10 ¹⁸
Zettabyte (ZB)	2 ⁷⁰	10 ²¹

- If there are n bits in the address, the maximum number of storage locations can be 2^n .
 - For n=8, 256 locations.
 - For n=16, 64K locations.
 - For n=20, 1M locations.
 - For n=32, 4G locations.
- Modern-day memory chips can store several Gigabits of data.
 - Dynamic RAM (DRAM).



Address	Contents
0000 0000	0000 0000 0000 0001
0000 0001	0000 0100 0101 0000
0000 0010	1010 1000 0000 0000
•	
1111 1111	1011 0000 0000 1010

An example: $2^8 \times 16$ memory

Some Examples

- A computer has 64 MB (megabytes) of byte-addressable memory. How many bits are needed in the memory address?
 - Address Space = 64 MB = $2^6 \times 2^{20} = 2^{26$
 - If the memory is byte addressable, we need 26 bits of address.
- 2. A computer has 1 GB of memory. Each word in this computer is 32 bits. How many bits are needed to address any single word in memory?
 - Address Space = 1 GB = 2³⁰ B
 - 1 word = 32 bits = 4 B
 - We have $2^{30}/4 = 2^{28}$ words
 - Thus, we require 28 bits to address each word.

Byte Ordering Conventions

- Many data items require multiple bytes for storage.
- Different computers use different data ordering conventions.
 - Low-order byte first
 - High-order byte first
- Thus a 16-bit number 11001100 00101010 can be stored as either:

Data Type	Size (in Bytes)
Character	1
Integer	4
Long integer	8
Floating-point	4
Double-precision	8

Typical data sizes

11001100	00101010	or	00101010	11001100
----------	----------	----	----------	----------

The two conventions have been named as:

a) Little Endian

- The least significant byte is stored at lower address followed by the most significant byte. Examples: Intel processors, DEC alpha, etc.
- Same concept followed for arbitrary multi-byte data.

b) Big Endian

- The most significant byte is stored at lower address followed by the least significant byte. Examples: IBM's 370 mainframes, Motorola microprocessors, TCP/IP, etc.
- Same concept followed for arbitrary multi-byte data.

An Example

• Represent the following 32-bit number in both Little-Endian and Big-Endian in memory from address 2000 onwards:

01010101 00110011 00001111 11000011

Little Endian		
Address	Data	
2000	11000011	
2001	00001111	
2002	00110011	
2003	01010101	

Big Endian		
Address	Data	
2000	01010101	
2001	00110011	
2002	00001111	
2003	11000011	

Memory Access by Instructions

- The program instructions and data are stored in memory.
 - In von-Neumann architecture, they are stored in the same memory.
 - In Harvard architecture, they are stored in different memories.
- For executing the program, two basic operations are required.
 - a) Load: The contents of a specified memory location is read into a processor register.

 LOAD R1, 2000
 - b) Store: The contents of a processor register is written into a specified memory location.

 STORE 2020, R3

An Example

• Compute S = (A + B) - (C - D)


```
LOAD R1,A
LOAD R2,B
     R3,R1,R2 // R3 = A + B
ADD
LOAD R1,C
LOAD
     R2,D
     R4,R1,R2 // R4 = C - D
SUB
     R3,R3,R4 // R3 = R3 - R4
SUB
STORE S,R3
```

Classification of Computer Architecture

- Broadly can be classified into two types:
 - a) Von-Neumann architecture
 - b) Harvard architecture
- How is a computer different from a calculator?
 - They have similar circuitry inside (e.g. for doing arithmetic).
 - In a calculator, user has to interactively give the sequence of commands.
 - In contrast, a computer works using the stored-program concept.
 - Write a program, store it in memory, and run it in one go.


Von-Neumann Architecture

- Instructions and data are stored in the same memory module.
- More flexible and easier to implement.
- Suitable for most of the general purpose processors.
- General disadvantage:
 - The processor-memory bus acts as the bottleneck.
 - All instructions and data are moved back and forth through the pipe.



Harvard Architecture

- Separate memory for program and data.
 - Instructions are stored in program memory and data are stored in data memory.
- Instruction and data accesses can be done in parallel.
- Some microcontrollers and pipelines with separate instruction and data caches follow this concept.
- The processor-memory bottleneck remains.



Instruction Set Architecture

Introduction

- Instruction Set Architecture (ISA)
 - Serves as an interface between software and hardware.
 - Typically consists of information regarding the programmer's view of the architecture (i.e. the registers, address and data buses, etc.).
 - Also consists of the instruction set.
- Many ISA's are not specific to a particular computer architecture.
 - They survive across generations.
 - Classic examples: IBM 360 series, Intel x86 series, etc.

Instruction Set Design Issues

- Number of explicit operands:
 - 0, 1, 2 or 3.
- Location of the operands:
 - Registers, accumulator, memory.
- Specification of operand locations:
 - Addressing modes: register, immediate, indirect, relative, etc.
- Sizes of operands supported:
 - Byte (8-bits), Half-word (16-bits), Word (32-bits), Double (64-bits), etc.
- Supported operations:
 - ADD, SUB, MUL, AND, OR, CMP, MOVE, JMP, etc.

Evolution of Instruction Sets

1. Accumulator based: 1960's (EDSAC, IBM 1130)

2. Stack based: 1960-70 (Burroughs 5000)

3. Memory-Memory based: 1970-80 (IBM 360)

4. Register-Memory based:1970-present (Intel x86)

5. Register-Register based: 1960-present (MIPS, CDC 6600, SPARC)

1: 1-address instructions:

ADD X \rightarrow ACC = ACC + Mem[X]

2: 0-address instructions:

ADD \rightarrow TOS = TOS + NEXT

3: 2- or 3-address instructions:

ADD A,B \rightarrow Mem[A] = Mem[A] + Mem[B]

ADD A,B,C \rightarrow Mem[A] = Mem[B] + Mem[C]

4: 2-address instructions:

LOAD R1,X \rightarrow R1 = Mem[X]

5: 3-address instructions:

ADD R1,R2,R3 \rightarrow R1 = R2 + R3

Example Code Sequence for Z = X + Y

• Stack machine:


PUSH X

PUSH Y

ADD

POP Z

 The ADD instruction pops two elements from stack, adds them, and pushes back result.




Accumulator based machine:

```
LOAD X // ACC = Mem[X]

ADD Y // ACC = ACC + Mem[Y]

STORE Z // Mem[Z] = ACC
```

• All instructions assume that one of the operands (and also the result) is in a special register called *accumulator*.




• Register-Memory machine:

```
LOAD R2,X. // R2 = Mem[X]

ADD R2,Y // R2 = R2 + Mem[Y]


STORE Z,R2 // Mem[Z] = R2
```

 One of the operands is assumed to be in register and another in memory.



• Register-Register machine:

 Also called *load-store architecture*, as only LOAD and STORE instructions can access memory.




About General Purpose Registers (GPRs)

- Older architectures had a large number of special purpose registers.
 - Program counter, stack pointer, index register, flag register, accumulator, etc.
- Newer architectures, in contrast, have a large number of GPRs.
- Why?
 - Easy for the compiler to assign some variables to registers.
 - Registers are much faster than memory.
 - More compact instruction encoding as fewer bits are required to specify registers.
 - Many processors have 32 or more GPR's.

COMPARISON BETWEEN VARIOUS ARCHITECTURE TYPES

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



• Example: Y = A / B - (A - C * B)

PUSH A

PUSH B

DIV

PUSH A

PUSH C

PUSH B


MUL

SUB

SUB

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



• Example: Y = A / B - (A - C * B)

PUSH A

PUSH B

DIV

PUSH A

PUSH C

PUSH B


MUL

SUB

SUB

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



• Example: Y = A / B - (A - C * B)

PUSH A

PUSH B

DIV

PUSH A

PUSH C

PUSH B


MUL

SUB

SUB

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



• Example: Y = A / B - (A - C * B)

PUSH A

PUSH B

DIV

PUSH A

PUSH C

PUSH B


MUL

SUB

SUB

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



• Example: Y = A / B - (A - C * B)

PUSH A

PUSH B

DIV

PUSH A

PUSH C

PUSH B


MUL

SUB

SUB

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



• Example: Y = A / B - (A - C * B)

PUSH A

PUSH B

DIV

PUSH A

PUSH C

PUSH B


MUL

SUB

SUB

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



• Example: Y = A / B - (A - C * B)

PUSH A

PUSH B

DIV

PUSH A

PUSH C

PUSH B


MUL

SUB

SUB

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



• Example: Y = A / B - (A - C * B)

PUSH A

PUSH B

DIV

PUSH A

PUSH C

PUSH B


MUL

SUB

SUB

• Typical instructions:

PUSH X, POP X ADD, SUB, MUL, DIV



```
Example: Y = A / B - (A - C * B)
PUSH A
PUSH B
DIV
PUSH A
PUSH C
PUSH B
MUL
SUB
SUB
```

POP Y

Y = RESULT

(b) Accumulator Architecture

• Typical instructions:

```
LOAD X, STORE X

ADD X, SUB X, MUL X, DIV X
```

```
Example: Y = A / B - (A - C * B)
 LOAD C
 MUL B
STORE D //D = C * B
 LOAD A
SUB D
STORE D //D = A - C * B
 LOAD A
      В
 DIV
SUB D
STORE Y
```

(c) Memory-Memory Architecture

Example: Y = A / B - (A - C * B)

```
• Typical instructions (3 operands):
```

Typical instructions (2 operands):

```
MOV X,Y
```

(d) Load-Store Architecture

• Typical instructions:

LOAD R1,X

STORE Y,R2

ADD R1,R2,R3

SUB R1,R2,R3

Example: Y = A / B - (A - C * B)

LOAD R1,A

LOAD R2,B

LOAD R3,C

DIV R4,R1,R2

MUL R5,R3,R2

SUB R5,R1,R5

SUB R4,R4,R5

STORE Y,R4

Registers: Pros and Cons

- The load-store architecture forms the basis of RISC ISA.
 - We shall explore one such RISC ISA, viz. MIPS32.
- Helps in reducing memory traffic once the memory data are loaded into the registers.
- Compiler can generate very efficient code.
- Additional overhead for save/restore during procedure or interrupt calls and returns.
 - Many registers to save and restore.

INSTRUCTION FORMAT AND ADDRESSING MODES


Instruction Format

opcode operand (s)

- An instruction consists of two parts:-
 - Operation Code or Opcode
 - Specifies the operation to be performed by the instruction.
 - Various categories of instructions: data transfer, arithmetic and logical, control, I/O and special machine control.
 - Operand(s)
 - Specifies the source(s) and destination of the operation.
 - Source operand can be specified by an immediate data, by naming a register, or specifying the address of memory.
 - Destination can be specified by a register or memory address.

- Number of operands varies from instruction to instruction.
- Also for specifying an operand, various addressing modes are possible:
 - Immediate addressing
 - Direct addressing
 - Indirect addressing
 - Relative addressing
 - Indexed addressing, and many more.

Instruction Format Examples



Addressing Modes

- They specify the mechanism by which the operand data can be located.
- Some ISA's are quite complex and supports many addressing modes.
- ISA's based on load-store architecture are usually simple and support very limited number of addressing modes.
- Various addressing modes exist:
 - Immediate, Direct, Indirect, Register, Register Indirect, Indexed, Stack, Relative, Autoincrement, Autodecrement, Based, etc.
 - Not all processors support all addressing modes.
 - We shall briefly look at the common addressing modes and how they work.

(a) Immediate Addressing

- The operand is part of the instruction itself.
 - No memory reference is required to access the operand.
 - Fast but limited range (because a limited number of bits are provided to specify the immediate data).
- Examples:

```
• ADD #25 // ACC = ACC + 25
```

• ADDI R1,R2,42 // R1 = R2 + 42


opcode immediate data

(b) Direct Addressing

• The instruction contains a field that holds the memory address of the operand.


opcode operand address

- Examples:
 - ADD R1,20A6H // R1 = R1 + Mem[20A6]
- Single memory access is required to access the operand.
 - No additional calculations required to determine the operand address.
 - Limited address space (as number of bits is limited, say, 16 bits).



(c) Indirect Addressing


- The instruction contains a field that holds the memory address, which in turn holds the memory address of the operand.
- Two memory accesses are required to get the operand value.
- Slower but can access large address space.
 - Not limited by the number of bits in operand address like direct addressing.
- Examples:
 - ADD R1,(20A6H) // R1 = R1 + (Mem[20A6])



(d) Register Addressing


- The operand is held in a register, and the instruction specifies the register number.
 - Very few number of bits needed, as the number of registers is limited.
 - Faster execution, since no memory access is required for getting the operand.
- Modern load-store architectures support large number of registers.
- Examples:

```
    ADD R1,R2,R3 // R1 = R2 + R3
    MOV R2,R5 // R2 = R5
```




(e) Register Indirect Addressing

- The instruction specifies a register, and the register holds the memory address where the operand is stored.
 - Can access large address space.
 - One fewer memory access as compared to indirect addressing.
- Example:
 - ADD R1,(R5) // PC = R1 + Mem[R5]




(f) Relative Addressing (PC Relative)

- The instruction specifies an offset of displacement, which is added to the program counter (PC) to get the effective address of the operand.
 - Since the number of bits to specify the offset is limited, the range of relative addressing is also limited.
 - If a 12-bit offset is specified, it can have values ranging from -2048 to +2047.



(g) Indexed Addressing

- Either a special-purpose register, or a general-purpose register, is used as *index register* in this addressing mode.
- The instruction specifies an offset of displacement, which is added to the index register to get the effective address of the operand.
- Example:
 - LOAD R1,1050(R3) // R1 = Mem[1050+R3]
- Can be used to sequentially access the elements of an array.
 - Offset gives the starting address of the array, and the index register value specifies the array element to be used.



(h) Stack Addressing

- Operand is implicitly on top of the stack.
- Used in zero-address machines earlier.
- Examples:
 - ADD
 - PUSH X
 - POP X
- Many processors have a special register called the stack pointer (SP) that keeps track of the stack-top in memory.
 - PUSH, POP, CALL, RET instructions automatically modify SP.

Some Other Addressing Modes

Base addressing

- The processor has a special register called the *base register* or *segment register*.
- All operand addresses generated are added to the base register to get the final memory address.
- Allows easy movement of code and data in memory.

Autoincrement and Autodecrement

- First introduced in the PDP-11 computer system.
- The register holding the operand address is automatically incremented or decremented after accessing the operand (like a++ and a-- in C).

RISC and CISC Architecture

Broad Classification

- Computer architectures have evolved over the years.
 - Features that were developed for mainframes and supercomputers in the 1960s and 1970s have started to appear on a regular basis on later generation microprocessors.
- Two broad classifications of ISA:
 - Complex Instruction Set Computer (CISC)
 - Reduced Instruction Set Computer (RISC)

CISC versus RISC Architectures

Complex Instruction Set Computer (CISC)

- More traditional approach.
- Main features:
 - Complex instruction set
 - Large number of addressing modes (R-R, R-M, M-M, indexed, indirect, etc.)
 - Special-purpose registers and Flags (sign, zero, carry, overflow, etc.)
 - Variable-length instructions / Complex instruction encoding
 - Ease of mapping high-level language statements to machine instructions
 - Instruction decoding / control unit design more complex
 - Pipeline implementation quite complex

CISC Examples:

• IBM 360/370 (1960-70)


• VAX-11/780 (1970-80)

• Intel x86 / Pentium (1985-present)

Only CISC instruction set that survived over generations.

- Desktop PC's / Laptops use these.
- The volume of chips manufactured is so high that there is enough motivation to pay the extra design cost.
- Sufficient hardware resources available today to translate from CISC to RISC internally.

Register Set in Pentium



Addressing Modes in VAX

Addressing Mode	Example	Micro-operation
Register direct	ADD R1,R2	R1 = R1 + R2
Immediate	ADD R1,#15	R1 = R1 + 15
Displacement	ADD R1,220(R5)	R1 = R1 + Mem[220+R5]
Register indirect	ADD R1,(R3)	R1 = R1 + Mem[R3]
Indexed	ADD R1,(R2+R3)	R1 = R1 + Mem[R2+R3]
Direct	ADD R1, (1000)	R1 = R1 + Mem[1000]
Memory indirect	ADD R1,@(R4)	R1 = R1 + Mem[Mem[R4]]
Autoincrement	ADD R1,(R2)+	R1 = R1 + Mem[R2]; R2++
Autodecrement	ADD R1,(R2)-	R1 = R1 + Mem[R2]; R2
Scaled	ADD R1,50(R2)[R3]	R1 = R1 + Mem[50+R2+R3*d]

Reduced Instruction Set Computer (RISC)

- Very widely used among many manufacturers today.
- Also referred to as Load-Store Architecture.
 - Only LOAD and STORE instructions access memory.
 - All other instructions operate on processor registers.

• Main features:

- Simple architecture for the sake of efficient pipelining.
- Simple instruction set with very few addressing modes.
- Large number of general-purpose registers; very few special-purpose.
- Instruction length and encoding uniform for easy instruction decoding.
- Compiler assisted scheduling of pipeline for improved performance.

- RISC Examples:
 - CDC 6600 (1964)
 - MIPS family (1980-90)
 - SPARC
 - ARM microcontroller family

- Almost all the computers today use a RISC based pipeline for efficient implementation.
 - RISC based computers use compilers to translate into RISC instructions.
 - CISC based computers (e.g. x86) use hardware to translate into RISC instructions.

Results of a Comparative Study

- A quantitative comparison of VAX 8700 (a CISC machine) and MIPS M2000 (a RISC machine) with comparable organizations was carried out in 1991.
- Some findings:
 - MIPS required execution of about twice the number of instructions as compared to VAX.
 - Cycles Per Instructions (CPI) for VAX was about six times larger than that of MIPS.
 - Hence, MIPS had three times the performance of VAX.
 - Also, much less hardware is required to build MIPS as compared to VAX.

Conclusion:


- Persisting with CISC architecture is too costly, both in terms of hardware cost and also performance.
- VAX was replaced by ALPHA (a RISC processor) by Digital Equipment Corporation (DEC).
- CISC architecture based on x86 is different.
 - Because of huge number of installed base, backward compatibility of machine code is very important from commercial point of view.
 - They have adopted a balanced view: (a) user's view is a CISC instruction set, (b) hardware translates every CISC instruction into an equivalent set of RISC instructions internally, (c) an instruction pipeline executes the RISC instructions efficiently.

MIPS Instruction Encoding

- All MIPS32 instructions can be classified into three groups in terms of instruction encoding.
 - R-type (Register), I-type (Immediate), and J-type (Jump).
 - In an instruction encoding, the 32 bits of the instruction are divided into several fields of fixed widths.
 - All instructions may not use all the fields.
- Since the relative positions of some of the fields are same across instructions, instruction decoding becomes very simple.

(a) R-type Instruction Encoding

- Here an instruction can use up to three register operands.
 - Two source and one destination.
- In addition, for shift instructions, the number of bits to shift can also be specified.




• Examples of R-type instructions:

```
add $s1, $s2, $s3
sub $t1, $s3, $s4
sla $s1, $s2, 5 // shift left $s2 by 5 places, and store in $s1
```

- An example instruction encoding: add \$t1, \$s1, \$s2
 - Recall: \$t1 is R9, \$s1 is R17, and \$s2 is R18.
 - For "add", opcode = 000000, and funct = 100000.

(b) I-type Instruction Encoding

- Contains a 16-bit immediate data field.
- Supports one source and one destination register.



• Examples of I-type instructions:


```
lw $s1,50($s5)
sw $t1,100($s1)
addi $t0,$s1,188
beq $s1,$s2,Label // Label is encoded as a 16-bit offset relative to PC
bne $s3,$zero,Label
```

- An example instruction encoding: /w \$t1, 48(\$s1)
 - Recall: \$t1 is R9, \$s1 is R17.
 - For "lw", opcode = 100011.


31	26	25	21	20	16	15		0
100	011	100	01	010	001		000000000110000	

(c) J-type Instruction Encoding

- Contains a 26-bit jump address field.
 - Extended to 28 bits by padding two 0's on the right.
- Example: *j Label*



A Quick View



- Some instructions require two register operands rs & rt as input, while some require only rs.
- Gets known only after instruction is decoded.
- While decoding is going on, we can prefetch the registers in parallel.
 - May or may not be required later.
- Similarly, the 16-bit and 26-bit immediate data are retrieved and signextended to 32-bits in case they are required later.

Addressing Modes in MIPS32

• Register addressing add \$\$1, \$\$2, \$\$3

• Immediate addressing addi \$\$1, \$\$2, 200

• Content of a register is added to a "base" value to get the operand address.

• PC relative addressing beg \$\$1, \$\$2, Label

16-bit offset is added to PC to get the target address.

Pseudo-direct addressing j Label

26-bit offset if shifted left by 2 bits and then added to PC to get the target address.