

OpenVAF — Verilog-A LRM Compliance

Clause-by-clause coverage of the Verilog-A language (VAMS LRM 2023, Annex C)

Ngspice + OpenVAF Enhancements project

July 2026

Contents

OpenVAF — Verilog-A LRM Compliance	3
1. Compilation model and scope (LRM 1, Annex C)	3
2. Lexical conventions (LRM 2) — ✓	3
3. Data types (LRM 3)	4
4. Expressions (LRM 4)	6
5. Analog behavior (LRM 5)	7
6. Hierarchy (LRM 6) — ✓	9
7. System tasks and functions (LRM 9)	9
8. Compiler directives (LRM 10) — ✓	10
9. Compliance summary	11

OpenVAF — Verilog-A LRM Compliance

How the `openvaf-r` compiler in this repository covers the Verilog-A language, clause by clause against the Verilog-AMS Language Reference Manual (the 2023 edition, [docs/VAMS-LRM-2023.pdf](#); Verilog-A is its Annex C analog-only subset). Every claim in this document is backed by a committed, executable check: the code examples are drawn from the verify suites under [examples/](#), which compile each construct with the committed compiler, simulate it with the committed ngspice, and compare the numbers against closed-form expectations on every regression run.

Status marks used throughout:

Mark	Meaning
✓	fully implemented and runtime-verified
⚠	implemented with LRM-sanctioned fallback semantics, or a documented deviation
×	out of scope: a Verilog-AMS (mixed-signal) feature outside Annex C

A one-page summary table closes the document. Companion references: the [User Handbook](#) (task-oriented), the [openvaf change report](#) (where each capability was implemented and why), and the per-enhancement write-ups in [enhancements_doc/](#).

1. Compilation model and scope (LRM 1, Annex C)

OpenVAF compiles one Verilog-A source file (with its ``include` closure) into an OSDI shared object: analytic residuals and Jacobians are generated by automatic differentiation, so every construct below is “supported” only if it produces correct derivatives as well as correct values — a stricter bar than parsing. Hierarchy is resolved by a compile-time elaboration pass (§7), after which the pipeline sees a single flat module.

Annex C draws the language boundary this project targets: the analog subset. Digital and mixed-signal constructs (reg/wire logic, digital `always/initial`, connect modules, ``default_discipline`, discrete-domain disciplines) are × out of scope by definition, and the compiler rejects them with located diagnostics rather than accepting them silently — e.g. `domain discrete` on a discipline with natures is a proper two-label error citing LRM 3.6.2.2.

2. Lexical conventions (LRM 2) — ✓

Identifiers, including escaped identifiers (LRM 2.7.1):

```
electrical \node-1a ;           // any printable characters until whitespace
parameter real \my.gain = 2.0;
```

Numbers (LRM 2.5): decimal integers, reals with exponents, SI scale suffixes (1k, 2.5u, 10n), and based integer literals in all four bases with optional size and sign, underscores as separators:

```
integer a, b, c, d;
analog begin
  a = 8'hFF;           // sized hex           -> 255
  b = 'sb1010_1100;    // signed binary with separators
  c = 'o17;            // octal               -> 15
  d = 4'd12;           // sized decimal
end
```

The don't-care digits x/z/? are additionally accepted in the power-of-two bases when the literal is a casex/casez item (§5.4); anywhere else they are a located error rather than silent zeros.

Strings (LRM 2.6.3) with the full escape set — `\n`, `\t`, `\\`, `\"`, and octal `\ddd` — processed by a single-pass unescaper (a sequential-replacement implementation corrupted overlapping escapes and was rewritten). Comments both styles, including the edge case of a `//` comment at end-of-file without a trailing newline (formerly a lexer hang). Attributes (`* ... *`) parse everywhere the LRM allows and carry simulator-facing metadata (§9.6).

3. Data types (LRM 3)

3.1 Value types — ✓

integer (32-bit), real (IEEE double), and string variables, with genuine persistence across evaluations for both numeric types (a Verilog-A module variable keeps its value between solver calls, the foundation of event counters and iterative models):

```
integer count;           // persists across evaluations
analog begin
    @(cross(V(in) - 0.5, +1))
        count = count + 1; // genuinely accumulates
end
```

Uninitialized strings default to `""`; declaration initializers work on scalars and (multi-dimensional) arrays, evaluating once at setup when parameter-only:

```
real x = 2.0 * gain;
real taps[0:3] = '{0.1, 0.2, 0.3, 0.4};
```

3.2 Parameters (LRM 3.4) — ✓

Ranges and exclusions enforced on user-given values; `localparam` genuinely non-overridable; `alias-param` including `$param_given` through the alias; string parameters (usable in case dispatch); array parameters of any dimensionality, expanded to per-element OSDI parameters that are individually overridable from SPICE:

```
parameter real r = 1k from (0:inf) exclude 1e6;
parameter integer sel = 0 from [0:15];
localparam real g = 1.0 / r;           // tracks r, not overridable
parameter real w[0:1][0:2] = '{1,2,3}, {4,5,6}';
// SPICE: .model m dev(w[1][2]=9.5)
```

One deliberate reading of the LRM, matching industry practice (the CMC convention): a parameter's default is exempt from its own range — compact models use out-of-range defaults as "feature disabled" markers — while every user-given value is fully validated. [△](#) documented in the [handbook's limitations chapter](#).

Block-scoped parameters (LRM 6.3): a parameter/localparam declared inside a named `begin: label` block is a compile-time constant local to that block, read hierarchically and derivable from the module's parameters (E-87):

```
analog begin
    begin: s
        parameter real g2 = gain * gain; // block param, from a module param
        real contrib = g2 + 1.0;
    end
```

```

    vout = s.contrib;                                // hierarchical read
end

```

Overriding a module parameter propagates into the block-scoped parameters that depend on it. The LRM's `#(.blk.p(4))` instance override of a block-scoped parameter is illegal (LRM 6.3.2) and rejected with a targeted diagnostic.

paramset blocks (a Verilog-AMS 3.4.6 feature adopted because real model libraries use them) work, including hidden-system-parameter assignments:

```

paramset fast_nmos nmos_va;
    .w = 2e-6; .l = 60e-9;
    .$mfactor = 4;
endparamset

```

3.3 Natures, disciplines, nets (LRM 3.5–3.7)

✓ Discipline/nature declarations with attribute access from expressions (`net.potential.abstol`); derived natures — nature `Xf` : Flow and deriving from a discipline's nature (`: electrical.flow`) — with full attribute inheritance; ground declarations in both orderings; vectored nets and ports with bit-selects; net initializers that become solver nodesets; domain continuous:

```

nature CurrentX : Current;    // derived nature, inherits abstol/units
    abstol = 1e-15;
endnature

electrical [3:0] bus;          // vectored net (range-then-name)
electrical data[0:7];          // vectored net (name-then-range, E-89)
electrical vout = 2.5;         // initializer -> OSDI nodeset (initial guess)
ground electrical gnd;

```

Both declaration orders are accepted for vectored nets and ports: the range-then-name form `electrical [3:0] bus;` / `input [3:0] bus;` and the name-then-range form `electrical bus[3:0];` / `input bus[3:0];` (E-89). A bit of a multi-bit input bus port reads its own terminal regardless of the port's position in the header — a bus port that is not the last port keeps its bits contiguous and in header order, so the simulator's positional terminal mapping stays correct (E-90). The name-then-range form also accepts a multi-name list with per-name widths (`input a[0:1], b[0:3], c;`, E-91). A net/port/array width may reference a parameter (`electrical [0:N-1] out;`, `real w[0:N-1];`, E-91): it is folded from the parameter's elaboration-time default and fixed at that value — a structural parameter, since the OSDI descriptor has one node count per module (a model card override does not resize it). A multi-dimensional vectored port (`in[0:2][0:1]`) is not supported in either declaration order.

Signal-flow disciplines (potential-only or flow-only) are fully usable, including probe-only branches — probing a branch that is never contributed to reads its true flow (an ideal ammeter) instead of the 0-and-open-circuit a naive topology gives.

Named port branches (LRM 3.7.2) work as of E-84 and carry the same defining equation as a direct port-flow probe; contributing to one is a proper diagnostic (port branches are probe-only per the LRM):

```

branch (<p>) probe_p;          // named branch over port p
iprobe = I(probe_p);          // same value as I(<p>)

```

Hierarchical branch probes (E-86) read another instance's branches from outside it — named, unnamed, and port-branch forms, the last via a 0V ammeter synthesized at flattening so it reads that instance's own current rather than the node total:

```

V(top.a1.b)                    // named branch of instance a1
V(top.d1.branch(va, vb))       // unnamed branch of instance d1

```

```
I(top.d1.branch(<p>)) // d1's own current into its port p
```

4. Expressions (LRM 4)

4.1 Operators and precedence (LRM 4.1, Table 4-2) — ✓

The full operator surface — arithmetic (incl. `**`), comparison, logical, bitwise, shifts (`<</>>` and arithmetic `<<</>>>`), ternary (including over strings), concatenation `{a,b}` and replication `{n{x}}` — was audited operator-by-operator and level-by-level against Table 4-2 with self-checking bitmask modules whose failure modes are numerically visible. Two real defects found and fixed in the audits: unary `~` emitted arithmetic negate, and the constant folder disagreed with the runtime on `>>`; one precedence defect: `%` bound tighter than `*/` (so `6*7%4` evaluated to 18 instead of 2). Associativity verified including `2**3**2 = 64` (left-associative per Verilog) and unary binding above `**` (`-2**2 = 4`).

4.2 Built-in and environment functions (LRM 4.3, 9.7) — ✓

`ln/log/exp/sqrt/pow/min/max/abs/floor/ceil`, trigonometric and hyperbolic families (integer `min/max/abs` correctly integer-typed; integer division/rounding away from zero per the LRM), and the environment: `$temperature` (kelvin — verified as the exact kT/q law across a $-50...150$ °C sweep), `$vt` and `$vt(T)`, `$abstime`, `$realtime` (identical in the continuous-time analog context), `$simparam` and `$simparam$str`, `$param_given`, `$port_connected`, `$mfactor` and the position hidden parameters.

4.3 Analog operators (LRM 4.5) — ✓ (one documented deviation)

Every analog operator produces exact Jacobian contributions via autodiff. The full argument surface (trailing tolerances, optional arguments) was audited at runtime — compiling proves nothing about whether a trailing argument is honored.

```
// time derivative & integrals
I(p,n) <+ ddt(c * V(p,n));
phi = idtmod(K * V(vco), 0.0, 1.0); // phase wrapping (VCO idiom)
x    = idt(V(in), 0.5, rst);         // reset form holds at ic

// delays and filters
V(out) <+ absdelay(V(in), 1n);
V(out) <+ transition(sel ? 1.0 : 0.0, 0, 10n, 5n);
V(out) <+ slew(V(in), 1e6, -1e6); // LRM negative max_neg_rate
V(out) <+ laplace_np(V(in), '{1.0}', '{-6.283e3, 0.0}'); // complex pairs
V(out) <+ zi_nd(V(in), '{0.5, 0.5}', '{1.0}', 1u);

// small-signal & events
gm = ddx(Id, V(g,s)); // symbolic derivative
tc = last_crossing(V(in) - 0.5, +1);
V(out) <+ ac_stim("ac", 1.0, 90.0); // module AS the AC stimulus
```

- `ddt`, `idt` (with initial conditions that survive into transient, and the assert/reset forms stable enough for relaxation oscillators), `idtmod` (integrates unbounded internally, wraps the returned value), `ddx` with respect to potentials *and* flows: ✓
- `absdelay` (+`maxdelay`), `transition` (3/4/5-argument, ``default_transition` defaults, DC well-posed), `slew` (honoring the LRM's *negative* `max_neg_slew_rate` — the sign defect that made it ignore its input was found in the audit): ✓
- `laplace_nd/np/zd/zp` via exact state-space realization and `zi_nd/np/zd/zp` via bilinear transform, both with complex pole/zero pairs per the LRM's (re, im) vector convention and parameter-dependent coefficients: ✓

- `last_crossing` with simulator-side waveform history: ✓
- noise sources (LRM 4.6): `white_noise`, `flicker_noise`, `noise_table`, `noise_table_log` (in-line or file data); operating-point-dependent factors and `ddt()`-shaped noise are exact with no extra matrix unknowns; same-named sources sum coherently per LRM 4.6.4 including anti-phase cancellation: ✓

```
I(a,b) <+ white_noise(4.0 * `P_K * $temperature / r, "thermal");
I(d,s) <+ gm * white_noise(gamma_4kT, "induced"); // op-dependent factor
```

- `analysis("ac","tran",...)` variadic, with the AC/noise operating point counting as its parent analysis per LRM 4.6.1: ✓
- `$limit` (built-in `pnjlim` and user functions — genuinely engages SPICE-style iteration limiting), `$bound_step`, `$discontinuity(n)` (clamps the next step *and* makes the integrator bisect onto the event): ✓
- `$table_model` (LRM 9.19 by clause, listed here as a modeling operator): 1-D piecewise-linear, N-dimensional multilinear, and natural cubic-spline interpolation — lowered to differentiable MIR so *all* partial derivatives feed the Jacobian (a table-based MOSFET gets exact `gm` and `gds`):

```
I(d, s) <+ $table_model(V(g, s), V(d, s), "mos_iv.tbl", "1L");
```

- `△ limexp` is implemented stateless (exact exp below the overflow threshold, tangent-continued above): a stateful previous-iterate limiting version was built and *reverted* because correct converged values under limiting require the simulator's limiting-RHS correction, which applies to circuit unknowns, not to `limexp`'s derived argument. `$limit` provides genuine iteration limiting. Documented decision with the failing evidence preserved.

Restrictions enforced as the LRM demands (4.5.1): analog operators inside loops or solution-dependent conditionals are rejected with diagnostics that name the actual construct and cite the clause.

5. Analog behavior (LRM 5)

5.1 Analog blocks (LRM 5.2, 6.2) — ✓

Multiple `analog` and `analog initial` blocks per module execute as-if-concatenated in source order — verified including across instance flattening and with declarations interleaved between blocks.

5.2 Contribution statements (LRM 5.6) — ✓

Direct contributions with accumulation semantics, switch branches (V-then-I), indirect branch assignment (the LRM's ideal-op-amp construct), and port-flow probes:

```
V(out): V(inp, inn) == 0; // indirect: drive out so V(inp,inn)=0
I(p,n) <+ V(p,n)/r; // accumulates with other <+ statements
iport = I(<p>); // total flow through port p (ideal probe)
branch (<p>) pb; // named port branch: I(pb) == I(<p>) (E-84)
```

`$port_connected` works on connected *and* unconnected ports of flattened instances (resolved per instance at elaboration time), and instantiating an undefined module is a hard error rather than a silent drop (both E-84). Bus actuals may be part-selects — positional, named, or width-1 onto a scalar port (E-85):

```
adc2 hi (out[3:2], in); // positional slice
adc2 lo (.out(out[1:0]), .in(r)); // named slice
```

5.3 Procedural statements (LRM 5.7–5.9) — ✓

if/else; case over integers, reals, strings, and arrays (element-wise); all four loops with runtime trip counts that honor model-card parameter overrides; `disable` as the LRM's early-exit (Verilog-A has no break/continue, and the compiler says so with the `disable` idiom in the diagnostic):

```
for (i = 0; i < n; i = i + 1) acc = acc + w[i] * x[i];
repeat (4) y = f(y);
do begin y = y/2; end while (y > 1);    // post-test: body runs once

begin : scan
    integer k;
    for (k = 0; k < 8; k = k + 1)
        if (v[k] > vth) disable scan;    // the break idiom
end
```

5.4 `casex` / `casez` — ✓

The don't-care case variants, with the 2-state semantics the analog subset implies: x/z/? digits of a based literal written directly as an item form a comparison mask — the arm matches on every *care* bit. `casex` treats x/z/? as don't-cares, `casez` only z/?. The classic priority-encoder idiom (from the committed [examples/casexz_examples/](#)):

```
casex (req)
    4'b1xxx: grant = 8;    // highest set bit wins
    4'b01xx: grant = 4;
    4'b001x: grant = 2;
    4'b0001: grant = 1;
    default: grant = 0;
endcase
```

Don't-care literals anywhere else, x digits under `casez`, and non-integer discriminants are located errors — no silent zeros.

5.5 Events (LRM 5.10) — ✓

@(initial_step) and @(final_step) genuinely gate (once at the start; once at the *successful* end, seeing the converged solution), with analysis-phase lists filtering by analysis type; cross/above/ timer with tolerances and persistent state; event OR lists:

```
@(initial_step("ac", "tran")) voff = 0.1;
@(cross(V(s) - vth, +1) or timer(0, 1u))
    n_events = n_events + 1;
@(final_step) $strobe("peak = %g at end of run", peak);
```

An operating point fires both step events (a single point is first and last); a failed analysis never fires `final_step`.

5.6 Analog functions (LRM 5.11) — ✓

Declared functions with input/output/inout arguments, arrays in all three roles plus array return values, locals (including array locals), loops inside bodies; inlined at the call site so derivatives flow through automatically:

```
analog function real dot;
    input real a[0:3], b[0:3];
    integer k;
```



```

begin
    dot = 0;
    for (k = 0; k <= 3; k = k + 1)
        dot = dot + a[k]*b[k];
    end
endfunction

```

Recursion is illegal in Verilog-A; both direct and mutual recursion are clean errors naming the call cycle (mutual recursion formerly overflowed the compiler stack).

6. Hierarchy (LRM 6) — ✓

Module instantiation with named and positional ports and parameter overrides, open ports, instance arrays, arbitrary nesting, across `include boundaries; **generate** in all three forms with genvars usable in any expression; **defparam** with its LRM precedence over instance overrides; hierarchical names and \$root; implicit nets; net concatenation in port connections:

```

// genvars usable in any expression, e.g. a parameter override
module gpexpr(a, c);
    inout a, c; electrical a, c;
    genvar i;
    generate
        for (i = 0; i < 3; i = i + 1) begin : g
            res #(.r(1e3*(i+1))) ri (a, c); // 1k || 2k || 3k
        end
    endgenerate
endmodule

```

```

defparam u1.r = 2e3; // hierarchical override
defparam u1.u2.r = 4e3; // two levels down; wins over #(...)

```

One boundary the OSDI target makes explicit (and the compiler explains in its diagnostic): structure binds at compile time — a generate condition or bound may depend on genvars and literals but not on module *parameters*, because parameters arrive from model cards at simulation time, after structure is frozen. Loop trip counts and if arms, being behavior, may depend on parameters freely. ⚠ documented deviation with rationale.

7. System tasks and functions (LRM 9)

7.1 Display (LRM 9.4) — ✓

All five kinds (\$strobe, \$display, \$write, \$monitor, \$debug) with the complete format surface — [flags] [width] [.precision] on every conversion, dynamic * widths, %e/f/g/r (engineering notation), %d/h/o/b/c/s, %m, %% — verified against exact printf output:

```

$strobe("Vth=%7.4f V region=%2d id=%r name=%s", vth, reg, id, name);

```

7.2 File and string I/O (LRM 9.5, 9.8) — ✓

\$fopen/\$fclose/\$fdisplay/\$fwrite/\$fstrobe/\$fmonitor/\$fdebug/\$fflush/ \$ftell/\$fseek/\$rewind/\$feof and \$write/\$sformat/\$sscanf/ \$fgets/\$fscanf:

```

integer fd;
analog @(final_step) begin
    fd = $fopen("iv.dat");
    $fdisplay(fd, "%g %g", vpeak, ipeak);
end

```

```

    $fclose(fd);
end

```

7.3 Random and distributions (LRM 9.13) — ✓ (deterministic semantics)

\$random, \$arandom, and every \$dist_*/\$rdist_* (uniform, normal, exponential, poisson, chi-square, t, erlang), verified against closed-form moments. $\triangle$ One deliberate semantic: draws are a deterministic function of (*seed*, *call site*) with no in-place seed advance — an advancing seed would return different values on every Newton iteration and destroy convergence. This gives reproducible Monte Carlo and independent per-instance variation, at the cost of in-evaluation sequences (which have no convergent meaning in an analog solver anyway).

```

parameter integer seed = 1;
real gain;
analog begin
    gain = 1.0 + sigma * $rdist_normal(seed, 0.0, 1.0); // per-instance mismatch
    ...
end

```

7.4 Simulation control (LRM 9.6–9.7) — ✓

\$finish, \$stop, \$fatal are honored with simulator-correct timing (at the accepted-point boundary; \$finish fires @(*final_step*) and ends the analysis cleanly; \$fatal during setup reads as a configuration rejection), and \$warning/\$error/\$info display.

7.5 The mechanism-unavailable group — $\triangle$

\$test\$plusargs/\$value\$plusargs (ngspice has no plusargs), \$simprobe, \$analog_node_alias/\$analog_port_a compile and return their LRM-specified fallback values (false / supplied default / 0). This is the LRM's own escape hatch for hosts without the mechanism; models using them run predictably instead of being rejected.

7.6 Attributes as simulator metadata — ✓

(* desc="..." *) on a variable exposes it as an operating-point variable (print @n1[gm], .save, .meas); (* type="instance" *) on a parameter puts it on the instance line and under alter/.dc sweeps; desc/units on parameters populate the OSDI descriptor.

8. Compiler directives (LRM 10) — ✓

The predefined source-location macros work (E-85): `__FILE__` expands to the source file's basename, `__LINE__` to the exact line (a use inside a ``define` body reports the definition site — documented textual-expansion semantics):

```

$strobe("evaluated at %s:%0d", `__FILE__, `__LINE__);

`define with arguments (macros-in-macros, macro calls as arguments), `ifdef/`ifndef/`elsif/`else/
`endif chained and nested, `include chains, `undef, `resetall, `default_transition, and the
housekeeping set (`celldefine, `timescale, `line, `pragma, `default_nettype, ...). Recursive
macro expansion — direct or mutual — is a clean located error (formerly a compiler stack overflow),
while the legal same-macro nesting inside arguments (`QUAD(x) = `TWICE(`TWICE(x))) expands
finitely:

`define TWICE(x) ((x)*2.0)
`define QUAD(x) (`TWICE(`TWICE(x))) // same-macro nesting in ARGUMENTS: legal
`ifdef HIGH_PRECISION

```

```

`define TOL 1e-12
`else
`define TOL 1e-9
`endif

```

(*default_discipline* is AMS-only and out of scope — implicit nets themselves are Verilog-A and work, taking their discipline from the connected port.)

9. Compliance summary

LRM area	Status	Verified by
2 Lexical (identifiers, numbers, strings, attributes)	✓	escid, stresc, comment suites
3.2–3.3 Value types, variables, persistence	✓	vartype, variable_persistence, intstate, varinit
3.4 Parameters (ranges, localparam, aliasparam, arrays, paramset, block-scoped)	✓ (default-exemption △ documented)	paramrange, localparam, array, paramset, paramsethsp, blockparam
3.5–3.7 Natures, disciplines, nets, buses, nodesets	✓	derivednature, domainbind, bus, netinit, ground, signalflow
4.1–4.3 Operators, precedence, functions	✓ (audited)	operator, precedence, shift, concat
4.5 Analog operators (all)	✓ (limexp stateless △ documented)	absdelay, laplace, zi, slew, transition, idt*, ddx, opargs, discontinuity, last_crossing
4.6 Noise (incl. correlation 4.6.4)	✓	noise, noisecorr, noisejw
5.2/6.2 Analog blocks (multiple)	✓	multianalog
5.6 Contributions, indirect assignment, port flow (incl. named port branches)	✓	indirect_assignment, portflow, signalflow, lrm
5.7–5.9 Procedural statements, loops, disable	✓	analogloop, dowhile, repeat, disable, arraycase
casex/casez	✓	casexz
5.10 Events (steps, cross/above/timer, OR lists, phase lists)	✓	initial_step, finalstep, cross, timer, lrmcorner
5.11 Analog functions (arrays in/out/return)	✓	funcarray, arrayout, arrayret
6 Hierarchy (instantiation, generate incl. legacy analog-block form, defparam, \$root, part-select connections, hierarchical branch probes)	✓ (param-shaped structure △ explained)	instantiation, generate, legacygen, defparam, hiername, implicitnet, partselect, hierbranch
9.4–9.8 Display, file/string I/O	✓	display, fileio, stringio
9.13 Random/distributions	✓ (deterministic seed △ documented)	rng, montecarlo
9 misc (\$finish family, \$simparam, attributes) plusargs / simprobe / node aliases	✓ △ LRM fallbacks	simctrl, simparamstr, opvar alias

LRM area	Status	Verified by
10 Compiler directives (incl. `__FILE__/ `__LINE__)	✓	preproc, directive, defaulttransition, filemacro
Mixed-signal / digital (outside Annex C)	× by scope	—

As of E-84 the standard's own examples are a compliance suite: every code example in the LRM 2023 PDF is extracted and compiled (examples/lrm_examples/ — 40 compile, 19 documented limitations pinned to their diagnostics, 21 correctly rejected as mixed-signal), and the 146 non-module fragments double as a no-crash fuzz corpus.

Beyond construct-level checks, three cross-cutting guards pin that the *whole language implementation* produces correct physics: the 92-model industry corpus compiles and runs, the static/dynamic/thermal physics suites recover textbook device laws through the full pipeline (60 mV/dec, $C \equiv dQ/dV$ across analyses, $E_g \approx 1.25$ eV from a compiled MEXTRAM), and the twin benchmarks show OSDI output matching hand-coded simulator devices to machine precision.