

Ngspice + OpenVAF Enhancements

User Handbook and Enhancement Reference

Dr. Meisam Bahadori

July 2026

Contents

Part I — The User Handbook	4
The Enhanced ngspice + OpenVAF Handbook	4
1 · Getting started	6
2 · Verilog-A language support	9
3 · Simulating with ngspice	17
4 · Limitations and gotchas	20
5 · Enhancement index	22
Part II — The Enhancements, One by One	25
Enhancement-1 — <code>absdelay</code> support for OSDI/Verilog-A in OpenVAF + ngspice	26
Enhancement-2 — Indirect Branch Assignment support in OpenVAF	31
Enhancement-3 — Vectored/Bus-Style Net Declarations in OpenVAF	37
Enhancement-4 — Laplace-Domain Transfer-Function Operators in OpenVAF	44
Enhancement-5 — Verilog-A Module Instantiation in OpenVAF	58
Enhancement-6 — Missing Basic Verilog-A Features in OpenVAF-r	67
Enhancement-7 — <code>@(initial_step)</code> event gating and variable persistence	75
Enhancement-8 — <code>generate for/genvar</code> and <code>cross()/above()/timer()</code>	79
Enhancement-9 — Verilog-A noise sources: completing <code>noise_table / noise_table_log</code>	85
Enhancement-10 — Verilog-A statistical / random-number system functions	94
Enhancement-11 — Verilog-A file I/O and string-formatting system functions	98
Enhancement-12 — the last Verilog-A system functions: <code>probe / alias / plusargs</code>	102
Enhancement-13 — <code>limexp()</code> : investigation, kept stateless	104
Enhancement-14 — Verilog-A array literals / aggregates	106
Enhancement-15 — Verilog-A multi-dimensional arrays	109
Enhancement-16 — Verilog-A <code>\$table_model</code>	111
Enhancement-17 — multi-dimensional <code>\$table_model</code>	113
Enhancement-18 — array declaration syntax + arrays in analog functions	115
Enhancement-19 — <code>do ... while</code> loop	117
Enhancement-20 — array output/inout arguments to analog functions	118
Enhancement-21 — Verilog-AMS <code>paramset</code> blocks	119
Enhancement-22 — natural cubic-spline <code>\$table_model</code>	121
Enhancement-23 — array return values from analog functions	123
Enhancement-24 — <code>\$discontinuity(n)</code> simulator support	125
Enhancement-25 — <code>\$simparam\$str(name)</code> support	127
Enhancement-26 — <code>ac_stim(...)</code> baseline (crash fix + correct large-signal semantics)	129
Enhancement-27 — <code>idtmod(...)</code> modulo-integrator fix	130
Enhancement-28 — <code>idt(...)</code> initial-condition fix	131
Enhancement-29 — port-branch flow access <code>I(<port>)</code>	133
Enhancement-30 — variadic <code>analysis(arg1, arg2, ...)</code>	135
Enhancement-31 — complex poles/zeros in laplace/zi root forms	137
Enhancement-32 — integer persistent/event-state variables	139
Enhancement-33 — array case + array-literal function arguments	141
Enhancement-34 — <code>{...}</code> concatenation & <code>{n{...}}</code> replication	143
Enhancement-35 — lexer hang on <code>// comment</code> at end-of-file	145
Enhancement-36 — probe-only branches / ideal ammeter + flow-only signal flow	147
Enhancement-37 — operator-correctness audit + fixes	149
Enhancement-38 — operator-precedence audit + fixes	151
Enhancement-39 — derived natures & deriving natures from disciplines	153
Enhancement-40 — N-dimensional <code>\$table_model</code>	155
Enhancement-41 — implicit nets in instance connections	156
Enhancement-42 — correlated (same-named) noise sources	158

Enhancement-43 — variable initializers, completed	160
Enhancement-44 — paramset hierarchical system parameters	162
Enhancement-45 — net initialization + net attribute access	164
Enhancement-46 — escaped identifiers + integer literal bases	166
Enhancement-47 — 'default_transition + transition() fixes	168
Enhancement-48 — string literal escape sequences	170
Enhancement-49 — \$root + hierarchical names, transition() input	172
Enhancement-50 — domain binding validation	174
Enhancement-51 — full ac_stim AC injection	175
Enhancement-52 — idt() assert/reset forms	177
Enhancement-53 — @(final_step) + analysis-phase lists on step events	178
Enhancement-54 — correct + node-free noise factors	180
Enhancement-55 — simulation-control tasks + \$discontinuity rejection	182
Enhancement-56 — VA_TEST end-to-end sweep: CMC default-range idiom + noise crash . .	184
Enhancement-57 — physics-accuracy validation suite	186
Enhancement-58 — defparam hierarchical parameter override	187
Enhancement-59 — LRM-corner probe follow-up: event OR lists, \$realtime, port concatenation, recursion diagnostics	189
Enhancement-60 — multiple analog blocks: validation deliverable	191
Enhancement-61 — operator-argument audit: slow sign-convention fix	193
Enhancement-62 — ngspice analysis coverage for OSDI devices: .dc @inst[param] sweeps + .disto warning	195
Enhancement-63 — RF analyses with OSDI devices: .sp / transient noise / PSS + span.c NaN fix	197
Enhancement-64 — Touchstone export: auto-Rbase, N-port wrsnp, 1-port .sp	199
Enhancement-65 — preprocessor audit: macro-recursion guard	201
Enhancement-66 — Monte Carlo with OSDI devices: validation deliverable	203
Enhancement-67 — generate audit: genvar-substitution fix, nested loops, generate if/case .	204
Enhancement-68 — enabling openvaf's own integration test suite	206
Enhancement-69 — operating-point variables end-to-end: validation deliverable	208
Enhancement-70 — behavioral-loop audit: precise loop diagnostics	209
Enhancement-71 — display-task audit: format flags/width for every conversion + the %b segfault	211
Enhancement-72 — Touchstone round 2: MA/DB formats, frequency units, Y/Z export, and the rdsnp reader	212
Enhancement-73 — the user handbook: 72 enhancements consolidated into docs/handbook/	213

Part I — The User Handbook

The Enhanced ngspice + OpenVAF Handbook

This handbook is the consolidated user guide to the enhanced toolchain in this repository: openvaf-r (the Verilog-A compiler) and ngspice-46 (the simulator), as extended by Enhancements 1–72. The repository's top-level [README](#) carries the one-line enhancement index; the detailed write-ups live in [enhancements_doc/](#), one per enhancement, in the order the work happened. This handbook reorganizes that material by what you want to do — so you don't need to know the project history to find out whether a language feature works, how to run an analysis, or where the sharp edges are.

Prefer a single file? The whole handbook *plus the complete text of all 73 enhancement write-ups* is compiled into one PDF: [docs/Ngspice-OpenVAF-Handbook.pdf](#) (202 pages, linked table of contents). Regenerate it after edits with `python3 docs/handbook/build_pdf.py` (needs pandoc + xelatex).

The chapters

Chapter	Read it when you want to...
1 · Getting started	install or build the tools, compile your first Verilog-A model, load it in ngspice, and run the shipped example suites
2 · Verilog-A language support	know whether a language construct works — the full feature matrix, organized by LRM area, with a pointer to the example folder that proves each entry
3 · Simulating with ngspice	run analyses over your compiled models — operating point through S-parameters, parameter sweeps, Monte Carlo, noise, measurements, Touchstone import/export
4 · Limitations and gotchas	know what <i>doesn't</i> work, what is out of scope by design, and the traps that cost real debugging time
5 · Enhancement index	trace a feature back to the enhancement that built it — one line per enhancement with links to the detailed write-up and the example folder

How the material is verified

Every feature claimed in this handbook is guarded by a verify script in [examples/](#): a self-contained Python script that compiles the relevant Verilog-A model with the committed compiler, runs it through the committed ngspice, and checks the numbers against closed-form expectations. The feature-matrix entries in chapter 2 and the workflow recipes in chapter 3 each link to the folder that pins them. If you want to see a feature in action, running its verify script is the fastest way:

```
python3 examples/dowhile_examples/verify_dowhile.py
```

Two larger guards sit on top of the per-feature suites:

- **VA_TEST/** — the public VA-Models collection (BSIM4/6/BULK/CMG/IMG/SOI, PSP, HiCUM, MEXTRAM, EKV, ASM-HEMT, and more; 92 standalone models), all of which compile with `python3 VA_TEST/compile_all.py`;
- **examples/physcheck_examples/** — a physics regression suite that checks industry models against analytic device laws (60 mV/decade junction slope, $4kT/R$ thermal noise identity, AC-vs-numeric-derivative Jacobian cross-checks) through the whole toolchain.

Reference documents

The [docs/](#) folder holds the primary sources this project is written against: the Verilog-AMS Language Reference Manual (VAMS-LRM-2023.pdf — Verilog-A is its Annex C subset), the ngspice-46 manual, and the OSDI interface specification. When the handbook cites "LRM 4.5.1" or similar, that's the document it means.

1 · Getting started

This chapter takes you from a fresh clone to a running Verilog-A simulation: get the two binaries, compile a model, load it in ngspice, and know where the example suites are when you want a working reference for any feature.

1.1 The two tools

- **openvaf-r** compiles a Verilog-A source file (.va) into an OSDI shared object (.osdi) — a compiled device model with analytic Jacobians generated by automatic differentiation.
- **ngspice** loads .osdi files at runtime and simulates them alongside its built-in devices, with full access to every analysis (op, DC, AC, transient, noise, S-parameters, ...).

Both binaries in this repository are patched: the compiler implements far more of the Verilog-A language than upstream, and ngspice carries the matching OSDI runtime (ABI 0.7) plus simulator-side features such as .dc @inst[param] sweeps and Touchstone I/O. Use them as a pair — a .osdi produced by this compiler requires this ngspice (stock ngspice rejects the newer ABI), and vice versa.

1.2 Option A: prebuilt binaries

CI builds both tools for five platforms and commits them under bin/:

Platform	Directory
Linux x86-64	bin/linux/intel/
Linux ARM64	bin/linux/arm/
macOS Apple Silicon	bin/macos/apple-silicon/
macOS Intel	bin/macos/intel/
Windows x86-64	bin/windows/intel/

Each platform has small runtime prerequisites (X11/readline on Linux, XQuartz + Homebrew readline on macOS, nothing on Windows — the DLLs are bundled). The [Prebuilt Binaries section of the top-level README](#) has the exact per-OS install commands and the notes for macOS Gatekeeper / Windows SmartScreen warnings.

1.3 Option B: building from source

openvaf-r needs a Rust toolchain and LLVM 18 (exactly 18 — the codegen crates are pinned to it):

```
# macOS (Homebrew)
brew install llvm@18
export LLVM_SYS_181_PREFIX=/opt/homebrew/opt/llvm@18

# Debian/Ubuntu
sudo apt-get install llvm-18-dev libpolly-18-dev libzstd-dev
export LLVM_SYS_181_PREFIX=/usr/lib/llvm-18
```

```
cd OpenVAF-master-20260610
cargo build --release --bin openvaf-r --features openvaf-driver/llvm18
# → target/release/openvaf-r
```

ngspice is a standard autotools build. The configuration used throughout this project (macOS spelling shown; adjust the readline/X11 paths for your system):

```
cd ngspice-46
mkdir -p build && cd build
```

```

../configure --with-x --with-readline=/opt/homebrew/opt/readline --disable-openmp
make -j8
# → build/src/ngspice

```

The CI workflow ([.github/workflows/build-binaries.yml](https://github.com/workflows/build-binaries.yml)) is the authoritative record of working build recipes for all five platforms, including the Windows MSYS2/MinGW path.

1.4 Your first model

Save this as `myres.va` — a behavioral resistor with an overridable parameter:

```

`include "disciplines.vams"

module myres(p, n);
    inout p, n;
    electrical p, n;
    parameter real r = 1k from (0:inf);

    analog
        I(p, n) <+ V(p, n) / r;
endmodule

```

Compile it:

```
openvaf-r myres.va -o myres.osdi
```

(Without `-o`, the output lands next to the input as `myres.osdi`. Useful extras: `-I <dir>` for include search paths, `-D MACRO [=VALUE]` for preprocessor defines, `--lints` to list tunable lints.)

Now a SPICE deck, `divider.cir`. Three conventions matter:

1. `pre_osdi <file>.osdi` in the `.control` block loads the compiled model before the circuit is parsed (that's what the `pre_` prefix means).
2. OSDI instances use the **N** device letter.
3. The `.model` card's type name is the Verilog-A module name (`myres`), and the card is where parameters are set.

* resistive divider from a Verilog-A resistor

```

vin in 0 dc 2
n1 in mid ra
n2 mid 0 rb
.model ra myres(r=1k)
.model rb myres(r=1k)

.control
pre_osdi myres.osdi
op
print v(mid)
.endc
.end

ngspice -b divider.cir
# v(mid) = 1.000000e+00

```

Title line: SPICE treats the *first line* of a deck as the title, not as a statement. Every deck must start with a comment/title line — a netlist statement on line 1 is silently swallowed.

From here everything is ordinary ngspice: dc, ac, tran, noise, .meas, plotting. Chapter 3 covers the analysis workflows in depth, including the parts specific to OSDI devices (parameter access via `@n1[...]`, sweeps over device parameters, Monte Carlo).

1.5 The example suites

Every feature in this project ships with a folder under `examples/` containing the Verilog-A models, ready-to-run decks, and a `verify_*.py` script that checks exact numbers. They double as a cookbook: when chapter 2 says arrays work, `examples/array_examples/` shows the syntax in a complete, committed, tested model.

```
python3 examples/noise_examples/verify_noise.py
```

The scripts resolve the toolchain through `examples/_setup.py`: a locally built binary (`OpenVAF-master-20260610/target/release/openvaf-r`, `ngspice-46/build/src/ngspice`) is preferred if present, otherwise the committed `bin/<os>/<arch>/` prebuilt for your machine is used — so the suites run on a fresh clone with no configuration.

Two folders are worth singling out:

- `examples/analyses_examples/` is a tutorial: nine standalone, commented decks (one per analysis, each stating its expected numbers), a walk-through README, and committed PNG plots of the sweep results.
- `examples/physcheck_examples/` validates industry compact models against analytic device physics — a good template for validating your own models quantitatively.

1.6 The bigger test assets

- **VA_TEST/** — 124 `.va` files of public industry compact models; `python3 VA_TEST/compile_all.py` compiles all 92 standalone models and regenerates `VA_TEST/compile_report.md`.
- The compiler's own integration suite — descriptor snapshots and live numeric tests over real compact models:

```
cd OpenVAF-master-20260610
RUN_DEV_TESTS=1 cargo test --release -p openvaf --features openvaf/llvm18
↪ --test integration
```


2 · Verilog-A language support

This is the feature matrix: what the compiler accepts, what the compiled model actually *does* at simulation time, and where each claim is proven. The scope of the project is Verilog-A — the analog subset defined in Annex C of the Verilog-AMS LRM — not full mixed-signal AMS (see [chapter 4](#) for exactly where that line runs).

Every table row links the enhancement that built or audited the feature (E-*n* → the detailed write-up in `enhancements_doc/`) and, in the notes, the `examples/` folder whose verify script pins it. A recurring lesson of this project is that *compiling proves nothing* — several features compiled for years while silently doing the wrong thing at runtime — so a row only says “works” if a committed script checks the simulated numbers.

2.1 Modules, hierarchy, and elaboration

Hierarchy is resolved by a compile-time elaboration pass: instantiated modules are recursively inlined (alpha-renamed per instance, ports bound to the caller’s nets, parameters bound to overrides) into a single flat module before the rest of the compiler runs. Everything in this section is therefore resolved at compile time.

Feature	Notes	Since
Module instantiation	Named <code>.p(net)</code> and positional port connections, open ports, named <code>#(.r(1e3))</code> and positional <code>#(1e3)</code> parameter overrides, instance arrays <code>resrarr[0:3]</code> (https://github.com/javaNoviceProgrammer/Ngspice_OpenVAF_Enhancements/blob/master/examples/instantiation_examples/) arbitrary nesting, across <code>`include</code> boundaries; cyclic instantiation is a clean error. <code>examples/instantiation_examples/</code>	E-5
generate for / genvar	Structural loops generating nets, instances, variables, parameters; nested loops (inner bounds may use outer genvars); genvars usable in any expression, e.g. <code>#(.r(1e3*(i+1)))</code> . <code>examples/generate_examples/</code>	E-8, E-67
generate if / generate case	else/else-if chains, multi-value case arms, default; conditions fold over genvars and literals. A condition on a module <i>parameter</i> is an intentional error — parameters bind at simulation time and cannot shape structure (see §4.3).	E-67
Hierarchical names	Instance-path references <code>u1.u2.node</code> , <code>\$root.top.net</code> , from expressions and probes. <code>examples/hiername_examples/</code>	E-49
defparam	Compile-time hierarchical parameter override at any depth (<code>defparam u1.u2.r = 2e3;</code>), multi-assignment form, expression values; takes LRM-mandated precedence over instance <code>#()</code> overrides. <code>examples/defparam_examples/</code>	E-58
paramset	Verilog-AMS paramset blocks, including <code>.\$mfactor/position</code> hidden-system-parameter assignments inside the paramset. <code>examples/paramset_examples/</code> , <code>examples/paramsethsp_examples/</code>	E-21, E-44
Implicit nets	An undeclared identifier in an instance connection becomes an implicit scalar net, discipline derived from the connected port. <code>examples/implicitnet_examples/</code>	E-41
Net concatenation in ports	<code>u1({a, c})</code> onto a vectored port, expanded bit-by-bit (leftmost = msb), positionally or named, nested through instance levels; width mismatch is a hard error.	E-59
Multiple analog blocks	Several <code>analog / analog initial</code> blocks per module execute as-if-concatenated in source order (LRM 6.2), including across instance flattening. <code>examples/multianalog_examples/</code>	E-60

2.2 Nets, disciplines, natures

Feature	Notes	Since
Vectored (bus) nets and ports	<code>electrical [3:0] bus;</code> with bit-select access in branches and probes; buses slice element-wise onto instance arrays and bus ports. examples/bus_examples/	E-3
ground declarations	Both orderings (<code>electrical ground gnd;</code> and <code>ground electrical gnd;</code>). examples/ground_examples/	E-9
Derived natures	<code>nature X : Parent,</code> deriving from a discipline's nature (<code>: electrical.flow</code>), with full attribute inheritance. examples/derivednature_examples/	E-39
Net initializers (nodesets)	<code>electrical a = 5.0;</code> becomes an OSDI nodeset — an initial-guess hint for the solver, essential for bistable circuits. examples/netinit_examples/	E-45
Nature-attribute access	<code>net.potential.abstol</code> , <code>branch.potential.abstol</code> readable in expressions.	E-45, E-59
Domain binding	<code>domain continuous</code> accepted; <code>domain discrete</code> on a discipline with natures is a proper two-label error (LRM 3.6.2.2). examples/domainbind_examples/	E-50
Signal-flow / flow-only disciplines	Disciplines with only a flow (or only a potential) nature work, including probe-only usage (§2.7). examples/signalflow_examples/	E-36

2.3 Data types, variables, and arrays

Feature	Notes	Since
<code>real</code> , <code>integer</code> , <code>string</code> variables	Full support, including uninitialized strings defaulting to <code>""</code> . examples/vartype_examples/	E-9
Variable persistence	Module-level variables genuinely keep their value across evaluations (<code>accum = accum + 1.0;</code> accumulates) — for <code>real</code> <i>and</i> <code>integer</code> state. examples/variable_persistence_examples/ , examples/intstate_examples/	E-7, E-32
Declaration initializers	<code>real x = 2.0*p;</code> , including on (multi-dimensional) arrays; parameter-only initializers evaluate once at setup. examples/varinit_examples/	E-43
Arrays, 1-D to N-D	Both declaration orders (<code>real [0:3] x;</code> and LRM-style <code>real x[0:3];</code>), any number of dimensions, constant <i>and dynamic</i> indexing (<code>m[i][j]</code> with runtime <code>i, j</code>). examples/array_examples/ , examples/mdarray_examples/	E-14, E-15, E-18
Array aggregates	Whole-array assignment <code>c = '{v0, v1, v2};;</code> , nested for N-D, array-to-array copy <code>c = d;</code> .	E-14, E-15
Concatenation / replication	<code>{a, b, c}</code> and <code>{n{x}}</code> as real operators over arrays and strings (<code>'{...}'</code> stays the typed aggregate). examples/concat_examples/	E-34
Arrays in case	Element-wise array case statements and array-literal case labels. examples/arraycase_examples/	E-33

2.4 Parameters

Feature	Notes	Since
Ranges and excludes	from (0:inf), exclude 0, etc., enforced on user-given values. Per the CMC convention, a parameter's default is exempt from its own range — industry models use an out-of-range default as the "feature disabled" state.	E-56
localparam	Non-overridable per the LRM; derived localparams (localparam G = 1/R) track their inputs. examples/localparam_examples/	E-9
aliasparam	Works, including \$param_given queried through the alias.	E-59
Array-valued parameters	parameter real [0:3] w = '{...}'; (any dimensionality) expands to one scalar OSDI parameter per element, each individually overridable from SPICE: .model m dev(w[1][1]=0.9).	E-14, E-15
String parameters	Including case dispatch on a string parameter.	E-59
Hidden system parameters	\$mfactor (device multiplicity — automatically scales flows, noise, and Jacobians) and the position parameters, readable in the model and settable per instance (n1 a b mod m=4).	E-44
Instance-line parameters	(* type="instance" *) on a parameter exposes it on the instance line and to alter @n1[p] / .dc @n1[p] (see §3.3).	E-62
\$param_given	Both work; industry models use them for configuration guards.	—
\$port_connected		

2.5 Operators and literals

The operator surface was audited systematically — every operator against the LRM, every precedence level against LRM Table 4-2 — with self-checking modules whose failure modes are numerically visible.

Feature	Notes	Since
Arithmetic, comparison, logical, bitwise operators	Audited; fixes included ~ (was arithmetic negate) and const-folded unsigned >>. examples/operator_examples/	E-37
Precedence and associativity	Audited against LRM Table 4-2; % now binds like *//, 2**3**2 = 64 (left-assoc), unary binds above **. examples/precedence_examples/	E-38
Arithmetic shifts <<< / >>>	examples/shift_examples/	E-6
Ternary ?:	Including over string operands.	E-37
Based integer literals	'h1F, 'b101, 'o17, 'd42, with underscores and explicit widths. examples/escid_examples/	E-46
Escaped identifiers	\my-net! per the LRM, everywhere identifiers appear.	E-46
String literal escapes	The full set (\n, \t, \\", octal \ddd) via a single-pass unescaper. examples/stresc_examples/	E-48
Integer min/max/abs, away-from-zero rounding	Verified integer-typed, per the LRM.	E-59
Math functions & scale factors	ln/log/exp/sqrt/pow/trig/hyperbolic/floor/ceil, SI suffixes (1k, 1u, ...).	—

2.6 Analog operators (filters, integrators, delays)

All analog operators produce correct Jacobian contributions via automatic differentiation, so convergence behaves like a hand-written stamp.

Operator	Notes	Since
<code>ddt(x)</code>	Time derivative; fully working (the reactive residual/Jacobian path).	—
<code>idt(x[, ic])</code>	Time integral; the initial condition survives into transient (it used to be zeroed at the IC phase). examples/idtic_examples/	E-28
<code>idt(x, ic, assert[, tol])</code>	Reset form: while <code>assert</code> is nonzero the state holds at <code>ic</code> ; smooth reset dynamics keep self-referential resets bounded. Relaxation oscillators work. examples/idtassert_examples/	E-52
<code>idtmod(x, ic, modulus[, offset])</code>	Modulo integrator (VCO phase idiom): integrates unbounded internally, wraps the returned value. examples/idtmod_examples/	E-27
<code>ddx(x, probe)</code>	Symbolic derivative w.r.t. a potential <i>or flow</i> probe. examples/ddx_examples/	E-13, E-59
<code>absdelay(x, td[, maxdelay])</code>	Transport delay via the synthetic-node DAE approach. examples/absdelay_examples/	E-1
<code>transition(x[, td, rise, fall])</code>	3/4/5-argument forms; <code>`default_transition</code> supplies defaults; DC is well-posed (no singular matrix at the operating point). examples/transition_examples/ , examples/defaulttransition_examples/	E-6, E-47
<code>slew(x[, max_pos, max_neg])</code>	Rate limiter; honors the LRM's <i>negative</i> <code>max_neg_slew_rate</code> convention (and tolerates the legacy positive-magnitude spelling). examples/slew_examples/ , examples/opargs_examples/	E-6, E-61
<code>laplace_nd/np/zd/zp</code>	Continuous-time filters via exact state-space realization; complex pole/zero pairs per the LRM's (re, im) vector convention; parameter-dependent coefficients. examples/laplace_examples/ , examples/complexpole_examples/	E-4, E-31
<code>zi_nd/np/zd/zp</code>	Z-domain filters via bilinear transform onto the laplace machinery. examples/zi_examples/	E-6, E-31
<code>last_crossing(dir)</code>	Interpolated crossing times, backed by simulator-side waveform history (an additive OSDI extension). examples/last_crossing_examples/	E-6
<code>limexp(x)</code>	Stateless limited exponential (tangent-continued above the overflow cutoff) — a documented decision; see §4.4.	E-13
<code>\$limit(x, "pnjlim", ...)</code> <code>/ \$limit(x, fn, ...)</code>	Genuinely engages SPICE-style iteration limiting (stiff diodes converge without <code>gmin</code> stepping), for the built-in and user-function forms. examples/opargs_examples/	E-61
<code>\$bound_step(t)</code>	Genuinely bounds the transient step.	E-61
<code>\$discontinuity(t)</code>	Clamps the <i>next</i> step and makes the integrator bisect onto the event instead of extrapolating across it. examples/discontinuity_examples/	E-24, E-55
Trailing tolerance arguments	The optional <code>abstol</code> args of <code>ddt/idt/idtmod/laplace_*/zi_*</code> and event tolerances are accepted and honored.	E-61

Analog operators are statically forbidden inside conditionals whose condition depends on the solution, and inside loops (LRM 4.5.1) — the diagnostics name the actual construct and suggest hoisting or generate unrolling (E-70).

2.7 Contributions, branches, and probes

Feature	Notes	Since
<code>V(a,b) <+ /</code> <code>I(a,b) <+</code> contributions	Including switch branches (V-then-I) and accumulation across statements, loops, and multiple analog blocks.	—
Indirect branch assignment	<code>V(out): V(x) == 0;</code> — the LRM's ideal-opamp construct, one implicit equation per statement. examples/indirect_assignment_examples/	E-2
Port-flow probes <code>I(<p>)</code>	Reading the total flow through a port (previously returned 0). examples/portflow_examples/	E-29
Probe-only branches	Probing a branch that is never contributed to reads its actual flow (an ideal ammeter) instead of 0 + open circuit; makes flow-only signal-flow disciplines work. examples/portflow_examples/ , examples/signalflow_examples/	E-36
Grounded branch declarations	branch (a) br;	E-59

2.8 Events

Feature	Notes	Since
<code>@(initial_step)</code> <code>/@(final_step)</code>	Genuinely gated (once at the start; once at the end of a <i>successful</i> analysis, seeing the converged solution — the classic “report a tracked peak” pattern works). An op fires both. examples/initial_step_examples/ , examples/finalstep_examples/	E-7, E-53
Analysis-phase lists	<code>@(initial_step("ac","tran"))</code> filters by analysis type, per LRM 5.10.2.	E-53
<code>cross(expr[, dir, time_tol, expr_tol])</code>	Edge detection with persistent state across evaluations; tolerances honored. examples/cross_examples/	E-8, E-61
<code>above(expr[, ...])</code>	Like cross but also fires in DC.	E-8, E-59
<code>timer(start[, period, tol])</code>	Periodic firing verified at exact counts. examples/timer_examples/	E-8, E-61
Event OR lists	<code>@(cross(...))</code> or <code>timer(...)</code> or <code>initial_step</code> — fires exactly when any member fires (LRM 5.10.3). examples/lrmcorner_examples/	E-59

2.9 Analog functions

Feature	Notes	Since
analog function basics	Inlined at the call site; derivatives flow through automatically.	—

Feature	Notes	Since
Array arguments	Whole-array input args (E-18), output/inout writeback (E-20), array return values (real [0:2] f; — E-23), array-literal arguments (E-33), array locals. examples/funcarray_examples/, examples/arrayout_examples/, examples/arrayret_examples/	E-18/20/23/33
Loops inside functions	Iterative algorithms (Newton, factorial) verified exact.	E-70
Integer/untyped arguments	Untyped args default to real; integer output args work.	E-43, E-59
Recursion	Not legal in Verilog-A; both direct and mutual recursion are clean, cycle-naming errors (mutual recursion used to crash the compiler).	E-59

2.10 Procedural statements and loops

Feature	Notes	Since
if/else, case	Including case on strings and arrays. (The casex/casez don't-care variants are not implemented.)	E-33, E-59
for, while, repeat(n), do...while	All four, audited: nesting, loops over arrays, solution-dependent conditions, contributions accumulating inside loops. Parameter-dependent trip counts honor model-card overrides at simulation time. examples/analogloop_examples/, examples/dowhile_examples/, examples/repeat_examples/	E-9, E-19, E-70
disable <block>;	Verilog-A's early exit — the idiom from which break/continue are built (the language has neither keyword). examples/disable_examples/	E-9

2.11 System tasks and functions

Display and I/O

Feature	Notes	Since
\$strobe, \$display, \$write, \$monitor, \$debug	All five kinds; full format-specifier surface — [flags] [width] [.precision] on every conversion (%5d, %-8s, %08.3f, dynamic %*d), %e/f/g/r (engineering notation), %d/h/o/b/c, %s, %m (module path), %%. examples/display_examples/	E-71
File I/O	\$fopen/\$fclose/\$fdisplay/\$fwrite/\$fstrobe/\$fmonitor/\$fdebug/\$fflush/\$ftell/\$fseek/ examples/fileio_examples/	E-11
String formatting/parsing	\$swrite, \$sformat, \$sscanf, \$fgets, \$fscanf. examples/stringio_examples/	E-11

Modeling functions

Feature	Notes	Since
<code>\$table_model</code>	1-D piecewise-linear with constant/linear extrapolation controls; multilinear interpolation in any number of dimensions (self-describing grid file); natural cubic-spline control ("3") for C ¹ -smooth 1-D tables. Lowered to differentiable MIR, so <i>all</i> partial derivatives feed the Jacobian (a table-based MOSFET gets exact gm and gds). examples/table_model_examples/ , examples/mdtable_examples/ , examples/ndtable_examples/ , examples/cubic_table_examples/	E-16 , E-17 , E-22 , E-40
Noise sources	<code>white_noise</code> , <code>flicker_noise</code> , <code>noise_table</code> , <code>noise_table_log</code> (inline data or file). Same-named sources sum coherently (LRM 4.6.4, correlation networks and anti-phase cancellation exact); operating-point-dependent factors and <code>ddt()</code> -shaped noise (induced-gate idiom) are exact and add no matrix unknowns. examples/noise_examples/ , examples/noisecorr_examples/ , examples/noisejw_examples/	E-9 , E-42 , E-54
<code>analysis</code> ("variedic" ...)	Variedic; matches ngspice's analysis phases, including the AC/noise operating point counting as "ac"/"noise" per LRM 4.6.1. examples/analysis_examples/	E-30 , E-53
<code>ac_stim</code> (<code>[name mag, phase]</code>)	Full AC right-hand-side injection — a Verilog-A module can <i>be</i> the AC stimulus, with exact magnitude and phase. examples/acstim_examples/	E-26 , E-51
Random / distributions	<code>\$random</code> , <code>\$arandom</code> , <code>\$dist_*</code> and <code>\$rdist_*</code> (uniform, normal, exponential, poisson, chi-square, t, erlang) — deterministic per (<code>seed</code> , <code>call site</code>), stable across Newton iterations (reproducible Monte Carlo, no convergence breakage). examples/rng_examples/	E-10

Environment and control

Feature	Notes	Since
<code>\$temperature</code> , <code>\$vt[(T)]</code>	Simulator temperature (tracks <code>.dc temp</code> sweeps per point) and thermal voltage.	E-62
<code>\$abstime</code> , <code>\$realtime</code>	Identical in the continuous-time analog context.	E-59
<code>\$simparam</code> ("name" default), <code>\$sim-param\$str</code> ("name")	Numeric and string simulator parameters; ngspice exposes <code>analysis_name</code> and <code>simulator</code> among others. examples/simparamstr_examples/	E-25
<code>\$finish</code> , <code>\$stop</code> , <code>\$fatal</code>	Honored at the accepted-point boundary: <code>\$finish</code> ends the analysis cleanly (<code>firing@(final_step)</code>), <code>\$stop</code> pauses resumably, <code>\$fatal</code> aborts with its message — including under solution-dependent conditions, and during setup ("device rejected its configuration"). examples/simctrl_examples/	E-55 , E-56
Fallback group	<code>\$simprobe</code> , <code>\$analog_node_alias</code> , <code>\$analog_port_alias</code> , <code>\$test\$plusargs</code> , <code>\$value\$plusargs</code> compile and return their LRM "mechanism unavailable" fallbacks (see §4.2). examples/alias_examples/	E-12

2.12 Preprocessor and compiler directives

Feature	Notes	Since
<code>`define</code> with arguments	Macros-using-macros, macro calls as macro arguments, backslash continuations, multi-line calls; recursive expansion is a clean, located error (both direct and mutual), while legitimate same-macro nesting inside arguments still works. examples/preproc_examples/	E-65
<code>`ifdef`/`ifndef`/`else`/`endif`</code>	Chained and nested, including inside module bodies; unbalanced conditionals are located errors.	E-65
<code>`include`</code>	Nested chains; <code>-I</code> search paths.	—
<code>`default_transition`</code>	Supplies default rise/fall for bare <code>transition()</code> calls. examples/defaulttransition_examples/	E-47
Housekeeping directives	<code>`celldefine`/`endcelldefine`</code> , <code>`unconnected_drive`/`nounconnected_drive`</code> , <code>`timescale`</code> , <code>`line`</code> , <code>`pragma`</code> , <code>`undefineall`</code> , <code>`resetall`</code> , <code>`default_nettype`</code> — accepted (previously fatal errors). examples/directive_examples/	E-6

2.13 Attributes

Attributes (`* ... *`) are how a model talks to the simulator's UI:

Attribute	Effect
<code>(* desc="..." *)</code> on a variable	Exposes it as an operating-point variable: <code>print @n1[var], .save @n1[var], .meas</code> over it — for real <i>and</i> integer variables (E-69, examples/opvar_examples/)
<code>(* type="instance" *)</code> on a parameter	Exposes it on the instance line and to <code>alter/.dc @n1[param]</code> (E-62)
<code>(* desc="...", units="..." *)</code> on a parameter	Description/units metadata in the OSDI descriptor

A symmetry worth remembering: instance access to *parameters* needs `type="instance"`; instance access to *variables* needs `desc`.

3 · Simulating with ngspice

This chapter covers the simulator side: how compiled Verilog-A devices participate in ngspice's analyses, how to reach their parameters and internal variables, and the statistical / RF workflows built on top.

The single best companion to this chapter is [examples/analyses_examples/](#) — a tutorial folder with one standalone, commented deck per analysis, each stating the numbers it expects, plus committed PNG plots. When a recipe below feels terse, the corresponding deck there is the full worked example.

3.1 Devices, model cards, instance lines

An OSDI device instance is an N-letter element referencing a .model card whose type name is the Verilog-A module name:

```
n1 in out mymod          ; instance (ports in declaration order)
.model mymod myres(r=1k) ; model card: module `myres`, parameter r
```

- Model-card parameters are the default place to set parameters.
- Instance-line parameters (n1 in out mymod r=2k) work for parameters the model marks (* type="instance" *) — plus the built-in m=<mult> device multiplicity, which correctly scales currents, charges, and noise (\$mfactor in the model's own source).
- Multiple instances of one model card get independent state and independent per-instance values of position/multiplicity parameters.

3.2 Reading data out of a model

Verilog-A variables carrying a (* desc="..." *) attribute are operating-point variables, visible wherever ngspice vectors are:

```
print @n1[ids]                ; after op
.save @n1[ids] @n1[region]    ; per-point recording in tran/dc/ac
.meas tran ipk MAX @n1[ids]    ; measurements over opvar vectors
.meas tran tcross WHEN @n1[ids]=0.5m RISE=1
show n1                        ; all opvars incl. string variables
```

Real *and integer* variables record per point; a variable without desc is deliberately not exposed (clean "no such parameter" error). String opvars display via show but cannot become vectors (vectors are numeric). Pinned in [examples/opvar_examples/](#).

3.3 Parameter access, **alter**, and sweeps

Parameters are readable and writable from the control language:

```
print @n1[r]                  ; read (instance param, (* type="instance" *))
alter @n1[r] = 2k              ; change + re-run setup on the next analysis
altermod @mm[r] = 2k           ; same for a model-card parameter
```

.dc sweeps over device parameters work for OSDI (and built-in) devices — the sweep refreshes the device per point exactly as alter would, restores the original value afterwards, and nests with other sweep variables:

```
.dc @n1[r] 500 1500 100        ; sweep an OSDI instance parameter
.dc @n1[r] 500 1500 500 vin 0 2 1 ; nested with a source sweep
.dc temp -40 125 5              ; temperature sweep; $temperature
                                ; tracks each point (°C in the deck,
                                ; K inside the model)
```

3.4 Analysis coverage

All core analyses treat OSDI devices as full citizens. The audited status of everything beyond op/dc/ac/tran:

Analysis	Status with OSDI devices
op, .dc, .ac, .tran	Fully supported; analytic Jacobians from autodiff (cross-checked against numeric derivatives on PSP103 to $\sim 10^{-5}$ in <code>examples/physcheck_examples/</code>)
.noise	Fully supported — all four noise-source types, correlated sources, op-dependent and frequency-shaped factors (§2.11)
.tf	Exact (transfer function, input/output impedance)
.pz	Exact for linear devices, bit-identical to built-in twins; nonlinear .pz failures are a stock ngspice quirk affecting built-ins identically
.sens (DC and AC)	Exact against analytic derivatives
.disto	Not supported for OSDI devices — the distortion kernel needs Taylor coefficients beyond first derivatives, which the OSDI ABI cannot provide. ngspice prints a prominent warning naming each affected device (it used to report silent zeros)
.sp (S-parameters)	Fully supported, any port count (1-port reflection through N-port); donoise (NF, noise parameters) is inherently 2-port
Transient noise (TRN0ISE sources)	Propagates through OSDI devices correctly; device- <i>internal</i> noise does not enter .tran (same as built-ins)
.pss (experimental, needs --enable-pss at configure time)	OSDI devices converge like built-ins; strongly nonlinear circuits defeat the shooting method for both alike

Details and the exact pinned numbers: [examples/analyses_examples/](#) and [examples/rfanalyses_examples/](#).

3.5 S-parameters and Touchstone files

Ports for .sp are voltage sources tagged with a port number and reference impedance (V1 in 0 DC 0 AC 1 portnum 1 z0 50). After an sp run the plot holds complex S_{i_j} (and Y_{i_j}/Z_{i_j}) vectors plus Rbase (published automatically from port 1's z0; a manual `let Rbase = ...` still overrides).

Export — Touchstone v1, any port count, full option surface:

```
wrsnp out.s2p          ; classic: # Hz S RI R 50
wrsnp out.s2p ma ghz   ; magnitude/angle, GHz frequency column
wrsnp out.s2p db       ; dB-magnitude/angle
wrsnp out.y2p y        ; Y-parameters (normalized to Rbase per spec)
wrsnp out.z2p z mhz    ; Z-parameters, MHz
```

Options (ri|ma|db, s|y|z, hz|khz|mhz|ghz) combine in any order; the 2-port default output is byte-identical to the classic wrs2p, and $N \geq 3$ files use the spec's row-major layout.

Import — `rdsnp` reads any Touchstone v1 file (yours or a VNA's) into a new plot with a Hz frequency scale and complex vectors matching the .sp conventions, so measured data diffs against simulation in one expression:

```
sp lin 100 1MEG 1G
let s21sim = S_2_1
```

```
rdsn timer.s2p          ; port count from the extension (or: rdsn f 3)
let err = maximum(mag(S_2_1 - {sp1}.s21sim))
```

MA/DB files convert back to real/imaginary on read, Y/Z de-normalize to absolute values, and the imported plot's Rbase lets it round-trip back out through wrsnp. Pinned round-trip accuracy: 4×10^{-8} (the file's own 6-digit precision is the limit). See [examples/touchstone_examples/](#).

3.6 Monte Carlo

Both standard ngspice MC idioms reach OSDI parameters ([examples/montecarlo_examples/](#)):

The **reset** idiom — a random-valued .param feeds a model card; each reset re-throws the dice and re-runs OSDI setup:

```
.param rr = agauss(1k, 100, 3)      ; nominal 1k,  $\sigma = 100/3$ 
.model mm myres(r={rr})
...
.control
let n = 0
while n < 200
  reset
  op
  ...collect...
  let n = n + 1
end
.endc
```

The **alter** idiom — draw in the control language and alter the parameter (no re-parse, and matched devices can share one draw):

```
setseed 42                                ; whole ensembles bit-reproducible
let r = 1k + 33.3*sgauss(0)
alter @n1[r] = r
```

Three gotchas, pinned by the verify suite: every textual occurrence of a random {param} draws independently (use the alter idiom for matched devices); ngspice's sunif(0) is uniform on $[-1, 1]$, not $[0, 1]$; and wrdata cannot export control-created vectors (parse print output instead — see §4.5).

3.7 Statistical modeling inside the device

Monte Carlo can also live in the Verilog-A source itself: \$rdist_normal and friends give each *instance* an independent, reproducible draw (stable across Newton iterations — see §2.11), which is the right tool for per-device mismatch, with the simulator-side idioms above layered on top for lot-level variation.

3.8 When something misbehaves

- Compile-time: openvaf-r diagnostics are located and specific (wrong construct in a condition, recursion cycles, width mismatches). --lints lists tunable lints; -A/-W/-E adjust their level.
- A model that rejects its configuration via \$fatal/\$finish *during setup* surfaces as "a Verilog-A device rejected its configuration during setup", naming the device.
- \$strobe/\$display output appears on ngspice's stdout — printf-exact formatting (§2.11) makes temporary debug output dependable.
- For convergence work: \$limit genuinely engages iteration limiting, nodesets (electrical n = 5.0;) seed the solver, and \$discontinuity / \$bound_step steer the transient integrator (§2.6).

4 · Limitations and gotchas

An honest map of the edges: what is out of scope by design, what carries fallback semantics, the deliberate design decisions, and the traps that cost real debugging time in this project. Everything here is *documented behavior* — most entries are pinned by a verify script so they can't regress silently into something different.

4.1 Scope: Verilog-A, not full AMS

The project targets Verilog-A — the analog-only subset defined in Annex C of the Verilog-AMS LRM. Features that exist only in full Verilog-AMS are out of scope, most notably:

- digital/mixed-signal constructs — `reg`/`wire` logic, `always/initial` (digital) blocks, delays/event control on digital signals, connect modules and auto-insertion;
- **``default_discipline`** — the directive is AMS-only. (Implicit nets *are* Verilog-A, and work: an undeclared net takes its discipline from the connected port — [E-41](#).)
- discrete-domain disciplines — `domain discrete` combined with `natures` is rejected with a proper error per LRM 3.6.2.2.

When in doubt whether a construct is Verilog-A or AMS-only, Annex C of the LRM (in [docs/](#)) is the authority the compiler follows.

4.2 Features with fallback semantics

These compile and behave predictably, but the OSDI/ngspice target has no underlying mechanism for them, so they return their LRM-specified "mechanism unavailable" values ([E-12](#)):

Function	Behavior
<code>\$test\$plusargs / \$value\$plusargs</code>	<code>false</code> / default (ngspice has no <code>plusargs</code>)
<code>\$simprobe</code>	the supplied default
<code>\$analog_node_alias / \$analog_port_alias</code>	<code>0</code> (no runtime hierarchical aliasing)

4.3 Compile time vs. simulation time

The single most useful mental model for this toolchain:

- Structure binds at compile time. Hierarchy, generate blocks, `genvars`, `defparam`, `paramsets`, bus widths — all resolved by the elaboration pass. Consequently a generate condition or bound on a module parameter is an intentional, explained error: parameters arrive from model cards at simulation time, after structure is frozen ([E-67](#)).
- Behavior binds at simulation time. Loop trip counts, `if` arms, and expressions may depend on parameters (and the solution) freely — a model-card override genuinely changes how many times a for loop runs ([E-70](#)).

4.4 Documented design decisions

- **`limexp()`** is stateless ([E-13](#)): `exp(x)` below the overflow cutoff, tangent-continued above — exact in every analysis. A stateful, previous-iterate limiting version was built and reverted: correct converged values under limiting require SPICE's limiting-RHS correction, which applies to circuit unknowns, not to `limexp`'s derived argument. Use `$limit` for genuine iteration limiting.
- Random draws don't advance a seed ([E-10](#)): each `$random/$dist_*` call site is a deterministic function of (seed, call site). An advancing seed would return different values on every Newton iteration and destroy convergence. Sequences within one evaluation are therefore not available; per-instance/per-call-site independence is.

- **.disto** warns instead of pretending (E-62): the small-signal distortion kernel needs higher-order Taylor coefficients the OSDI ABI cannot carry; OSDI devices are skipped with a loud warning (they used to contribute silent zeros).
- **@(final_step)** fires only on success: a failed or interrupted analysis never fires it — “final” means the converged end of the run (E-53).

4.5 ngspice control-language traps

Pinned during this project’s own verification work — they will bite anyone scripting ngspice:

- The first line of a deck is the title, not a statement. A netlist line placed first is silently swallowed.
- **wrdata** mispairs control-created vectors (it attaches the current plot’s scale, which for a control-made vector is length 1). Export such vectors by parsing `print` output, or `wrdata` only plot-native vectors (E-66).
- **print** of an imported/foreign plot omits the scale column — `print frequency[0]`-style expressions separately (E-72).
- **sunif(0)** is uniform on $[-1, 1]$, not $[0, 1]$; and every textual occurrence of a random-valued `{param}` draws independently — matched devices need the `alter` idiom (E-66).
- Control scripts continue past aborted analyses — detect completion from data, not from echo markers after the analysis command (E-56).
- **sp lin 2 f1 f2** yields one point (a stock ngspice quirk; `lin 3` and up behave; E-63).
- Module names that collide with ngspice built-in device types (`cccs`, `vccs`, `vcvs`, ...) break model creation — name your modules something else (E-29).

4.6 Assorted edges

- **casex/casez** are not implemented — plain `case` (including over strings and arrays) is; the don’t-care variants are rejected at parse time.
- **break/continue** don’t exist in Verilog-A — the compiler rejects them with the `disable <block>;` idiom as the alternative (E-9, E-70).
- Analog operators can’t sit in loops or solution-dependent conditionals (LRM 4.5.1) — hoist them or unroll with `generate`; the diagnostics say which (E-70).
- Recursion in analog functions is illegal — direct and mutual forms are clean errors naming the cycle (E-59).
- String opvars display via `show` but can’t become vectors (ngspice vectors are numeric) — `print @n1[stvar]` fails with a clear message (E-69).
- **sin** is a reserved word in Verilog-A — don’t name a net `sin` (E-36).
- OSDI ABI pairing: this ngspice requires $\text{OSDI} \geq 0.7$; `.osdi` files from older compilers must be recompiled, and this compiler’s output won’t load into stock ngspice (E-54).
- Parameter default ranges: a parameter’s default is exempt from its own `from range` (the CMC “disabled feature” idiom) — but every user-given value is fully validated. Don’t rely on an out-of-range *given* value sneaking through (E-56).
- Corpus models that “fail” by design: some industry models reject default configurations on purpose (HiSIM’s `$port_connected` guards, VBIC floating internal nodes at `RCX=0` — use `.option rshunt`, FBH-HBT needing `fb>0`). The triage lives in E-56.

5 · Enhancement index

One line per enhancement, in order. Doc links the detailed write-up in `enhancements_doc/`; Examples links the folder whose verify script pins the behavior (the result plots live in the example folders). This same table is the enhancement index of the top-level [README](#).

#	What it delivered	Doc	Examples
1	<code>absdelay()</code> transport delay via synthetic-node DAE	doc	absdelay
2	Indirect branch assignment (<code>V(out): V(x)==0</code> — ideal op-amps)	doc	indirect_assignment
3	Vectored (bus) nets and ports with bit-select access	doc	bus
4	<code>laplace_*</code> filter operators + array-variable declarations	doc	laplace , bessel_filter
5	Module instantiation (hierarchy via compile-time flattening)	doc	instantiation
6	Directives, <code><<</>>></code> , <code>slew/transition</code> , <code>zi_*</code> , <code>last_crossing</code>	doc	directive , shift , slew , zi , last_crossing
7	<code>@(initial_step)</code> gating + genuine variable persistence	doc	initial_step , variable_persistence
8	<code>generate for/genvar + cross()/above()/timer()</code> events	doc	generate , cross , timer
9	<code>noise_table(_log)</code> , <code>localparam</code> , <code>ground</code> , <code>strings</code> , <code>repeat/disable</code>	doc	noise , repeat , disable
10	<code>\$random</code> + all <code>\$dist_*</code> / <code>\$rdist_*</code> distributions	doc	rng
11	File I/O (<code>\$fopen...</code>) + string formatting/parsing (<code>\$sscanf...</code>)	doc	fileio , stringio
12	<code>\$simprobe</code> /aliases/plusargs as LRM fallbacks (last unsupported builtins)	doc	alias
13	<code>limexp()</code> kept stateless (documented decision); <code>ddx()</code> demo	doc	ddx
14	Array literals/aggregates, array parameters, dynamic indexing	doc	array
15	Multi-dimensional arrays (N-D, per-element param override)	doc	mdarray
16	<code>\$table_model</code> 1-D lookup tables (differentiable)	doc	table_model
17	2-D/3-D <code>\$table_model</code> (multilinear, exact Jacobian partials)	doc	mdtable
18	<code>real x[0:n]</code> declaration order + arrays in analog functions	doc	funcarray
19	<code>do ... while</code> loops	doc	dowhile
20	Array output/inout function arguments	doc	arrayout
21	<code>paramset</code> blocks	doc	paramset
22	Natural cubic-spline <code>\$table_model</code> (control "3")	doc	cubic_table
23	Array return values from analog functions	doc	arrayret
24	<code>\$discontinuity(n)</code> next-step clamp	doc	discontinuity
25	<code>\$simparam\$str</code> (+ <code>ngspice</code> <code>analysis_name/simulator</code> params)	doc	simparamstr
26	<code>ac_stim</code> crash fix + correct large-signal baseline	doc	acstim
27	<code>idtmod()</code> modulo-integrator fix	doc	idtmod
28	<code>idt()</code> initial condition survives into transient	doc	idtic
29	Port-flow probes <code>I(<port>)</code>	doc	portflow
30	Variadic analysis (" <code>ac</code> ", " <code>tran</code> ", ...)	doc	analysis
31	Complex poles/zeros in <code>laplace_*/zi_*</code> root forms	doc	complexpole

#	What it delivered	Doc	Examples
32	Integer persistent/event-state variables (compiler crash fix)	doc	intstate
33	Array case + array-literal function arguments	doc	arraycase
34	{...} concatenation and {n{...}} replication operators	doc	concat
35	Lexer hang on // comment at EOF	doc	comment
36	Probe-only branches (ideal ammeters, flow-only disciplines)	doc	signalflow
37	Operator-correctness audit (~, const-folded >>, string ?:)	doc	operator
38	Precedence audit vs LRM Table 4-2 (% level fix)	doc	precedence
39	Derived natures (nature X : Parent, : electrical.flow)	doc	derivednature
40	\$table_model in any number of dimensions	doc	ndtable
41	Implicit nets in instance connections	doc	implicitnet
42	Correlated (same-named) noise sources sum coherently	doc	noisecorr
43	Variable declaration initializers, completed (N-D arrays)	doc	varinit
44	Paramset hidden system parameters (. \$mfactor)	doc	paramsethsp
45	Net initializers (nodesets) + nature-attribute access	doc	netinit
46	Escaped identifiers + based integer literals	doc	escid
47	`default_transition + transition() fixes	doc	defaulttransition
48	String-literal escape sequences (single-pass unescaper)	doc	stresc
49	Hierarchical names + \$root	doc	hiername
50	Domain-binding validation (LRM 3.6.2.2)	doc	domainbind
51	Full ac_stim AC-RHS injection (OSDI ABI 0.6)	doc	acstim
52	idt() assert/reset forms (relaxation oscillators)	doc	idtassert
53	@(final_step) + analysis-phase lists on step events	doc	finalstep
54	Correct, node-free noise factors (OSDI ABI 0.7)	doc	noisejw
55	\$finish/\$stop/\$fatal honored + \$discontinuity step rejection	doc	simctrl
56	Corpus sweep: CMC default-range idiom + noise crash fix	doc	paramrange
57	Physics-accuracy validation suite	doc	physcheck
58	defparam hierarchical override	doc	defparam
59	LRM corners: event OR lists, \$realtime, port concat, recursion diags	doc	lrncorner
60	Multiple analog blocks — validation	doc	multianalog
61	Operator-argument audit — slew sign fix, \$limit, \$bound_step	doc	opargs
62	.dc @inst[param] sweeps + .disto warning + analyses tutorial	doc	analyses
63	RF analyses: N-port .sp, trnoise, PSS + span.c NaN fix	doc	rfanalyses
64	Touchstone export: auto-Rbase, N-port wrsnp, 1-port .sp	doc	touchstone
65	Preprocessor audit — macro-recursion guard	doc	preproc
66	Monte Carlo with OSDI — validation (+ zero-warning build chore)	doc	montecarlo
67	Generate audit — genvar fix, nesting, generate if/case	doc	generate

#	What it delivered	Doc	Examples
68	The compiler's own integration test suite, enabled (28 models)	doc	—
69	Operating-point variables end-to-end — validation	doc	opvar
70	Behavioral-loop audit — precise loop diagnostics	doc	analogloop
71	Display-task audit — full format surface + %b segfault fix	doc	display
72	Touchstone round 2 — MA/DB, units, Y/Z, rdsnp reader	doc	touchstone
73	This handbook, its PDF edition, and the README index	doc	docs/handbook

Part II — The Enhancements, One by One

The complete engineering record: for every enhancement, what was broken or missing, how it was fixed, and how the fix was verified. These are the detailed documents the handbook's matrix rows and the top-level README summaries point at.

Enhancement-1 — **absdelay** support for OSDI/Verilog-A in OpenVAF + ngspice

This document describes, step by step, every source change made to turn the original OpenVAF and ngspice-46 sources into version 2. It was produced by diffing `original/` against `version2/`.

The single goal of version 2 is to make the Verilog-A **absdelay()** operator work end-to-end through the OSDI flow — compile a model that uses **absdelay** with `openvaf-r`, and simulate it in ngspice for DC, AC, and transient analysis.

Nothing outside the OSDI subsystem of ngspice is touched, and on the OpenVAF side only the **absdelay** lowering + OSDI code-gen path is changed.

1. The idea (how **absdelay** is modeled)

`absdelay(V(in), td)` returns the input delayed by `td` seconds. A delay is not expressible as a local algebraic/reactive stamp, so version 2 splits each **absdelay** call into two synthetic implicit equations that the compiler emits and the simulator closes:

```
eq_y (AbsDelayInput) : V(y_synth) = y_expr          ← stamped by the model
eq_z (AbsDelayOutput): V(z)      = delayed(V(y_synth), td) ← stamped by ngspice
```

- The model (OpenVAF output) owns `eq_y`: it forces a synthetic node `y_synth` to equal the input expression, and it stores the current `td`.
- The simulator (ngspice) owns `eq_z`: it keeps a waveform history of `V(y_synth)` and stamps the row that ties output node `z` to the delayed value (interpolated from history in transient, $e^{-j\omega t}$ in AC, pass-through in DC).

To connect the two, OpenVAF exports a small descriptor per delay slot and ngspice reads it at `.osdi` load time:

```
OsdiAbsDelayInfo { uint32 y_node; uint32 z_node; uint32 td_offset; }
```

plus two module-level arrays: `OSDI_ABSDELAY_COUNTS[i]` (number of delay slots in descriptor `i`) and `OSDI_ABSDELAY_INFOS[]` (the flattened slot descriptors). This contract is the heart of version 2.

2. OpenVAF compiler changes

8 source files. The job: lower **absdelay** to the two-equation form, carry the `td` value into instance data, and export the slot descriptors in the `.osdi`.

2.1 `openvaf/hir_lower/src/lib.rs` — new IR vocabulary

- New `PlaceKind::AbsDelayTime(u32)` — a real-typed place that holds the current `td` for slot `i` (so it can be written into instance data and read back by the simulator).
- New `ImplicitEquationKind::AbsDelayInput(u32)` and `AbsDelayOutput(u32)` — the `eq_y` / `eq_z` synthetic-node equations.
- New field on `HirIntern`: `absdelay_equations: Vec<(ImplicitEquation, ImplicitEquation)>` — records the (`eq_y`, `eq_z`) pair for every slot, in order.

2.2 `openvaf/hir_lower/src/ctx.rs`

- `PlaceKind::AbsDelayTime(_)` initializes to `F_ZERO` (default value before the model body assigns it).

2.3 `openvaf/hir_lower/src/expr.rs` — the actual lowering (core change) The original code for `absdelay` was a disabled `/* TODO */` block that tried to approximate the delay with a reactive (ddt-style, `res/3`) term and then fell through to an “unsupported” arm. Version 2 replaces it with the two-node form:

1. lower `y_expr = args[0]` and `td = args[1]` (clamp to `tdmax` if a third arg is present);
2. allocate `eq_y = AbsDelayInput(idx)` and `eq_z = AbsDelayOutput(idx)` and push (`eq_y`, `eq_z`) onto `absdelay_equations`;
3. emit the resistive residual `y_expr - V(y_synth) = 0` on `eq_y`;
4. store `td` into the `AbsDelayTime(idx)` place;
5. return `V(z)` as the value of the `absdelay` expression — `eq_z`’s row is left for the simulator to stamp.

2.4 `openvaf/sim_back/src/topology.rs` — keep equation indices aligned The DAE builder used to filter_map away equations with dead/collapsed unknowns. That would renumber equations and break the slot→node mapping. Version 2 changes it to map so every implicit equation keeps a slot in the unknowns vector; dead/collapsed ones get a `Contribution::default()` (zero-contribution) placeholder. The `absdelay` output rows are exactly these “empty” rows — ngspice fills them in. This guarantees `ImplicitEquation` indices stay valid as node indices.

2.5 `openvaf/sim_back/src/context.rs`

- Treat `PlaceKind::AbsDelayTime(_)` as a real output place (so it participates in output/eval-slot handling like other stored quantities).

2.6 `openvaf/osdi/src/inst_data.rs` — carry `td` into instance data

- New `delay_times: Vec<EvalOutputSlot>` on the instance-data layout, one slot per `absdelay`, populated from the `AbsDelayTime(i)` outputs.
- New `store_delay_times(...)` — writes each `td` slot during eval.
- New `delay_time_offset(i, target_data)` — returns the byte offset of slot `i`’s `td` inside the instance struct (this becomes `td_offset` in the descriptor).

2.7 `openvaf/osdi/src/eval.rs`

- Call `inst_data.store_delay_times(instance, &builder)` inside the generated `eval` so `td` is live in instance memory whenever the simulator reads it.

2.8 `openvaf/osdi/src/lib.rs` — export the descriptors

- Define the `OsdiAbsDelayInfo { y_node, z_node, td_offset }` LLVM struct type.
- For each module, for each (`eq_y`, `eq_z`) slot, resolve `y_node/z_node` from the DAE unknowns (`SimUnknownKind::Implicit(eq) → node index`) and `td_offset` from `delay_time_offset(i)`, and build a const struct.
- If any module uses `absdelay`, export the global arrays **`OSDI_ABSDELAY_COUNTS`** (per-descriptor slot count) and **`OSDI_ABSDELAY_INFOS`** (flattened slot descriptors).

3. ngspice simulator changes

9 OSDI files (8 edited + 1 new). The job: read the descriptors, allocate the delay-row matrix entries and waveform history, and stamp `eq_z` for DC, AC, and transient. The core analysis engine (`dctran.c`, `acan.c`, `optran.c`, ...) is unchanged — all support lives in the OSDI device layer.

3.1 `src/include/ngspice/osdiitf.h` — registry entry

- Added `uint32_t num_absdelays` and `const void *absdelay_infos` to `OsdiRegistryEntry`, filled at load time from the exported symbols.

3.2 `src/osdi/osdidefs.h` — data structures

- New `OsdiAbsDelayInfo { y_node, z_node, td_offset }` (mirrors the OpenVAF export).
- Extended `OsdiExtraInstData` with:
 - `delay_hist[][] + delay_hist_cap` — per-slot waveform history of $V(y_{\text{synth}})$, indexed by accepted timepoint;
 - `delay_jac_y[], delay_jac_z[]` — active matrix-entry pointers for the (z, y_{synth}) and (z, z) stamps;
 - `delay_jac_{y,z}_csc[], delay_jac_{y,z}_cx[]` — KLU-only saved real and complex pointers (used by the AC fix in §3.8).

3.3 `src/osdi/osdiregistry.c` — read the descriptors

- At `.osdi` load, look up `OSDI_ABSDELAY_COUNTS` and `OSDI_ABSDELAY_INFOS`; for each descriptor compute its slice into the flattened infos array (12 bytes/slot) and store `num_absdelays + absdelay_infos` on the entry.

3.4 `src/osdi/osdiext.h` and `src/osdi/osdiinit.c` — register accept hook

- Declare `OSDIaccept` and wire it as `OSDIinfo->DEVaccept = OSDIaccept`; so ngspice calls it after each accepted transient timepoint.

3.5 `src/osdi/osdisetup.c` — allocate entries + KLU binding

- In `OSDIsetup`: when `num_absdelays > 0`, allocate the history/pointer arrays and create the two matrix entries per slot with `SMPmakeElt(matrix, z_row, y_col)` and `SMPmakeElt(matrix, z_row, z_row)`.
- In `OSDIbindCSC` (KLU): rebind each delay pointer from the temporary COO buffer to the live KLU matrix, saving both the real (CSC) and complex (CSC_Complex) addresses (`delay_jac*_csc / delay_jac*_cx`).
- In `OSDIupdateCSC` (KLU real↔complex switch): repoint the active `delay_jac_*` pointers to the complex array for AC and back to real for DC/tran — see §3.8.

3.6 `src/osdi/osdiload.c` — DC and transient stamping (largest change) New static helpers + hooks in `OSDIload`:

- `absdelay_ensure_timepoints / absdelay_grow_hist` — lazily allocate and grow `CKTtimePoints` and the per-slot history (ngspice only allocates `CKTtimePoints` for LTRA otherwise).
- `absdelay_lookup` — interpolate the delayed $V(y_{\text{synth}})$ at $t - td$ from the accepted history (binary search), returning the value and a Jacobian α .
- `absdelay_stamp_dc` — steady state: a delay is an ideal wire, so stamp `jac[z,y]+=1, jac[z,z]+=-1` ($V(z)=V(y_{\text{synth}})$), keeping the matrix non-singular.
- `absdelay_stamp_tran` — transient: initialize history on the first step, then stamp the interpolated delayed value into `eq_z`. Sub-femtosecond delays (`td < 1e-15`) are treated as DC pass-through so the epsilon delays that appear in photonic S11/S22 terms don't collapse the timestep.
- `OSDIload` calls `absdelay_stamp_tran` (transient) or `absdelay_stamp_dc` (DC) after the normal device load.

3.7 `src/osdi/osdiaccept.c` — new file, commit history

- `OSDIaccept` runs after each accepted transient timepoint and writes the converged $V(y_{\text{synth}})$ into `delay_hist[k][CKTtimeIndex]`, growing the history if `CKTtimePoints` grew. This is the data `absdelay_lookup` reads next step.

3.8 `src/osdi/osdiacld.c` — AC stamping

- For each slot, stamp the complex delay row: $(z, y_{\text{synth}}) += e^{-j\omega\tau} = \cos(\omega\tau) - j \cdot \sin(\omega\tau)$ and $(z, z) += -1$. Magnitude is 1 (lossless delay); only the phase rotates with frequency, which is the physical group delay.

4. Bug fixes made while bringing the three analyses up

Two defects were found and fixed during development; both are folded into the files above.

4.1 Transient “timestep too small” from epsilon delays Some models emit `absdelay` terms with $\sim 1e-20$ s delays (`S11/S22` phase derivatives). Feeding those into the integrator drove the timestep toward zero. Fix: in `absdelay_stamp_tran`, any `td < 1e-15` is stamped as a DC pass-through ($V(z)=V(y_{\text{synth}})$) instead of a true delay (`osdiload.c` §3.6).

4.2 AC singular matrix under KLU KLU keeps two arrays per matrix entry — real (`CSC`) for DC/`tran` and complex (`CSC_Complex`) for AC — and swaps the active pointer on every DC↔AC transition. The `absdelay` delay-row pointers were only ever bound to the real array, so during the AC complex solve the delay rows were stamped into the unused real array → empty complex rows → singular matrix. (The legacy `SPARSE` solver was unaffected because it stores `[real, imag]` adjacently in one element.)

Fix (`osdidefs.h` + `osdisetup.c`): save both `CSC` and `CSC_Complex` for each delay entry in `OSDIbind-CSC`, and in `OSDIupdateCSC` switch the active `delay_jac_*` pointer to the complex array for AC and back to real for DC/`tran` — mirroring exactly how `ngspice` already handles the regular device Jacobian. After the fix, KLU and `SPARSE` AC results are bit-identical.

5. Summary of changed files

OpenVAF (**version2/OpenVAF-master**)

file	lines	what
<code>openvaf/hir_lower/src/lib.rs</code>	12	IR kinds: <code>AbsDelayTime</code> , <code>AbsDelayInput/Output</code> , <code>absdelay_equations</code>
<code>openvaf/hir_lower/src/ctx.rs</code>	1	default <code>td</code> place to 0
<code>openvaf/hir_lower/src/expr.rs</code>	58	lower absdelay to the two-node DAE form
<code>openvaf/sim_back/src/topology.rs</code>	20	keep equation indices aligned (placeholder rows)
<code>openvaf/sim_back/src/context.rs</code>	5	<code>AbsDelayTime</code> is an output place
<code>openvaf/osdi/src/inst_data.rs</code>	31	store <code>td</code> in instance data; offset accessor
<code>openvaf/osdi/src/eval.rs</code>	1	call <code>store_delay_times</code> in <code>eval</code>
<code>openvaf/osdi/src/lib.rs</code>	62	export OSDI_ABSDELAY_COUNTS / OSDI_ABSDELAY_INFOS

`ngspice` (**version2/ngspice-46/src**)

file	lines	what
include/ngspice/osdiitf.h	4	num_absdelays, absdelay_infos on registry entry
osdi/osdidefs.h	29	OsdAbsDelayInfo, history + matrix-pointer fields
osdi/osdiregistry.c	29	read the exported symbols at load time
osdi/osdiext.h	1	declare OSDIaccept
osdi/osdiinit.c	1	register DEVaccept = OSDIaccept
osdi/osdisetup.c	90	allocate entries/history; KLU bind + real/complex switch
osdi/osdiload.c	226	DC pass-through + transient history stamping
osdi/osdiaccept.c	86	new — commit converged V(y_synth) to history
osdi/osdiacld.c	46	AC $e^{-j\omega t}$ stamping

The core ngspice analysis files (acan.c, dctran.c, optran.c, span.c, noisean.c) are unchanged.

6. Build & verify

```
# compiler
cd ./OpenVAF-master && ./configure && ./build.sh --release
# -> target/release/openvaf-r (also copied to ./bin/openvaf-r)

# simulator
cd ./ngspice-46/build && make -C src -j4
# -> src/ngspice (also copied to ./bin/ngspice)

# end-to-end checks
cd ./absdelay_examples
bash examples/run_examples.sh # DC/AC/tran, KLU vs SPARSE agree
bash benchmark/run_benchmark.sh # KLU vs SPARSE timing sweep
```

Enhancement-2 — Indirect Branch Assignment support in OpenVAF

This document describes every source-code change made to OpenVAF in the `version3/` directory, on top of `version2/` (Enhancement-1, `absdelay`), to implement Verilog-AMS indirect branch assignment. It was produced by diffing `version2/OpenVAF-master` against `version3/OpenVAF-master`.

The goal of Enhancement-2 is to make the Verilog-AMS construct

```
<lhs_access>(<branch>) : <rhs_access>(<branch>) == <expr> ;
```

compile and simulate correctly end-to-end (DC, AC, transient) through the OSDI flow. The canonical motivating example, taken directly from the LRM (Accellera Std VAMS-2023, p. 114), is an ideal op-amp:

```
module opamp(out, pin, nin);
    inout out, pin, nin;
    electrical out, pin, nin;
    analog
        V(out):V(pin,nin) == 0;
endmodule
```

Before this change, OpenVAF's parser rejected the `:` token here:

```
error: unexpected token ':'; expected ';'
--> opamp.va:9:15
  |
9 |         V(out):V(pin,nin) == 0;
  |                   ^
```

Unlike Enhancement-1, this change is entirely confined to OpenVAF (`parser` $\rightarrow$ `AST` $\rightarrow$ `HIR` $\rightarrow$ `HIR lowering`). No ngspice/OSDI changes were needed — see §5.

1. The idea (how indirect branch assignment is modeled)

Indirect branch assignment introduces one new free unknown u per statement, plus one new implicit equation that solves for it:

Quantity	Meaning
u	a fresh DAE unknown, contributed into the LHS branch exactly like a normal <code><+ u></code> contribution
residual	$\text{constraint_lhs} - \text{constraint_rhs} = 0$, where $\text{constraint_lhs} == \text{constraint_rhs}$ is the RHS of the statement

For `V(out):V(pin,nin) == 0;`:

- u is contributed into the `out` branch as a voltage contribution (`V(out) <+ u`), because the LHS access function is `V`. This reuses OpenVAF's existing voltage-source stamping path, which already augments the DAE with the auxiliary current unknown a voltage source needs (the same mechanism behind plain `V(br) <+ expr;`) — nothing new had to be built for that half.
- The residual equation enforces $V(\text{pin}, \text{nin}) - 0 = 0$, i.e. it solves u (the now-ideal output voltage) for whatever value makes the input pins equal — exactly the nullor behavior of an ideal op-amp.

This is conceptually the same “new unknown + new implicit equation” DAE pattern Enhancement-1 used for `absdelay` (see `version2/.../hir_lower/src/expr.rs`, `BuiltIn::absdelay`), except:

- Enhancement-1 needed two implicit equations per call (`AbsDelayInput`, `AbsDelayOutput`) plus a runtime/OSDI contract because the second equation was stamped by ngspice (it needs a time-domain delay history).
- Enhancement-2 needs only one implicit equation per statement, and it is stamped entirely by OpenVAF at compile time — both halves (the branch contribution and the residual) are ordinary algebraic MIR, so no new OSDI export or ngspice-side code was required.

2. OpenVAF changes

9 source files touched, all under `openvaf/{parser,syntax,hir_def,hir_ty,hir,hir_lower}`.

2.1 `openvaf/parser/src/grammar/stmts.rs` — `accept : assign_or_expr()` previously only accepted `<+` (contribute) or `=` (assign) after the LHS expression. Added `T![:]` to the accepted `TokenSet`; the `:` token already existed in the lexer (used for ternary `?:`, case labels, array ranges), so no lexer change was needed.

```
if p.eat_ts(TokenSet::new(&[T![<+], T![=], T![:]])) {
```

2.2 `openvaf/syntax/veriloga.ungram + src/ast/{node_ext,expr_ext}.rs` — new `AssignOp` variant

- `veriloga.ungram`: Assign rule's operator alternatives extended to (`'<+' | '=' | ':'`).
- `node_ext.rs`: new `AssignOp::IndirectBranch` variant; `Assign::op()` recognizes `T![:]`.
- `expr_ext.rs`: the parallel (currently unused outside this enum) `AssignmentOp` got a matching `IndirectBranch` arm in `op_details()`, for consistency.

The generated AST node `Assign { syntax }` carries no per-operator fields (the operator is read directly off the raw syntax node), so no AST codegen regeneration was required — only the two hand-written extension files above.

2.3 `openvaf/hir_def/src/body/lower.rs,src/expr.rs` — no change `hir_def::Stmt::Assignment { dst, val, assignment_kind }` already carries `assignment_kind: ast::AssignOp` opaquely, so it picks up the new variant for free. For the indirect form, `dst` is the LHS access expression (`V(out)`) and `val` is the entire RHS expression after `:` — i.e. the equality expression `V(pin,nin) == 0`, parsed as one ordinary `== BinaryOp` (the expression grammar already understood `==`; nothing new needed there).

2.4 `openvaf/hir_ty/src/inference.rs` — validate & decompose the constraint This is where most of the new logic lives.

- New `InferenceResult::indirect_branch_constraints: AHashMap<StmtId, (ExprId, ExprId)>` — for an indirect-branch `StmtId`, the decomposed (`lhs`, `rhs`) operand `ExprIds` of its `==` constraint.
- `Ctx::infe_stmt`'s `Stmt::Assignment` arm now special-cases `assignment_kind == AssignOp::IndirectBranch`: it still calls `infe_assignment_dst` (unchanged `dst`-resolution logic — `V()/I()` branch access detection is identical to the `Contribute` path), but routes `val` through a new method instead of the generic `infe_assignment`:

```
fn infe_indirect_branch_constraint(&mut self, stmt: StmtId, val: ExprId,
    ↪ dst_ty: Option<Type>)
```

This requires `val` to be a top-level `Expr::BinaryOp { op: Some(BinaryOp::EqualityTest), lhs, rhs }`. If it isn't, a new diagnostic `InferenceDiagnostic::IndirectAssignRequiresEquality`

`{ e }` is emitted (e.g. `V(out):V(pin,nin) <+ 0;` or `V(out):1;` are rejected with a clear error instead of a generic type mismatch or a panic). If it is, both operands are type-checked against `dst_ty` (`Type::Real`, same rule as a normal contribution) and recorded in `indirect_branch_constraints`.

Crucially, the constraint operands are inferred individually — `val` itself (the whole `==` expression, whose value type is boolean-like) is never type-checked against the branch-access `Real` type, which is what a naive reuse of `inference_assignment` would have done and incorrectly rejected.

- The `(dst, assignment_kind)` operator-compatibility match gained an arm so `(AssignDst::Var | AssignDst::FunVar, AssignOp::IndirectBranch)` is rejected with the existing `InvalidAssignDst` diagnostic (you can't use `:` on a plain variable), grouped with the existing `Contribute` rejection.

2.5 `openvaf/hir_ty/src/diagnostics.rs` — error reporting

- `InvalidAssignDst` report: added `AssignOp::IndirectBranch` arms to both the primary-message match and the `maybe_different_operand` hint match (e.g. "found a branch access, perhaps you meant an indirect branch assignment (:)").
- New report arm for `IndirectAssignRequiresEquality`: *"invalid indirect branch assignment ... help: indirect branch assignment requires a constraint of the form <access> == <expr>"*.

2.6 `openvaf/hir/src/body.rs` — new `Stmt::IndirectContribute`

- New HIR statement variant:

```
Stmt::IndirectContribute {
    kind: ContributeKind,
    branch: BranchWrite,
    constraint_lhs: ExprId,
    constraint_rhs: ExprId,
}
```

- `BodyRef::get_stmt`: when `inference.indirect_branch_constraints` has an entry for the statement, emits `Stmt::IndirectContribute` (mapping `AssignDst::Flow/Potential` to `ContributeKind::Flow/Potential`, exactly like the existing `Contribute` path); otherwise falls through to the unchanged `Stmt::Assignment/Stmt::Contribute` logic.

2.7 `openvaf/hir_lower/src/lib.rs` — new implicit equation kind

- New `ImplicitEquationKind::IndirectBranch(u32)` — one per indirect branch assignment slot; its residual row enforces `constraint_lhs == constraint_rhs`.
- New `HirInterner::indirect_branch_equations`: `Vec<ImplicitEquation>` — slot index $\rightarrow$ implicit equation, parallel to `Enhancement-1's absdelay_equations` but a 1-tuple per slot instead of a pair (only one equation is needed here).

2.8 `openvaf/hir_lower/src/stmt.rs` — lowering

- Refactored `contribute()` (used for plain `V/I(br) <+ expr;`) into a thin wrapper around a new value-based primitive:

```
fn contribute_value(&mut self, voltage_src: bool, write: BranchWrite, rhs:
    ↪ Value, is_zero: bool)
```

`contribute_value` contains the exact same branch-stamping logic `contribute()` had (unnamed-branch resolution, `IsVoltageSrc` place, collapse-hint call, accumulating the `Contribute` place) but takes an already-lowered MIR `Value` instead of an `ExprId`. `contribute()`

now just lowers its rhs expression and calls `contribute_value` — behavior for ordinary `<+` statements is unchanged (verified by the unmodified `absdelay/regression` test suite, see §7).

- New `indirect_contribute()`:

```
fn indirect_contribute(&mut self, voltage_src: bool, branch: BranchWrite,
                      constraint_lhs: ExprId, constraint_rhs: ExprId)
```

1. Allocates one implicit equation: `(eq, u) = self.ctx.implicit_equation(ImplicitEquationKind::I`
 2. Contributes `u` into branch via `contribute_value(voltage_src, branch, u, false)` — i.e. literally `V(branch) <+ u` or `I(branch) <+ u`, reusing the exact same backend stamping path (and its automatic auxiliary-unknown augmentation for voltage contributions) as a normal contribution.
 3. Lowers `constraint_lhs` and `constraint_rhs`, builds `residual = lhs - rhs`, and calls `self.ctx.def_resist_residual(residual, eq)` — the same `ImplicitEquation/residual` primitives Enhancement-1 used for `eq_y` in `absdelay`.
- `lower_stmt` dispatches the new `Stmt::IndirectContribute` to `indirect_contribute`, alongside the existing `Stmt::Contribute` arm.

3. Diff summary (version2 → version3)

File	Kind of change
<code>openvaf/parser/src/grammar/stmts.rs</code>	new <code>AssignOp</code> as a 3rd assignment operator
<code>openvaf/syntax/veriloga.grammar</code>	new grammar: Assign op alternatives
<code>openvaf/syntax/src/ast/node.rs</code>	new <code>AssignOp::IndirectBranch + Assign::op()</code>
<code>openvaf/syntax/src/ast/expr.rs</code>	new <code>Expr::IndirectBranch</code>
<code>openvaf/hir_ty/src/inference.rs</code>	new constraint map, new inference method, new diagnostic, operator-compat match
<code>openvaf/hir_ty/src/diagnostics.rs</code>	new report text for the two new/extended diagnostics
<code>openvaf/hir/src/body.rs</code>	new <code>Stmt::IndirectContribute</code> + dispatch in <code>get_stmt</code>
<code>openvaf/hir_lower/src/lib.rs</code>	new <code>ImplicitEquationKind::IndirectBranch</code> , new interner field
<code>openvaf/hir_lower/src/stmt.rs</code>	<code>contribute()</code> refactor + new <code>contribute_value/indirect_contribute</code>

No changes to `openvaf/hir_def`, `openvaf/mir*`, `openvaf/sim_back`, or `openvaf/osdi` — see next section for why.

4. New diagnostics

Diagnostic	When
<code>InvalidAssignDst</code> (extended)	: used on a non-branch-access LHS (e.g. a plain variable)
<code>IndirectAssignRequiresEq</code> (new)	RHS of <code><+</code> is not a top-level <code>==</code> expression (e.g. <code>V(out):1</code> ; or <code>V(out):V(pin,nin) <+ 0</code> ;))

Both produce a normal compiler error with a source span and a help note, not a panic.

5. Why no backend/OSDI changes were needed

Both halves of an indirect branch assignment lower to mechanisms the backend (`sim_back`) and the OSDI exporter already handle generically:

1. The branch contribution (`contribute_value`) produces exactly the same `PlaceKind::Contribute / PlaceKind::IsVoltageSrc` outputs as a literal `V(br) <+ expr;` would — `sim_back::topology` doesn't know or care whether the contributed value came from a lowered expression or a fresh implicit unknown.
2. The constraint residual uses the exact same `ImplicitEquation / PlaceKind::ImplicitResidual` mechanism as `absdelay's eq_y` — already wired all the way through `sim_back/src/topology/lineralize.rs` and the OSDI Jacobian/residual export.

This was confirmed empirically: the generated MIR for the op-amp example (`openvaf/test_data/mir/indirect_branch`) shows the implicit unknown flowing straight into the `Contribute` place and the residual into the `ImplicitResidual` place with no special-casing required, and the compiled `.osdi` simulates correctly (§7) without touching a single line in `sim_back` or `osdi`.

6. Build

```
cd version3/OpenVAF-master
cargo clean
LLVM_SYS_181_PREFIX=/opt/homebrew/opt/llvm@18 \
  cargo build --release --bin openvaf-r --features openvaf-driver/llvm18
cp target/release/openvaf-r ../bin/macos/apple-silicon/openvaf-r
```

(`--features openvaf-driver/llvm18` is required — `mir_llvm/openvaf-driver` have no default LLVM version feature, see their `Cargo.toml`.)

7. Testing & verification

7.1 Compiler unit / snapshot tests

- `cargo test -p syntax -p hir_def -p hir_ty -p hir -p hir_lower` — all existing fast tests pass unchanged (no regression in plain `<+/=` contributions, `absdelay`, case statements, etc).
- New MIR snapshot test `openvaf/test_data/mir/indirect_branch.va / .mir`, exercising the op-amp example end-to-end through `hir_lower::MirBuilder`. The generated MIR confirms the unknown is contributed to the out branch and the residual is $V(\text{pin}, \text{nin}) - 0$.

7.2 End-to-end compile `version3/opamp.va` (the LRM example, using ``include "disciplines.vams" — resolved by OpenVAF's built-in stdlib, no -I needed) compiles to a working .osdi with zero errors/warnings.`

7.3 ngspice simulation — new feature `version3/examples/indirect_assignment_examples/` — a unity-gain buffer built from the op-amp (`nin` tied to `out`), simulated with `version3/bin/.../ngspice:`

- DC sweep `-2V...2V: V(out) == V(pin)` exactly.
- AC 1kHz...1GHz: flat 0 dB gain, 0° phase (ideal, infinite bandwidth).
- Transient 1MHz sine: `V(out)` tracks `V(pin)` with no lag.

PNG plots of all three are in that folder (`dc.png`, `ac.png`, `tran.png`).

7.4 Regression — Enhancement-1 (**absdelay**) version3/examples/absdelay_examples/ recompiled (`absdelay.va` $\rightarrow$ `.osdi` with the new `openvaf-r`) and re-run (DC/AC/transient, KLU vs SPARSE): DC and transient bit-identical between solvers, AC differs only by $\sim 2e-15$ (floating-point roundoff) — matching the documented Enhancement-1 baseline.

This confirms indirect branch assignment support introduced no regressions in the existing `absdelay`-based models or the broader OSDI/ngspice pipeline.

Enhancement-3 — Vectored/Bus-Style Net Declarations in OpenVAF

This document describes every source-code change made to OpenVAF in the `version4/` directory, on top of `version3/` (Enhancement-2, indirect branch assignment), to implement Verilog-AMS vectored net declarations — bus syntax for nets and ports, with bit-select access in branch declarations and `V()/I()` branch-access calls.

The goal is to make constructs like

```
module bus_buffer(in, out);
    input in;
    output [0:3] out;
    electrical in;
    electrical [0:3] out;
    analog begin
        V(out[0]) <+ 0.25 * V(in);
        V(out[1]) <+ 0.50 * V(in);
        V(out[2]) <+ 0.75 * V(in);
        V(out[3]) <+ 1.00 * V(in);
    end
endmodule
```

(the non-ANSI port style above — bare names in the module header, direction and width declared separately in the body — is the common Verilog-A idiom and is fully supported; see §2.8 for the fix this required.)

compile and simulate correctly end-to-end (DC, transient) through the OSDI flow, with branch (bus[2], bus[0]) `br;`-style bit-select endpoints also supported.

Scope, confirmed up front with the user:

- Declaration: `<discipline> [msb:lsb] name, ...;` for both `NetDecl` and `PortDecl` (body and module-head forms).
- Bit-select bus `[i]` valid in `BranchDecl` endpoints and `V()/I()` branch-access arguments. `i` must be a compile-time-constant integer (a literal, optionally unary-negated), range-checked against the bus's declared `[msb:lsb]`.
- Part-select bus `[hi:lo]` is only legal in the declaration's own width clause — never as a branch endpoint or call argument. This OpenVAF subset compiles one standalone compact model at a time (no submodule instantiation), and a branch endpoint is exactly one node, so there is no "vector branch expansion" to support.
- A bare bus name used without an index anywhere a node is expected produces a clean diagnostic, never a panic.

1. The idea (how bus declarations are modeled)

Unlike Enhancement-1 (`absdelay`) and Enhancement-2 (indirect branch assignment), this feature needs no new DAE machinery — no implicit equations, no new MIR places. A bus is purely a name-resolution-time construct:

A declaration `electrical [3:0] bus;` is expanded, at item-tree lowering time, into four independent scalar **Net/Node** entries, with synthesized names `"bus[3]"`, `"bus[2]"`, `"bus[1]"`, `"bus[0]"`. OpenVAF's `Name` type is just a `SmolStr` wrapper with no identifier-syntax restriction, and node/port lookup throughout the compiler is plain `Name` equality — so synthesizing non-identifier-shaped names like `"bus[3]"` is safe and requires no change to the lookup data structures themselves.

A new HIR expression node `Expr::BitSelect { base, index }` resolves `bus[i]`: it constant-folds `i`, range-checks it against the bus's recorded `[msb:lsb]`, synthesizes the same `"bus[i]"` name, and resolves it exactly like an ordinary `Expr::Path` would — producing `Ty::Node`. Because everything downstream of `Ty::Node` (branch resolution, MIR lowering, OSDI export) is already agnostic to *how* a `NodeId` was produced, this requires zero changes in `hir_lower`, `mir*`, `sim_back`, or `osdi` — only one match-arm addition in `hir::body::get_expr`. This is a stronger form of the “no backend changes needed” result Enhancement-2 documented.

`BranchDecl` endpoints (`branch (bus[2], gnd) br;`) are handled the same way, but one layer earlier: since `hir_def::BranchKind` is built directly from `ast::BranchKind` during item-tree lowering (before any HIR body/type inference exists), a bit-select endpoint there is constant-folded and resolved to a synthesized `hir_def::Path` (`Path::new_ident("bus[2]")`) right at that point, reusing the exact same `Path` type every other branch endpoint already uses.

2. OpenVAF changes

2.1 `openvaf/syntax/verilog.ungram` — grammar

- `NetDecl/PortDecl` gained an optional `width: Range?` field, reusing the pre-existing `Range` rule (`'[' Expr ':' Expr ']'`) already used by parameter `from/exclude` constraints.
- New `Expr` alternative, parallel to `PathExpr`:
`BitSelectExpr = base: Path '[' index: Expr ']'`

2.2 `sourcegen/src/ast/src.rs` — manual `SyntaxKind` registration `BIT_SELECT_EXPR` had to be added to the hand-maintained nodes: `&[...]` list in `KINDS_SRC` (the `SyntaxKind` enum and `tokens/src/parser/generated.rs` are *not* auto-derived from the ungram's node list — only the `ast` struct/accessor codegen is). Regenerated via `cargo test -p sourcegen`.

2.3 Parser (`openvaf/parser/src/grammar/`)

- `items.rs`: new `pub(super) fn width_range(p)` parses `'[' expr ':' expr ']'` into a `RANGE` node — a small dedicated helper (the existing `range_or_expr`, used by parameter constraints, also has to disambiguate parenthesized sub-expressions and was left untouched).
- `items/module.rs`: `net_decl/port_decl` (covering both module-head and body port-decl forms) call `width_range(p)` when the next token is `[`, right after the discipline/net_type prefix and before the name list.
- `expressions.rs`: `atom_expr`'s `IDENT | ROOT_KW` arm gained a third case (alongside the existing call/bare-path cases): if the next token is `[`, parse `'[' expr ']'` into `BIT_SELECT_EXPR`. This single insertion point covers `V()/I()` call arguments and `BranchDecl` arguments for free, since both already parse arguments via the shared `expr()/atom_expr()` path.

2.4 `openvaf/syntax/src/ast/node_ext.rs` — AST extensions

- `Expr::as_bit_select(&self) -> Option<(Path, Expr)>`, mirroring the existing `as_path()`.
- New `BranchEndpoint` enum (`Plain(Path) / BitSelect(Path, Expr)`). `BranchKind::NodeGnd/Nodes` now hold `BranchEndpoint` instead of a bare `Path`, so a branch can mix a bit-select and a plain endpoint (e.g. `branch (bus[2], gnd) br;`).
- `openvaf/syntax/src/validation.rs`'s `validate_branch_decl` (which rejects non-identifier branch arguments with a clean `IllegalBranchNodeExpr` diagnostic) gained `ast::Expr::BitSelectExpr` as an accepted endpoint shape, alongside the existing plain-path and port-flow cases.

2.5 `openvaf/hir_def` — item-tree expansion and the new `Expr::BitSelect`

- `expr.rs`: new `Expr::BitSelect { base: Path, index: ExprId }` HIR variant, with a `walk_child_exprs` arm visiting `index`.
- `body/lower.rs`: a `collect_expr` arm lowers `ast::Expr::BitSelectExpr` into `Expr::BitSelect`.
- `item_tree.rs`:
 - Module gained `pub buses: Vec<BusDecl>`.
 - New `BusDecl { base_name, msb, lsb, ast_id }`, with `min_max()`, `contains_bit(bit)`, and `bit_name(bit)` helpers.
 - New `ItemTreeDiagnostic::NonConstantBusWidth { ast_id }` for a `[msb:lsb]` clause that doesn't constant-fold.
- `item_tree/lower.rs`:
 - `fold_width_range(range: &ast::Range) -> Option<(i32, i32)>` — a tiny AST-level constant folder (via `ast::Expr::as_constexprval()`, the existing literal/negated-literal evaluator used elsewhere for attribute values), restricted to integer literals.
 - `expand_bus_names(...)` — for each declared name, if a width clause is present and folds successfully, registers a `BusDecl` and emits one `(name, name_idx)` per bit (`"bus[3]"` .. `"bus[0]"`, ascending, declaration `[msb:lsb]` direction only affects range checks); on a non-constant width, pushes `NonConstantBusWidth` and falls back to an ordinary scalar declaration so compilation proceeds.
 - `lower_net_decl/lower_port_decl` now call `expand_bus_names` instead of iterating `decl.names()` directly; the rest of the per-name `Net/Port/Node` insertion logic — including the existing "merge into an already-declared node of the same name" path that already produces a clean duplicate-declaration diagnostic — is completely unchanged, since it already only operates on `Names`.
 - `lower_branch` gained `resolve_branch_endpoint(ast::BranchEndpoint) -> Option<Path>`: a plain endpoint resolves via the existing `Path::resolve`; a bit-select endpoint constant-folds its index (via `as_constexprval`) and synthesizes `Path::new_ident("base[idx]")` — the exact same path the corresponding bus bit was declared under. A non-constant index simply fails to resolve, degrading the branch to `BranchKind::Missing` (the same graceful fallback any other unresolvable branch endpoint already takes — no panic).

2.6 `openvaf/hir_ty` — bit-select inference and diagnostics

- `inference.rs`:
 - `Ctx` gained an `owner: DefWithBodyId` field (set in `infe_body_query`) and a `find_bus(&self, name) -> Option<BusDecl>` helper that looks up the owning module's `BusDecl` registry (only meaningful inside a module body; returns `None` otherwise).
 - The existing `Expr::Path { port: false }` arm gained a bare-bus check: if the path is a single identifier matching a known bus's base name, a new `BareBusReference` diagnostic is emitted instead of attempting ordinary resolution (which would otherwise produce a confusing generic "unresolved identifier" error).
 - New `infe_bit_select(stmt, expr, base, index) -> Option<Ty>`: resolves `base` against the bus registry (falling through to ordinary path resolution — and its existing diagnostics — if it isn't a known bus, so a genuine typo still gets a normal error rather than a bus-specific one); type-checks `index` via the normal expression inference path, then separately requires it to constant-fold to `Expr::Literal(Literal::Int)` (optionally wrapped in a single `UnaryOp::Neg`); range-checks the result against the bus's `[msb:lsb]`; and finally resolves the synthesized `"base[idx]"` name through the same `resolve_path` machinery as ordinary identifiers, producing `Ty::Node`.
 - `infe_expr`'s `match` gained an `Expr::BitSelect { ref base, index }` arm dispatching to `infe_bit_select`.

- Four new InferenceDiagnostic variants: InvalidBusReference, NonConstantBitSelectIndex, BitSelectOutOfRange, BareBusReference.
- `diagnostics.rs`: report text for all four, in the same style as Enhancement-2's IndirectAssignRequiresEquality (primary label + source span + help note, never a panic).

2.7 `openvaf/hir_def/src/item_tree/lower.rs` — non-ANSI bus ports A module header may declare a port by bare name only (`module m(in, out);`), with its direction/discipline/width given separately in the body (`output [3:0] out;`) — standard non-ANSI Verilog-A port style, and already supported for scalar ports before this enhancement (the body declaration's exact-name match finds and fills in the header's placeholder Node). For a *bus* port declared this way, the header only ever creates one placeholder node under the bare base name ("out"), but the body's width clause then needs to expand it into four nodes ("out[0]".."out[3]") — a mismatch the original per-name exact-match lookup couldn't bridge, leaving the header's "out" placeholder dangling and unresolved (manifesting as `error[L016]: no direction declared for port 'out'`).

Fix: `expand_bus_names` now marks the *first* synthesized bit of every bus with its original base name. A new `find_node_for_decl` helper tries an exact-name match first (the existing behavior), and — only for that first bit — falls back to finding a still-unresolved (`decls.is_empty()`) node under the base name and renaming it in place to the first bit's name before attaching the declaration. This reuses the header's placeholder Node (and its already-recorded position/identity) for bit 0, rather than discarding it; bits 1..N are still created as brand new nodes, same as before.

This is also why `openvaf/hir_def/src/data.rs`'s `ModuleData::module_data_query` changed: it used to classify a module's nodes into ports vs. internal nodes by slicing `nodes[0..num_ports]/nodes[num_ports..]` where `num_ports` is captured right after the header's port list is lowered — *before* the body runs. A bus port expanding from 1 header placeholder to 4 nodes during body processing therefore grew nodes past the already-frozen `num_ports` cutoff, so its extra bits were silently misclassified as internal nodes instead of OSDI terminals (error: too many nodes connected to instance from ngspice, since the compiled model under-reported its terminal count). The fix replaces the positional slice with a filter on `Node::is_port`, which is correct regardless of when or where in nodes a port node was created or expanded.

2.8 `openvaf/hir/src/body.rs` — the only downstream change `BodyRef::get_expr`'s match gained `hir_def::Expr::BitSelect { .. }` as a second pattern on the existing `hir_def::Expr::Path { .. }` $\Rightarrow$ `Expr::Read(self.resolve_path(expr))` arm. `resolve_path` only consults `infer.expr_types`, not the raw `hir_def::Expr` shape, so this one line is sufficient — confirmed by the MIR evidence in §6 below.

3. Diff summary (version3 $\rightarrow$ version4)

File	Kind of change
<code>openvaf/syntax/verilog/grammar.rs</code>	add <code>Expr::BitSelectExpr, width: Range?</code> on <code>NetDecl/PortDecl</code>
<code>sourcegen/src/ast/syntax.rs</code>	register <code>BIT_SELECT_EXPR</code> in the manual <code>SyntaxKind</code> list
<code>openvaf/parser/src/grammar.rs</code>	new <code>hir_def::Expr::BitSelectExpr</code> helper
<code>openvaf/parser/src/grammar.rs</code>	add <code>Expr::BitSelectExpr</code> to <code>decls_decl/port_decl</code>
<code>openvaf/parser/src/grammar.rs</code>	add <code>Expr::BitSelectExpr</code> to <code>atom_expr</code>
<code>openvaf/syntax/src/ast/branch.rs</code>	add <code>Expr::BitSelectExpr</code> to <code>BranchEndpoint</code> , updated <code>BranchKind</code>
<code>openvaf/syntax/src/ast/ports.rs</code>	add <code>Expr::BitSelectExpr</code> to <code>BranchEndpoint</code>
<code>openvaf/syntax/src/ast/branch.rs</code>	add <code>Expr::BitSelectExpr</code> as a valid <code>BranchDecl</code> endpoint shape
<code>openvaf/hir_def/src/expr.rs</code>	add <code>Expr::BitSelectExpr</code> HIR variant
<code>openvaf/hir_def/src/body/lower.rs</code>	add <code>Expr::BitSelectExpr</code> to <code>lower_expr</code>

File	Kind of change
openvaf/hir_def/src/module_lower.rs	ModuleLower, BusDecl, ItemTreeDiagnostic::NonConstantBusWidth
openvaf/hir_def/src/fix_wire_lower.rs	expand_bus_names, bus-aware lower_net_decl/lower_port_decl/lower_branch, find_node_for_decl (non-ANSI bus port merge, §2.7)
openvaf/hir_def/src/module_data_query.rs	classify ports/internal nodes by is_port, not a num_ports positional cutoff (§2.7)
openvaf/hir_def/src/export.rs	Export BusDecl
openvaf/hir_ty/src/inference.rs	infer_bit_select, bare-bus check, 4 new diagnostics
openvaf/hir_ty/src/diagnostic.rs	diagnostic text for the 4 new diagnostics
openvaf/hir/src/body.rs	match-arm addition in get_expr

No changes to openvaf/hir_lower, openvaf/mir*, openvaf/sim_back, or openvaf/osdi — see §6.

4. New diagnostics

Diagnostic	When
ItemTreeDiagnostic::NonConstantBusWidth	ConstantBusWidth clause doesn't constant-fold to two integer literals; the declaration falls back to an ordinary scalar net/port
InferenceDiagnostic::InvalidBusReference	Invalid bus reference in a simple identifier
InferenceDiagnostic::NonConstantBitSelectIndex	Non-constant bit-select index on a constant integer literal (optionally negated), e.g. V(bus[i]) for a variable i
InferenceDiagnostic::BitSelectOutOfRange	Bit-select outside the bus's declared [msb:lsb]
InferenceDiagnostic::BareBusReference	Bare bus reference by its base name with no bit-select, e.g. V(bus, n)

All five produce a normal compiler error with a source span and a help note, never a panic. A bare bus name used as a BranchDecl endpoint (branch (bus, gnd) br;) is a known, narrower gap: it degrades gracefully to BranchKind::Missing (no crash, the branch just doesn't resolve) rather than emitting one of the diagnostics above — surfacing a dedicated hir_def-level diagnostic for that specific case was left out of scope here in favor of the higher-value V()/I()-argument and declaration-time checks, which cover the common cases.

5. Why almost no backend/OSDI changes were needed

A bus bit's Net/Port/Node entry is, by the time it reaches hir_lower/mir_build/sim_back/osdi, indistinguishable from any other scalar net or port declared the ordinary way — same NodeId, same PlaceKind::Contribute/IsVoltageSrc stamping, same OSDI terminal/node export. The *only* place that needed to know about buses at all was name resolution (hir_def item-tree lowering and hir_ty inference); once a bit-select expression resolves to a NodeId, every later stage treats it exactly like V(some_ordinary_net).

This was confirmed empirically: the new MIR snapshot test (§6) and a direct --dump-unopt-mir/-dump-mir run on the bus example (§7.2) both show the synthesized node names (bus[0]..bus[3]) flowing through ordinary branch resolution, DAE/Jacobian stamping, and OSDI export with no special-casing — and the compiled .osdi simulates correctly in ngspice (§7.3) without touching a single line in sim_back or osdi.

6. Build

```
cd version4/OpenVAF-master
cargo test -p sourcegen # regenerate SyntaxKind + AST from the
↪ ungram
LLVM_SYS_181_PREFIX=/opt/homebrew/opt/llvm@18 \
  cargo build --release --bin openvaf-r --features openvaf-driver/llvm18
cp target/release/openvaf-r ../bin/macos/apple-silicon/openvaf-r
```

7. Testing & verification

7.1 Compiler unit / snapshot tests `cargo test -p syntax -p hir_def -p hir_ty -p hir -p hir_lower` — all existing tests pass unchanged (0 failures), confirming no regression in plain scalar net/port declarations, `absdelay`, indirect branch assignment, or any other existing construct (every pre-existing `.va` fixture has no width clause, so width is simply `None` and behaves exactly as before).

New `.mir` snapshot fixture `openvaf/test_data/mir/bus_basic.va/.mir`:

```
module bus_test(p, n);
  inout p, n;
  electrical p, n;
  electrical [3:0] bus;
  branch (bus[2], bus[0]) br_a;
  analog begin
    V(bus[1], n) <+ 1.0;
    I(br_a) <+ V(bus[3]) * 2;
  end
endmodule
```

This exercises declaration, `branch(bus[2], bus[0])`, and `V()/I()` bit-select end-to-end through `hir_lower::MirBuilder`. A direct `openvaf-r --dump-unopt-mir/--dump-mir` run on the same file shows the “Partially optimized MIR (with DAE)” output stamping `bus[0]..bus[3]` as ordinary nodes (visible in the literal table: `'bus[0]'`, `'bus[1]'`, `'bus[2]'`, `'bus[3]'`, `'flow(bus[1],n)'`), feeding the Jacobian/residual rows exactly like any scalar net — no special-casing artifacts.

New ui diagnostic fixtures under `openvaf/test_data/ui/`: `bus_bare_reference.va` (`V(bus, n)`), `bus_out_of_range.va` (`V(bus[10], n)` against a `[3:0] bus`), `bus_nonconstant_index.va` (`V(bus[i], n)` for a real variable `i`) — each produces a clear, correctly-spanned error (e.g. `bus 'bus' requires a bit-select [i], bus bit-select index out of range, bus bit-select index must be a constant`), verified by hand against the generated `.log` files.

7.2 End-to-end compile `version4/examples/bus_examples/bus_buffer.va` — a 4-tap fractional voltage buffer using a vectored port, declared non-ANSI style (bare names in the module header, direction/width given in the body — see §2.7):

```
module bus_buffer(in, out);
  input in;
  output [0:3] out;
  electrical in;
  electrical [0:3] out;
  parameter real gain = 1.0 from (0:inf);
  analog begin
```

```

V(out[0]) <+ 0.25 * gain * V(in);
V(out[1]) <+ 0.50 * gain * V(in);
V(out[2]) <+ 0.75 * gain * V(in);
V(out[3]) <+ 1.00 * gain * V(in);
end
endmodule

```

compiles to a working `.osdi` with zero errors/warnings. The bus port expands to 5 OSDI terminals in declaration order (`in`, `out[0]`, `out[1]`, `out[2]`, `out[3]`), connected positionally in the SPICE netlist exactly like any other multi-terminal device.

7.3 ngspice simulation — new feature version4/examples/bus_examples/ (`dc_sim.cir`, `ac_sim.cir`, `tran_sim.cir`), simulated with version4/bin/.../ngspice:

- DC sweep $-2V \dots 2V$: each tap tracks its exact fraction of the input (e.g. at $V_{in} = 2.0V$: $out_0 = 0.5V$, $out_1 = 1.0V$, $out_2 = 1.5V$, $out_3 = 2.0V$ — exactly $0.25 \times / 0.5 \times / 0.75 \times / 1.0 \times$ gain).
- AC 1kHz...1GHz: each tap shows a flat gain of -12.04 dB / -6.02 dB / -2.50 dB / 0 dB respectively (exactly $20 \times \log_{10}(\text{tap fraction})$) and 0° phase across the entire sweep — as expected for a purely algebraic model with no reactive elements.
- Transient 1kHz sine input: all four taps track the input instantaneously (purely resistive/algebraic model, no reactive elements), with the same exact fractional relationship at every sample.

Raw results saved in `dc.txt/ac.txt/tran.txt`, plotted in `dc.png/ac.png/tran.png`, in that directory (see `examples/bus_examples/README.md`).

7.4 Regression — `absdelay` (Enhancement-1) and indirect branch assignment (Enhancement-2) Both `version4/examples/absdelay_examples/absdelay.va` and `version4/examples/indirect_assignment_examples/indirect_assignment_examples.va` were recompiled with the new `openvaf-r` and re-simulated (DC) against the documented Enhancement-2 baselines:

- `absdelay` 5-stage delay line DC sweep: bit-identical to `examples/absdelay_examples/examples/dc_sparse.txt`.
- `opamp` indirect-branch-assignment unity-gain buffer DC sweep: bit-identical to `examples/indirect_assignment_examples/dc.txt`.

This confirms vectored net declaration support introduced no regressions in either prior enhancement or the broader OSDI/ngspice pipeline.

Enhancement-4 — Laplace-Domain Transfer-Function Operators in OpenVAF

This document describes every source-code change made to OpenVAF in the `version5/` directory, on top of `version4/` (Enhancement-3, vectored/bus net declarations), to implement:

1. Verilog-A's four Laplace transform filter analog operators (§1-8 below).
2. Array-variable declarations (`real [msb:lsb] x;`), added as a follow-up once it became clear `laplace_*`'s array-literal *arguments* ('`{...}`') were a different feature from array *variables* — see §9.
3. Array variables as **laplace_* num/den** arguments — letting a bare array-variable reference (`coeffs`) stand in for an array literal in a `laplace_*` call, so Parts 1 and 2 compose — see §17.
4. A large-integer-literal crash fix, found and fixed while building a real 5th-order Bessel filter example whose coefficients include large bare-integer-shaped literals — see §22.

Part 1: Laplace transform filter operators

The four operators:

```
laplace_nd(in, num_coeffs, den_coeffs)    // num/den given as polynomial
↪ coefficients
laplace_np(in, num_coeffs, den_poles)     // num as coefficients, den as poles
↪ (roots)
laplace_zd(in, num_zeros, den_coeffs)     // num as zeros (roots), den as
↪ coefficients
laplace_zp(in, num_zeros, den_poles)      // both num/den given as roots
```

The goal is to make constructs like

```
module laplace_lpf(in, out);
  input in;
  output out;
  electrical in, out;
  parameter real tau = 1e-6 from (0:inf);
  analog begin
    V(out) <+ laplace_nd(V(in), '{1.0}', '{1.0, tau}');
  end
endmodule
```

(a first-order RC-style low-pass filter, $H(s) = 1/(1+\tau s)$) compile and simulate correctly end-to-end (DC, transient) through the OSDI flow, for all four `laplace_*` forms, with coefficient/root lists given as '`{...}`' array-literal arguments.

Scope, confirmed up front with the user:

- All four forms — `laplace_nd`, `laplace_np`, `laplace_zd`, `laplace_zp`.
- num/den (or zero/pole) arguments are compile-time-constant real array literals ('`{...}`'), as already enforced by pre-existing `hir_ty` validation (see §1.3) — this was *not* new validation written for this enhancement.
- The optional trailing tolerance (`laplace_*_tol`) / nature argument is accepted for signature compatibility but has no effect: the realization built here is an exact algebraic transformation of the transfer function into an ODE system, not an approximation that would need an error tolerance to converge.
- `zi_nd/zi_np/zi_zd/zi_zp` (the z-domain/discrete-time analogues) remain out of scope and still report `is_unsupported`.

1. What was actually there already (and what wasn't)

Before writing any new logic, the existing scaffolding for `laplace_*` turned out to be front-end-complete but parser/lowering-incomplete — a more interesting starting state than Enhancement-3's bus feature, which started from nothing:

1. `BuiltIn::laplace_nd/np/zd/zp` already existed as recognized keywords, with `hir_ty` signatures (`LAPLACE_FILTER`, taking two `ArrayAnyLength{ty: Real}` arguments plus optional tolerance/nature) already wired up — but marked `is_unsupported()`, so any use was rejected with a hard compile error ("function ... is currently not supported by OpenVAF") before reaching `hir_lower` at all.
2. The array-literal expression syntax ('{a, b, c}', `ARRAY_EXPR` in the ungram/SyntaxKind/AST layers) was fully scaffolded but never parsed: `openvaf/parser/src/grammar/expressions.rs` had a complete `array_expr` parser function sitting commented out behind a `// TODO properly implement arrays` marker, with `atom_expr` never dispatching to it. So '{1.0, 2.0}' was a syntax error everywhere, independent of `laplace_*`.
3. `hir_ty::inference::infere_array` (the array-literal type-checker) had a latent bug: it returned `Ty::Val(ty)` — the *element* type — instead of `Ty::Val(Type::Array { ty, len })`, so even with parsing fixed, a 3-element real array literal would type-check as a bare real, not an array, failing every `ArrayAnyLength` signature match.
4. `openvaf/hir_lower/src/expr.rs::lower_array` was `todo!("arrays")` — arrays were never lowered as general MIR values (and still aren't; they remain a syntax-only construct consumed positionally by builtins like `laplace_*/noise_table`, never materialized as a runtime array value — see §2.2).

So this enhancement closes three latent gaps (#2-#4) in addition to the actual new feature (the transfer-function-to-DAE lowering, #5 below).

2. The idea (how Laplace operators are modeled)

2.1 No new "Laplace" DAE primitive — reuse of `idt`'s machinery Unlike `absdelay` (Enhancement-1), which needed a genuinely new simulator-side mechanism (history-based delay lookup, `PlaceKind::AbsDelayTime`, a dedicated `OsdiAbsDelayInfo` struct), a Laplace transfer function $H(s) = \text{num}(s)/\text{den}(s)$ can be realized exactly as an ordinary linear ODE system — no approximation, no new backend concept.

The standard controllable canonical form state-space realization is used: for a proper rational $H(s)$ of order $n = \text{deg}(\text{den})$, with n state variables $x_0 \dots x_{n-1}$:

$$\begin{aligned} dx_0/dt &= x_1 \\ dx_1/dt &= x_2 \\ &\dots \\ dx_{n-2}/dt &= x_{n-1} \\ dx_{n-1}/dt &= u - (a_{\text{bar}_0} * x_0 + a_{\text{bar}_1} * x_1 + \dots + a_{\text{bar}_{n-1}} * x_{n-1}) \end{aligned}$$

$$y = c_0 * x_0 + c_1 * x_1 + \dots + c_{n-1} * x_{n-1} + d * u$$

where u is the operator's input expression, $a_{\text{bar}_i} = \text{den}[i]/\text{den}[n]$ is the monic-normalized denominator, $d = \text{num}[n]/\text{den}[n]$ is the direct feedthrough term (only present when num is exactly proper, i.e. $\text{deg}(\text{num}) == \text{deg}(\text{den})$), and $c_i = (\text{num}[i] - d * \text{den}[i])/\text{den}[n]$.

Each state x_i is exactly the same shape as the existing `idt()` builtin's implicit equation: a fresh implicit unknown (`ctx.implicit_equation`) with a *reactive* residual of x_i (contributing $d(x_i)/dt$ to KCL) and a *resistive* residual of $-(\text{RHS of } dx_i/dt)$, so that the simulator's standard $d(\text{react})/dt + \text{resist} = 0$ stamping produces exactly $dx_i/dt = \text{RHS}$. This is the same mechanism `lower_integral` already

uses for `idt(arg)` (`react = val, resist = -arg` there). The output `y` is then a purely algebraic linear combination of state values (plus `d*u`) — it needs no implicit equation of its own.

Because this reduces entirely to ordinary implicit-equation residuals (the same primitive `idt/absdelay` already use), no changes were needed in `sim_back` or `osdi` — exactly the same “no backend changes” result Enhancement-3 reported for bus nets, but here it falls out of reusing an *existing* DAE primitive rather than needing none at all.

2.2 Root-to-polynomial expansion for `np/zd/zp` `laplace_np/laplace_zd/laplace_zp` give one or both of `num/den` as a list of roots (poles/zeros) rather than polynomial coefficients. These are expanded into ascending-power coefficients at MIR-build time by repeated synthetic polynomial multiplication by `(s - root)`:

```
poly := [1]                                // the empty product
for each root r:
    poly := poly * (s - r)                  // convolution, fully unrolled
```

Since the *number* of roots/coefficients is always known at compile time (it’s the literal length of an `{...}` array — no constant-folding of the array *length* is needed, unlike the array *element values*, which are MIR Values computed normally via `lower_expr` and may depend on instance parameters), this unrolls into a small, fixed sequence of `fmul/fsub/fneg` MIR instructions per call site — no runtime loop, no new MIR opcode.

2.3 Why arrays are still not general MIR values `lower_array/Expr::Array` remain syntax-only: a `{...}` argument to `laplace_*` is never lowered as a single array Value. Instead, `array_elems()` reads the raw `hir::Expr::Array` node directly (bypassing `lower_expr` for the array as a whole) and lowers each element individually with the ordinary `lower_expr`. This mirrors how `noise_table_log({...})` and other pre-existing `ArrayAnyLength` consumers were always implicitly expected to work, and avoids having to invent a real “array value” MIR representation for a four-builtin, syntax-only feature.

3. OpenVAF changes

3.1 `openvaf/parser/src/grammar/expressions.rs` — enable array-literal parsing

- `atom_expr`’s dispatch gained `T!['{' | '['] => array_expr(p)` (previously a commented-out TODO covering only `{}`).
- The `array_expr` parser function itself was uncommented and fixed: the original draft checked `p.at(T!['']')` for its loop-exit condition (a copy-paste bug from a `[...]` array sketch) instead of `T!['']'`, which would have looped past the actual closing brace. Now parses `('{' | '[') (Expr (',' Expr)*)? '}'` into an `ARRAY_EXPR` node, matching the pre-existing `BIT_SELECT_EXPR`-style structure already wired through the rest of the AST/HIR/type-inference stack (§3.2-3.3 confirm those layers were already complete).
- Both `{a, b, c}` and bare `{a, b, c}` are accepted as the opening delimiter, lexed as distinct tokens (`ArrStart` for `{`, `OpenBrace` for plain `{`) but parsed identically — `array_expr`’s opening bump uses `p.bump_ts(TokenSet::new(&T!['{' | '['], T!['}' | ']'))` rather than a single fixed token. This matches a precedent already in the codebase: `openvaf/parser/src/grammar/items.rs`’s constraint parser (for parameter `from/exclude` array-style constraints) already accepted both spellings (`p.eat(T!['{' | '[']) || p.eat(T!['}' | ''])`) before this enhancement touched anything — `array_expr` simply needed to follow the same convention. Verified end-to-end: `laplace_nd(V(in), {1.0}, {1.0}, tau)` (bare braces) and `laplace_nd(V(in), '{1.0}', '{1.0}, tau)` (with leading `'`) compile to bit-identical MIR and produce identical simulated results.

This is a prerequisite for *any* array literal anywhere in the language, not just `laplace_*` arguments — `noise_table_log` and other pre-existing `ArrayAnyLength`-typed builtins benefit identically as a side effect.

3.2 `openvaf/hir_ty/src/inference.rs` — fix `infe_array`'s return type `infe_array` (the array-literal type-checker) returned `Ty::Val(ty)` — the unified *element* type — instead of `Ty::Val(Type::Array { ty: Box::new(ty), len })`. This made every non-empty array literal type-check as a bare scalar of its element type, so it could never satisfy an `ArrayAnyLength{ty: Real}` parameter requirement (only the *element* type matched, not "is an array"), failing overload resolution for every `laplace_*/noise_table_log` call with a literal array argument. Fixed to construct the correct `Type::Array` value, matching the `(Ty::Val(Type::Array{ty: ref ty1, ..}), TyRequirement::ArrayAnyLength{ty: ty2}) => equiv.compare_ty(ty1, ty2)` match arm in `hir_ty/src/types.rs` that was already correctly written to expect it.

3.3 `openvaf/hir_def/src/builtin.rs` / `sourcegen/src/hir_builtins.rs` — mark Laplace as supported `laplace_nd/laplace_np/laplace_zd/laplace_zp` removed from the `UNSUPPORTED` list in `sourcegen/src/hir_builtins.rs` (the source of truth; `openvaf/hir_def/src/builtin.rs` is regenerated from it via `cargo test -p sourcegen`, so it was *not* hand-edited directly). `zi_*` (z-domain) builtins were left in `UNSUPPORTED`, out of scope.

3.4 `openvaf/hir_lower/src/lib.rs` — new implicit-equation kind

- New `ImplicitEquationKind::LaplaceState(u32)` variant — purely a descriptive tag (mirroring `AbsDelayInput/AbsDelayOutput/ IndirectBranch`) for debug/MIR-dump readability; nothing downstream pattern-matches on `ImplicitEquationKind` beyond `hir_lower` itself (confirmed by `grep` — only `lineralize.rs`'s unrelated `inline-ddt()` handling and `hir_lower/src/stmt.rs`'s `IndirectBranch` push do, and neither needed to change), so this needed no further wiring.

3.5 `openvaf/hir_lower/src/expr.rs` — the actual lowering

- `lower_builtin`'s match gained a `Builtin::laplace_nd | laplace_np | laplace_zd | laplace_zp => self.lower_laplace(builtin, args)` arm.
- `lower_laplace`: lowers the input expression, lowers each num/den (or zero/pole) array element via the ordinary `lower_expr`, and dispatches num/den through `laplace_roots_to_poly` for whichever of the two (if either) the specific builtin variant gives as roots (`laplace_zd/laplace_zp` for num, `laplace_np/laplace_zp` for den), then calls `laplace_state_space`.
- `array_elems`: reads `hir::Expr::Array` directly off `self.body` for a given `ExprId` (falling back to treating the expression as a single-element array if it somehow isn't a literal array — defensive, not expected to trigger given the type-level `ArrayAnyLength` requirement).
- `laplace_roots_to_poly`: the polynomial-from-roots expansion of §2.2.
- `laplace_state_space`: builds the controllable-canonical-form realization of §2.1 — normalized denominator, direct feedthrough, output coefficients, `n` implicit equations with paired reactive/resistive residuals, and the final algebraic output combination. Handles the degenerate `n == 0` case (constant-gain, dynamics-free) directly as `(num[0]/den[0]) * input`.

3.6 No changes needed in `sim_back` or `osdi` As in Enhancement-3, confirmed empirically (§5 below): once a Laplace call lowers to ordinary implicit-equation residuals, every later stage (topology linearization, Jacobian/residual stamping, OSDI export) treats the resulting states exactly like any other `idt()`-style implicit unknown.

4. Diff summary (version4 → version5)

File	Kind of change
openvaf/parser/src/grammar/expr/array_literal	array literal parsing (array_expr, dispatch in atom_expr) — fixes a pre-existing dead/buggy stub, prerequisite for any array-literal use
openvaf/hir_ty/src/inference/array	fix inference array to return Type::Array{..} instead of the bare element type — pre-existing latent type-inference bug
sourcegen/src/hir_builtins/laplace_nd/np/zd/zp	from UNSUPPORTED (regenerates openvaf/hir_def/src/builtin.rs)
openvaf/hir_lower/src/Type/ImplicitEquationKind::LaplaceState	new Type
openvaf/hir_lower/src/Expr/laplace, array_elems, laplace_roots_to_poly, laplace_state_space	lowering

No changes to openvaf/hir_def item-tree/lowering, openvaf/mir*, openvaf/sim_back, or openvaf/osdi.

5. Why almost no backend/OSDI changes were needed

Once laplace_state_space finishes, every state x_i is, from mir_opt/sim_back/osdi's point of view, indistinguishable from an `idt()` integrator's implicit unknown: same `ImplicitEquation` index space, same `PlaceKind::ImplicitResidual{equation, reactive}` stamping, same OSDI Jacobian-entry generation. The output value y is a plain algebraic MIR expression (sums and products of state/parameter values), so it needs no special handling at all — it flows into the branch contribution exactly like any other expression.

This was confirmed via `--dump-unopt-mir/--dump-mir` on the test fixtures in `examples/laplace_examples/`: the `Implicit equations`: section of the HIR interner dump lists one `LaplaceState(i)` entry per state (one for a first-order `laplace_nd/laplace_np` filter, two for a second-order `laplace_zd/laplace_zp` filter), feeding ordinary reactive/resistive residuals with no special-casing artifacts anywhere in the dump.

6. Build

```
cd version5/OpenVAF-master
cargo test -p sourcegen # regenerate is_unsupported() from
↪ hir_builtins.rs
LLVM_SYS_181_PREFIX=/opt/homebrew/opt/llvm@18 \
  cargo build --release --bin openvaf-r --features openvaf-driver/llvm18
cp target/release/openvaf-r ../bin/macos/apple-silicon/openvaf-r
```

7. Testing & verification

7.1 Compiler unit / snapshot tests `cargo test -p syntax -p hir_def -p hir_ty -p hir -p hir_lower` — all existing tests pass unchanged (0 failures), including the Enhancement-2 (`mir::indirect_branch.va`) and Enhancement-3 (`mir::bus_basic.va`) MIR snapshot fixtures, confirming the array-literal parser/type-inference fixes and the new Laplace lowering introduced no regression in any existing construct.

7.2 End-to-end compile version5/examples/laplace_examples/:

- `laplace_lpf.va` — `laplace_nd(V(in), '{1.0}', '{1.0, tau})`, a first-order RC-style low-pass filter (single bus-free port pair).
- `laplace_variants.va` — all four forms side by side: `laplace_nd/ laplace_np` both realizing the same $H(s) = 1/(1+\tau s)$ (coefficient form vs. pole form), and `laplace_zd/ laplace_zp` both realizing the same second-order $H(s) = (s+2e6)/((s+1e6)(s+3e6))$ (zero-with- coefficient-denominator form vs. fully factored pole/zero form).
- `laplace_zd_only.va` — an isolated single-call fixture used to cross-check the multi-call comparison file's results column-by-column.

All compile to a working `.osdi` with zero errors/warnings. `--dump-unopt-mir/--dump-mir` confirm the expected implicit-equation counts: 1 state for each first-order filter, 2 states for each second-order filter (`openvaf-r --dump-mir laplace_zd_only.va` shows `0 : LaplaceState(0) / 1 : LaplaceState(1)`).

7.3 ngspice simulation — new feature version5/examples/laplace_examples/ (`dc_sim.cir`, `ac_sim.cir`, `tran_sim.cir` for the primary `laplace_lpf` model, plus `dc_variants.cir/ dc_zd_only.cir` for the four-forms cross-check), simulated with `version5/bin/.../ngspice`. Raw results saved in `dc.txt/ac.txt/ tran.txt`, plotted via `plot_results.py` (matplotlib) into `dc.png/ac.png/tran.png`:

- DC (`dc.txt/dc.png`), `laplace_lpf` (first-order, $\tau=1e-6$): out tracks in exactly 1:1 across a -2V..2V sweep — correct, since $H(0) = 1/(1+0) = 1$.
- DC, `laplace_variants` (`dc_variants.txt`): at $in = 2.0$, $out_{nd} = out_{np} = 2.0$ (both realize $H(0)=1$) and $out_{zd} = out_{zp} = 1.33333e-6$ (both realize the second-order system's $H(0) = 2e6/3e12 = 6.667e-7$, so $2.0 * 6.667e-7 = 1.3333e-6$) — all four forms agree exactly on equivalent transfer functions, cross-validating the coefficient and root-expansion code paths against each other.
- AC (`ac.txt/ac.png`), `laplace_lpf` swept 1kHz..1GHz: a textbook single-pole Bode response — flat 0 dB / 0° well below the corner frequency $f_{pole} = 1/(2\pi\tau) = 159.2$ kHz, exactly -3.0 dB / -45.0° at f_{pole} (read directly off the AC sweep data, e.g. 158.5 kHz $\rightarrow$ -2.99 dB, -0.7833 rad = -44.88°), a -20 dB/decade rolloff above it, and phase asymptoting to -90° at high frequency — confirming the realization's frequency-domain behavior, not just its DC/step response, matches the analytic transfer function.
- Transient (`tran.txt/tran.png`), `laplace_lpf` step response: a $0 \rightarrow 1V$ step at $t=0$ produces $V(out) = 0.632...$ at $t = \tau = 1\mu s$ — exactly $1 - e^{-1} = 0.63212...$, the analytic first-order step response, confirming the state-space realization's *dynamics* (not just its DC gain) are correct.

7.4 Regression — bus nets (Enhancement-3), `absdelay` (Enhancement-1), indirect branch assignment (Enhancement-2) `examples/bus_examples/bus_buffer.va`, `examples/absdelay_examples/absdelay.va`, and `examples/indirect_assignment_examples/opamp.va` all recompile cleanly with the new `openvaf-r` (zero errors/warnings), and their corresponding `hir_lower` MIR snapshot tests (`mir::bus_basic.va`, plus the full `-p hir_lower` suite) pass unchanged — confirming the parser/type-checker fixes needed for array literals (§3.1, §3.2) didn't disturb bit-select expressions, branch resolution, or any other prior-enhancement construct.

8. Known limitations

- Improper transfer functions are not diagnosed. If $\deg(num) > \deg(den)$ (more numerator coefficients than the state-space realization can use), the extra high-order numerator terms are

silently dropped rather than producing a diagnostic or supporting differentiation of the input. Enhancement-3 set a precedent of documenting this kind of narrower gap rather than blocking on it (its bare-bus-as-branch-endpoint case); the same call is made here given improper transfer functions are an unusual/degenerate modeling case. A `hir_ty`-level diagnostic (comparing num/den array-literal lengths, no constant-folding needed) would be the natural follow-up.

- **zi_nd/zi_np/zi_zd/zi_zp** (z-domain/discrete-time filters) remain unimplemented (`is_unsupported`), as scoped up front.

Part 2: Array-variable declarations (`real [msb:lsb] x;`)

9. Motivation and prior state `laplace_*`'s `'{...}'` arguments (Part 1) are array-literal expressions — fixed-size constant lists, never assigned to or indexed by a runtime-variable index, and not a storage location. Verilog-A separately allows declaring an array variable — a named, indexable piece of mutable storage, e.g.:

```
real [0:4] coeffs;
analog begin
    coeffs[0] = 0.1;
    V(out) <+ coeffs[0] * V(in);
end
```

This was previously unsupported: `VarDecl`'s grammar rule (`openvaf/syntax/veriloga.ungram`) had no width/range field at all (unlike `NetDecl/PortDecl`, which already gained one in Enhancement-3), so `real [0:4] x;`/`real x[0:4];` were both syntax errors.

10. Design: same compile-time-constant-index expansion as bus nets Rather than building genuine runtime-indexable array storage (a much larger change — a new MIR memory/array primitive, since today's MIR only has scalar SSA values, confirmed by `hir_lower::lower_array` still being unimplemented, see §2.3 in Part 1), array variables are modeled exactly like Enhancement-3's bus nets: `real [msb:lsb] x;` is expanded at item-tree lowering time into independent scalar `Var` entries (`"x[4]" .. "x[0]"`), and `x[i]` reuses the already-generic `Expr::BitSelect` machinery from Enhancement-3 — `i` must be a compile-time-constant integer (a literal, optionally unary-negated), range-checked against the declared `[msb:lsb]`. This is a real, if narrower, capability than a general indexable array: a for-loop with a runtime-variable index into the array (`x[i]` for non-constant `i`) is not supported, same constraint bus-net bit-select already had.

The syntax chosen is `<type> [msb:lsb] name;` — the *prefix*-range form already established for `NetDecl/PortDecl` in this codebase — rather than chasing the LRM's postfix `name[size]` declarator form, for consistency with the existing bus-declaration convention.

11. Why this needed almost no new machinery The key discovery, made before writing any code: `Expr::BitSelect` resolution (`hir_ty::inference::inference_bit_select`) was already fully generic past the point of finding a `BusDecl` and constant-folding the index — its *only* bus-specific step was the final match on what the synthesized `"x[i]"` name resolved to:

```
match self.resolve_path(stmt, expr, &synth_path)? {
    ScopeDefItem::NodeId(node) => Some(Ty::Node(node)),
    _ => None,    // a Var resolution was silently dropped here
}
```

Adding one arm — `ScopeDefItem::VarId(var) => Some(Ty::Var(self.db.var_data(var).ty.clone(), var))` — was the *entire* change needed for `x[i]` to work as a value (read) and as an assignment target (write):

- So unlike Part 1 (which needed a genuinely new lowering, `lower_laplace`), this feature needed no new `hir_lower/mir/sim_back/osdi` code at all — each expanded scalar `Var` is, from MIR onward, indistinguishable from a variable declared without a width clause.

12.1 **openvaf/syntax/veriloga.ungram** — grammar `VarDecl` gained an optional `width`: `Range?` field, reusing the pre-existing `Range` rule, identical in shape to `NetDecl/PortDecl`'s:

12.2 **openvaf/parser/src/grammar/items.rs** — `parser` `var_decl` calls the existing `width_range(p)` helper (built for `NetDecl/PortDecl` in Enhancement-3) when the next token is `[`, right after the type and before the name list — the same insertion pattern `net_decl/port_decl` already use.

- Module gained `pub var_arrays: Vec<BusDecl>`, kept as a separate list from buses (nets/ports) purely so the two declaration kinds stay distinguishable for diagnostics/debugging — `BusDecl` itself (base name, `msb`, `lsb`, `ast_id`) is reused verbatim, since an array variable is structurally identical to a bus: a base name plus an `[msb:lsb]` range expanding into independent scalar entries.
- New `ItemTreeDiagnostic::ArrayVarUnsupportedScope { ast_id }` for a width clause that appears somewhere array-variable resolution doesn't support (§12.4).

- The module-body call site (inside `lower_module_items`) passes `Some(&mut var_arrays)`, an accumulator threaded through `lower_module` exactly like buses already is, attached to the final `Module { ..., var_arrays }`.
- The `analog` function-body and nested-block call sites pass `None` — array-variable bit-select resolution is module-body scope only (mirroring `find_bus`'s existing `DefWithBodyId::ModuleId`-only lookup; a function has its own `DefWithBodyId::FunctionId` owner, so a registry keyed only on the module wouldn't be reachable from inside one anyway without further plumbing). A width clause in either unsupported scope triggers `ArrayVarUnsupportedScope` and degrades gracefully to an ordinary scalar variable, never a panic.

51

Enhancement-3 added), and a `BusDecl` is recorded. A non-constant width falls back to `NonConstantBusWidth` (the same diagnostic bus nets already use) plus a scalar declaration, exactly mirroring `expand_bus_names`.

A default initializer on an array declaration (`real [0:4] x = 1.0;`) is silently ignored (not assigned to any bit) — see §13.

12.5 `openvaf/hir_ty/src/inference.rs` — resolution

- New `find_var_array(&self, name) -> Option<BusDecl>`, identical in shape to `find_bus` but querying `Module::var_arrays`.
- `infe_bit_select`: the base-name lookup is now `self.find_bus(&name).or_else(|| self.find_var_array(&name))` — a bit-select base can be *either* a bus or an array variable (the two can't collide on the same name, since they'd already conflict as ordinary duplicate declarations).
- The final resolution match gained `ScopeDefItem::VarId(var) => Some(Ty::Var(self.db.var_data(var).var))` (§11) — the one line that makes everything else work.
- The bare-reference check (`Expr::Path` with no bit-select) now also checks `find_var_array`, so `V(out) <+ coeffs * V(in);` (forgetting the `[i]`) reuses the existing `BareBusReference` diagnostic rather than falling through to a generic “unresolved identifier” error. Its message text was generalized from “bus referenced...”/“select a single bit” to “bus/array referenced...”/“select a single element” to read sensibly for both cases (`openvaf/hir_ty/src/diagnostics.rs`).

13. New/changed diagnostics

Diagnostic	When
<code>ItemTreeDiagnostic::AnArrayVarWithoutWidth</code>	Some <code>VarDecl</code> inside an analog function body or a nested <code>begin...end</code> block (only module body scope is supported); falls back to a scalar variable
<code>ItemTreeDiagnostic::NonConstantBusWidth</code>	On a bus net that doesn't constant-fold, on an array variable same as on a bus net
<code>InferenceDiagnostic::BareBusReference</code>	(rebased, rephrased according) an array variable referenced by its base name with no bit-select, e.g. <code>V(out) <+ coeffs * V(in);</code>
<code>InferenceDiagnostic::BitSelectOutOfRange</code>	Rebased, rephrased against a declared <code>[0:4]</code> array
<code>InferenceDiagnostic::NonConstantBitSelectIndex</code>	Rebased, rephrased against constant/variable <code>i</code>

All confirmed via hand-written `.va` fixtures producing clean, correctly spanned errors, never a panic (see §15).

14. Diff summary (additive to Part 1's table)

File	Kind of change
<code>openvaf/syntax/verilog/VarDecl</code>	gains <code>width: Range?</code>
<code>openvaf/parser/src/grammar/items</code>	reuses the existing <code>width_range</code> helper
<code>openvaf/hir_def/src/module/vars</code>	reuses <code>var_arrays</code> , <code>ArrayVarUnsupportedScope</code> diagnostic
<code>openvaf/hir_def/src/item_tree/vars</code>	gains array expansion + module-body-only scope restriction; <code>lower_module/lower_module_items</code> thread the new <code>var_arrays</code> accumulator
<code>openvaf/hir_def/src/report_text</code>	for <code>ArrayVarUnsupportedScope</code>

File	Kind of change
openvaf/hir_ty/src/infer/infer_var_array; infer_bit_select	checks both registries and resolves ScopeDefItem::VarId; bare-reference check covers array variables too
openvaf/hir_ty/src/diagnostics	generalized BareBusReference wording

No changes to openvaf/hir, openvaf/hir_lower, openvaf/mir*, openvaf/sim_back, or openvaf/osdi (§11).

15. Testing & verification version5/examples/array_var_examples/array_var_fir.va — a 5-tap weighted-sum model exercising declaration, indexed write, and indexed read end-to-end:

```

module array_var_fir(in, out);
  input in;
  output out;
  electrical in, out;
  real [0:4] coeffs;
  analog begin
    coeffs[0] = 0.1;
    coeffs[1] = 0.2;
    coeffs[2] = 0.3;
    coeffs[3] = 0.2;
    coeffs[4] = 0.2;
    V(out) <+ (coeffs[0]+coeffs[1]+coeffs[2]+coeffs[3]+coeffs[4]) * V(in);
  end
endmodule

```

(coefficients sum to 1.0, so V(out) should track V(in) exactly — a closed-form expected result, same spirit as examples/bus_examples/bus_buffer.va). Compiles with zero errors/warnings; dc_sim.cir DC sweep (dc.txt) confirms V(out) = V(in) exactly across a -2V..2V sweep.

Diagnostics verified by hand with isolated fixtures: coeffs[10] = 1.0; (out-of-range, against [0:4]), coeffs * V(in) (bare reference), and a real [0:2] tmp; declared inside an analog function (unsupported scope) — each produces a clean, correctly spanned error, never a panic.

Regression: cargo test -p syntax -p hir_def -p hir_ty -p hir -p hir_lower passes unchanged (only one snapshot intentionally updated — test_data/ui/bus_bare_reference.log's wording, for the generalized bare-reference message in §12.5). All Part 1 (Laplace), Enhancement-3 (bus nets), Enhancement-2 (indirect branch assignment), and Enhancement-1 (absdelay) examples recompile cleanly with the rebuilt openvaf-r.

16. Known limitations

- No runtime-variable indexing. x[i] for a non-constant i (e.g. a for loop accumulating into an array) is not supported — i must constant-fold, identical to bus-net bit-select's existing constraint. Genuine indexable array storage would need a new MIR memory/array primitive (hir_lower::lower_array is still todo!), out of scope here.
- Module-body scope only. Array variables inside analog function bodies or nested begin..end blocks degrade to scalars with a diagnostic (§12.4) rather than being supported — extending find_var_array's lookup to function/block scope would need a registry keyed on more than just the owning module.
- Default initializers are silently dropped on array declarations (real [0:4] x = 1.0; doesn't assign to any bit) — there's no well-defined per-bit meaning for a single scalar initializer on an array declaration; a diagnostic rejecting the combination outright would be the natural follow-up.

Part 3: Array variables as `laplace_* num/den` arguments

17. Motivation Parts 1 and 2 were built independently and didn't initially compose: a `laplace_* num/den` argument had to be a literal `'{...}'/{...}'` array, and a bare reference to an array *variable* (`coeffs` for `real [0:n] coeffs;`) was rejected by the `BareBusReference` diagnostic (§3.5's array-literal-only `array_elems` never saw anything else). So

```
real [0:1] coeffs;
analog begin
    coeffs[0] = -2e6;
    coeffs[1] = 0.0;
    V(out) <+ laplace_zd(V(in), coeffs, '{3e12, 4e6, 1.0}');
end
```

failed to compile with `'coeffs'` requires a bit-select `[i]` — correct per the rules as they stood, but an unnecessary restriction: there's nothing about the state-space realization that requires `num/den`'s *structure* (element count) to come from literal syntax specifically, as opposed to a previously-declared array variable of fixed size. Only the *element count* needs to be known at compile time (to size the realization) — the *element values* were already lowered as ordinary runtime values either way (see §2.2/§2.3), so an array-variable element written to at runtime is no harder to support than an array-literal element referencing a parameter.

18. Design: treat a bare array-variable reference as an implicit array literal A bare `coeffs` in a `laplace_* num/den` position is now accepted as exactly equivalent to writing out `'{coeffs[0], coeffs[1], ..., coeffs[n]}'` by hand (ascending declared-index order) — no new syntax, no new MIR concept, just one more shape `infer_laplace_array_arg` recognizes for that specific argument position. A *part-select*-style mid-array variable (`coeffs[1:3]`) is not supported — only a bare reference to the *whole* declared array, matching the scope already established for everything else in this enhancement (no part-select anywhere, per Enhancement-3's original scope).

19. Why this needed real (if contained) plumbing, unlike Part 2 Part 2 needed almost no new machinery because `infer_bit_select` resolving to `Ty::Var` flowed transparently through every existing generic mechanism (ordinary reads, ordinary assignment-destination resolution). This case is different: the *bare* `coeffs` (no bit-select at all) was, by design, deliberately rejected everywhere via the `BareBusReference` check inside `infer_expr`'s generic `Expr::Path` arm — and that check is unconditional, with no way to make it context-sensitive (e.g. "unless this is a laplace argument") from inside `infer_expr` itself. Three changes were needed:

1. `openvaf/hir_ty/src/inference.rs` — bypass generic argument inference for `laplace_*`'s `num/den` positions. `infer_builtin` gained a `laplace_nd | laplace_np | laplace_zd | laplace_zp` arm that short-circuits to a new `infer_laplace` function — mirroring the pre-existing `ddx` special case (`ddx`'s second argument is also not an ordinary value-typed expression, and already bypasses the shared `resolve_function_args` machinery the same way). `resolve_function_args` (used by every other builtin/ function call) unconditionally calls `infer_expr` on each argument, which would hit the bare-reference check before a laplace-specific override could intervene — so `laplace_*` needed its own argument loop instead of reusing it.

`infer_laplace` type-checks `args [0]` (input, must be `Real`) normally, dispatches `args [1]/args [2]` through the new `infer_laplace_array_arg` helper, and type-checks an optional `args [3]` (tolerance/nature) normally — picking the matching `LAPLACE_NO_TOL/LAPLACE_TOL/LAPLACE_NATURE_TOL` signature constant (their identity isn't otherwise load-bearing anywhere in the codebase — confirmed by `grep` — so this is purely for diagnostic/ tooling accuracy).

`infer_laplace_array_arg(stmt, arg):`

- if `arg` is `Expr::Array(elems)` (the pre-existing literal-array case): delegates to the existing `infer_array` exactly as before.
- if `arg` is a bare `Expr::Path` whose name matches a known `find_var_array` entry: resolves each `coeffs[bit]` (`lo..=hi`, via the same `Path::new_ident(bus.bit_name(bit)) + resolve_path` pattern `infer_bit_select` already uses) to a `VarId`, records the ordered list in a new `InferenceResult::array_var_refs: AHashMap<ExprId, Vec<VarId>>` field, and assigns the argument `Ty::Val(Type::Array{ty: Real, len})` directly — never calling `infer_expr`/triggering `BareBusReference` for this one expression.
- anything else: falls back to ordinary `infer_expr`, so a genuine scalar argument or typo still gets its normal diagnostic (the usual “expected array” type mismatch).

2. `openvaf/hir_ty/src/validation/body.rs` — stop forcing `num/den` into `BodyCtx::Const`.

The pre-existing laplace validation arm forced every argument past the input signal into a constant-expression context (`validate_const_expr`, which sets `BodyCtx::Const` and rejects ordinary variable references via `allow_var_ref`). This was already stricter than what Part 1’s lowering actually needs — each array element was always lowered as an ordinary `lower_expr` value (supporting e.g. parameter references), never literally constant-folded — so it was leftover-strict scaffolding rather than a real requirement. The laplace arm was split off from `zi_*` (which keeps the original behavior, unaffected since it’s still `is_unsupported` and never reaches this code in practice) and changed to only force-const the *optional trailing* tolerance/nature argument, validating `args[0..3]` (input, num, den) normally — which is what allows an ordinary (non-const) array-variable reference, and its `coeffs[i]` element reads, to pass body validation at all.

3. `openvaf/hir/src/body.rs` + `openvaf/hir_lower/src/expr.rs` — surface the resolved `VarIds` to the lowering pass. `BodyRef` gained `array_var_ref(&self, expr) -> Option<Vec<Variable>>`, projecting `InferenceResult::array_var_refs` into the `hir` crate’s public `Variable` wrapper type (the lowest layer that already has one, since `hir_ty` doesn’t depend on it). `lower_laplace_array_arg` (renamed from the old array-literal-only `array_elems`) checks this first: if present, each element is read directly via the existing `ctx.read_variable(var)` (the same primitive an ordinary `coeffs[i]` read anywhere else in the model already uses) — no `ExprIds`, no `lower_expr` call, since there’s no array-literal syntax node to walk for this case at all. Otherwise it falls back to the original array-literal-element path unchanged.

No changes were needed in `openvaf/hir_def` (item-tree/body lowering), `openvaf/mir*`, `openvaf/sim_back`, or `openvaf/osdi` — once the elements are `Values`, `laplace_roots_to_poly/laplace_state_space` (§3.5) don’t care whether they came from a literal or a variable.

20. Testing & verification The motivating example from §17 now compiles and simulates correctly. Two variants were checked:

- The exact mixed declaration above (`coeffs[0]=-2e6, coeffs[1]=0.0, laplace_zd(V(in), coeffs, '{3e12, 4e6, 1.0})`) compiles with zero errors and simulates to $V(out) \approx 0$ at DC — correct, *given the literal contents written*: `coeffs` has two elements, so it’s a two-root zero list $((s - (-2e6)) \cdot (s - 0) = s^2 + 2e6 \cdot s$, which is zero at $s=0$), not the single zero $(s+2e6)$ an inline comment in the source suggested. This is a property of what the model actually declares (an authoring mismatch between a 2-element array and a 1-root-numerator comment), not a compiler bug — confirmed by checking the equivalent literal-only form `laplace_zd(V(in), '{-2e6, 0.0}, ...)`, which produces the identical (correct, for *that* input) result.
- A corrected one-element version (`real [0:0] zero_coeffs; zero_coeffs[0] = -2e6;`, i.e. an actual single zero at $s=-2e6$) gives $V(out) = 1.3333e-6$ at $V(in) = 2.0$ — exactly $2.0 \cdot 2e6/3e12 = 2.0 \cdot 6.667e-7$, matching the originally-intended $H(s) = (s+2e6)/((s+1e6)(s+3e6))$, $H(0) = 6.667e-7$.

Regression: `cargo test -p syntax -p hir_def -p hir_ty -p hir -p hir_lower` passes unchanged (0 failures, no snapshot updates needed this time). All Part 1/Part 2 fixtures (`laplace_lpf.va`, `laplace_variants.va`, `laplace_zd_only.va`, `array_var_fir.va`) and the bare-reference diagnostic *outside* a `laplace` call (`V(out) <+ coeffs * V(in);`, still correctly rejected) recompile/re-diagnose identically to before this addition.

21. Known limitations (additive to §16)

- Only a bare, whole-array reference is accepted as a `laplace_*` argument — `coeffs[1:3]` (part-select) or any expression more complex than a single identifier naming a known array variable is not recognized as the “array variable” shape and falls through to ordinary scalar inference (producing the standard “expected array” type mismatch rather than a tailored diagnostic).
- Mixing is still one-or-the-other per argument, not per-element — you can write `laplace_zd(in, coeffs, '{...}')` (one arg a variable, the other a literal, as in §17/§20) but not splice a variable element into the middle of a literal’s element list directly; for that, index the variable explicitly inside the literal instead (`'{coeffs[0], 1.5, coeffs[2]}'` — already supported, since each literal element is just an ordinary expression, see §2.3).

Part 4: Fixed a large-integer-literal crash, verified with a real 5th-order Bessel filter

22. Motivation To exercise `laplace_nd` with a non-toy example, a genuine 5th-order analog Bessel low-pass filter was built: `scipy.signal.bessel(N=5, ...)` designs the filter, and the *exact same* coefficients (not hand-derived, avoiding any transcription mismatch) are written into a `laplace_nd` call, so the ngspice/OpenVAF simulation can be cross-checked against an independent analytical computation of the identical transfer function.

Some of a 5th-order Bessel filter’s coefficients are large (e.g. 6134876650875544) and, written as bare digit strings with no `./exponent`, crashed the compiler outright:

```
Panic occurred in file 'openvaf/syntax/src/ast/expr_ext.rs' at line 340
called `Result::unwrap()` on an `Err` value: ParseIntError { kind: PosOverflow }
```

23. Root cause and fix `ast::IntNumber::value()` parsed the literal’s text directly as `i32` and `.unwrap()`ed the result — Verilog-A’s integer type is 32-bit in this compiler (`hir_def::expr::Literal::Int(i32)`), used consistently across ~10 call sites: bit-select indices, bus/array widths, MIR’s `iconst`), so that part is by design. The bug is that any bare integer-shaped literal exceeding `i32` range crashed the whole compiler, even when used in a `Real`-typed context (like a `laplace_nd` coefficient) where it isn’t semantically an integer at all — it’s just a real number the user didn’t bother giving a decimal point.

Two designs were considered:

- Promote to `i64`. Rejected: `Literal::Int` is `i32` everywhere downstream (bit-select indices, bus width folding, MIR’s `iconst`), so this would only move the crash threshold from ~2.1e9 to ~9.2e18 — and the Bessel filter’s own leading coefficient (9.79e18) already exceeds `i64::MAX`, so it would still crash. Widening `Literal::Int` itself to `i64` to fully fix it would ripple through all ~10 call sites for a problem that isn’t really about integer width at all.
- Fall back to a float literal on overflow (chosen). A bare digit string is always valid `f64` syntax too, and `f64`’s range (~1e308) covers any realistic literal. This fixes the crash for literals of any size, not just those between `i32` and `i64::MAX`.

Implemented at two call sites:

- `openvaf/syntax/src/ast/expr_ext.rs`: `IntNumber::value()` now returns `Option<i32>` (None on overflow, instead of panicking); new `IntNumber::value_as_f64()` is the fallback parse.

- `openvaf/hir_def/src/body/lower.rs` (`Literal::`, the actual panic site): on `None`, produces `Literal::` instead of `Literal::`.
- The same `IntNumber::value()` call inside `expr_ext.rs`'s `as_constexprval` (used by bus-width/parameter-constraint constant folding) was fixed the same way, falling back to `ConstExprValue::`.

Because every consumer that actually needs integer semantics (bit-select index, bus/array width) already only matches `Literal::` specifically, a `Literal:: for an oversized literal used in one of those positions automatically falls through to the existing "not a constant integer" diagnostics (NonConstantBitSelectIndex, NonConstantBusWidth) — no new diagnostic code was needed, and it's arguably the correct diagnosis anyway (nothing has 6×10^{15} bits).`

24. Testing & verification

- The exact literals that crashed before now compile and simulate correctly (verified with a standalone fixture reproducing the crash case, giving the expected DC gain).
- A huge literal used where an integer is actually required still degrades gracefully to the pre-existing diagnostics, confirmed for both a bit-select index and a bus/array width — no panic, no behavior change from before this fix in the cases that were already erroring cleanly.
- New regression fixture `test_data/ui/huge_int_literal.va/.log`.
- `cargo test -p syntax -p hir_def -p hir_ty -p hir -p hir_lower` passes unchanged (10/10 ui tests, up from 9, with the new fixture).

25. The Bessel filter example `examples/bessel_filter_examples/`:

- `design_bessel.py` designs a 5th-order analog Bessel low-pass filter (`fc = 1 kHz`) with `scipy.signal.bessel(N=5, Wn=2*pi*1000, analog=True, norm='phase')` and writes the exact coefficients into `bessel5.va`'s `laplace_nd(V(in), num, den)` call (confirmed via `--dump-mir`: exactly 5 `LaplaceState` implicit equations, matching the filter order).
- `compare_bessel.py` computes $H(j\omega)$ (AC) and the step response (transient) directly from the *same* `b`, `a` via `scipy.signal.freqs/ scipy.signal.step`, and overlays them against the ngspice/OpenVAF simulation (`ac_sim.cir/tran_sim.cir`).

Result: numerical-noise-level agreement — max AC gain error $5.6e-7$ dB, max AC phase error $7.2e-7^\circ$, max step-response error $6.6e-6$ V. The AC plot shows the classic Bessel shape (gentle magnitude rolloff, near-linear phase out to -450° across 5 poles); the step response shows the characteristic small ($\sim 1\%$), non-ringing overshoot Bessel filters are chosen for.

26. Diff summary (additive to Parts 1-3's tables)

File	Kind of change
<code>openvaf/syntax/src/ast/IntNumber.rs</code>	<code>value()</code> returns <code>Option<i32></code> instead of panicking; new <code>value_as_f64()</code> ; <code>as_constexprval</code> falls back to <code>ConstExprValue::<float></float></code>
<code>openvaf/hir_def/src/body/lower.rs</code>	<code>Literal::<new></new></code> falls back to <code>Literal::<float></float></code> on <code>i32</code> overflow instead of panicking
<code>openvaf/test_data/ui/huge_int_literal.va/.log</code>	new regression fixture

No changes to `openvaf/hir_ty`, `openvaf/hir_lower`, `openvaf/mir*`, `openvaf/sim_back`, or `openvaf/osdi` — this was purely a parsing/lowering robustness fix, unrelated to the Laplace realization itself.

Enhancement-5 — Verilog-A Module Instantiation in OpenVAF

This document describes every source-code change made to OpenVAF in the `version6/` directory, on top of `version5/` (Enhancement-4, Laplace-domain transfer-function operators), to implement Verilog-A module instantiation — one module placing other modules as sub-circuit elements on its own nets, e.g.:

```
module resistor(p, n);
    inout p, n;
    electrical p, n;
    parameter real r = 1000;
    analog begin
        I(p, n) <+ V(p, n) / r;
    end
endmodule

module divider(in, out, gnd);
    inout in, out, gnd;
    electrical in, out, gnd;
    resistor #(.r(1e3)) r1(in, out);
    resistor #(2e3) r2(.p(out), .n(gnd));
    resistor rarr[0:1](out, gnd);
endmodule
```

Full feature scope, confirmed up front with the user (“full support and implementation”, not a cut-down v1):

- Both positional (`resistor r1(in, out);`) and named (`resistor r1(.p(in), .n(out));`) port connections, including open ports (`inst(a, , c);` — a blank slot leaves that port internally floating).
- Both positional (`#(1e3, 2e3)`) and named (`#(.r(1e3))`) parameter overrides.
- Instance arrays (`resistor rarr[0:3](out, gnd);`), expanding to N independent instances at compile time.
- Arbitrary nesting depth (a module instantiating a module instantiating a module, ...).
- Cyclic instantiation is a hard compile error, diagnosed by name (not a stack overflow).

1. What was actually there already (and what wasn't)

Unlike Enhancement-4's `laplace_*` operators (front-end-complete but lowering-incomplete), module instantiation had zero support anywhere in the compiler before this enhancement:

- The grammar's `ModuleItem` production (`openvaf/syntax/verilog.ugram`) had exactly 7 variants (`BodyPortDecl`, `NetDecl`, `AnalogBehaviour`, `Function`, `BranchDecl`, `VarDecl`, `ParamDecl`, `AliasParam`) — no instantiation form, and no parser code path for it either.
- `hir::ScopeDef::ModuleInstance(Module)` existed but was dead code from a user's perspective: it's only ever produced for top-level module declarations (`ScopeDefItem::ModuleId` in the root scope), never for an actual instantiation statement, because no such statement could be parsed.
- Everything downstream of `hir_def` — `hir_ty`, `hir_lower`, `mir*`, `sim_back::DaeSystem`, `osdi::OsdDescriptor` — is architected around exactly one flat module per compiled artifact: per-module-local node IDs (`LocalNodeId = Idx<Node>`), one `DaeSystem` built per module, one flat node/parameter/Jacobian table per OSDI descriptor. There is no composition/nesting primitive anywhere in that stack, and building one would mean risky, invasive surgery through the entire backend.
- No TODOs, comments, or partial scaffolding anywhere suggested hierarchy was ever planned.

1.1 Why this isn't solved with a CST/HIR-level splice The first design instinct — clone the sub-module's parsed syntax subtree, rename its identifiers, and splice it into the parent's tree before `hir_def` runs — does not work with this codebase's architecture. Every layer that consumes syntax (basedb::AstIdMap, hir_def::ItemTree, hir_def::body::Body::body_with_sourcemap_query, lint/diagnostic collection) independently re-derives its input from `db.parse(root_file)`, keyed purely by `FileId`, using (`TextRange`, `SyntaxKind`) pointers into *that one real parse*. There is no seam to hand a mutated/spliced tree to all of those consumers at once — a change made at one layer (e.g. after parsing) is invisible to every other layer, which independently re-parses the *original* file text.

The only mechanism consistent with this architecture is text-level elaboration: synthesize a fully flattened Verilog-A source for any module that contains instantiation statements — inlining each instantiated module's own declarations, alpha-renamed per instance, with ports bound to the caller's net expressions and parameters bound to the caller's override expressions — register that synthesized text as a new file, and feed *that* through the entirely unmodified `parse` → `hir_def` → `hir_ty` → `hir_lower` → `mir*` → `sim_back` → `osdi` pipeline. This is conceptually the same trick SPICE simulators use for `.subckt`/X-instance expansion.

Part 1: Grammar and parser (**openvaf/syntax**, **openvaf/parser**, **sourcegen**)

2. New grammar productions `openvaf/syntax/veriloga.ungram` gained a `ModuleItem` variant and five supporting rules:

```
Instantiation =
  AttrList* module:NameRef ParamOverrides?
  (InstanceUnit (',' InstanceUnit)*) ';'

ParamOverrides =
  '#' '(' (ParamAssign (',' ParamAssign)*)? ')'

ParamAssign =
  ('.' name:Name '(' val:Expr ')') | val:Expr

InstanceUnit =
  name:Name width:Range? PortConns

PortConns =
  '(' (PortConn (',' PortConn)*)? ')'

PortConn =
  ('.' name:Name '(' net:Expr ')') | net:Expr
```

`Range` (the `[msb:lsb]` clause) is reused verbatim from Enhancement-3/4's vectored-net support for instance-array ranges. `PortConn`/`ParamAssign` each produce a single AST node with two independently-optional fields (name, net/val) rather than a named/positional enum — a bare `PortConn` with neither field present represents an open/unconnected port (an empty slot between commas, e.g. `inst(a, , c)`).

New `SyntaxKinds` (`INSTANTIATION`, `PARAM_OVERRIDES`, `PARAM_ASSIGN`, `INSTANCE_UNIT`, `PORT_CONNS`, `PORT_CONN`) were registered in `sourcegen/src/ast/src.rs`'s `KindsSrc::nodes` list; running `cargo test -p sourcegen ast` regenerated `openvaf/tokens/src/parser/generated.rs` and `openvaf/syntax/src/ast/generated/{nodes,tokens}.rs` from the updated `ungram` (standard workflow in this codebase — the test writes the files and fails once, then passes on the immediate re-run).

3. Parser disambiguation `openvaf/parser/src/grammar/items/module.rs`'s `module_items()` dispatch previously sent every bare IDENT unconditionally to `net_decl::<false>` (a discipline-name-first net declaration, e.g. `electrical p, n;`). Module instantiation (`resistor r1(in, out);`) also starts with a bare IDENT, so a 2-token lookahead disambiguates the two, added as a new `is_instantiation` guard before the existing IDENT arm:

- # immediately after the first identifier is an unambiguous instantiation signal (`resistor #(...` `r1(...)`) — net declarations never contain #.
- Otherwise: a second IDENT followed by `(` or `[` (instance ports, or an instance-array range) means instantiation; followed by `,`/`;` means an ordinary (possibly single-net) net declaration.

This is exact and requires no backtracking. `instantiation()`, `param_assign()`, `instance_unit()`, `port_conns()`, and `port_conn()` were added to `module.rs` mirroring the existing `branch_decl/net_decl` parsing style.

Part 2: `hir_def` item tree, name resolution, diagnostics

4. Item tree representation `openvaf/hir_def/src/item_tree.rs` gained `ModuleItem::Instantiation` and a new `Instantiation` item-tree node:

```
pub struct Instantiation {
    pub name: Name,           // instance name (or synthesized "r[2]" for an array
                             ↪ element)
    pub unit_idx: usize,      // which comma-separated InstanceUnit this is
    pub array_index: Option<i32>,
    pub module: Name,         // referenced module name, unresolved
    pub ast_id: AstId<ast::Instantiation>,
}
```

One `Instantiation` entry is created per array element (mirroring how `Net/Var/Param` handle comma-separated declarations — all names from one source statement share an `ast_id`, disambiguated by index), reusing `bus_bit_name/fold_width_range` from Enhancement-4's bus-range folding for the `[msb:lsb]` instance-array expansion. Deliberately not captured here: port/parameter binding details — those are read straight from the AST (via `ast_id`) by name resolution and by the elaboration pass, exactly like how `Net/Port` only cache their discipline in the item tree and leave everything else to the AST.

5. Name resolution (`openvaf/hir_def/src/namer/collect.rs`) Module instantiation needed the collector to change from a single forward pass to two passes: originally, `collect_root_map()` called `collect_module()` once per module in file order, which both registered the module's name in the root scope *and* processed its internal items in the same step. A module instantiating another module declared later in the same file would then fail to resolve, purely because of a body/root collector ordering, not a Verilog-A semantic. Fixed by splitting `collect_module` into `predeclare_module` (registers every module's name and opens its scope) and `collect_module_items` (processes internal items, including instantiation resolution), and running all predeclarations before any item collection.

Each instantiation is resolved against the (now fully predeclared) root scope, producing a new `ScopeDefItem::InstantiationId(InstantiationId)` — deliberately not reusing `ScopeDef::ModuleInstance`, which represents a module *definition*; an instantiation is a *use*. `InstantiationId/InstantiationLoc` follow the exact `impl_intern!` pattern already used for `BranchId/FunctionId/etc`.

6. New diagnostics A DFS with a 3-color visiting-set over the file's instantiation graph detects cycles (`DefDiagnostic::CyclicInstantiation`) before any per-site resolution runs, so a self-/mutually-

recursive instantiation is a clean compile error rather than infinite recursion. Per-instantiation-site diagnostics (checked once per distinct `InstanceUnit`, not once per array element, to avoid N duplicate reports for an N-wide array) resolve against the target module's own item tree, no flattening required:

- `UnknownInstantiatedModule` — referenced module doesn't exist in the file.
- `InstancePortCountMismatch` — positional port list length $\neq$ target's port count.
- `UnknownInstancePort` — a named `.port(net)` names a port the target doesn't have.
- `UnknownInstanceParam` — a named `.param(value)` names a parameter the target doesn't have.
- `TooManyInstanceParams` — more positional overrides than the target has parameters.

All five are `hir_def::namer::diagnostics::DefDiagnostic` variants (the existing channel used for `AlreadyDeclared`), rendered through the same `Diagnostic/Report` machinery as every other compiler error.

Part 3: Elaboration — the text-flattening pass (`openvaf/hir/src/elaborate.rs`)

7. Where it runs `elaborate_instantiations(db: &mut CompilationDB)` runs once, as ordinary Rust code, at the very end of `CompilationDB::new` (`openvaf/hir/src/db.rs`) — not as a salsa query hooked into the preprocess/parse chain (that was the original plan; direct inspection of `AstIdMap/item_tree/body_with_sourcemap_query`, which all independently call `db.parse(root_file)`, showed there's no query-graph seam to intercept — see §1.1). Instead:

1. Cheap fast path: `db.item_tree(root_file)` is checked for any `ModuleItem::Instantiation` anywhere in the file; if none, return immediately. This keeps the pass a true no-op (one item-tree lookup) for the overwhelming majority of `.va` files, which never use the feature.
2. If `def_map.diagnostics` already contains a `CyclicInstantiation` diagnostic, skip elaboration entirely (a cyclic graph can't be flattened — recursing would never terminate) and let the normal diagnostic-printing path surface the cycle against the *original* file.
3. Otherwise, walk the root file's already-parsed `SourceFile::items()`; for each `ModuleDecl`, `flatten_top_level_module` produces its final text (verbatim, unless it directly contains an instantiation).
4. The concatenated result is registered as a new virtual file via `Vfs::add_virt_file`, the original file's `include_dirs/macro_flags/global_lint_overwrites` salsa inputs are copied onto the new `FileId` (they're per-`FileId` inputs, so the synthetic file needs its own copies to behave identically to the real one), and `CompilationDB::root_file` is redirected to it via a new `pub(crate) fn set_root_file`.

Everything from `hir_def::item_tree` onward — `hir_ty`, `hir_lower`, `mir*`, `sim_back`, `osdi`, `mir_llvm` — required zero changes: they simply compile what looks like an ordinary, hand-written flat module.

8. How flattening actually works `render_with_holes(text, holes, scope)` is the one primitive everything else is built from: it tokenizes text (via the existing lexer crate), rewrites `SimpleIdent` tokens using an exact-match `scope.subst: HashMap<String, String>`, and — for each `(byte_range, replacement)` in `holes` — emits the replacement verbatim instead of individually inspecting the tokens inside that range. That last property is what makes composing renamed scopes correct: an already-fully-resolved nested instance's text, or an override expression written in a caller's scope, is never accidentally re-renamed using the wrong module's `subst` map, because the tokenizer never looks inside a hole.

`scope`: `Scope` bundles two things: `subst` (plain whole-identifier renames) and `bus_ports: HashMap<Name, BTreeMap<i32, String>>` (bus-typed ports — see below). `render_with_holes` always starts by computing bus-port holes via `find_bus_port_holes` and merging them with whatever holes the caller already had, before doing the token pass.

Rendering one instantiated module (`render_instance_content`) builds a Scope covering every name the target module itself declares:

- Scalar ports are bound to the caller's connected net text (already resolved at the *caller's* level — see "resolve, then recurse" below), or, if left open, get a fresh internal net (`{prefix}open__{port}`, redeclared with the port's own discipline) — inserted into `scope.subst`.
- Bus-typed ports need a fundamentally different mechanism: an ordinary rename ($p \rightarrow \text{prefix_}p$) is one whole-token substitution, but a bus port's bit 0 and bit 1 need to become *different* identities, and the source text only ever contains the bare base identifier with the bit-select as separate tokens right after it — there's no single token to hang a per-bit answer on. These go into `scope.bus_ports[base]` instead: a per-bit map, each bit either the caller's binding (itself possibly *sliced* from a caller-scope bus of matching width — see below) or a freshly declared net if left open. `find_bus_port_holes` then scans for ident '[' int_literal ']' token sequences matching a `bus_ports` base name and replaces the whole sequence as one hole.
- Internal nets/vars/branches/functions/alias-params get a unique per-instance prefix (`{prefix}{name}`) in `scope.subst`.
- Internal bus/array nets and variables (Enhancement-3/4) are renamed by their *base* name only ($\text{bus} \rightarrow \{\text{prefix}\}\text{bus}$) in `scope.subst` — `bus[3]`-style bit-select syntax keeps the base identifier as its own token, so this one substitution correctly renames every bit without needing per-bit entries (this is the mechanism internal buses use, in contrast to bus *ports*, which can't use it — see above).
- Parameters are renamed like other locals; an override (if supplied) replaces only the *default-value* sub-expression inside the parameter's own (renamed) declaration — resolved once at declaration time, not patched at every reference site.

The target module's own port-direction (`inout p, n;`) and discipline (`electrical p, n;`, including a vectored `electrical [3:0] p;`) declarations are dropped, not merely renamed, when inlining an instance — a port's identity now refers to an already-declared net from an outer scope (or a freshly declared one), so re-declaring it inside the inlined body would collide with that outer declaration. `NetDecl/BodyPortDecl` items get filtered per-*base-name* (a single `electrical` line may legally mix port and non-port names/buses).

Resolve, then recurse: an instantiation's port/parameter argument expressions are written in the *instantiating* module's scope. Each recursive call receives already-fully-resolved (renamed) bindings — the resolution (`apply_rename/resolve_port_bindings` against the parent's own Scope) happens once, in the parent, immediately before recursing, never inside the child. This is what lets `#(.r(r_base*2))` (an override expression referencing the *parent's own* parameter) and arbitrarily deep nesting compose correctly without a second rename pass ever touching already-resolved text.

Bus/array slicing (`find_matching_caller_bus`) is the one heuristic layered on top of "resolve, then recurse": a port actual, or an instance-array port actual, is sliced per-bit/per-element only when it's a *bare identifier* naming a bus, in the instantiating module's own scope, whose bit width exactly matches what needs slicing:

- A bus-typed target port (`bus_resistor br(a, b);`, where `bus_resistor` declares input `[1:0] p;` `electrical [1:0] p;`) slices caller bus `a` bit `i` onto target port `p` bit `i` (`bind_port`, aligned by relative position, not absolute index — so a caller bus `[7:4]` correctly maps onto a target bus `[3:0]`).
- An instance array (`resistor rarr[0:3](p, gnd);`) slices a matching-width caller bus `p` onto array element `i`'s port (`expand_instantiation`'s per-element loop) — this is the array-level analogue of the same idea, reusing the identical `find_matching_caller_bus` width/name check.

Anything that doesn't match this heuristic (a plain scalar net, a mismatched width, a non-trivial expression) falls back to plain `bind/broadcast` — e.g. `resistor rarr[0:3](out, gnd);` where `out` is an ordinary scalar net still connects every array element to the same `out/gnd`, exactly like the original (pre-slicing) behavior.

Part 4: Verification

9. End-to-end result `examples/instantiation_examples/resistor_divider.va` exercises the full feature set in one file: nested instantiation (`divider` $\rightarrow$ `buffer` $\rightarrow$ `resistor`), named and positional ports, named and positional parameter overrides, and an instance array.

- MIR/DAE structural check: building `divider`'s `CompiledModule` produces a `DaeSystem` with exactly 3 unknowns (`in`, `out`, `gnd` — the module's 3 real ports; no spurious extra unknowns, confirming port binding merges node identities rather than adding equations) and 7 Jacobian entries, consistent with two parallel-resistor groups cross-coupling those 3 nodes.
- Real OSDI + ngspice DC sweep: `openvaf-r resistor_divider.va -o resistor_divider.osdi` (built with `--features llvm18` against a Homebrew LLVM 18 toolchain) produces a working `.osdi` shared library; loaded into ngspice (`examples/instantiation_examples/dc_sim.cir`), a `.dc Vin -2 2 0.5` sweep is cross-checked in `examples/instantiation_examples/compare_divider.py` against the analytically combined resistor network (`buffer` $\parallel$ `r1` between `in/out`; `r2` $\parallel$ `rarr[0]` $\parallel$ `rarr[1]` between `out/gnd`) — matches to $\sim 1e-9$, i.e. solver precision.
- Bus-port/array-slicing check (`openvaf/test_data/ui/instantiation_bus.va`): a module with a 2-bit bus port (`bus_resistor`, ports `p/n` each `[1:0]`) instantiated as `bus_resistor br(a, b)`; where `a/b` are 2-bit buses in the caller, plus `resistor rarr[0:1](a, c)`; (per-element array slicing onto the same bus `a`) and `resistor rbroadcast[0:1](c, d)`; (plain scalars — confirms broadcast still applies where slicing doesn't). Compiled to a real `.osdi` and driven with ideal DC sources at `a[0]=1V/a[1]=2V`: with nothing else loading `b[0]/b[1]`, the zero-current KCL condition through `br`'s resistors forces `b[0]=a[0]` and `b[1]=a[1]` *exactly* — confirmed by ngspice (`v(b[0])=1.0, v(b[1])=2.0`), verifying the bus port bound bit `i` to bit `i`, not some other pairing.
- Regression: every pre-existing `.va` example from Enhancements 2-4 (`laplace_examples`, `bus_examples`, `array_var_examples`, `bessel_filter_examples`, `combined_examples`, `absdelay_examples`, `indirect_assignment_examples`), plus `resistor_divider.va`, still compile unchanged through the pipeline after the bus-port/slicing work. The full fast test suite (`cargo test --workspace`, minus two pre-existing failures confirmed to already fail identically and unmodified in `version5` — a stale MIR-value-numbering snapshot in `sim_back`'s `dae/init/topology` unit tests, and a header-parsing quirk in `sourcegen`'s `osdi::gen_osdi_structs` — neither touched by this enhancement) passes with zero new failures.
- Cross-``include` instantiation (`examples/instantiation_examples/resistor_divider_include.va` + `resistor_lib.va`): a module can instantiate a target declared in a *different* file, pulled in via ``include`, with no special-casing anywhere in the elaboration code. This falls directly out of where the pass sits in the pipeline (§7): ``include` is a preprocessor directive, resolved by the preprocessor crate *before* `db.parse` ever runs, so by the time elaboration inspects `parse.tree().items()`, the included file's modules are already merged into the same single parse tree as the including file's own modules — indistinguishable from a same-file declaration. The flattened output (and every DC/AC/transient result) is byte-for-byte/numerically identical to the equivalent same-file version.

New fixtures:

- `openvaf/test_data/item_tree/instantiation.{va,item_tree,def_map}` — positional/named ports, positional/named params, and an instance array, checked at the item-tree and name-resolution level.
- `openvaf/test_data/ui/instantiation_errors.{va,log}` — exercises all four new diagnostics in one file (unknown module, port-count mismatch, unknown param override, mutually-

recursive cycle).

- `openvaf/test_data/ui/instantiation_ok.{va,log}` — the nested/positional/ named/array-instance case, asserting zero diagnostics.
 - `openvaf/test_data/ui/instantiation_bus.va` — bus-typed ports and per-element array slicing (both the sliced and the broadcast case in one file), asserting zero diagnostics.
-

10. Known limitations

- No span provenance into inlined code. Diagnostics for code that originated inside an instantiated module point at the synthesized flattened file (`<name>__elaborated.va`), not the original module's source location. The codebase's `preprocessor::sourcemap` machinery (`CtxSpan/SourceContext`) solves exactly this problem for ``include/macro` expansion, but hooking into it would have meant operating at the token-stream level inside the preprocess salsa query — which, per §1.1/§7, isn't where this pass can run. Diagnostics are still fully readable, just not pointing at the file the user actually wrote for inlined content.
- Bus-typed ports and per-element instance-array slicing are supported, via one heuristic (`find_matching_caller_bus`, `openvaf/hir/src/ elaborate.rs`): a port actual is sliced only when it is a *bare identifier* naming a bus, in the instantiating module's own scope, whose bit width exactly matches what needs slicing — the target bus port's width (`bus_resistor br(a, b);`, wiring bit *i* of port *p/n* to bit *i* of caller-scope buses *a/b*), or the instance array's element count (`resistor rarr[0:3](p, gnd);` where *p* is itself a matching-width bus, wiring element *i* to *p[i]*). Anything else (a non-bus net, a mismatched width, a non-trivial expression) falls back to plain bind/broadcast, matching the original (*v1*) semantics — so `resistor rarr[0:1](out, gnd);` where *out* is an ordinary scalar net still connects every array element to the same *out/gnd*, as before. A bus port needed a different substitution mechanism than everything else in this pass, since a plain identifier-*rename* can't express "bit 0 and bit 1 become different identities" — `find_bus_port_holes` scans for `'[' int_literal ']'` token sequences matching a bus port's base name and replaces the whole sequence as one hole, reusing the existing hole-splicing machinery rather than teaching the core renamer a new substitution kind. Combining both at once (a bus-typed port *on* an array instance, e.g. `bus_resistor barr[0:3](p, q);`) is not sliced on the array dimension — only the per-bit port dimension is resolved.
- Escaped identifiers (`\foo`) inside an instantiated module aren't renamed by the token-level substitution (only `SimpleIdent` tokens are matched) — a very rare Verilog-A construct in practice.
- A module that is instantiated by another also continues to be compiled as its own standalone top-level OSDI descriptor if it appears at the top level of the file, unchanged from today's `collect_modules` behavior (every top-level module is always compiled). This is a real, useful capability worth calling out explicitly: a single `.osdi` file already exposes *every* top-level module in the source `.va` file as an independently `.model`-able SPICE device, so a netlist can compose two *separately compiled* OSDI descriptors from the same file (ordinary SPICE-level hierarchy) alongside Verilog-A-level `instantiate` (compile-time inlining within one descriptor) — two complementary mechanisms, not competing ones. See `examples/instantiation_examples/dc_sim_multi_model.cir` for a worked example (chaining standalone buffer and divider instances from `resistor_divider.osdi` in one netlist) — including a naming-collision gotcha (`resistor` collides with ngspice's own built-in `resistor .model` keyword, unrelated to OpenVAF/OSDI).

11. Diff summary

File	Kind of change
openvaf/syntax/veriloga.ungram	New Instantiation/ParamOverrides/ParamAssign/InstanceUnit/PortC
sourcegen/src/ast/src.rs	grammar rules Registers the 6 new SyntaxKinds consumed by codegen
openvaf/tokens/src/parser/generated.rs, open- vaf/syntax/src/ast/generated/{nodes,tokens}.rs	Regenerated via cargo test -p sourcegen ast
openvaf/parser/src/grammar/items/module.rs	2-token lookahead disambiguation + instantiation/param/port parsing
openvaf/hir_def/src/item_tree.rs	Instantiation item-tree node, ModuleItem::Instantiation, NonConstantInstanceArrayWidth diagnostic
openvaf/hir_def/src/item_tree/{lower,diagnostic_rendering.rs}	lowering, diagnostic rendering, pretty-printing for the new node
openvaf/hir_def/src/lib.rs	InstantiationId/InstantiationLoc interning
openvaf/hir_def/src/db.rs	New intern_instantiation salsa query
openvaf/hir_def/src/nameres.rs	ScopeDefItem::InstantiationId variant + all exhaustive-match sites
openvaf/hir_def/src/nameres/collect.rs	Two-pass module collection (predeclare, then collect items); instantiation resolution + 5 new diagnostics
openvaf/hir_def/src/nameres/diagnostics.rs	5 new DefDiagnostic variants + Report rendering, plus ReservedModuleName (§12)
openvaf/hir_ty/src/inference.rs	ScopeDefItem::InstantiationId treated as Ty::Scope (matches ModuleId/BlockId)
openvaf/hir/src/lib.rs	ScopeDefItem::InstantiationId in the "implementation detail" bucket of declarations()
openvaf/hir/src/db.rs	pub(crate) fn set_root_file; calls elaborate::elaborate_instantiations at the end of CompilationDB::new
openvaf/hir/src/elaborate.rs	New — the text-flattening elaboration pass (§7-8)
openvaf/hir/Cargo.toml	Adds lexer/tokens path dependencies (for token-level rename)
openvaf/basedb/src/lints.rs	New reserved_module_name lint (§12)
openvaf/test_data/item_tree/instantiation.*	New regression fixtures
openvaf/test_data/ui/instantiation_*.*, open- vaf/test_data/ui/reserved_module_name.*	
openvaf/test_data/ui/{ddx,formatting,functionality}.*	Updated (UPDATE_EXPECT=1) — pre-existing fixtures name their module diode, now correctly flagged by §12's new lint
examples/instantiation_examples/	New end-to-end examples + ngspice cross-checks (§9, §11)

No changes to openvaf/mir*, openvaf/sim_back, openvaf/osdi, or openvaf/mir_llvm — by design,

per §1.1/§7.

12. `reserved_module_name` lint

The resistor/ngspice-built-in collision found while building §11's multi-model example turned out to be worth catching at *compile time*, not just documenting: a new lint, `reserved_module_name` (`openvaf/basedb/src/lints.rs`, doc id 18, warn by default), fires when a top-level module's name matches — case-insensitively — one of ngspice's built-in native SPICE device names (`RESERVED_NGSPICE_DEVICE_NAMES` in `openvaf/hir_def/src/names/collect.rs`, collected from every `.name = "..."` in `ngspice-46/src/spicelib/devices/**/*.c`; ~55 names — Resistor, Capacitor, Diode, BSIM4, Mos1, etc.). This was a natural fit for OpenVAF's existing lint framework (`basedb::lints`, same machinery `port_without_direction/trivial_probe` already use): fully suppressible (`-A reserved_module_name`) and promotable to a hard error (`-E reserved_module_name`) via the standard CLI flags, with no special-casing needed beyond registering the lint and implementing `Diagnostic::lint()` on the new `DefDiagnostic::ReservedModuleName` variant (`openvaf/hir_def/src/names/diagnostics.rs`) to return it.

The check runs once per module in `predeclare_module` (`openvaf/hir_def/src/names/collect.rs`) — the same place module names are first registered into the root scope — so it needs nothing beyond the name already available there, and fires for every top-level module regardless of whether it's ever instantiated.

Verified: `.model resmodel resistor (r=500)` in ngspice is empirically confirmed to silently fail to bind to the OSDI resistor module (falls through to ngspice's own built-in resistor parsing instead, producing an "unrecognized parameter" warning and wrong circuit behavior) — this isn't a hypothetical. Running the lint against the existing test suite surfaced the same collision in three *pre-existing*, unrelated fixtures that happened to name their module `diode` (`openvaf/test_data/ui/{ddx, formatting, function}.va`) and in this enhancement's own resistor-named examples — all expected `.log` snapshots were updated to include the new warning (`UPDATE_EXPECT=1`), zero other regressions.

Enhancement-6 — Missing Basic Verilog-A Features in OpenVAF-r

This document describes every source-code change made to OpenVAF-r in the `version7/` directory, on top of `version6/` (Enhancement-5, module instantiation), following a deep gap analysis of the compiler against the Verilog-A/Verilog-AMS LRM across five categories: operators, scale factors, keywords, math functions, and compiler directives.

0. Gap analysis summary

A systematic audit (five parallel research passes over the OpenVAF-r source) found:

Category	Verdict
Scale factors (T,G,M,K/k,m,u,n,p,f,a)	Complete — all 10 correct.
Math functions (ln,exp,sqrt,sin,...,hypot,limit,clog2)	Complete.
Operators	Essentially complete for the analog-only LRM subset (<code>**</code> , <code>^~/~^</code> , <code><</>></code> , <code><+</code> all present). <code>==</code> / <code>!=</code> , <code>{}</code> concat/replication, reduction ops, <code>++</code> / <code>--</code> , compound assign are digital/SystemVerilog constructs with no semantic in a pure-analog compiler — correctly out of scope. <code><<</>>></code> were lexed but dead — fixed in this enhancement (§2).
Keywords	<code>generate/genvar</code> blocks entirely unimplemented (out of scope here — comparable in size to a whole enhancement on its own). <code>cross/above/timer</code> missing entirely (deferred — see §6). <code>zi_*</code> , <code>last_crossing</code> , <code>slew</code> , <code>transition</code> were parsed/type-checked but explicitly stubbed as unsupported — implemented in this enhancement (§4-5).
Compiler directives	Only 9 of ~17 standard directives worked; everything else hard-failed compilation with <code>MacroNotFound</code> instead of being ignored — fixed in this enhancement (§1).

Sections below cover what was actually implemented, in the order it was done.

1. Compiler directives (**openvaf/preprocessor**)

Real foundry/vendor `.va` files routinely carry boilerplate directives that this compiler previously treated as undefined macro calls, hard-failing the whole compilation. Added recognition (and correct token-consumption) for:

```
`undefineall, `celldefine, `endcelldefine, `default_discipline, `default_nettype, `unconnected_drive, `nounconnected_drive, `timescale, `line, `pragma.
```

1.1 Design

- `openvaf/preprocessor/src/parser.rs`: new `CompilerDirective` enum variants, matched by literal text in `compiler_directive()`.
- Two new Parser helpers:
 - `skip_rest_of_line(&mut self, err)` — for directives whose argument grammar isn't worth parsing precisely (``timescale`, ``line`, ``pragma`, ``unconnected_drive`, ``default_nettype`): scans the raw source for the next `\n` and discards every token up to it. Robust regardless of how the argument text happens to tokenize, since Verilog/Verilog-AMS directives with inline arguments are always terminated by end-of-line, not by `;`.

- `bump_directive_and_capture_ident(&mut self, err) -> Option<&str>`
— for ``default_discipline` (captures the discipline name, then falls through to `skip_rest_of_line`).
- `openvaf/preprocessor/src/processor.rs`: Processor gained a `default_discipline`: `Option<&'a str>` field, set by the new directive but not yet wired into net-discipline resolution — doing that fully would mean threading it through `hir_def`'s name-resolution/discipline-inference code (every net currently requires an explicit discipline; see `hir_ty/src/validation.rs:699`, "no discipline for net"), which is a separate, larger feature. Recording it at least means the directive no longer breaks compilation.
- ``undefineall` clears `self.macros` for real.
- Everything else is a documented no-op (matches how real simulators treat directives they don't implement — ignorable, not fatal).

1.2 Tests `openvaf/preprocessor/src/tests.rs::misc_directives` exercises all ten new directives in one file, asserting zero diagnostics and that the expanded output contains only the real module body (golden file `test_data/misc_directives_expanded.va`).

2. <<< / >>> arithmetic shift operators

2.1 A pre-existing lexer bug While wiring these up, found that `openvaf/lexer/src/lib.rs`'s three-symbol match arms for `ShlA/ShrA` only called `self.bump()` once instead of twice, so `<<<` tokenized as a 2-character `ShlA` token followed by a stray `<` — a real, independent bug, not something introduced by this work:

```
// before (only consumes 2 of the 3 characters):
'<' if self.first() == '<' && self.second() == '<' => {
    self.bump();
    ShlA
}

// after:
'<' if self.first() == '<' && self.second() == '<' => {
    self.bump();
    self.bump();
    ShlA
}
```

Same fix applied to `ShrA`. Verified via a standalone lexer harness (`Literal / Whitespace / ShlA len=3 / ...` instead of `len=2 + stray Lt`).

2.2 Wiring

- `openvaf/parser/src/grammar/expressions.rs`: `<<</>>>` added to the Pratt-parser precedence table at the same tier as `<</>>`.
- `openvaf/syntax/src/ast/expr_ext.rs`: new `BinaryOp::ArithmeticLeftShift / ArithmeticRightShift` variants, `op_details()/Display` updated.
- `openvaf/syntax/veriloga.ungram`: `BinExpr` operator list updated (documentation; codegen for this node's accessors is hand-written, not ungram-generated).
- `sourcegen/src/mir_instructions.rs` + regenerated `openvaf/mir/src/instructions/generated.rs / openvaf/mir/src/builder/generated.rs`: new `Opcode::Iashr` (arithmetic — sign-extending — right shift). `<<<` reuses `Opcode::Ishl`: per the LRM, arithmetic and logical left shift are identical (both always zero-fill); only right shift differs (logical zero-fills, arithmetic sign-extends).

- `openvaf/hir_ty/src/inference.rs`, `openvaf/hir_lower/src/expr.rs`: type inference and MIR lowering for the two new `BinaryOp` variants.
- `openvaf/mir_llvm/src/builder.rs`: `Opcode::Iashr` $\rightarrow$ `LLVMBuildAShr` (vs. `Opcode::Ishr` $\rightarrow$ `LLVMBuildLSshr`).
- `openvaf/mir_interpret/src/lib.rs`, `openvaf/mir_opt/src/const_eval.rs`, `openvaf/mir_opt/src/simplify.rs`, `openvaf/mir_autodiff/src/lib.rs`, `openvaf/mir_autodiff/src/builtins.rs` and the six other places that pattern-match `Opcode` exhaustively (or via `unreachable!()/matches!()`, which the compiler doesn't flag as non-exhaustive) needed the new variant added too — found by running actual `.va` files through each optimization pass, not just `cargo check` (several of these use wildcard `_ => unreachable!()` arms that compile fine but panic at runtime on an unhandled opcode).

2.3 Verification 4 <<< 1 constant-folds to 8 (same as <<); -4 >>> 1 constant-folds to -2 (arithmetic/sign-extending), confirmed via `--dump-mir` showing the correctly-folded `0x1.8p2 = 6.0` for `(4<<<1) + (-4>>>1)`.

3. `slew()` / `transition()` — compile-time rate-limited tracking loop

Previously lowered as a literal identity passthrough (`self.lower_expr(args[0])`) and gated behind `is_unsupported()` specifically to stop that silently-wrong stub from reaching users.

3.1 Numerical approach The LRM's `slew()` is an ideal (non-smooth, "bang-bang") rate limiter: track the input exactly whenever possible, else ramp at the bound. That's not directly expressible as a well-posed continuous residual — a naive `dy/dt = clamp(dx/dt, -neg, pos)` formulation leaves the DC operating point undetermined (any `y` satisfies `dy/dt = 0` at DC). Instead:

`dy/dt = clamp(K * (x - y), -max_neg_rate, max_pos_rate)` (K = 1e9, large)

a saturating tracking loop — well-posed at DC (`y = x` uniquely, since `K` is large), and reproduces the rate-limited ramp whenever `x` moves faster than the bound allows, converging to the ideal limiter as `K` $\rightarrow \infty$. Implemented as an ordinary `idt`-style implicit equation (`ImplicitEquationKind::Slew(u32)`) — no simulator/OSDI changes needed, same category as `laplace_*`.

`transition(x, td, trise, tfall[, tol]) = slew(absdelay(x, td), 1/trise, 1/tfall)`: the delay stage reuses `absdelay`'s exact mechanism (factored out into a new shared `lower_delay` helper), the rate stage reuses the same tracking loop (`ImplicitEquationKind::Transition(u32)`). `trise/tfall` are transition *times* per the LRM; converting to a rate via `rate = 1/t` assumes a unit-amplitude transition — exact for the common comparator-style 0/1 input, an approximation for arbitrary-amplitude inputs.

New code: `openvaf/hir_lower/src/expr.rs` (`lower_slew`, `lower_transition`, `lower_delay`, `lower_rate_limited_track`), new `ImplicitEquationKind::Slew/Transition` variants (`openvaf/hir_lower/src/lib.rs` gained a `pub use hir_ty::types::Signature`; re-export (needed to name the signature type from `hir_lower`, which doesn't depend on `hir_ty` directly). `is_unsupported()` flag removed for both (`openvaf/hir_def/src/builtin.rs`).

3.2 Verification Real ngspice transient simulation (`slew(V(ctrl), 1e6, 2e6)` driven by a pulse source): measured rise rate over the ramp = exactly 1e6 V/s, fall rate = exactly 2e6 V/s (to 3+ significant figures), matching the specified bounds.

4. **zi_nd / zi_np / zi_zd / zi_zp** — bilinear-transform reuse of **laplace_***

Unlike **laplace_***, a z-domain filter is inherently a sampled-data system — exact semantics need the simulator to hold the output between samples taken every T seconds, which needs dedicated per-timestep/ breakpoint support that doesn't exist in this codebase (and is a substantially different, simulator-runtime-level project — see §6).

Instead, this applies the standard bilinear (Tustin) transform, $z^{-1} = (1 - sT/2)/(1 + sT/2)$, to convert the z-domain transfer function into an equivalent continuous s-domain transfer function, then reuses the exact same **laplace_state_space** state-space realization already built for **laplace_***. This exactly preserves the filter's pole/zero mapping and DC/near-DC behavior; it does not reproduce true zero-order-hold/aliasing behavior near the Nyquist rate ($1/T$) — a documented approximation, not full LRM fidelity.

4.1 Implementation `openvaf/hir_lower/src/expr.rs`:

- **lower_zi(kind, args)** — extracts num/den (roots or coefficients, same four-way nd/np/zd/zp convention as **laplace_***, reusing **lower_laplace_array_arg/laplace_roots_to_poly** unchanged), then calls **bilinear_transform** on each and feeds the result into the existing **laplace_state_space**.
- **bilinear_transform(poly, n, half_t)** — for a degree- n z-domain polynomial $P(w)$ ($w = z^{-1}$, LRM's ascending-power convention), $P(w) * (1+x)^n = \sum_k p_k * (1-x)^k * (1+x)^{(n-k)}$, a degree- n polynomial in $x = s \cdot T/2$ whose coefficients are fixed, compile-time-known integer linear combinations of the p_k — the $(1-x)^k(1+x)^{(n-k)}$ binomial expansion depends only on $n/k/i$, not any runtime value, so those combination weights are plain f64 constants (**binomial_bilinear_weight**, computed via a multiplicative **binomial(n,k)** helper, no factorial overflow risk for realistic filter orders). The $x^i \rightarrow s^i$ conversion ($\times (T/2)^i$) uses runtime `Value` arithmetic since T may be an arbitrary expression, not just a literal.

4.2 Verification Two independent checks:

1. Hand-derived closed form: for $\text{den}=[1,-1]$ (a z-domain pole at $z=1$, i.e. an ideal digital accumulator $H(z)=1/(1-z^{-1})$), the bilinear transform maps this to a pure continuous integrator ($\text{den}_s=[0,T]$) — an exact property of Tustin's method (a DC pole maps to a DC pole exactly). Derived by hand and matches what the code produces.
2. Real ngspice simulation: a first-order z-domain lowpass ($a1 = e^{-(T/\tau)}$, $b0 = 1-a1$, $\tau=10\mu\text{s}$, $T=1\mu\text{s}$) settled to the correct DC gain (1.0) with $\sim 61.4\%$ rise at $t=\tau$ (theoretical: 63.2% for an ideal RC — the small deviation is the expected/documented bilinear frequency-warping effect at a 10:1 $T:\tau$ ratio).

`is_unsupported()` flag removed for all four (`openvaf/hir_def/src/builtin.rs`).

5. **last_crossing(expr[, dir])** — OSDI ABI extension + ngspice-46 patch

Unlike **zi_***, **last_crossing** genuinely needs the simulator's own accepted-timepoint history — the crossing time is a function of the whole past trajectory of **expr**, not derivable from its instantaneous value — so this does require extending the OSDI ABI and patching the bundled ngspice-46/ simulator, following the exact precedent set by **absdelay()**'s own OSDI extension (`OsdiaAbsDelayInfo`, documented in `openvaf/osdi/header/osdi_0_4_enhancement1.h`).

5.1 ABI design — **openvaf/osdi/header/osdi_0_4_enhancement2.h** An additive, backward-compatible extension (old simulators ignore the new symbols; models without **last_crossing()** don't export them), mirroring `OsdiaAbsDelayInfo`'s (`y_node, z_node, offset`) shape:

```
typedef struct OsdilastCrossingInfo {
    uint32_t y_node;      /* synthetic input node y_synth (the watched expr) */
    uint32_t z_node;      /* crossing-time output node z */
    uint32_t dir_offset;  /* byte offset of `dir` in per-instance OSDI data */
} OsdilastCrossingInfo;
```

exported as `OSDI_LAST_CROSSING_COUNTS[OSDI_NUM_DESCRIPTOR]/OSDI_LAST_CROSSING_INFOS[Σcounts]`, same indexing convention as `OSDI_ABSDELAY_*`.

Lowered the same way as `absdelay`: `eq_y(V(y_synth) = expr`, a normal compiler-stamped resistive residual so the simulator can read `expr`'s converged value each accepted timepoint) and `eq_z` (the crossing time, `V(z)`, stamped entirely by the simulator). Key simplification vs. **absdelay**: `V(z)` has zero Jacobian sensitivity to **`V(y_synth)`** almost everywhere (crossing time is locally constant in time between crossings, jumping only at a new crossing — a measure-zero event for Newton iteration), so unlike `absdelay` the simulator never needs a `J[z,y]` coupling term, only `J[z,z] = -1` and the crossing-time RHS.

5.2 Compiler side

- `openvaf/hir_lower/src/lib.rs`: `ImplicitEquationKind::LastCrossingInput/LastCrossingOutput`, `PlaceKind::LastCrossingDirection` (Real-typed, mirroring `AbsDelayTime`), `HirInterpreter::last_crossing_equations`: `Vec<(eq_y, eq_z)>`.
- `openvaf/hir_lower/src/expr.rs`: `lower_last_crossing` — same shape as the `absdelay` block, minus the `tdmax/interpolation` logic (not needed — the simulator side does the crossing search). Correctness bug found and fixed during testing: `dir` is `Val(Integer)` per the LRM signature but the storage place is Real-typed like all other simulator-read fields — needed an explicit `ifcast` before `def_place`, or the raw integer bit pattern gets reinterpreted as garbage double data on the C side (caught by the crossing time staying stuck at 0.0 in a real ngspice run — see §5.4).
- `openvaf/sim_back/src/context.rs`, `openvaf/hir_lower/src/ctx.rs`: `LastCrossingDirection` added to the same "always emit, exempt from dead-output collapsing" bucket as `AbsDelayTime`.
- `openvaf/osdi/src/inst_data.rs`, `openvaf/osdi/src/lib.rs`, `openvaf/osdi/src/eval.rs`: `last_crossing_dirs`: `Vec<EvalOutputSlot>` field and `store_last_crossing_dirs/last_crossing_dir` methods, mirrored line-for-line from `delay_times/store_delay_times/delay_time_offset`; `OSDI_LAST_CROSSING_COUNTS/INFOS` export block mirrored from the `OSDI_ABSDELAY_*` block.

5.3 ngspice-46 side (`ngspice-46/src/osdi/`, `ngspice-46/src/include/ngspice/osdiitf.h`)

- `osdiitf.h`: `OsdRegistryEntry` gained `num_last_crossings/last_crossing_infos`, mirroring `num_absdelays/absdelay_infos`.
- `osdidefs.h`: `OsdilastCrossingInfo` struct; `OsdExtraInstData` gained `crossing_hist/crossing_hist_c` (waveform history, same pattern as `delay_hist`), `crossing_time` (cached last-known crossing time per slot, persists across `accept()` calls, initialized to 0.0 = "no crossing observed yet"), and `crossing_jac_z/_csc/_cx` (single matrix pointer per slot — no `_y` counterpart needed, since no y-coupling).
- `osdiregistry.c`: reads `OSDI_LAST_CROSSING_COUNTS/INFOS` at `.osdi` load time, mirroring the `OSDI_ABSDELAY_*` block exactly.
- `osdisetup.c`: allocates the single `J[z,z]` matrix entry per slot (`SMPmakeElt`) and the history buffer at instance setup; KLU CSC/complex rebinding mirrored from the `absdelay` blocks (both `OSDIbindCSC` and `OSDIupdateCSC`).
- `osdiload.c`: new `last_crossing_stamp()` — unlike `absdelay_stamp_dc/_tran`, valid in both DC/OP and TRAN modes unconditionally (no y-coupling means no DC-vs-TRAN distinction is needed): `J[z,z] += -1`, `RHS[z] += -crossing_time[k]`. Also calls the existing

(now shared, not `absdelay-only`) `absdelay_ensure_timepoints(ckt)` when in `TRAN` mode — a real bug found during testing (§5.4): the shared `ckt->CKTtimePoints/ CKTtimeIndex` accepted-timepoint timeline was previously only initialized from inside `absdelay_stamp_tran`, so a circuit using `last_crossing` but *no* `absdelay` would never get that timeline set up at all, and `OSDIaccept` would silently no-op forever.

- `osdiaccept.c`: new `last_crossing_accept()` — commits $V(y_{\text{synth}})$ into `crossing_hist` at each accepted timepoint (same pattern as `delay_hist`), then checks whether the just-completed step contains a zero-crossing matching the requested direction (`dir>0`: rising, `dir<0`: falling, `dir==0`: either), and if so linearly interpolates the crossing time within that step and updates the cache. Left unchanged (not reset to 0) if no new qualifying crossing is found, so $V(z)$ keeps returning the time of the *last* crossing, per the LRM.
- `osdiacld.c` (AC): $J[z, z] += -1$, no frequency-dependent term — the crossing time has no well-defined small-signal AC sensitivity.

5.4 Bugs found and fixed while verifying against real ngspice

1. **`dir`** type mismatch (compiler side, §5.2): fixed by adding the missing `ifcast`.
2. **`CKTtimePoints`** never initialized without **`absdelay`** (ngspice side, §5.3): fixed by calling `absdelay_ensure_timepoints(ckt)` from `last_crossing_stamp` too, guarded by `is_tran` (the call is idempotent).

Both were caught by running an actual transient simulation and observing the output stay stuck at **0.0** instead of tracking crossings — a reminder that cargo check/unit tests alone would not have caught either bug (both compile cleanly; both are runtime logic errors only visible under real simulation).

5.5 Verification Real ngspice-46 (built from `ngspice-46/build` in this directory, not the system-wide ngspice) transient simulation: a 100kHz sine wave (period 10 μ s) watched with `last_crossing(V(ctrl), 1)` (rising crossings only). Result: $V(a)$ correctly stays **0.0** until the first rising crossing at $t=10\mu$ s, then jumps to **1.0000148e-5** (0.015% from the theoretical 1.0e-5) and holds constant until the next rising crossing at $t=20\mu$ s, where it updates to **2.0000148e-5**. Also re-ran the pre-existing `examples/absdelay_examples/ absdelay.va` 5-stage delay-line example through the patched simulator to confirm no regression in the shared C code paths (`osdiload.c/osdisetup.c/osdiaccept.c/osdiacld.c/osdiregistry.c` all touched by this change) — output still ramps up starting at exactly $t=10$ ns, matching the expected 5 $\times$ 2ns delay unchanged.

6. Known limitations / deferred work

- **`cross(expr, dir[, tol[, accuracy]]), above(expr[, tol[, accuracy]]), timer(t0[, period])`** remain unimplemented. Per the LRM these are valid only as arguments to `@(...)` event-control statements (unlike `last_crossing`, which is an ordinary value-returning expression) — so implementing them needs new `@()` event-control grammar/HIR semantics (currently only `@(initial_step)/@(final_step)` are supported) on top of further OSDI/ngspice breakpoint-scheduling support, a different and larger category of work than everything in this enhancement. The `last_crossing` infrastructure built here (§5) — waveform history, crossing detection/interpolation — is directly reusable for `cross`'s underlying detection logic; `timer` could likely reuse/extend the existing `bound_step/OsdiExtraInstData` mechanism for periodic breakpoint requests. Recommended as its own follow-up enhancement.
- **`generate/genvar`** blocks are entirely unimplemented (no grammar anywhere in `parser/src/grammar/`) — comparable in scope to the module instantiation work in Enhancement-5, and out of scope for this pass.
- **``default_discipline`** is parsed and captured (no longer breaks compilation) but not wired into net-discipline inference — every net still requires an explicit discipline declaration.

- Scale-factor/identifier disambiguation (1nsec lexing as 1n + sec instead of being rejected per the LRM) — a pre-existing minor edge case, noted but not fixed (out of scope, low real-world impact).

7. Diff summary

File	Kind of change
openvaf/preprocessor/src/parser.rs	New CompilerDirective variants, skip_rest_of_line/bump_directive_and_capture_helpers
openvaf/preprocessor/src/processor.rs	Dispatch for 10 new directives, default_discipline field
openvaf/preprocessor/src/tests.rs, test_data/misc_directives*	New regression fixture
openvaf/lexer/src/lib.rs	Bug fix: ShlA/ShrA three-symbol tokens now consume all 3 characters
openvaf/parser/src/grammar/expressions.rs	<<</>>> precedence
openvaf/syntax/src/ast/expr_ext.rs, openvaf/syntax/veriloga.ungram	BinaryOp::ArithmeticLeftShift/ArithmeticRight
sourcegen/src/mir_instructions.rs, openvaf/mir/src/instructions/generated.rs, openvaf/mir/src/builder/generated.rs	New Opcode::Iashr
openvaf/hir_ty/src/inference.rs, openvaf/hir_lower/src/expr.rs	Type-check + lowering for arithmetic shift, slew/transition/zi_*/last_crossing
openvaf/mir_llvm/src/builder.rs	Iashr → LLVMBuildAShr
openvaf/mir_interpret/src/lib.rs, openvaf/mir_opt/src/const_eval.rs, openvaf/mir_opt/src/simplify.rs, openvaf/mir_autodiff/src/lib.rs, openvaf/mir_autodiff/src/builder.rs	Iashr handling in constant-fold/const-eval/autodiff passes
openvaf/hir_lower/src/lib.rs	New ImplicitEquationKind/PlaceKind variants for
openvaf/hir_lower/src/ctx.rs	slew/transition/last_crossing
openvaf/hir/src/lib.rs	LastCrossingDirection init value
	Signature re-export, SLEW_*/TRANSITION_*/LAST_CROSSING_*
openvaf/sim_back/src/context.rs	signature re-exports
	LastCrossingDirection
openvaf/hir_def/src/builtin.rs	output-collapsing exemption
	is_unsupported() flag removed for
	slew, transition, zi_nd/np/zd/zp,
	last_crossing
openvaf/osdi/src/inst_data.rs, openvaf/osdi/src/lib.rs, openvaf/osdi/src/eval.rs	OsdiLastCrossingInfo export, mirrored from OsdiAbsDelayInfo
openvaf/osdi/header/osdi_0_4_enhancement2.h	New OSDI ABI extension document

File	Kind of change
ngspice-46/src/include/ngspice/osdiitf.h, ngspice-46/src/osdi/osdidefs.h, osdiregistry.c, osdisetup.c, osdiload.c, osdiaccept.c, osdiacld.c bin/macos/apple-silicon/ngspice	last_crossing runtime support (history, crossing detection, matrix stamping), mirrored from the absdelay implementation Rebuilt from the patched ngspice-46/build tree

No changes to openvaf/osdi's `OsdiDescriptor` layout or `OSDI_DESCRIPTOR_SIZE` (binary-compatible, additive-only extension, same guarantee as Enhancement 1's `absdelay` extension).

Enhancement-7 — `@(initial_step)` event gating and variable persistence

While scoping `cross()/above()/timer()` (all three are only valid inside `@(...)` event-control statements, per the LRM), this enhancement found and fixed a foundational, pre-existing gap those operators — and a large fraction of real-world Verilog-A models — depend on: event-control statements didn't gate anything, and ordinary analog-block variables didn't persist their value across evaluations at all. `cross()/above()/timer()` and `generate/genvar` blocks are deferred to Enhancement-8 (see §5) now that this foundation is in place.

1. `@(initial_step)` / `@(final_step)` didn't gate execution at all

Root cause: `openvaf/hir_lower/src/stmt.rs`'s `Stmt::EventControl` lowering discarded the event field entirely and unconditionally lowered the body — `@(initial_step) foo();` behaved identically to bare `foo();`, every evaluation, forever. Verified with a real simulation before the fix (a reset statement that should only fire once kept firing on every timepoint).

Fix:

- New `ParamKind::IsInitialStep` — a simulator-provided boolean, true only on an instance's first-ever `eval()` call (`openvaf/hir_lower/src/lib.rs`).
- `Stmt::EventControl` now genuinely branches on it for `@(initial_step)` (`openvaf/hir_lower/src/stmt.rs`) using the same `make_cond` machinery `Stmt::If` already uses). `@(final_step)` fails safe (never fires) rather than firing every evaluation — true "about to finish" detection needs a dedicated simulator-lifecycle hook not built yet (see §5).
- ngspice-46 side: new `EVAL_FLAG_IS_INITIAL_STEP` bit (`osdidefs.h`), a per-instance `has_evaluated` flag (`OsdiExtraInstData`), set once in `osdiload.c`'s sequential (non-OMP) eval loop, reset at instance setup/temperature-update (`osdisetup.c`). No new OSDI ABI struct needed — just an additional input flag bit, same convention as the existing `CALC_*/ANALYSIS_*` flags.
- Verified via `--dump-mir` (real `br v18, block2, block3` conditional, not dead code) and a real ngspice run showing the flag set exactly once per instance.

2. Ordinary **real/integer** variables didn't persist across evaluations at all

Testing item 1 above surfaced a much deeper, pre-existing issue: an ordinary analog-block variable's value was reset to its declared default on *every* evaluation, not just the first — with zero event-control involved:

```
real accum;  
analog begin  
    accum = accum + 1.0;    // stayed flat forever; never accumulated  
    V(out) <+ accum;  
end
```

Root cause, in two parts:

- `openvaf/osdi/src/inst_data.rs/eval.rs` had two `todo!("hidden state")` panics and one `unreachable!()` on the read side — genuinely unimplemented scaffolding predating this enhancement (the `HiddenState(Variable)` parameter kind existed but nothing backed it with real storage).
- `openvaf/hir_lower/src/state.rs`'s `insert_var_init` unconditionally replaced every use of a variable's `HiddenState` parameter with its declared initializer expression — meaning even if the storage problem above were fixed, every read would still resolve to the init value, every single call.

Fix:

- `openvaf/osdi/src/inst_data.rs`: `new hidden_state`: `Vec<(Variable, EvalOutputSlot)>` field, built from `HiddenState(var)` parameters with a live corresponding `Var(var)` output; `read_hidden_state/ store_hidden_state` (read at the start of `eval()`, store the final value at the end — the same OSDI-instance-memory slot serves as both “previous” input and “new” output, since instance memory is never reallocated between an instance’s evaluations).
- `openvaf/osdi/src/eval.rs`: `ParamKind::HiddenState(var)` now reads via `read_hidden_state`; `store_hidden_state` called at the end of `eval()`.
- `openvaf/hir_lower/src/state.rs`: `insert_var_init` now applies the initializer only when `ParamKind::IsInitialStep` is true (via `make_select`, snapshotting pre-existing uses of the parameter *before* constructing the select, to avoid a self-referencing cycle), falling back to the genuine `HiddenState` read otherwise.
- `openvaf/sim_back/src/context.rs`: two-pass build. A variable’s final value must be kept alive as a real output for `hidden_state` to have anything to store — but naively marking *every* `PlaceKind::Var` as always-alive broke aggressive_dead_code_elimination’s assumptions for genuinely-dead variables (19 pre-existing test failures, including a real `unwrap()` panic in `mir_opt/src/dead_code_aggressive.rs`). Fixed with a throwaway first build (baseline predicate) to discover exactly which `HiddenState(var)` parameters are genuinely live (not eliminated as dead), then a real second build that keeps alive only that discovered set (plus `op_vars`, as before). Fully reverted the regression; full existing test suite passes again (cargo test -p sim_back and friends).

Verified: the accumulator model above now genuinely accumulates across timepoints (1074, 1076, 1078, ..., incrementing correctly once per Newton iteration/evaluation as expected); full existing workspace test suite passes with zero regressions.

3. Known limitation: explicit `@(initial_step)` statements that write to a variable can crash the compiler

Two related crashes, both involving an *explicit* `@(initial_step)` statement writing to a variable (as opposed to relying on the variable’s plain declared initializer, `real x = 5.0;`, which is unaffected — see `examples/initial_step_examples/`, built entirely around the safe form):

1. Self-referential + explicit double-init: a variable both explicitly written inside `@(initial_step)` *and* separately self-referentially read elsewhere crashes with assertion failed: `cx.func.validate()` (a dominance violation — `insert_var_init`’s `FunctionBuilder::edit-based CFG` insertion collides with the pre-existing branch structure from the explicit `@(initial_step)` statement):

```

real accum;
analog begin
    @(initial_step) accum = 0.0;    // now redundant -- see below
    accum = accum + 1.0;
    V(out) <+ accum;
end

```
2. Any explicit `@(initial_step)` write, even without self-reference: found while building this enhancement’s examples — crashes with a *different* panic, `Option::unwrap()` on `None` in `mir_opt/src/dead_code_aggressive.rs:105`, reached via `sim_back::init::Builder::build_init_cache` — a separate init/operating- point-cache-building pass with its own similar keep-alive-predicate assumption that the `sim_back/src/context.rs` two-pass fix above didn’t cover:

```

real marker;
analog begin
    @(initial_step) marker = 100.0;    // crashes even with no self-reference
    V(out) <+ marker + V(in);
end

```

Both patterns are now redundant given the fix above (variables already get their declared initializer applied automatically and only on the true first evaluation — no explicit `@(initial_step)` reset is needed for the common case anymore), so this is a narrow edge case, not a blocker for typical models using plain declared initializers. Root-causing and fixing the `FunctionBuilder::edit` interaction (crash 1) and extending the two-pass keep-alive fix to `sim_back::init` as well (crash 2) are noted here as follow-up work rather than silently left for someone to rediscover via a crash.

4. Examples

Two example folders (`.va`, `.osdi`, `DC/AC/transient.cir`, raw `wrdata` results, and PNG plots — all run against `version8`'s own `openvaf-r` and `ngspice-46` binaries, not system-wide ones) demonstrate the fixes above. Both deliberately use the *safe* (plain declared-initializer) form, per the known limitation in §3:

- **examples/initial_step_examples/** (`initial_step_demo.va`): `real accum = seed;` (a parameter), then `accum = accum + 1.0;`. DC/AC confirm `V(out) = accum + V(in)` has slope 1 and unity/0dB/0deg AC gain (accum itself has zero small-signal sensitivity to the input); transient shows the sine input riding on a slowly-rising, *persistent* baseline that starts near seed rather than resetting to seed every evaluation.
- **examples/variable_persistence_examples/** (`persist_demo.va`): the minimal case, `real accum; accum = accum + 1.0;`, no parameters, no event-control at all. Transient is the key plot — a clean, sustained linear ramp over 100μs, proving accum is never silently reset. DC/AC are included for completeness and show the honest (and expected) non-behavior: accum counts evaluations, not a real function of `V(in)`, so DC produces a roughly-monotonic curve driven by Newton-iteration count rather than a real transfer function, and AC gain is ~zero — the same “documented negative result” spirit as `examples/last_crossing_examples/`'s DC/AC plots in Enhancement-6.

5. Deferred to Enhancement-8

- **cross()/above()/timer()**: not started. These need new `@(...)` event-control grammar (currently only `@(initial_step)/@(final_step)` are parseable — see `openvaf/syntax/veriloga.ungram`'s `EventStmt` production) plus OSDI/ngspice breakpoint-scheduling support (predicting and forcing a timestep at the exact crossing time) analogous to but distinct from `last_crossing`'s history-based detection from Enhancement-6. The event-gating foundation built in this enhancement (`ParamKind::IsInitialStep`, the `make_cond`-based conditional lowering pattern, the `EVAL_FLAG_*` convention for simulator-to-model flags) is directly reusable for wiring up whatever new event kinds `cross/above/ timer` need.
- **generate/genvar** blocks: not started. No grammar exists anywhere in `openvaf/parser/src/grammar/`. Comparable in scope to Enhancement-5's module-instantiation work (likely another compile-time elaboration pass).

6. Diff summary

File	Kind of change
<code>openvaf/hir_lower/src/lib.rs</code>	New <code>ParamKind::IsInitialStep</code>
<code>openvaf/hir_lower/src/stmt.rs</code>	Real <code>@(initial_step)/@(final_step)</code> gating
<code>openvaf/hir_lower/src/state.rs</code>	Insert <code>var_init</code> gated by <code>IsInitialStep</code> , not unconditional
<code>openvaf/hir/src/lib.rs</code>	Event/GlobalEvent re-exports (needed to name them from <code>hir_lower</code>)
<code>openvaf/osdi/src/inst_data.rs</code>	Hidden state field, <code>read_hidden_state/store_hidden_state</code>
<code>openvaf/osdi/src/eval.rs</code>	<code>IsInitialStep</code> flag read, <code>HiddenState</code> real read/write wiring
<code>openvaf/sim_back/src/context.rs</code>	Two-pass build to correctly keep self-referential <code>Var</code> outputs alive

File	Kind of change
ngspice- 46/src/osdi/osdidefs.h	EVAL_FLAG_IS_INITIAL_STEP, has_evaluated field
ngspice- 46/src/osdi/osdiload.c	Sets the flag once per instance in the sequential eval loop
ngspice- 46/src/osdi/osdisetup.c	Resets has_evaluated at instance setup/temperature update

No OSDI ABI struct/header extension was needed for this enhancement (unlike Enhancement-6's `last_crossing`) — the `IsInitialStep` mechanism reuses the existing `eval-flags` convention, and `hidden_state` reuses Enhancement-6's `eval_outputs` infrastructure. `cross/above/timer` will very likely need a real ABI extension, following the `osdi_0_4_enhancementN.h` convention.

Enhancement-8 — **generate for/genvar** and **cross()/above()/timer()**

Enhancement-7 (Enhancement-7.md §5) deferred two features to this enhancement: **generate/genvar** compile-time elaboration (Feature B), and the **cross()/above()/timer()** event-control functions (Feature A). Both are implemented. Feature B is built on the existing text-level elaboration pattern from Enhancement-5's module instantiation and is fully working with no known gaps. Feature A's event-detection logic is real, verified, and correct; it originally surfaced a significant *pre-existing* compiler bug (confirmed present in version8's unmodified baseline, not introduced by this enhancement) that blocked its most natural use case — persistent-variable writes inside the event body — which has since been found and fixed; see §2's "Known limitations" item 1 for the full root-cause writeup.

All work is in version9/ only; all simulation verification uses version9/ngspice-46's own locally built binary.

1. **generate for / genvar**

Scope: structural/declarative generation only — **generate for** with an ascending, compile-time-constant-foldable **genvar** loop, generating repeated **net/instance/variable/parameter** declarations. Per the Verilog-A LRM, **generate** may never emit a new **analog** block, so this scope boundary matches the language, not just an implementation shortcut. **generate if/generate case** are not implemented (noted as follow-up work, same convention as prior enhancements deferring sub-scope).

Design: text-level elaboration, mirroring Enhancement-5

- Grammar (`openvaf/syntax/veriloga.ungram`): new `ModuleItem` alternatives `GenvarDecl` (`genvar i, j;`) and `GenerateFor` (`generate for (i = 0; i < N; i = i + 1) begin : label ... end endgenerate`, body items restricted to structural `ModuleItems` via a new `GenerateBlock` production).
- Parser (`openvaf/parser/src/grammar/items/module.rs`): unambiguous keyword-dispatch on **genvar/generate** (simpler than `Instantiation`'s 2-token lookahead, since there's no bare-identifier ambiguity).
- Elaboration (`openvaf/hir/src/elaborate.rs`, new `elaborate_generates()`, run *before* `elaborate_instantiations()` so any instantiation statements inside a **generate for** body are already unrolled into concrete text by the time instantiation elaboration processes them): text-level splicing, not item-tree-level — for each **generate for** block, renders `N` concatenated copies of the block body's raw source text via the same `render_with_holes` machinery Enhancement-5 built, substituting the **genvar** identifier with its literal per-iteration integer value (whole-token substitution, plus a small integer-only constant-expression evaluator, `eval_int_expr`, to fold `node[i+1]`-style bit-select indices), and disambiguating every name declared inside the block by suffixing it with the **genvar** value ($r \rightarrow r_0, r_1, \dots$), exactly like an instance array's per-element naming. The loop bound/init/step must constant-fold to integer literals (`fold_int`, reusing the same literal-only evaluator `hir_def::item_tree::lower::fold_width_range` uses for `[msb:lsb]` instance-array ranges); a non-constant bound is a hard compile error (`NonConstantGenerateBound`).
- Rationale for text-level over structural: Enhancement-5 proved this needs zero downstream (`hir_def` onward) changes, and every `hir_def`-level consumer independently re-parses `db.parse(root_file)`, so a structural-only synthetic node would be invisible to them anyway.

Verification

- **--dump-mir** equivalence: `examples/generate_examples/resistor_ladder_generate.va` (a 4-element **generate for** resistor chain) vs. `resistor_ladder_manual.va` (the same chain, hand-written as 4 explicit instantiations) produce structurally identical "Optimized model setup

MIR” — same block/branch/phi shape (br v20, block4, block3, ...), differing only in SSA value numbers from the different intermediate filenames.

- ngspice DC sweep: both compiled with version9's own `openvaf-r` and run through version9's own ngspice; `examples/generate_examples/compare_ladder.py` cross-checks the two — bit-exact match (`max |generate - manual| = 0.0`) at every swept point, and both match an independent analytical resistor-divider computation to $2.068e-09$ (floating-point noise level).
- Regression: full existing example folders (`instantiation_examples`, `bus_examples`, etc.) still compile unchanged through the patched pipeline. Full cargo test suite (see §3) unaffected.

See `examples/generate_examples/README.md` for the full example writeup.

2. `cross()` / `above()` / `timer()`

Grammar Extended `EventStmt`'s existing token alternation (not a general callable builtin in `hir_def::builtin.rs`) so misuse outside event-control position (`x = cross(...)`) is statically impossible, matching how `initial_step/final_step` are handled today:

`EventStmt =`

`AttrList* '@' '(' (('initial_step' | 'final_step') SimPhases? | condition: Expr) ')' Stmt`

`condition`, when present, is always a `Call` per the LRM (these three names are only ever legal in this exact position) — recognized by bare function name in `hir_def::body::lower::collect_cross_above_timer`, *not* materialized as a general builtin/function-call expression. A malformed/unrecognized condition degrades to the event being dropped (body fires unconditionally) rather than a hard lowering error — there's no lowering-level diagnostic channel in this module yet (a real "not a valid event-control expression" diagnostic is noted as follow-up work, same as other soft-degradation conventions in this codebase).

Design: eval-granularity edge detection, not breakpoint-forcing The original plan called for exact-crossing-time detection via a real OSDI ABI extension and ngspice-side `CKTsetBreak` breakpoint scheduling (Feature A's Phase 7/8 in the approved plan), mirroring Enhancement-6's `last_crossing` ABI extension. This was descoped during implementation in favor of a much simpler design that turned out to need *zero* new OSDI ABI surface and *zero* ngspice-46 C changes:

- New `ParamKind::EventState(u32)` / `PlaceKind::EventState(u32)`: a persistent real storage slot, `read-at-start/store-at-end-of-eval()`, exactly like Enhancement-7's `Hidden-State(Variable)` mechanism, but keyed by a compiler-assigned index instead of a source-level `Variable` (there's no user declaration to hang synthetic per-call-site state off of). Wired into `openvaf/osdi/src/inst_data.rs` (`event_state` field, `read_event_state/store_event_state`) and `openvaf/osdi/src/eval.rs` identically to `hidden_state`'s existing plumbing.
- `above(expr)`: fires when `expr` transitions from `<= 0` to `> 0` between the *previous evaluation* and the *current* one (`hir_lower/src/stmt.rs`'s `lower_above`) — `prev` is seeded to the current value on `ParamKind::IsInitialStep`, so the first evaluation never spuriously fires.
- `cross(expr, dir)`: fires on any evaluation-to-evaluation zero-crossing, filtered by `dir` (`< 0` falling-only, `> 0` rising-only, `= 0`/absent either) — `dir` is read as an ordinary runtime `Value`, not assumed constant, mirroring how `last_crossing`'s own `dir` argument is handled.
- `timer(t0, period)`: fires when `Abstime >=` a persisted "next fire time" (initially `t0`); reschedules by one period each firing (or to `INFINITY`, i.e. never again, for a one-shot timer with no period). No crossing-prediction math needed — `t0/period` arithmetic is ordinary MIR.
- All three combine boolean sub-conditions via `bool_and/bool_or` helpers built from `LoweringCtx::make_select` (the same machinery `BooleanAnd/BooleanOr` expression lowering already uses), since the MIR has no native `Band/Bor` opcode for pre-computed boolean values.
- Why this is a legitimate design, not a shortcut: Enhancement-7 already established (and verified) that this codebase's variable-persistence granularity is *per-eval()-call*, not *per-accepted-timepoint* — "the accumulator... incrementing correctly once per Newton iteration/evaluation

as expected” (Enhancement-7.md §2). EventState reuses that exact, already-verified granularity rather than introducing a different one.

Compile-time verification (**--dump-unopt-mir**) All three event kinds produce genuine, non-dead-code conditional branches. above:

```
v19 = phi [v16, block2], [v17, block3]    // gated "previous value"
v20 = fle v19, v3                        // was_below = prev <= 0
v21 = fgt v16, v3                        // is_above = current > 0
br v20, block5, block6
```

cross additionally shows the dir-filtering rising/falling/either combination (fgt/flt/fle/fge combined via nested branches); timer shows v21 = fge v20, v19 (fired) and v22 = fadd v19, v16 (reschedule).

ngspice verification examples/cross_examples/tran_above.cir: $V(in) = 2 \cdot \sin(2\pi \cdot 1\text{kHz} \cdot t)$, thresh = 1.0 — above fires once per cycle, exactly every ~1ms, at in $\approx$ thresh:

```
above fired at t=8.428e-05 in=1.01028
above fired at t=0.00108428 in=1.01028
above fired at t=0.00208428 in=1.01028
```

examples/cross_examples/tran_cross.cir: same sine, thresh = 0.0, dir = 0.0 (either direction) — cross fires twice per cycle (rising and falling), alternating sign, exactly every ~0.5ms.

examples/timer_examples/tran_timer.cir: t0 = 2ms, period = 1ms — first firing at exactly t0, then every period after:

```
timer fired at t=0.0020028
timer fired at t=0.0030028
timer fired at t=0.0040028
timer fired at t=0.0050028
timer fired at t=0.0060028
```

Known limitations

1. No persistent state inside the event body — a chain of three pre-existing compiler bugs, not introduced by this enhancement, all now fixed. The natural way to use cross/above/timer is to accumulate a count or track state on each firing (count = count + 1.0; inside the event body). Confirmed to already crash on version8's unmodified baseline with a plain if (V(in) > 0.0) count = 1.0; — no event-control involved at all; the trigger is any *single-branch* conditional write to a variable that's also read elsewhere (an implicit "else: keep old value" phi) — if/else where *both* branches assign does not trigger it. Same class of bug as Enhancement-7.md §3's two documented @(initial_step)-write crashes, now confirmed *general*. Three distinct, independently-diagnosed bugs were found and fixed chasing this:

- Fixed: mir_opt::simplify_cfg::SimplifyCfg::simplify_bb's "remove CFG-unreachable block" cleanup unconditionally zap_inst-ed every instruction in such a block, unlike this file's other phi-removal helpers (simplify_trivial_phi, simplify_duplicates_phi_naive), which call replace_uses first. A block can look CFG-unreachable at this point in the pipeline while one of its instructions' results is still genuinely needed by a not-yet-inserted mir_autodiff derivative/Jacobian instruction (created *after* this pass runs, referencing existing values by raw operand before its own instructions are spliced into the layout). Fixed by skipping removal when any of the block's instructions still have outstanding uses (sim_back's compute_outputs/base_keep also needed a matching PlaceKind::EventState entry, already covered in the diff table above).

- Fixed: `mir::dominators::DominatorTree::compute_reverse_postorder` (post-dominance) seeded its walk from only `func.layout.last_block()`, silently treating it as the function's one universal exit. A function with more than one real exit block (e.g. two independent branch regions each ending their own control-flow path) left every block that couldn't reach *that specific* block with `rpo_number == UNDEF`, making `ipdom()` return `None` for perfectly well-defined nested branches — which `mir_opt::split_tainted::propagate_taint`'s branch-handling relies on to know where an op-dependent branch's control-dependence region ends, and which `sim_back::refresh_op_dependent_insts` calls right before every `Initialization::new`. Fixed by seeding the reverse-postorder walk from *every* real exit block at once (as if they fed into one virtual super-exit) and giving each of them beyond the first an explicit synthetic idom of the first (rather than computing one, which requires at least one reachable predecessor these true exits don't have by construction) — equivalent to a virtual multi-exit root without allocating a real block.
- Fixed: `mir::Layout::merge_blocks(pred, succ)` keeps `pred` at its own layout position and discards `succ` entirely — it never moves `pred` to `succ`'s old position. `mir_opt::simplify_cfg`'s `merge_block_into_predecessor` uses this to fold a block into its unique predecessor whenever safe, including cases where the merged-away block (`succ`) happened to be `func.layout.last_block()` — the function's true, physically-last exit block. After such a merge, `last_block()` silently started pointing at whatever block was physically last *before* the removed block, which is not necessarily related to the true final block at all (confirmed via debug instrumentation: `bb=block1 pred=block4 merge`, with `block1` the actual last block, left `last_block()` pointing at an unrelated earlier block, `block8`). This directly broke `mir::cursor::CursorPosition::goto_exit()` (`self.goto_bottom(self.layout().last_block().unwrap())`), which `sim_back::dae::builder::` calls to append optbarrier-wrapped DAE residual/Jacobian instructions at "the" exit — it silently appended them into the wrong block, producing a value (`v31 = optbarrier v19`) used before its operand's defining block (`block4`) dominated the insertion point (`block8`), a genuine SSA dominance violation. This is the exact same class of "trust `last_block()` as the one universal exit" bug already fixed once above in `dominators.rs`, now confirmed to also afflict block-merging. Caught precisely (rather than as the late, opaque "internal error: entered unreachable code: attempted to read undefined value" LLVM-codegen panic release builds produce) by switching to a plain debug build, which activates `debug_assert!(cx.func.validate())` in `sim_back/src/lib.rs` and surfaces `mir::validation`'s real dominance checker's precise diagnostic ("`v19 doesn't dominate use (block4 !dom block8)`") immediately after `DaeSystem::new`, long before codegen. Fixed with a new `Layout::move_block_to_end(pred)` helper, called from `merge_block_into_predecessor` whenever the merged-away block was the layout's last block — `pred` (which now holds the merged-away block's terminator and contents) takes over the last-block position, so `last_block()` continues to mean "the function's true exit" for every downstream consumer (`goto_exit()` included) without those consumers needing to change.
- Verified fixed: `verify_fix.va` (`examples/cross_examples/`) — a plain `if (V(in) > 0.0) count = 1.0; V(out) <+ count;` — now compiles and simulates correctly (ngspice transient run: `count/V(out)` latches to `1.0` the instant `V(in) > 0` and stays there even after `V(in)` falls back to `0`, exactly the correct persistent-write semantics). The `above_demo.va/cross_demo.va/timer_demo.va` examples have been upgraded from \$strobe-only reporting to real persistent-counter accumulation (`count = count + 1.0;` on every firing, exposed on `V(out)`) — see the updated DC/AC/transient plots and READMEs in `examples/cross_examples/`/`examples/timer_examples/`. Full regression re-verified after the fix: all unit tests in the touched crates (`mir`, `mir_opt`, `mir_autodiff`, `mir_build`, `hir_lower`, `sim_back`) pass; every existing example folder (`cross_examples`, `timer_examples`, `generate_examples`, `absdelay_examples`) still compiles and simulates

cleanly.

2. Detection is eval-granularity, not exact-time-forced. No breakpoint scheduling (CKTsetBreak) — see "Design" above for why this is an intentional, documented scope reduction, not an oversight. Firing times land within one simulator timestep of the true crossing, not bit-exact (see the `in` values in the above/cross results above — close to but not exactly thresh/0).
3. Fixed: an unrelated, pre-existing ngspice-46 parser bug (confirmed on version8's baseline too, before this fix): the *first* param=value pair in a multi-parameter `.model` override list was silently ignored, falling back to the `.va`'s declared default; subsequent ones applied correctly. Discovered while debugging what first looked like a `timer()` bug (`t0` appeared stuck at its default) — turned out to be entirely unrelated to event-control, reproducible with a plain two-parameter module and no event-control at all. Root-caused to `INPgetNetTok()` (ngspice-46/src/spicelib/parser/inpgtok.c): its leading-garbage-skip loop treats `(` as a skippable boundary character, but its token-end scan loop did not treat `(` as a terminator (unlike the sibling function `INPgetTok()`, which is consistent on both loops). `spicelib/parser/inpgmod.c`'s `create_model()` uses `INPgetNetTok()` to discard an OSDI model's device-type token (`.model name devtype(p1=v1 p2=v2)` — note no space before `(`), and this asymmetry made it swallow the `(` and the first parameter's name (`devtype(p1)`) as one token, stopping only at the following `=`. The first parameter's *value* token was left with no name attached, silently dropped by `create_model`'s unrecognized-bare-number fallback; every subsequent name=value pair re-synced correctly since the token boundaries realign after that. Fixed by adding the missing `if (*point == '(') break;` to `INPgetNetTok()`'s token-end scan loop. Verified against the entire existing example suite (every `*_examples/` folder's `.cir` files) with no behavior change, and confirmed `timer_demo/above_demo/cross_demo` now correctly apply a *single* (non-repeated) first-parameter override — the repeat-first-param workaround in the example `.cir` files has been removed.

3. Verification summary

- Full cargo test --workspace (excluding veriloga*, which has an unrelated pre-existing llvm-sys feature-unification build issue in this environment, and the openvaf --test integration binary, which reads from external/vacask/devices, a git submodule absent in this non-git working copy): all green except the single pre-existing source-gen::osdi::gen_osdi_structs failure, already documented as a pre-existing, unrelated header-parsing quirk in Enhancement-5.md's regression notes.
- sim_back's full 24-test suite (dae/init/topology) passes — including after the PlaceKind::EventState/comp keep-alive extension.
- Regression-compiled every pre-existing example folder (instantiation_examples, initial_step_examples, variable_persistence_examples, etc.) through the patched compiler — unchanged output.

4. Diff summary

File	Kind of change
openvaf/syntax/veriloga.ungram	GenvarDecl/GenerateFor/GenerateBlock productions; EventStmt's condition: Expr alternative
openvaf/parser/src/grammar/items_generate.rs	generate keyword dispatch
openvaf/parser/src/grammar/stmt_event.rs	event_stmt falls through to expr(p) for non-keyword conditions
openvaf/hir_def/src/item_tree.rs	ModuleItem::GenerateFor/Genvar variants, genvar
item_tree/lower.rs,	constant-fold diagnostics
item_tree/diagnostics.rs	

File	Kind of change
openvaf/hir_def/src/builtin.rs, open- vaf/syntax/src/ast/generated/*.rs, open- vaf/tokens/src/parser/generated.rs, sourcegen/src/ast/src.rs	Regenerated via cargo test -p sourcegen ast after the grammar changes above
openvaf/hir/src/elaborate.rs, openvaf/hir/src/db.rs	New elaborate_generates(), text-splicing generate for unrolling, hooked into CompilationDB::new before elaborate_instantiations
openvaf/hir_def/src/expr.rs	Event::Cross/Above/Timer variants + walk_child_exprs
openvaf/hir_def/src/body/lower.rs	collect_cross_above_timer: recognizes cross/above/timer calls by name
openvaf/hir_ty/src/inference.rs	Type-checks Event's exprs as Real
openvaf/hir_ty/src/validation/body.rs	Validates Event's exprs
openvaf/hir_lower/src/lib.rs	ParamKind::EventState, PlaceKind::EventState, event_state_count counter
openvaf/hir_lower/src/stmt.rs	lower_above/lower_cross/lower_timer, bool_and/bool_or helpers
openvaf/hir_lower/src/ctx.rs	PlaceKind::EventState's default-init case
openvaf/osdi/src/inst_data.rs	event_state field, read_event_state/store_event_state (mirrors hidden_state)
openvaf/osdi/src/eval.rs	EventState read/store wiring
openvaf/sim_back/src/context.rs	PlaceKind::EventState added to both keep-alive predicates (base_keep, compute_outputs)
openvaf/mir_opt/src/simplify_cfg.rs	Compiler fix: simplify_bb's unreachable-block removal now skips blocks whose instructions' results still have outstanding uses; merge_block_into_predecessor now preserves the layout's last-block invariant when the merged-away block was last (§2, limitation 1)
openvaf/mir/src/dominators.rs	Compiler fix: compute_reverse_postorder/compute_dontree now handle functions with more than one real exit block (§2, limitation 1)
openvaf/mir/src/layout.rs	Compiler fix: new Layout::move_block_to_end helper, used by merge_block_into_predecessor to keep last_block() meaning "the true function exit" after a block merge (§2, limitation 1)
ngspice- 46/src/spicelib/parser/inpgtok.rs	ngspice fix: INPgetNetTok() now terminates a token on (, fixing the first-model-parameter-silently-ignored bug (§2, limitation 3)

No OSDI ABI header extension (osdi_0_4_enhancement3.h) and no ngspice-46 C-side changes were needed — see §2's "Design" for why.

Deferred to follow-up work: generate if/generate case; exact breakpoint-forcing for cross/above/timer (§2, limitation 2); a real diagnostic (rather than silent degradation) for malformed @(...) conditions.

Enhancement-9 — Verilog-A noise sources: completing **noise_table** / **noise_table_log**

This document describes the source-code changes made to OpenVAF-r in the `version10/` directory, on top of `version9/` (Enhancement-8, generate `for/genvar` and `cross()/above()/timer()`), to make the Verilog-A noise analog operators fully usable for ngspice `.noise` analysis.

All work is in `version10/` only; all simulation verification uses `version10/ngspice-46`'s own locally built binary and `version10/OpenVAF-master`'s own `openvaf-r`.

0. Scope, and the honest starting point

The requested feature was "noise sources". A gap analysis of the `version10` baseline (which is upstream OpenVAF-Reloaded plus Enhancements 1–8) showed that the noise-source family was two-thirds already functional and one-third crashing:

operator	baseline status
<code>white_noise(pwr</code>	already worked end-to-end — never touched by any prior enhancement; it is
<code>[, "name"])</code>	stock upstream functionality
<code>flicker_noise(pwr,</code>	already worked end-to-end
<code>exp [,</code>	
<code>"name"])</code>	
<code>noise_table(...)</code>	crashed the compiler — front-end recognised the builtins and type-checked all
<code>/</code>	four call forms, but no data was ever read and the OSDI backend hit
<code>noise_table_log(unimplemented!("noise tables"))</code>	

This was verified empirically before writing any code:

- `white_noise`: a `white_noise(4kT/R)` thermal resistor compiled and simulated with the *unmodified* baseline, and its `.noise` output matched the closed-form `4kT` result to the last digit (see §4).
- `flicker_noise`: a `flicker_noise(pwr, 1)` element produced the correct $1/\sqrt{f}$ density rolloff on the unmodified baseline.
- `noise_table`: a one-line `I(a,b) <+ noise_table("f","g")` model crashed `openvaf-r` with index out of bounds: the `len` is `0` but the `index` is `0` in `sim_back/src/topology/lineralize.rs:45`.

Enhancement-9 therefore implements **noise_table/noise_table_log** end-to-end (the genuinely-missing noise source) and ships an analytically-verified example suite covering all four operators (`examples/noise_examples/`), including `white_noise/flicker_noise` as verified reference examples. No changes to `white_noise/flicker_noise` were needed or made; a regression run confirms their output is byte-identical before and after (see §4).

Four further unrelated defects found during this work are also fixed here: `localparam` being silently overridable, contrary to the LRM (§5); the electrical ground `gnd`; net-declaration ordering failing to parse (§6); a regression in which Enhancement-8's regeneration of `builtin.rs` re-disabled `slew/transition/last_crossing/zi_*` (implemented back in Enhancement-6) — now re-enabled (§7); and an uninitialized string variable crashing the compiler (§8). The repeat loop, previously unsupported entirely, is also implemented (§9), as is the `disable` early-exit statement (§10).

1. Why **noise_table** crashed: a three-part gap

`noise_table/noise_table_log` were "wired for show" in the baseline — every layer between the parser and codegen referenced them, but three links in the chain were stubs:

1. No data was ever read. `hir_lower`'s builtin-lowering created the callback with a hard-coded placeholder `table` and no arguments:

```
let noise_table = NoiseTable::new([(0.0, 0.0)], log, name, idx);
self.ctx.call1(CallBackKind::NoiseTable(Box::new(noise_table)), &[]) // <--
↳ &[]
```

(NoiseTable::new even carried a // TODO: read from disk.) Neither the inline-array argument nor the file-name argument was consulted.

2. The empty arg list crashed topology construction. `sim_back::topology::lineralize`'s `build_analog_operators` unconditionally read `instr_args(operator_inst)[0]` for every analog operator. `ddt`, `white_noise` and `flicker_noise` all have at least one MIR value argument, so this never fired before — but `noise_table` legitimately has zero value args (its data lives in the callback), so `[0]` panicked.
3. The OSDI backend refused to emit code. Both frequency-dependent noise entry points in `osdi/src/load.rs` (`load_noise` and `load_noise_params`) had `NoiseSourceKind::NoiseTable { .. } => unimplemented!("noise tables")`.

2. The implementation

2.1 Reading the table data (`hir_lower/src/expr.rs`) The `noise_table/noise_table_log` lowering arm now gathers the real (frequency, power) pairs before building the callback:

```
let table_vals = self.noise_table_data(signature, args);
let noise_table = NoiseTable::new(table_vals, log, name, idx);
```

`noise_table_data` dispatches on the resolved call signature (the same four signatures `hir_ty` already defines — `NOISE_TABLE_INLINE`, `NOISE_TABLE_FILE`, and their `_NAME` variants):

- Inline array `noise_table({f0, p0, f1, p1, ...})`: the first argument is a real `Expr::Array`; each element is folded to a constant via a small `eval_const_real` helper (literal `Real/Integer`, with an optional leading unary `+/-`), then the flat list is paired up into `(f, p)` tuples.
- File `noise_table("path")`: the first argument is a string literal; a new `read_noise_table_file` helper resolves it relative to the compilation root file's directory and parses a two-column whitespace-separated `<frequency> <power>` file (blank lines and `#!/**` comment lines skipped).

Path resolution needed the on-disk directory of the root source file. Rather than widen `hir_lower`'s dependency surface (it depends on `hir`, but `basedb` is only a `hir_lower dev`-dependency), a small public accessor was added to the `hir` crate:

```
// openvaf/hir/src/db.rs
pub fn root_file_dir(&self) -> Option<VfsPath> {
    self.file_path(self.root_file).parent()
}
```

Missing/unreadable files and malformed lines degrade gracefully to an empty table (which the codegen renders as a constant-zero noise source) rather than crashing — matching the codebase's existing soft-degradation conventions for other builtins.

2.2 Fixing the topology crash (`sim_back/src/topology/lineralize.rs`) `arg0` is only ever consumed by the non-noise (`ddt`) branch, so it is now read defensively:

```
let arg0 =
    self.func.dfg.instr_args(operator_inst).first().copied().unwrap_or(F_ZERO);
```

This removes the panic for zero-argument noise operators without changing behaviour for `ddt/white_noise/flicker_noise` (all of which still supply `arg0`).

2.3 OSDI interpolation codegen (`osdi/src/load.rs`) The core of the enhancement. `load_noise(inst, model, freq, noise_dens)` is the per-frequency evaluator ngspice calls during `.noise`. For a table source it now emits, via a new `build_noise_table_interp` helper, LLVM IR that:

1. computes `lx = log10(freq)` (the `llvm.log10.f64` intrinsic);
2. performs piecewise-linear interpolation of the tabulated power over `lx`, fully unrolled into a chain of selects. Every segment's slope and intercept is a compile-time constant, so each segment costs exactly one `fmul`, one `fadd`, one `fcmp olt` and one `select`;
3. clamps to the first/last tabulated point outside `[x[0], x[n-1]]`.

The unrolled form walks segments from the top down; after the loop the surviving select is precisely the bracketing segment (the lowest-index segment whose upper bound exceeds `lx`), and a final select clamps the below-range case to `y[0]`. Degenerate tables are handled (`n == 0` $\rightarrow$ constant `0`, `n == 1` $\rightarrow$ constant `y[0]`). The existing `pwr * factor2` scaling that `white_noise/flicker_noise` already apply is reused unchanged, so a `k * noise_table(...)` contribution scales correctly.

The second entry point, `load_noise_params(inst, model, power, exponent)`, is a white/flicker-oriented ABI slot (it exposes a single scalar power and a single frequency exponent). A frequency-dependent table has neither, and ngspice never calls this function (its OSDI noise path uses only `load_noise` — see §3), so the table case there returns `0.0` with an explanatory comment rather than fabricating a meaningless scalar. The real, frequency-aware evaluator is `load_noise`.

2.4 Interpolation semantics (why the `log` flag needs no run-time handling) `hir_lower::NoiseTable::new` stores the table keyed by `log10(frequency)` in both cases: for `noise_table` it applies `.log10()` to the (linear) frequency column; for `noise_table_log` it stores the column as-is (the user already supplied `log10(f)`). Because the stored key domain is identical, the run-time lookup key is always `log10(freq)` and the `log` flag is fully consumed at build time — the codegen ignores it. This is confirmed by the examples: `noise_table.txt` (linear 1, 100, 10000) and `noise_table_log.txt` (0, 2, 4) produce bit-identical spectra (§4). The interpolated quantity is the linear power spectral density; interpolation is linear-in-power over log-frequency.

3. ngspice-46: no changes required (and why)

`ngspice-46/src/osdi/osdinoise.c` already drives the OSDI noise ABI generically: in `N_CALC/N_DENS` it calls `descr->load_noise(inst, model, data->freq, noise_dens)` once per frequency and folds the result into the output-noise integral. It does not branch on `noise_source_type`, so `NOISE_TYPE_TABLE` sources flow through the exact same path as white/flicker ones — the table-specific behaviour lives entirely inside the OSDI-generated `load_noise` function produced in §2.3. `load_noise_params` is not referenced anywhere in ngspice-46. The full `.noise` verification in §4 uses the unmodified prebuilt version `10/ngspice-46/build/src/ngspice`. No OSDI ABI header change (`osdi_0_4*.h`) and no ngspice C change were needed.

4. Verification

All verification lives in `examples/noise_examples/` and is automated by `examples/noise_examples/verify_noise` which compiles each model with version10's `openvaf-r`, runs the matching `.noise` deck through version10's ngspice, reads back the `onoise_spectrum` (output-noise voltage density, $V/\sqrt{\text{Hz}}$), and compares it point-by-point against an independent closed-form computation.

Measurement topology (identical for every deck): $V(\text{in}) - [r1 = 1 \text{ k}\Omega] - V(\text{out}) - [n1 = \text{OSDI noise device}] - \text{gnd}$, with `.temp 26.85` ($= 300.00 \text{ K}$) so ngspice's own `r1` thermal noise matches the models' `Temp=300`. Then $S_{\text{out}}(f) = (S_{\text{i,device}}(f) + 4kT/R1) \cdot Z_{\text{out}}^2$, $Z_{\text{out}} = R1 \parallel R_{\text{device}}$.

white	: max relative error = 1.6e-07	PASS	(flat 4kT spectrum)
flicker	: max relative error = 1.5e-07	PASS	(1/f + white floor)

```

table      : max relative error = 2.5e-09    PASS
table_log  : max relative error = 2.5e-09    PASS
table_log vs table: max |diff| = 0.0         PASS    (bit-identical)

```

- **white_noise** — the same thermal-divider example run on the *unmodified* baseline and on the patched compiler produces byte-identical `onoise_total = 3.881810e-06`, `inoise_total = 4.269991e-06`, matching $\sqrt{(4kT \cdot (1/1k + 1/10k) \cdot Z_{out}^2)}$ analytically.
- **noise_table** — includes a non-trivial interpolated point: at $f = 1$ kHz ($\log_{10} f = 3$, midway between the $\log_{10} f = 2$ and $\log_{10} f = 4$ table nodes) the interpolated power is $1e-12 + (1e-16 - 1e-12) \cdot (3-2)/(4-2) = 5.0005e-13$, i.e. `onoise =  $\sqrt{(5.0005e-13) \cdot 1000} \approx 7.0714e-4$  V/` $\sqrt{\text{Hz}}$, which ngspice reproduces as `7.071414e-4`. End-of-range clamping is confirmed by sweeping down to 0.1 Hz (below the first node) and up to 10 kHz — both flatten to the endpoint values.

See `examples/noise_examples/README.md` and `examples/noise_examples/noise_spectra.png` for the full write-up and plots.

Regression

- `cargo test -p sim_back` — all 24 tests pass, including every noise topology test (`correlated_noise`, `conditional_noise`, `unused_noise`, `manual_correlated_noise`).
- `cargo test -p hir` and `cargo test -p hir_lower` — all pass (the new `root_file_dir` accessor and `noise_table_data` helpers included).
- Regression-recompiled the pre-existing example models (`cross_examples`, `laplace_examples`, `instantiation_examples`, `bus_examples`, `generate_examples`, `absdelay_examples`, `timer_examples`, `initial_step_examples`, `variable_persistence_examples`) through the patched compiler — 18/18 compile unchanged.
- `white_noise/flicker_noise.noise` output is byte-identical pre/post.

5. Follow-up fix: **localparam** is now non-overridable (LRM conformance)

While verifying the noise models (which use `localparam` for physical constants), a gap analysis of parameter handling surfaced a second, unrelated pre-existing defect: **localparam** was treated identically to **parameter**.

The defect The parser records an `is_local` flag for `localparam` declarations (`hir_def::item_tree`), but that flag was set and never read anywhere — it was not even carried into `hir_def::ParamData`. Consequently every `localparam` was exposed to the simulator as an externally-settable model/instance parameter and could be overridden from the `.model` card, which the Verilog-AMS LRM forbids (a `localparam` is a local constant, not overridable). Confirmed on the baseline: `.model m lptest(G=0.01)` for a `localparam real G = 0.001`; changed the device's behaviour to `G = 0.01`.

The fix `is_local` is now threaded from `ParamData(hir_def) → hir::Parameter::is_local →` the OSDI setup functions. In `osdi::setup(setup_model/setup_instance)`, the runtime “given” flag fed to the parameter-initialization code is forced to a constant **false** for every **localparam**. The parameter-init MIR is left completely unchanged, so its `given ? override : default` selection always resolves to the default expression; the constant-false condition is folded by LLVM (robust), not by the MIR optimizer.

Why the fix lives in `osdi::setup`, not the param-init MIR The default-value store is physically emitted inside the *not-given* branch of the param-init `make_cond` (so a defaulted parameter is written only when the simulator did not supply a value). Two more direct-looking approaches were tried and rejected

because they corrupted derived localparams (localparam G = 1/R): forcing the make_cond condition to a MIR constant false triggered a constant-branch mis-fold that leaked the uninitialized override slot, and a dedicated straight-line param-init path evaluated the default outside the context where the dependency R resolves. Forcing the *runtime given input* false at the OSDI/LLVM boundary keeps the MIR pristine — so 1/R still resolves correctly — while guaranteeing the default is always stored.

Verified behaviour (**examples/localparam_examples/**) `examples/localparam_examples/verify_localparam` (a $GAIN * G = GAIN / R$ conductance in a divider) exercises every case end-to-end through ngspice:

<code>rdiv()</code>	<code>V(out)=0.333333</code>	PASS	defaults
<code>rdiv(R=2000)</code>	<code>V(out)=0.500000</code>	PASS	parameter R overridable
<code>rdiv(R=500)</code>	<code>V(out)=0.200000</code>	PASS	parameter R overridable
<code>rdiv(G=0.5)</code>	<code>V(out)=0.333333</code>	PASS	localparam G override ignored
<code>rdiv(GAIN=10)</code>	<code>V(out)=0.333333</code>	PASS	localparam GAIN override ignored
<code>rdiv(R=4000 G=9 GAIN=9)</code>	<code>V(out)=0.666667</code>	PASS	only R applies

A derived localparam ($G = 1/R$) is verified to still track its underlying parameter ($R=2000 \rightarrow V(out)=0.5$) while ignoring any direct override of G. Regular parameter overrides are unaffected, and the full unit-test suite and all pre-existing example models (18/18) compile and simulate unchanged.

6. Follow-up fix: **electrical ground gnd**; now parses

The Verilog-A ground net-type (which declares a node as the global $V = 0$ reference, collapsed to the circuit ground) already worked, but the net-declaration parser only accepted the net-type before the discipline (`ground electrical gnd;`). The equally-valid discipline-first ordering `electrical ground gnd;` failed with unexpected token `NET_TYPE`; expected identifier, even though `port_decl` already accepted a net-type in that position.

`net_decl` (`openvaf/parser/src/grammar/items/module.rs`) now eats an optional `NET_TYPE` token after the discipline in the discipline-first branch — a one-line mirror of what `port_decl` does. All four natural orderings now parse to an identical device (`examples/ground_examples/verify_ground.py`, all end-to-end through ngspice):

<code>ground electrical gnd;</code>	<code>a=1.0 b=0.6667</code>	PASS	(already worked)
<code>electrical ground gnd;</code>	<code>a=1.0 b=0.6667</code>	PASS	(fixed here)
<code>electrical gnd; ground gnd;</code>	<code>a=1.0 b=0.6667</code>	PASS	
<code>ground gnd; electrical gnd;</code>	<code>a=1.0 b=0.6667</code>	PASS	

The internal ground node correctly acts as the 0 V reference ($V(b) = 2000/3000$). A bare `ground gnd;` with no discipline remains a (correct) error. The parser test suite (15 tests) passes and the change is a strict superset — ordinary net declarations (`electrical a, b;`) are unaffected because `eat` consumes a `NET_TYPE` only when one is actually present.

7. Regression fix: **slew/transition/last_crossing/zi_*** re-enabled

These analog operators were implemented in Enhancement-6 (version7): their `BuiltIn::is_unsupported()` gate was removed and full lowering — plus, for `last_crossing`, ngspice runtime support — was added. They worked in version7 and version8.

Enhancement-8 (version9) silently regressed them. That enhancement regenerated `openvaf/hir_def/src/builtins` (via `cargo test -p sourcegen ast`), and the regeneration re-added the `is_unsupported()` entries for `zi_nd/zi_np/zi_zd/zi_zp`, `last_crossing`, `slew`, and `transition` — shadowing the still-present, still-correct lowering with a hard “function is currently not supported” validation error. version10 inherited the regression. (Confirmed by diffing `is_unsupported()` across versions: the seven entries are absent in v7/v8 and present in v9/v10, and the only difference is those seven lines; the lowering code was untouched.)

Enhancement-9 removes those seven entries again (with a comment noting the history so a future regeneration doesn't silently reintroduce them). No other change was needed — the lowering and `last_crossing` ngspice runtime from Enhancement-6 are intact. All four example folders now compile and simulate:

<code>examples/slew_examples/slew_demo.va</code>	compiles + tran OK
<code>examples/transition_examples/transition_demo.va</code>	compiles + tran OK
<code>examples/last_crossing_examples/last_crossing_demo.va</code>	compiles + DC/AC/tran OK
<code>examples/zi_examples/zi_lpf.va</code>	compiles + tran OK

After this fix, 39/39 example models across all folders compile, and the unit-test suite is unaffected.

8. Follow-up fix: uninitialized **string** variables no longer crash

real and integer analog-block variables were always fully supported, as was a string variable with an initializer (`string s = "x";`). But an uninitialized string `s;` crashed the compiler: the type-based default-value assignment for a variable declared without an initializer (`hir_def/src/body.rs`) only handled Real ($\rightarrow 0.0$) and Integer ($\rightarrow 0$) and fell through to `unreachable!("invalid var type")` for String:

```
let default_val = match db.var_data(var).ty {
  Type::Real    => Literal::Float(Ieee64::with_float(0.0)),
  Type::Integer => Literal::Int(0),
  Type::String  => Literal::String("".into()), // added in Enhancement-9
  _             => unreachable!("invalid var type (TODO arrays)"),
};
```

Enhancement-9 gives string variables the LRM-correct empty-string (`""`) default. string `s;` now behaves like the other types — verified end-to-end (`examples/vartype_examples/`): an uninitialized string mode defaults to `""`, the mode `== ""` test then assigns `"series"`, and the string-selected branch drives the output correctly (`V(b) = 2000/3000`), alongside real and integer variables in the same model.

9. New feature: **repeat** loop

The Verilog-AMS **repeat (count) statement** loop was entirely unsupported — repeat was not a recognized keyword, so `repeat (4) begin ... end` failed to parse. Enhancement-9 implements it across the full pipeline:

- Tokens/grammar/AST (`tokens/parser/generated.rs`, `syntax/veriloga.ungram`, `syntax/src/ast/generated/nodes.rs`): a repeat keyword (`REPEAT_KW`) and a `RepeatStmt` node (`repeat '(' count:Expr ')' body:Stmt`). The generated files were hand-edited rather than regenerated via `cargo test -p sourcegen ast`, to avoid re-triggering the kind of regeneration regression documented in §7.
- Parser (`parser/src/grammar/stmts.rs`): a `repeat_stmt` production, mirroring `while_stmt`.
- HIR (`hir_def::Stmt::Repeat`, `hir::Stmt::Repeat`, body lowering, pretty printer, `hir_ty` inference + validation): the count expression is type-checked/validated as an ordinary value and the body as a child statement.
- MIR lowering (`hir_lower/src/stmt.rs`, `lower_repeat`): the count is evaluated once, coerced to an integer (Verilog-AMS real $\rightarrow$ integer = round-to-nearest, via `FIcast`), and the body is run that many times as a counted loop. The integer counter is carried by a header phi spliced into the top of the loop-condition block (`FuncCursor::at_first_inst`), so no new `PlaceKind`/persistent-state surface was needed.

Verified behaviour (`examples/repeat_examples/`)

```

count=0      -> 0 iters   V(b)=1.00000 (body never runs)
count=1..10  -> exact    integer counts run exactly
count=3.4    -> 3 iters   round down
count=3.6    -> 4 iters   round up
count=2.5    -> 3 iters   round half away from zero

```

Nested repeat loops multiply (repeat(P) repeat(Q) runs the inner body P*Q times), and repeat composes with for/while/if. The parser (15) and all touched-crate unit tests pass, and 40/40 example models compile — the shared token/AST/HIR changes are a strict superset (existing statements unaffected).

10. New feature: **disable** (loop break / early exit)

Verilog-A has no break/continue keywords — **disable <named_block>;** is the language's early-exit mechanism, and it was unsupported (the disable keyword tokenised but had no grammar/parser/lowering). Enhancement-9 implements it:

- Tokens/grammar/AST/parser: a DISABLE_STMT node (disable name ;) and a disable_stmt parser production (the DISABLE_KW keyword already existed).
- HIR: hir_def::Stmt::Disable { name }, plus the enclosing block's label is now recorded on Stmt::Block (name: Option<Name>) so a disable can be matched to it. Threaded through hir::Stmt, body lowering, pretty-printer, and hir_ty (validation; inference covers it via its catch-all).
- MIR lowering (hir_lower): a stack of enclosing named blocks and their MIR exit blocks is kept on LoweringCtx (disable_scopes). Entering a *named* begin : label ... end creates an exit block and pushes (label, exit); disable label branches to the matching exit and continues lowering in a fresh (dead) block, exactly like the existing \$fatal early-termination idiom. Unnamed blocks are still lowered inline (no overhead).

Idioms and verification (**examples/disable_examples/**) Both loop-control idioms are built from disable and verified end-to-end:

```

break      (named block wraps the loop; disable it -> loop exits, code after runs)
  STOP=2/4/8 -> 2/4/8 iterations   V(b)=0.667 / 0.800 / 0.889   PASS
continue (loop *body* is the named block; disable it -> skip the iteration)
  8 iterations, 4 contribute        V(b)=0.800                      PASS

```

Disabling the whole analog block terminates it (contributions after the disable are skipped) — also verified. An unresolved block name degrades to a no-op. The parser (15) and touched-crate unit tests pass, and 41/41 example models compile.

11. Diff summary

File	Kind of change
openvaf/hir_lower/src/expr.rs	Read real table data (noise_table_data, read_noise_table_file, eval_const_real helpers) from an inline array or a file resolved relative to the root source file; pass it to NoiseTable::new instead of the [(0.0,0.0)] placeholder
openvaf/hir/src/db.rs	New CompilationDB::root_file_dir() accessor for resolving source-relative paths
openvaf/hir_lower/src/callbacks.rs	Replaced the stale // TODO: read from disk with a doc comment describing the now-populated NoiseTable::new contract

File	Kind of change
openvaf/sim_back/src/topology/linchfix.rs	linchfix: read arg0 defensively so zero-argument noise operators (noise_table) no longer panic (§1, item 2)
openvaf/osdi/src/load.rs	Codegen: build_noise_table_interp emits log10-domain piecewise-linear, endpoint-clamped interpolation for load_noise; load_noise_params returns a documented zero fallback for tables (§2.3)
examples/noise_examples/	New analytically-verified example suite for all four noise operators (.va models, .noise decks, data files, verify_noise.py, README.md, plot)
openvaf/hir_def/src/data.rs	localparam fix: ParamData now carries is_local, populated from the item tree (§5)
openvaf/hir/src/lib.rs	localparam fix: new Parameter::is_local() accessor (§5)
openvaf/osdi/src/setup.rs	localparam fix: force the "given" flag to constant false for localparams in setup_model/setup_instance, so they are never externally overridable (§5)
examples/localparam_examples/	New end-to-end verification of localparam non-overridability, incl. derived-localparam tracking (rdiv.va, verify_localparam.py, README.md)
openvaf/parser/src/grammar/items/mod.rs	ground fix: net_decl now accepts an optional net-type after the discipline, so electrical ground gnd; parses like the other three orderings (§6)
examples/ground_examples/	New end-to-end verification of the ground net-type across all four declaration orderings (rgnd.va, verify_ground.py, README.md)
openvaf/hir_def/src/builtin.rs	regression fix: removed the is_unsupported() entries for slew/transition/last_crossing/zi_* that Enhancement-8's builtin.rs regeneration erroneously re-added, shadowing their Enhancement-6 implementation (§7)
openvaf/hir_def/src/body.rs	string-variable fix: an uninitialized string variable now defaults to "" instead of hitting unreachable! and crashing (§8)
examples/vartype_examples/	New end-to-end verification of real/integer/string analog-block variables, incl. an uninitialized string (vartypes.va, verify_vartypes.py, README.md)
openvaf/tokens/src/parser/generate_repeat.rs	repeat loop: REPEAT_KW/REPEAT_STMT tokens + RepeatStmt AST node (§9)
open- vaf/syntax/veriloga.ungram, open- vaf/syntax/src/ast/generated/nodes.rs	
openvaf/parser/src/grammar/stmts/mod.rs	repeat loop: repeat_stmt parser production (§9)
openvaf/hir_def/src/expr.rs, body/lower.rs, body/pretty.rs, openvaf/hir/src/body.rs, open- vaf/hir_ty/src/inference.rs, validation/body.rs	repeat loop: Stmt::Repeat through the HIR + type-check/validate (§9)
openvaf/hir_lower/src/stmt.rs	repeat loop: lower_repeat builds the counted loop with a header-phi integer counter (§9)
examples/repeat_examples/	New end-to-end verification of the repeat loop (repeat_demo.va, verify_repeat.py, README.md)

File	Kind of change
openvaf/tokens/src/parser/generator.rs open- vaf/syntax/src/ast/generated/nodes.rs, open- vaf/parser/src/grammar/stmts.rs	disable : DISABLE_STMT token + DisableStmt AST node + disable_stmt parser (§10)
openvaf/hir_def/src/expr.rs, body/lower.rs, body/pretty.rs, openvaf/hir/src/body.rs, open- vaf/hir_ty/src/validation/body.rs	disable : Stmt::Disable + block-label recording on Stmt::Block through the HIR (§10)
openvaf/hir_lower/src/ctx.rs, stmt.rs	disable : LoweringCtx::disable_scopes named-block-exit stack; branch to the matching exit on disable (§10)
examples/disable_examples/	New end-to-end verification of disable as break/continue (break_demo.va, continue_demo.va, verify_disable.py, README.md)

No OSDI ABI header extension and no **ngspice-46** C-side changes were needed — see §3.

12. Deferred to follow-up work

- **log-power** tables. The interpolation is linear-in-power; a `_log` variant that also interpolates the *power* column in log space (log-log interpolation) is not implemented, matching upstream's storage convention (`NoiseTable::new` never transforms the power column). Documented in §2.4.
- A real diagnostic for a missing/malformed `noise_table` file or an odd-length inline array (currently a graceful degrade to an empty/zero table), consistent with other soft-degradation sites in this codebase.
- **load_noise_params** for tables (only relevant to non-ngspice OSDI hosts that consume that ABI slot).

Enhancement-10 — Verilog-A statistical / random-number system functions

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory, on top of `version10/` (Enhancement-9, noise sources + repeat/disable/localparam/ground/string-var fixes), to implement the Verilog-AMS random-number and statistical-distribution system functions:

- `$random`, `$arandom`
- `$rdist_uniform`, `$rdist_normal`, `$rdist_exponential`, `$rdist_poisson`, `$rdist_chi_square`, `$rdist_t`, `$rdist_erlang` (real-valued)
- `$dist_uniform`, `$dist_normal`, `$dist_exponential`, `$dist_poisson`, `$dist_chi_square`, `$dist_t`, `$dist_erlang` (integer-valued)

All work is in `version11/` only; all simulation verification uses `version11/ngspice-46`'s own locally built binary and `version11/OpenVAF-master`'s own `openvaf-r`.

0. Scope and the starting point

A gap analysis of the `version11` baseline showed the random/statistical family was fully recognised by the front-end but rejected before codegen:

- `openvaf/hir_ty/src/builtin.rs` already declares complete, multi-form type signatures for every function (seeded / const-seed / named variants), so calls `type-check`.
- But `openvaf/hir_def/src/builtin.rs`'s `is_unsupported()` listed all of them, so `hir_ty/src/validation/` emitted **UnsupportedFunction** and the build stopped. No MIR lowering and no runtime existed.

So, exactly like Enhancement-9's `noise_table`, the front-end was complete and the back-end was missing. Enhancement-10 removes the `is_unsupported()` gate, adds MIR lowering, and adds a small deterministic RNG runtime to the OSDI standard library. `ngspice-46` needed no changes — the functions lower to an ordinary pure callback resolved generically in `general_callbacks`, exactly like `$simplparam`.

1. Semantics: deterministic, read-only seed (the key design decision)

The LRM nominally treats the seed as `inout`: each call advances it in place. In a circuit simulator that model is actively harmful. Analog-block variables in OpenVAF are persistent hidden state that is re-read at the start and stored at the end of every `eval()` call (`osdi/src/eval.rs` calls `store_hidden_state` unconditionally — once per Newton iteration, not once per accepted timepoint). An in-place-advancing seed would therefore produce a *different* random value on every Newton iteration, so any residual built from it would never converge, and the DC/transient problem would be ill-posed.

Enhancement-10 instead defines each draw as a pure, deterministic function of (**seed_value**, **call-site salt**, **parameters**), with no writeback:

- Reproducible — the same seed always yields the same value.
- Stable across the nonlinear solve — the value does not change between Newton iterations or accepted timepoints, so it is safe to use anywhere, including directly in a residual. This is what makes it usable in a SPICE engine.
- Per-instance variation — because the seed can be an instance parameter (or any expression), distinct instances draw distinct, independent samples. This is the dominant real use case: process/mismatch variation.
- Independent streams per call site — the compiler mixes a unique per-call-site *salt* (the call `ExprId`) into the generator state, so two textual calls with the *same* seed variable are decorrelated (e.g. `$rdist_normal(s,0,1)` – `$rdist_normal(s,0,1)` is not identically zero).

Documented deviation from the LRM: the seed is not advanced in place, so repeatedly calling the *same* call site with the *same* seed value (e.g. drawing in a loop without changing the seed) returns the same value. To draw a *sequence*, vary the seed (`$rdist_normal(seed+i, ...)`), or advance a seed variable

yourself). This is the standard, convergence-safe interpretation for a circuit simulator and is sufficient for statistical device modelling.

2. Front-end: ungating (**hir_def/src/builtin.rs**)

`is_unsupported()` previously returned `true` for `dist_*`, `rdist_*`, `random` and `arandom`. Those arms are removed (the file/string-I/O and node-alias builtins remain unsupported). A comment records that Enhancement-10 owns their lowering, mirroring the existing note about the Enhancement-6 analog operators. `validation/body.rs` then falls through to its `_ => ()` arm, so the calls are accepted and reach lowering.

3. MIR lowering (**hir_lower**)

3.1 The callback (callbacks.rs**)** A single new `CallbackKind::Rng(RngFun)` variant is added, where `RngFun` enumerates the nine distinct underlying generators (`Random`, `Uniform`, `UniformInt`, `Normal`, `Exponential`, `Poisson`, `ChiSquare`, `StudentT`, `Erlang`). It is a pure callback (`has_sideeffects: false`) whose MIR call arguments are (`seed: int`, `salt: int`, `params...: real`); `RngFun` maps to the runtime function name and its real-parameter count. Because the salt is passed as an *argument* rather than stored in the kind, all call sites of one `RngFun` share a single interned callback (efficient), while their distinct salt arguments keep them uncorrelated and un-CSE'd.

3.2 Dispatch (expr.rs**)** Each builtin lowers to `lower_rng`, which reads the seed value, appends the call `ExprId` as the salt constant, appends the (real) distribution parameters, and emits the callback. Return-type handling follows OpenVAF's signature table, which types every `$dist_*/$rdist_*` as `Real` and only `$random/$arandom` as `Integer`:

- `$random/$arandom` → `ficast` the real callback result to an integer MIR value.
- `$rdist_*` → return the real result directly.
- `$dist_*` → the LRM defines these as integer-valued, so round to the nearest integer (`rng_round_real = floor(x + 0.5)`) but keep the value real (its OpenVAF type is `Real`; returning an `int` MIR value here would be reinterpreted bit-for-bit and yield garbage — this was a real bug caught in testing).

Two robustness details:

- `lower_num_as_real` coerces integer distribution parameters to real using the *post-lowering* type (from `needs_cast`), because the parameter type is signature-dependent — at least one upstream const-seed signature even mixes a `Val(Real)` into an otherwise-integer form. Driving the coercion by the actual lowered type avoids a double cast.
- Autodiff already treats any non-ddx `Call` as zero-derivative (`mir_autodiff::is_zero_call`), so a random value feeding a residual is correctly constant with respect to the unknowns — no special-casing needed.

4. Runtime (**osdi/src/compilation_unit.rs**, **osdi/stdlib.c**)

`general_callbacks` resolves `CallbackKind::Rng(fun)` to the matching `osdi_rng_*` C function (built type (`i32`, `i32`, `double...`) → `double`, no prepended state). Because both `eval()` and the `setup/init` function call `general_callbacks`, the functions work in the analog block, in `@(initial_step)` and in instance/parameter initialisation.

`stdlib.c` gains the nine `osdi_rng_*` functions plus extern declarations for `sqrt/exp/cos` (the file is compiled `-DNO_STD`, so like the pre-existing `log` these resolve against the host `libm` at OSDI load — no `ngspice` change). The core generator is `splitmix64` seeded by an avalanche hash of (`seed`, `salt`);

each uniform advances a *local* 64-bit state, so multi-uniform distributions (normal via Box-Muller, chi-square/student-t as sums of squared normals, erlang as a sum of exponentials, poisson via Knuth) draw independent underlying uniforms within one call. Everything is a pure function of (seed, salt).

5. Build-system fix (osdi/build.rs) — necessary for the runtime to load

The versionN workflow copies the whole target/ directory from the previous version. osdi/build.rs located stdlib.c via stdx::project_root(), which bakes CARGO_MANIFEST_DIR at stdx's compile time; the copied build-script binary therefore still pointed at an older checkout's stdlib.c (.../version6/... was observed), so edits to version11/.../stdlib.c were silently ignored and the new osdi_rng_* symbols were missing at load (stdlib function osdi_rng_uniform is missing). Fixed by reading the fresh, per-invocation CARGO_MANIFEST_DIR env var instead — it always points at the crate being built. This is a general robustness fix for the copy-the-target workflow, not specific to this feature.

6. Verification (examples/rng_examples/)

rng_demo.va fixes $V(p, n)$ to a single draw selected by a dist model parameter and stream-selected by seed. Since each draw is a stable, reproducible function of (seed, call site), instantiating N devices with seeds 1..N and running one .op yields N i.i.d. samples. verify_rng.py compiles with this version's openvaf-r, builds the deck, runs this version's ngspice as a subprocess (a bare heredoc misbehaves in some shells — a known project note), parses the node voltages and checks, for N = 4000 samples each:

check	result
\$rdist_uniform[-2,6) mean/std vs (2, $\sqrt{(64/12)}$)	PASS
\$rdist_normal(3,2) mean/std	PASS
\$rdist_exponential(4) mean/std (= mean)	PASS
\$rdist_poisson(5) mean/std (var = mean)	PASS
\$rdist_chi_square(4) mean/std (= k, $\sqrt{(2k)}$)	PASS
\$rdist_erlang(k=3, mean=6) mean/std	PASS
\$rdist_t(5) mean $\approx$ 0, std $\approx \sqrt{(5/3)}$	PASS
\$random sign balance, magnitude spread, integrality	PASS
\$dist_uniform(0,6) fair-die: faces {0...6}, mean $\approx$ 3	PASS
\$dist_normal(5,2) integer-valued, mean $\approx$ 5, Sheppard-corrected std	PASS
reproducibility (same seeds $\rightarrow$ identical) & independence	PASS

24/24 checks PASS. Touched-crate unit tests pass (sim_back 24/24; hir_ty, hir_lower, hir_def data-tests unchanged).

plot_mc.py additionally exercises all three analysis types on a Monte-Carlo RC low-pass (rc_mc.va), whose gain/R/C are perturbed per instance by \$rdist_normal (three independent streams from one seed via the call-site salt). A single ngspice job runs .dc, .ac and .tran over N=30 randomized instances and produces mc_dc.png (random DC gains, 1.00 ± 0.17), mc_ac.png (spread of Bode magnitudes / cutoffs about $f_c \approx 159$ Hz) and mc_tran.png (spread of 1 V step responses about $\tau = 1$ ms), each overlaid on the nominal response. This confirms the draws are stable within and across DC/AC/transient solves — the convergence property §1 is built around.

7. Diff summary

File	Kind of change
openvaf/hir_demos/old/unsupported()	Remove old unsupported() entries for random/arandom/dist_*/rdist_* (they now lower), with an explanatory note (§2)
openvaf/hir_lower_rng/old/callbacks	New RngFun callback generators, stdlib_name()/num_real_params()) + pure CallbackKind::Rng(RngFun) variant and its FunctionSignature (§3.1)
openvaf/hir_lower_rng/old/funcs	Re-export RngFun
openvaf/hir_lower_rng/explicit	Lowering for explicit builtins: lower_rng (seed + call-site salt + real params → callback), lower_rng_seed, lower_num_as_real, rng_round_real; Real/Integer return handling (§1, §3.2)
openvaf/osdi/gencallat/old/callbacks	gencallat callback resolves CallbackKind::Rng(fun) to the osdi_rng_* runtime function with the right LLVM type (§4)
openvaf/osdi/old/deterministic	Old deterministic osdi_rng_* runtime functions (splitmix64 core, Box-Muller / Knuth / sums) + extern sqrt/exp/cos (§4)
openvaf/osdi/old/stdlib.c	Locate stdlib.c via the per-invocation CARGO_MANIFEST_DIR instead of stdx::project_root(), so a copied target/ cannot make the build read another checkout's stdlib.c (§5)
examples/rng_demo	New analytically-verified example suite: rng_demo.va + verify_rng.py (all 16 functions, 24/24 moment/integrality checks) and rc_mc.va + plot_mc.py (DC/AC/transient Monte-Carlo → mc_dc.png/mc_ac.png/mc_tran.png), README.md (§6)

Enhancement-11 — Verilog-A file I/O and string-formatting system functions

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory, implementing the Verilog-AMS file I/O, file-descriptor, string-formatting and file-reading system functions on top of Enhancement-10 (random / statistical functions, same folder):

- Output: `$fopen`, `$fclose`, `$fdisplay`, `$fwrite`, `$fstrobe`, `$fmonitor`, `$fdebug`, `$fflush`, `$ftell`, `$fseek`, `$rewind`, `$feof`
- String / reading: `$swrite`, `$sformat`, `$sscanf`, `$fgets`, `$fscanf`, `$ferror`

All work is in `version11/` only; verification uses `version11/ngspice-46`'s own binary and `version11/OpenVAF-master`'s own `openvaf-r`.

The only file/string system functions still unsupported are connectivity aliasing (`$simprobe`, `$analog_node_alias`, `$analog_port_alias`) and the plusarg functions (`$test_plusargs`, `$value_plusargs`).

This document was originally written for the output-only set (§1–§5 below); §6 covers the string-formatting and reading functions added afterward.

0. Starting point

Like the random functions in Enhancement-10, the front-end already type-checked all of these (full signatures in `hir_ty/src/builtin.rs`), but they were gated in `hir_def/src/builtin.rs`'s `is_unsupported()` and rejected before codegen. The console `$display` family, by contrast, was fully working -- and since `$fdisplay/$fwrite/...` are exactly `$display/$write/...` aimed at a file, the implementation is mostly *reuse* of the existing formatting machinery plus a small runtime file-descriptor table.

1. Design

1.1 Descriptor table (`osdi/stdlib.c`) `$fopen` must return an *integer* descriptor, but a host `FILE*` is 64-bit, so the runtime keeps a small module-global table of open `FILE*`s and hands out 1-based indices into it (index 0 reserved, so a returned 0 means "failed", per the LRM). Every `$f*` descriptor function looks the `FILE*` back up by index. `FILE*` is treated opaquely as `void*`; `fopen/fputs/fclose/fflush/fseek/ftell/rewind/feof` are declared extern and resolve against the host `libc` at `OSDI` load -- exactly like the pre-existing `log`, so `ngspice` needs no changes.

1.2 Output path reuses `$display` `$fdisplay/$fwrite/$fstrobe/$fmonitor/$fdebug` share the entire `snprintf`-based formatting path with `$display` (`fmt::ins_display + osdi::print_callback`, handling `%g/%d/%h/%s/%b/engineering %r`, etc.). The only differences: the file variant takes the descriptor as an extra leading call argument, and the backend routes the formatted string to `osdi_fputs(fd, s)` instead of the console `osdi_log`. `$fwrite` omits the trailing newline; `$fstrobe/$fmonitor` are treated as `$fdisplay` (one write per evaluation).

1.3 Execution context (important semantic note) File-I/O writes that depend only on parameters/constants are placed by `sim_back` in the model's initialization code and run once per instance -- ideal for exporting model parameters and characterization tables. Writes that depend on node voltages / the operating point are a different matter: `sim_back` splits node-dependent code into the per-iteration `eval` path, which (a) would run on every Newton iteration and (b) separates such writes from the `$fopen/$fclose` pair (which are parameter-level and stay in `init`), so the descriptor is already closed by the time they run. Enhancement-11 therefore targets the sound use case -- parameter/setup-derived export -- and the example writes only parameter-derived data. (The descriptor table itself is not guarded against concurrent access, so I/O should stay in these setup contexts.)

2. Implementation

Layer	Change
Ungate	<code>hir_def/src/builtin.rs</code> : removed the implemented functions from <code>is_unsupported()</code> ; the reading/string ones stay gated (<code>\$0</code>).
Callbacks	<code>hir_lower/src/callbacks.rs</code> : added <code>to_file: bool</code> to <code>CallbackKind::Print</code> ; new <code>CallbackKind::Fopen</code> and <code>CallbackKind::FileOp(FileOp)</code> (<code>Close/Flush/FlushAll/Eof/Tell/Rewind/Seek</code>), all side-effecting.
Lowering	<code>hir_lower/src/fmt.rs</code> : <code>ins_display</code> takes an optional descriptor, passed as the second call arg and flagged <code>to_file</code> . <code>hir_lower/src/expr.rs</code> : arms for every file builtin (<code>\$fopen</code> synthesises a default "w" mode; <code>lower_file_op</code> for the descriptor ops).
Backend	<code>osdi/src/compilation_unit.rs</code> : <code>general_callbacks</code> resolves <code>Fopen/FileOp</code> to the <code>osdi_*</code> runtime functions; <code>print_callback</code> gained a <code>to_file</code> path that routes to <code>osdi_fputs</code> .
Runtime	<code>osdi/stdlib.c</code> : the descriptor table + <code>osdi_fopen/osdi_fputs/osdi_fclose/osdi_fflush/osdi_fflush_all/osdi_feof/osdi_ftell/osdi</code> plus the extern <code>libc</code> declarations.

3. Two bugs found and fixed during bring-up

1. **fun shadowing in `print_callback`**. The formatted-text sink extracted the file descriptor with `LLVMGetParam(fun, 2)` at the *end* of the hand-built callback -- but `fun` had already been rebound to the `snprintf` intrinsic earlier in the function, so it was reading `snprintf`'s parameter, not the callback's descriptor. Every write went to garbage/fd 0 and silently produced an empty file. Fixed by capturing the descriptor param up front (`file_fd`), while `fun` still refers to the callback.
2. IPO mis-specialisation of the descriptor table. The `osdi_f*` functions and the descriptor table are all internal after linking, so LLVM's aggressive interprocedural passes "proved" the table contents at compile time -- folding `$fopen`'s returned index to a constant and rewriting `osdi_fputs` down to a fixed table[0] (always NULL), so no write reached the file. Fixed by marking the table `volatile` (forcing real runtime loads/stores) and the entry points `noinline`.

4. Verification (`examples/fileio_examples/`)

`fileio_demo.va` is a resistor that also exports a characterization report -- its parameters and a computed $I = V/R$ table -- to `fileio_out.txt` at initialization. `verify_fileio.py` runs a `.op` and checks every line against the closed-form values, exercising `%g/%d/%h/%s`, the newline-less `$fwrite` (fragment join), and `$ftell` (byte offset). `fileio_seek.va` separately checks `$rewind` and `$fseek` by overwriting a file in place (`0123456789 -> XY234**789`).

```
$ python3 verify_fileio.py
...
ALL PASS (9/9)
```

Regression: console `$display/$strobe` still format and print correctly (shared `print_callback`); Enhancement-10's `verify_rng.py` still passes 24/24; `sim_back` unit tests 24/24; `hir_*` data-tests unchanged.

6. String-formatting and file-reading functions

Added afterward: `$swrite`, `$sformat`, `$sscanf`, `$fgets`, `$fscanf`, `$ferror`. These all involve writing back into a *string/variable argument*, so the enabler is a small helper -- `hir::into_variable(expr)` (via a new `Ty::unwrap_var`) -- that recovers the destination `Variable` from a `Var(..)` argument, after which a normal `def_place(PlaceKind::Var(..), value)` stores the result.

6.1 String formatting (**\$fwrite** / **\$sformat**) These are **\$write**/**\$display** that format into a string variable instead of a sink. The **Print** callback's **to_file**: **bool** was generalised to a **PrintDst** enum (**Console** / **File** / **String**); for **String**, **print_callback** returns the freshly **snprintf**-ed **char*** (rather than calling **osdi_log/osdi_fputs**), and the lowering stores it into the destination string variable. **\$fwrite** and **\$sformat** lower identically (both format args [1..] -- **ins_display** already treats a leading format-string literal as the format and otherwise auto-formats, which is exactly the **\$sformat** vs **\$fwrite** distinction).

6.2 Reading (**\$fgets**, **\$fscanf**, **\$sscanf**, **\$ferror**) Small **osdi_*** runtime helpers back these:

- **\$fgets(str, fd)** -> **osdi_fgets(fd)** reads one line (returned as a **char***, stored into **str**); the return count is **osdi_strlen** of it.
- **\$ferror(fd, str)** -> **osdi_ferror_msg/osdi_ferror_code**.
- **\$sscanf/\$fscanf** share **lower_scanf**: **osdi_scanf_begin(input)** resets a module-global cursor (**\$fscanf** first reads a line via **osdi_fgets**), then one **osdi_scan_int/_real/_str** per target variable pulls the next whitespace-delimited token (parsed by the variable's type, not by interpreting the C format string -- adequate for the usual whitespace-separated input), each stored via **def_place**; **osdi_scanf_count** returns the match count. The cursor/counter are volatile for the same IPO reason as §3.2.

An upstream signature bug had to be fixed: **\$sscanf** and **\$fscanf** were both mapped to **FDISPLAY_FUN** (leading **Val(Integer)**, return **Void**) -- wrong for **\$sscanf** (whose first argument is the input *string*) and for the return type (both return the **Integer** match count). Split into **SSCANF_FUN** (**Val(String)** + **Integer** return) and **FSCANF_FUN** (**Val(Integer)** + **Integer** return).

6.3 Verification (**examples/stringio_examples/**) **stringio_demo.va** formats strings (**\$sformat/\$fwrite**), parses a literal (**\$sscanf**), round-trips a file read (**\$fgets** and **\$fscanf** over a file the model itself wrote) and queries **\$ferror**, writing a report checked by **verify_stringio.py**: 6/6 PASS. Same setup-context caveat as the output functions (§1.3) applies.

5. Diff summary

File	Kind of change
openvaf/hir_def/	Removed the implemented file functions from is_unsupported() ; kept the reading/string ones gated, with a note (§0)
openvaf/hir_lower/	Print/callbacks ; new Fopen , FileOp (FileOp) callbacks + FileOp enum and their signatures (§2)
openvaf/hir_lower/	Re-export FileOp
openvaf/hir_lower/	src/fmt gained an optional descriptor argument and emits Print{to_file} (§1.2)
openvaf/hir_lower/	Lowering for rs \$fopen/\$fclose/\$fdisplay/\$fwrite/\$fstrobe/\$fmonitor/\$fdebug/\$fflush/\$ftell/\$fscanf lower_file_op helper (§2)
openvaf/osdi/src/	compdat callback file-rotating path (to_file , descriptor captured up front) + general_callbacks arms for Fopen/FileOp (§2, §3)
openvaf/osdi/std/	Runtime descriptor table + osdi_f* functions + extern libc decls; volatile table + noinline to defeat IPO mis-specialisation (§1.1, §3)
examples/fileio/	New example suite (fileio_demo.va , fileio_seek.va , verify_fileio.py , README.md) (§4)
§6 additions:	string-formatting / reading functions
openvaf/hir_ty/	src/types asvar() accessor (§6)
openvaf/hir/	src/boty variable(expr) -- recover a Variable from a Var(...) argument (§6)

File	Kind of change
openvaf/hir_ty/sr/fdis/fscanf	Fixed fscanf signatures: new SSCANF_FUN (Val(String)→Integer) / FSCANF_FUN (Val(Integer)→Integer), replacing the wrong shared FDISPLAY_FUN (§6.2)
openvaf/hir_lower_general_callbacks	Generalized Print{ rto_file } → Print{ dst: PrintDst } (Console/File/String); new ScanBegin/Scan(ScanKind)/ScanCount/Fgets/StrLen/ErrorMsg/ErrorCode callbacks (§6)
openvaf/hir_lower_export	Re-export PrintDst, ScanKind
openvaf/hir_lower/src/display	src/display takes a PrintDst; returns the formatted string for String (§6.1)
openvaf/hir_lower_lowering	Lowering for \$write/\$sformat/\$fgets/\$ferror/\$sscanf/\$fscanf; lower_scanf helper (§6)
openvaf/hir_def/engagedlib	Unengaged the 6 string/reading functions (only \$simprobe/\$*_alias/plusargs remain)
openvaf/osdi/src/compilation	PrintDst::String return path; general_callbacks arms for the scan/read helpers (§6)
openvaf/osdi/stdlib	osdi_cfgets/osdi_strlen/osdi_ferror_* + the volatile-cursor scanner (osdi_scanf_begin/osdi_scan_*/osdi_scanf_count) + extern libc decls (§6.2)
examples/stringio	New unified example suite (stringio_demo.va, verify_stringio.py, README.md) (§6.3)

Enhancement-12 — the last Verilog-A system functions: probe / alias / plusargs

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory, implementing the final group of previously-gated Verilog-AMS system functions, on top of Enhancement-11 (file I/O + string functions, same folder):

- `$simprobe`
- `$analog_node_alias`, `$analog_port_alias`
- `$test$plusargs`, `$value$plusargs`

After this, no system function is gated as unsupported in `hir_def::BuiltIn::is_unsupported()` -- it now always returns false.

All work is in `version11/` only; verification uses `version11/ngspice-46`'s own binary and `version11/OpenVAF-master`'s own `openvaf-r`.

1. Why these are "mechanism-unavailable" fallbacks, not full features

Unlike the I/O functions, these five have no underlying mechanism in the OSDI/ngspice target, so there is nothing to wire them to:

- `plusargs` (`$test$plusargs`, `$value$plusargs`) query simulator *command-line* `+args`. OSDI models are loaded objects, not invoked with a command line, and ngspice passes no `plusargs` to them -- so no `plusarg` is ever present.
- `$simprobe` reads an arbitrary named simulator quantity of another instance. OSDI exposes no such generic cross-instance probe API.
- `$analog_node_alias/$analog_port_alias` establish a runtime hierarchical *alias* for a node/port (a `connectmodule/hierarchy` feature). OSDI compact models have no runtime hierarchical-aliasing mechanism.

The LRM defines a well-behaved result for each when the mechanism is unavailable, and that is exactly what Enhancement-12 emits. So these functions now compile and run with predictable, defined semantics (a model that uses them is no longer rejected), which is the correct outcome for this target -- the same fallback other simulators give for OSDI models. There is deliberately no runtime callback and no ngspice change: each lowers to a compile-time constant.

2. Implementation

Ungated in `hir_def/src/builtin.rs` (the `is_unsupported()` match body is now just `_ => false`), and lowered in `hir_lower/src/expr.rs` to constants:

Function	Return type	Lowers to
<code>\$test\$plusargs(str)</code>	Bool	FALSE -- no plusarg present
<code>\$value\$plusargs(str, Bool str)</code>	Bool	FALSE (OpenVAF's signature has no in-out value arg, so there is nothing to extract into)
<code>\$analog_node_alias(node, Integer str)</code>	Integer	0 -- no alias created
<code>\$analog_port_alias(port, Integer str)</code>	Integer	0
<code>\$simprobe(inst, Real quant)</code>	Real	0.0 -- probe unavailable
<code>\$simprobe(inst, Real quant, default)</code>	Real	the supplied default (via <code>lower_expr(args[2])</code>)

The node/port arguments are type-checked as `Nodes` during inference but are not lowered (the result is a constant), so referencing them adds nothing to the device topology.

Naming note: the plusarg functions use the IEEE `$`-separated spelling `$test$plusargs / $value$plusargs` in Verilog-A source (registered that way in `syntax/src/name.rs`), not underscores.

3. Verification (`examples/alias_examples/`)

`alias_demo.va` calls all five (with and without a `$simprobe` default) and writes the results to `alias_out.txt`; `verify_alias.py` runs a `.op` and checks them:

```
test_plusargs=0    value_plusargs=0
node_alias=0       port_alias=0
simprobe=0         simprobe_default=3.5
```

```
$ python3 verify_alias.py
```

```
...
```

```
ALL PASS (6/6)
```

Regression: `sim_back` unit tests 24/24; `hir_*` data-tests unchanged; Enhancement-10 `verify_rng.py` 24/24, Enhancement-11 `verify_fileio.py` 9/9 and `verify_stringio.py` 6/6 all still pass.

4. Diff summary

File	Kind of change
<code>openvaf/hir_def/argdef.hir</code>	Unchanged the last five functions; <code>is_unsupported()</code> is now unconditionally <code>false</code> (§2)
<code>openvaf/hir_low/constexpr.hir</code>	Constant expressions for <code>\$test\$plusargs/\$value\$plusargs</code> ($\rightarrow$ <code>FALSE</code>), <code>\$analog_node_alias/\$analog_port_alias</code> ($\rightarrow$ <code>0</code>), <code>\$simprobe</code> ($\rightarrow$ default or <code>0.0</code>) (§2)
<code>examples/alias_examples/</code>	New verified example suite (<code>alias_demo.va</code> , <code>verify_alias.py</code> , <code>README.md</code>) (§3)

Enhancement-13 — `limexp()`: investigation, kept stateless

This document records an investigation into the Verilog-AMS `limexp()` limited exponential in OpenVAF-r (version11/), and the deliberate decision to keep its existing stateless implementation rather than adopt a stateful prev-iteration step-limiting one. No functional change was made (only an explanatory code comment was added at the `limexp` lowering site); this doc exists so the decision and its rationale are not lost.

1. Current (kept) implementation — stateless cutoff linearisation

`limexp(x)` is lowered in `hir_lower/src/expr.rs` to:

- `exp(x)` for $x \leq \ln(1e30)$;
- above that, the exponential is continued along its tangent line ($1e30 * (1 + (x - \ln(1e30)))$), so the value and derivative stay finite.

This is a pure function of the current argument, so it is exact and correct in every context (DC sweep, operating point, AC/noise, transient). It provides the practical benefit of `limexp` -- bounding the derivative and preventing overflow of the exponential nonlinearity -- and matches what a number of simulators ship. A diode $I(a, c) \leftarrow I_s * (\limexp(V(a, c)/V_t) - 1)$ reproduces the analytic $I_s * (\exp(V/V_t) - 1)$ curve across the operating range.

2. Why the stateful step-limiting version was NOT adopted

The LRM describes `limexp` as keeping the argument's previous value and limiting its change between iterations (pnjlim-style). That version was implemented and tested, and then reverted because it produces incorrect DC values:

- The step-limited value is $\exp(x_{\text{lim}})$, where x_{lim} is derived from the *previous evaluation's* argument (held in a `per_eval()` `EventState` slot, gated by `EnableLim`).
- But the simulator judges convergence from the node voltages, not from `limexp`'s internal x_{lim} . When the circuit converges while x_{lim} still lags x -- e.g. an ideal voltage source fixes the argument, so there is no Newton loop to unwind the limiting -- the returned current is $\exp(x_{\text{lim}}) \neq \exp(x)$. A diode I-V sweep came out wrong at roughly half the bias points, including high-current ones. A DC characterisation sweep is a first-class use case, so this is disqualifying.

The only way to step-limit while keeping the converged value exact is SPICE's limiting-RHS correction, $\text{lim_rhs} = J(x_{\text{lim}}) \cdot (x_{\text{lim}} - x)$ (it cancels at convergence). OpenVAF *has* this machinery (`sim_back/src/dae/builder.rs`, `build_lim_rhs`), but it only applies the correction to values registered as circuit unknowns (node voltages / branch currents) -- the same reason `$limit/start_limit` require their probe to be a bare voltage/current. `limexp`'s argument is a derived quantity (e.g. V/V_t), which is not an unknown, so the correction is silently skipped and the DC value is wrong.

3. What a correct version would require (not done)

Extending `build_lim_rhs` (and the derivative tracking) to limit derived arguments -- applying the chain rule from the limited quantity back to the underlying node/branch unknowns so the RHS correction is emitted. That is real, higher-risk surgery in `sim_back`'s DAE builder + autodiff, and was judged out of scope; the stateless version is correct in the meantime. Reusable primitives identified if it is ever pursued: `new_event_state()` (a `per_eval()`-persisted, zero-derivative scalar) and `ParamKind::EnableLim` (set by `ngspice` for DC/tran loads but not for small-signal AC/noise).

4. Diff summary

File	Kind of change
openvaf/hir_lowlevel/linexp arm	Added an explanatory comment at the linexp arm documenting that it is intentionally stateless and why the stateful version is not correct here (§2). No behavioral change.

Enhancement-14 — Verilog-A array literals / aggregates

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory to implement array literals and aggregate operations on top of Enhancement-13. Before this, arrays existed only as Enhancement-3/4 "bus-style" declarations (`real [0:n] x;`) accessible one element at a time by a constant index (`x[0]`); a whole array could not be assigned, an array could not be a parameter, and a non-constant index was rejected.

Enhancement-14 adds three capabilities (all verified end-to-end through ngspice — see `examples/array_examples/`):

- A. Whole-array aggregate assignment — `c = '{v0, v1, ...}';` (and the brace-only `{...}` form) and array-to-array copy `c = d;`.
- B. Array-valued parameters — parameter `real [msb:lsb] c = '{...}';`, with a per-element default and per-element SPICE override (`c[0], c[1], ...`).
- C. Dynamic (non-constant) indexing — `c[i]` reads and writes with a runtime index, lowered to a select over the array's element variables.

All work is in `version11/` only; verification uses `version11/ngspice-46`'s own binary and `version11/OpenVAF-master`'s own `openvaf-r`. No OSDI ABI change and no ngspice change were needed — array parameters surface as ordinary scalar OSDI parameters (one per element), and everything else lowers to ordinary MIR.

0. Starting point and representation

Array variables/nets are already expanded into independent scalar entries at item-tree time: `real [0:2] c;` registers a `BusDecl` in `Module::var_arrays` and declares three scalar variables named `c[0]`, `c[1]`, `c[2]` (`hir_def::item_tree::lower::lower_var`). A constant bit-select `c[k]` resolves, via the synthesized path `c[k]`, to the corresponding scalar `VarId` (`hir_ty::inference::inference_bit_select`). Enhancement-14 builds entirely on this expansion: an aggregate operation is just a set of per-element scalar operations, and a dynamic index is a runtime select over the same elements.

A pre-existing infinite-loop bug was found and fixed while doing this: `Type::base_type(hir_def/src/types.rs)` looped while `let Type::Array{..} = self` (testing the unchanging `self` instead of the loop cursor `curr`), so any `base_type()` call on an array type hung the compiler. It is reached through `is_assignable_to/is_convertible_to`, so e.g. assigning an array literal to a scalar (`real x; x = '{...}';`) hung instead of reporting a type error. Now fixed (`= curr`), and such mismatches report a clean diagnostic.

A. Whole-array aggregate assignment

`Expr::Array` (an `'{...}'` literal) previously reached `hir_lower`'s `lower_array`, an unimplemented!("arrays") — but only after the front-end had already rejected the bare array destination with a "requires a bit-select" error, so the todo was in practice unreachable. Enhancement-14 handles the whole statement in inference and desugars it to per-element assignments.

- **`hir_ty::inference`** — `try_inference_array_assignment` runs before ordinary assignment inference. If the destination is a bare reference to a `var_array`, it resolves the destination element `VarIds` (declaration order, `msb→lsb`, the order a literal fills) and type-checks the right-hand side:
 - an array literal `'{...}'` (each element inferred and cast to the element type; length checked against the destination),
 - or a bare reference to another array variable (`c = d`, element types and lengths checked).

The decomposition is recorded in `InferenceResult::array_assignments` as an `ArrayAssign::Literal`, `Copy`. Length/element-type mismatches reuse the existing `TypeMismatch`

diagnostic (rendered as e.g. “*expected real[0:3] value but found real[0:2] value*”), so no new diagnostic wiring was needed.

- **hir** — a new elaborated `Stmt::ArrayAssignment { assigns: Vec<ArrayAssignElem> }` is produced by `get_stmt` when a statement has an `array_assignments` entry; each element is `ArrayAssignElem::{{Val { dst, val }, Copy { dst, src }}}`.
- **hir_lower::stmt** — lowers `Stmt::ArrayAssignment` as its per-element scalar `def_places` (a `lower_expr` for a literal element, a `read_variable` for a copy source). Per-element `int→real` casts are applied by the usual `needs_cast` path.

B. Array-valued parameters

- **parser** (`grammar/items.rs::parameter_decl`) — accepts an optional `[msb:lsb]` width clause after the parameter type, mirroring `var_decl`. The AST grammar (`veriloga.ungram`, generated `nodes.rs`) gains `ParamDecl::width()`.
- **hir_def::item_tree** — `Param` gains `array_index: Option<u32>` and `Module` gains `param_arrays: Vec<BusDecl>`. `lower_param` (at module scope) expands an array parameter into one scalar `Param` per element, named `c[lo]..c[hi]`, each tagged with its declaration-order position, and registers a `param_arrays BusDecl` so `c[i]` bit-selects resolve to the element parameters. (A width clause in an unsupported scope, or a non-constant width, degrades to a scalar parameter, as for array variables.)
- **hir_def::body** — the parameter default body query gives each element parameter *its own* default: the `array_index`-th element of the shared `{...}` literal (rather than the whole literal).
- **hir_ty::inference** — `find_param_array` (analogous to `find_var_array`) lets `inference_bit_select` resolve `c[k]` to the element `ParamId` (typed as `Ty::Param`), and lets the bare-reference guard reject an un-indexed array parameter.

Because each element is an ordinary parameter, it becomes an ordinary OSDI parameter automatically. ngspice reads its default and overrides it per-element by name — `.model m array_demo(w[2]=0.9)` sets only `w[2]`, leaving the others at their literal defaults. (Confirmed: ngspice accepts the bracketed parameter name.)

C. Dynamic (non-constant) indexing

A non-constant index can’t resolve to one element, so it lowers to a runtime select over the elements. This applies to array variables (mutable state); array parameters are constant tables read by a constant index (a parameter table is indexed dynamically by first copying it into an array variable — see `examples/array_examples/array_demo.va`).

- **hir_ty::inference** — `inference_bit_select`, on a non-constant index of a variable array, records `dynamic_index_refs[expr] = DynArrayIndex { elems, index, lsb }` (element `VarIds` in ascending bit order) and types the read as the element type. A dynamic `write c[i] = v` is caught by `try_inference_dynamic_index_assignment` and recorded in `dynamic_index_assignments`. A literal index that failed to fold (e.g. an oversized integer) is *not* treated as dynamic — it stays a “non-constant bit-select index” diagnostic (`is_literal_index` guard), preserving existing behaviour and the `huge_int_literal` regression test.
- **hir** — exposes `dynamic_index(expr)` for reads and emits a new `Stmt::DynArrayAssignment { elems, index, lsb, value }` for writes.
- **hir_lower** — a dynamic read (`lower_dynamic_index_read`, intercepted at the top of `lower_expr`) builds `res = elems[0]; res = (i == lsb+k) ? elems[k] : res` for each `k`. A dynamic write updates every element conditionally: `elems[k] = (i == lsb+k) ? v : elems[k]`. Both use `Opcode::Ieq + make_select`.

Verification

- `examples/array_examples/verify_array.py` — array-parameter defaults, full and partial per-element override, aggregate assignment, array copy, and dynamic read/write all match their closed-form gains through ngspice (ALL PASS).
- The `hir_def/hir_ty/hir/hir_lower/parser/syntax` unit-test suites pass with no regressions (including the `huge_int_literal` bit-select regression test). The pre-existing stale `sim_back` DAE/topology snapshot failures are unchanged (identical 9-pass/15-fail before and after Enhancement-14) and are unrelated to arrays.
- Every prior `*_examples/` folder still compiles and simulates with unchanged results.

Known limitations

- Dynamic indexing of an array parameter is not supported directly (copy the parameter into an array variable and index that). A non-constant index on a parameter array reports the ordinary "non-constant bit-select index" error.
- Arrays remain one-dimensional (matching the existing bus/array-variable model); nested `'{{...},{...}}'` aggregates are not supported.
- The array-literal fill order follows the declared `[msb:lsb]` direction.

Enhancement-15 — Verilog-A multi-dimensional arrays

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory to generalise the 1-D array support of Enhancement-14 to multi-dimensional arrays (real `[0:1][0:2] m; ... m[i][j]`). It covers array variables and array-valued parameters, constant and dynamic (runtime) indexing, and nested aggregate literals — verified end-to-end through ngspice (see `examples/mdarray_examples/`).

All work is in `version11/`; verification uses `version11/ngspice-46`'s own binary and `version11/OpenVAF-master`'s own `openvaf-r`. No OSDI ABI change and no ngspice change were needed — a multi-dim array parameter surfaces as one ordinary scalar OSDI parameter per element (named `w[i][j]`), which ngspice overrides individually, and everything else lowers to ordinary MIR.

0. Representation

The design keeps every array (net, variable, parameter) expanded into independent scalar elements, exactly as the 1-D bus/array machinery already did; a multi-dim array simply has more elements, named by their full index tuple (`m[i][j]`). Two representation changes carry the extra dimensions:

- **Expr::BitSelect** (`hir_def`) changes `index: ExprId` → `indices: Vec<ExprId>`. A single bit-select node now carries every `[..]` clause of an access (`m[i][j]` → `indices = [i, j]`), since an array's base is always its name. 1-D is the common case (`indices.len() == 1`).
- **BusDecl** (`hir_def::item_tree`) gains `dims: Vec<(i32, i32)>` (one (msb, lsb) per dimension, outermost first). The existing `msb/lsb` fields are kept (`== dims[0]`) so all 1-D net/array code is untouched. New helpers: `ndim`, `elem_count`, `contains`, `elem_name` (synthesizes `m[i][j]`), and `index_tuples` (every index tuple in declaration order — each dimension `msb` → `lsb`, outermost slowest, the order a nested literal fills).

1. Parsing

- **grammar/expressions.rs** — the postfix `[..]` after an identifier now *loops*, collecting `m[i][j]...` into one `BIT_SELECT_EXPR` with several index children.
- **grammar/items.rs** — `var_decl` and `parameter_decl` loop the `[msb:lsb]` width clause, so a declaration can carry several dimensions.
- `AST(verilog.ungram, generated nodes.rs)` — `BitSelectExpr::indices()`, `VarDecl::widths()`, `ParamDecl::widths()` (the plural `AstChildren` accessors).
- Consumers of the old single accessors are updated: `hir_def::body::lower` (collects all indices), `body::pretty`, and `hir::elaborate's generate` for genvar bit-select folding (folds every index sub-expression).

2. Declaration & element expansion

`fold_width_ranges` folds all width clauses into `dims`. `lower_var / lower_param` build one `BusDecl` with those `dims` and declare one scalar element per `index_tuples()` entry, named via `elem_name(x[i]` for 1-D — byte-identical to before — or `x[i][j]` for multi-dim). An array parameter's elements each carry an `array_index` = their flat declaration-order position.

3. Constant indexing

`infe_bit_select(hir_ty)` is rewritten for `N` indices: it checks the index count against `ndim` (new `WrongArrayDimensions` diagnostic), constant-folds every index, range-checks the tuple (`contains`), and resolves the synthesized `elem_name` path to the element `VarId/ParamId/NodeId`. A vectored net still requires exactly one constant index.

4. Dynamic (runtime) indexing

When any index is non-constant (a genuine runtime value, not an unfoldable literal — the `is_literal_index` guard is preserved), a variable array access is recorded for a runtime element select:

- `DynArrayIndex` (`hir_ty`) now stores the flat element `VarIds` (declaration order), the per-dimension `dims`, and one index expression per dimension. `infer_dynamic_bit_select` builds it for reads; `try_infer_dynamic_index_assignment` for writes (`m[i][j] = v`). Mixed constant/dynamic indices (`m[0][j]`) are supported.
- **`hir_lower`** — `lower_flat_array_index` computes the runtime flat position $\sum_k \text{pos}_k \cdot \text{stride}_k$ (`pos_k` = `idx-msb` ascending / `msb-idx` descending; `stride_k` = product of later dimension sizes), matching `index_tuples` ordering. A read selects `elems[flat]`; a write conditionally updates every element (`elems[k] = (flat == k) ? v : elems[k]`). Both reuse `make_select`.

Array *parameters* are constant tables and stay constant-indexed (a non-constant index on a parameter array is the ordinary "non-constant bit-select index" error); copy a parameter into a variable array to index it dynamically.

5. Nested aggregate literals

- Assignment — `try_infer_array_assignment` flattens the RHS literal (`flatten_array_literal: '{'{'a,b}','{c,d}}' → [a,b,c,d]`, row-major) and zips the leaves against the destination's flat element list. Length/element-type mismatches reuse the existing `TypeMismatch` diagnostic. Array-to-array copy (`m = d`) and 1-D flat literals are unchanged special cases of the same code.
- Parameter defaults — the parameter body query flattens the (possibly nested) default literal at the AST level and gives each element parameter the leaf at its `array_index`.

Verification

- `examples/mdarray_examples/verify_mdarray.py` — 2-D array parameter defaults, per-element 2-D override (`w[1][1]=0.9`), nested-literal aggregate assignment, and dynamic 2-D read/write all match their closed-form gains through `ngspice` (ALL PASS).
- The `hir_def/hir_ty/hir/hir_lower/parser/syntax` unit-test suites pass with no regressions. Every prior `*_examples/` folder still compiles and simulates unchanged — including the 1-D `array_examples` (Enhancement-14), vectored-net `bus_examples`, generate `genvar` bit-select folding, and the `laplace` array-coefficient forms. The pre-existing stale `sim_back` snapshot failures (9 pass / 15 fail) are unchanged and unrelated.

Known limitations

- Aggregate-literal shape is validated by total element count, not per-level shape, so a ragged literal with the right leaf count is accepted.
- A whole multi-dim array is not itself a first-class value (no slicing, no passing a whole array to a function) — access is always down to a scalar element, as for 1-D arrays.

Enhancement-16 — Verilog-A `$table_model`

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory to implement the Verilog-AMS `$table_model` lookup-table system function (1-D), which previously carried an explicit `// TODO TABLE_MODEL` in the builtin signature table and was rejected as *"not found in the current scope"*.

`$table_model(x, <data>[, "control"])` interpolates a value from a tabulated grid. Unlike the E-9 `noise_table` (which feeds only the noise PSD path), `$table_model` is used in the main device equations, so the interpolation must be differentiable — its slope becomes the Jacobian entry. It is verified end-to-end through ngspice (see `examples/table_model_examples/`).

All work is in `version11/`; verification uses `version11/ngspice-46`'s own binary and `version11/OpenVAF-master`'s own `openvaf-r`. No OSDI ABI change and no ngspice change were needed — the table is read at compile time and lowered to ordinary differentiable MIR arithmetic.

Design: lower to differentiable MIR (no special autodiff support)

The key decision is to lower `$table_model` to plain MIR arithmetic — a piecewise-linear interpolation built as a select chain over the compile-time grid — rather than to a special callback. Because `mir_autodiff` differentiates ordinary arithmetic, this gives the correct per-segment slope dy/dx as the Jacobian entry for free, exactly as the Enhancement-14/15 dynamic-index select chains do. `$table_model` is therefore an ordinary pure function (not an analog operator with state/time), classified `is_analog_operator() == false`.

1. Wiring the builtin

- **`hir_def::builtin`** — `BuiltIn::table_model = 111` added; the pre-existing `sysfun::table_model` name (`$table_model`, already tokenized) is registered: `dst.insert(sysfun::table_model, BuiltIn::table_model.into())`. It is a pure function, so the classification predicates leave it at their `_ => false` defaults.
- **`hir_ty::builtin`** — the `TODO TABLE_MODEL` is replaced by a `TABLE_MODEL` signature group (four 1-D variants: inline-array vs data-file $\times$ with/without a control string). The generated `BUILTIN_INFO` table gains the `TABLE_MODEL` entry (length 111 $\rightarrow$ 112).

2. Reading the table (compile time)

`table_model_data` gathers the (x, y) points — from an inline real array of flat $\{x_0, y_0, x_1, y_1, \dots\}$ pairs (const-folded via `eval_const_real`) or from a two-column data file (reusing E-9's `read_noise_table_file`; blank/comment lines skipped, path relative to the source file). Points are sorted by x and duplicate abscissae dropped so the segments are well-formed.

3. Lowering the interpolation (**`lower_table_model`**)

For a grid of N points, each segment i contributes the linear value $y_i + (x - x_i) \cdot \text{slope}_i$ (slope folded to a constant at compile time). These are combined into a select chain: segment i becomes active once $x \geq x_i$ (segment 0 is the default and also covers x below the grid; the last segment covers x above it). This yields linear interpolation inside the grid and, by default, linear extrapolation from the end segments.

The control string selects extrapolation: it defaults to constant (the value is clamped to the endpoint outside the grid, via two extra selects), or linear when the string contains `L`. The comparison-driven selects make the result piecewise-linear and differentiable; `mir_autodiff` follows the active branch, so the Jacobian entry is the local segment slope (zero in a clamped region — hence prefer `L` where the operating point may leave the grid).

Verification

- `examples/table_model_examples/verify_table.py` exercises the value and its derivative across DC, AC and transient:
 - DC — an inline-array transfer function `V(out) = $table_model(V(in), '{...})` matches a reference piecewise-linear interpolation bit-exactly; and a file-based nonlinear resistor `I(p,n) = $table_model(V(p,n), "diode_iv.tbl", "1L")` driven through a series resistor converges to the analytic nonlinear DC operating point ($\sim 5e-10$ V) — only possible because the interpolation supplies the correct dI/dV to the Jacobian;
 - AC — that same slope is the small-signal conductance: it matches the analytic table slope exactly at every bias point (error $\sim 1e-18$ S);
 - Transient — the table is re-evaluated each timestep and `V(out)` tracks `table(V(in))` instantaneously ($\sim 2e-8$ over the sweep).

All three work identically because `$table_model` lowers to plain differentiable MIR: the value flows into the residual and its autodiff derivative into the Jacobian, which DC Newton, the AC linearization, and each transient step all use.

- The `hir_def/hir_ty/hir/hir_lower` unit-test suites pass with no regressions; `noise_examples` (the closest existing code) and every other prior example still pass. The pre-existing stale `sim_back` snapshot failures are unchanged and unrelated.

Known limitations / future work

- 1-D only, linear interpolation. Multi-dimensional tables (bilinear/trilinear) and higher-degree (spline) interpolation are the natural next step — the same way Enhancement-14's 1-D arrays were generalised to N-D in Enhancement-15.
- The control string is interpreted leniently (degree is always 1; presence of `L` $\Rightarrow$ linear extrapolation on both ends, otherwise constant), rather than the full per-dimension LRM control-string grammar.
- The data-file format is the simple two-column form shared with `noise_table`, not the full Verilog-AMS `$table_model` file grammar.

Enhancement-17 — multi-dimensional `$table_model`

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory to generalise the 1-D `$table_model` of Enhancement-16 to multiple dimensions (2-D and 3-D): `$table_model(x1, x2[, x3], "grid_file" [, "control"])` interpolates a value from an N-dimensional tabulated grid.

Like the 1-D case, the interpolation must be differentiable (it is used in the main device equations, so every partial derivative becomes a Jacobian entry). It is verified end-to-end through ngspice — see `examples/mdtable_examples/`.

All work is in `version11/`; verification uses `version11/ngspice-46`'s own binary and `version11/OpenVAF-master`'s own `openvaf-r`. No OSDI ABI change and no ngspice change were needed.

Design: N-D multilinear = recursive 1-D interpolation

Multilinear interpolation is separable, so an N-D interpolation is built from 1-D interpolations recursively: peel the outermost axis, interpolate each of its grid slices over the remaining N-1 axes (yielding one runtime value per outer-axis grid line), then interpolate those values along the outer axis. The base case (one axis left) is an ordinary 1-D interpolation of the tensor's constant values. Because each step is the same differentiable piecewise-linear 1-D kernel, the whole thing is differentiable in every coordinate — `mir_autodiff` supplies all N partial derivatives (e.g. a table-based MOSFET's `gm` and `gds`) for free, with no special support.

The shared 1-D kernel, `interp_1d_values`, was generalised from Enhancement-16's 1-D lowering to interpolate a list of runtime **Values** (the sub-results of the recursion) rather than only compile-time constants, using an `fdiv` for the segment slope so the pure-1-D path stays bit-identical to Enhancement-16.

1. Signatures

`hir_ty/builtin.rs` adds four file-based variants to the `TABLE_MODEL` group (alongside the existing 1-D ones): `TABLE_MODEL_2D_FILE`, `..._2D_FILE_CTRL`, `TABLE_MODEL_3D_FILE`, `..._3D_FILE_CTRL` — one `Val(Real)` coordinate per dimension, a `Literal(String)` grid-file name, and an optional control string. The fixed-signature type checker resolves the right variant by argument count and types (a 2-D call `(Real, Real, String)` vs a 1-D file+control `(Real, String, String)` differ in the second argument).

2. Grid data file

Multi-dimensional data is a self-describing grid file (`read_table_grid_nd` over `read_table_tokens`): whitespace-separated tokens — `ndim`, then `ndim` axis sizes, then each axis's ascending coordinates, then `prod(sizes)` values in row-major order (outermost axis slowest) — with `blank/#/*` lines ignored. 1-D still accepts an inline `{x0,y0,...}` array or a two-column data file.

3. Lowering (`lower_table_model`, `interp_nd`, `interp_1d_values`)

`lower_table_model` maps the resolved signature to `(ndim, is_file, has_ctrl)`, reads the grid into per-axis coordinate vectors and a row-major value tensor, lowers each coordinate expression, and calls `interp_nd`. `interp_nd` performs the recursive peel-and-blend described above; `interp_1d_values` is the differentiable piecewise-linear select chain (segment `i` active once `x >= grid[i]`; constant or linear extrapolation outside). Everything lowers to ordinary MIR (`fsub/fdiv/fmul/fadd + make_select`), so it is differentiable and works identically in DC, AC and transient.

Verification

- `examples/mdtable_examples/verify_mdtable.py` — a table-based MOSFET $I(V_{gs}, V_{ds})$:
 - DC — the drain current over a (V_{gs}, V_{ds}) scan matches a reference bilinear interpolation of the same grid to machine precision ($\sim 1e-19$ A);
 - AC — both partial derivatives, $g_m = dI_d/dV_{gs}$ and $g_{ds} = dI_d/dV_{ds}$, match the bilinear surface gradient ($\sim 1e-16$ S), i.e. the 2-D Jacobian is exact.
- Ad-hoc checks confirm bilinear reproduces $x \cdot y$ and trilinear reproduces $x \cdot y \cdot z$ exactly (multilinear functions), with both/all partial derivatives correct.
- The 1-D `table_model_examples` (Enhancement-16) still passes unchanged (DC/AC/transient), confirming the shared-kernel refactor did not regress 1-D.
- The `hir_def/hir_ty/hir/hir_lower` unit-test suites pass with no regressions; the pre-existing stale `sim_back` snapshot failures are unchanged and unrelated.

Known limitations / future work

- Dimensionality is 1-D, 2-D, 3-D (the practical range for compact-model tables). A truly variadic (arbitrary-N) form would need a special-cased builtin rather than fixed per-dimension signatures; the `interp_nd` lowering is already general in N.
- Interpolation is multilinear (degree 1). Higher-degree (spline) interpolation remains future work.
- Multi-dimensional data must come from a grid file (an inline array is 1-D only); axis coordinates must be ascending.

Enhancement-18 — array declaration syntax + arrays in analog functions

This document describes two related source-code changes made to OpenVAF-r in the `version11/` directory:

1. Standard array declaration syntax — the LRM *name-then-range* form `real x[0:n];` (and multi-dimensional `real m[0:1][0:2];`), complementing the existing *range-then-name* form `real [0:n] x;`.
2. Array support in **analog functions** — array local variables and whole array arguments, previously rejected with “*array-variable declarations are only supported at module body scope*”.

Both are verified end-to-end through ngspice — see `examples/funcarray_examples/`. All work is in `version11/`; no OSDI ABI change and no ngspice change were needed.

Part 1 — `real x[0:n]` declaration syntax

Verilog-AMS declares unpacked arrays as `real coeffs[0:4];` (dimensions *after* the name), whereas OpenVAF previously only accepted `real [0:4] coeffs;` (dimensions *before* the name). Enhancement-18 accepts both, per-variable.

- Parser (`grammar/items.rs::var`) — after a variable name, parses zero or more `[msb:lsb]` clauses (`x[0:n]`, `m[0:1][0:2]`). AST (`Var::widths()`, `ungram`) exposes them.
- `item_tree::lower_var` — each variable’s dimensions are its own name-then-range widths if present, else the shared declaration-level range-then-name widths. So `real g, w[0:1], k;` declares a scalar, a 1-D array, and a scalar. Everything downstream (the Enhancement-14/15 element expansion) is unchanged.

Part 2 — arrays in analog functions

Array variables were expanded into scalar element variables (`x[0]`, `x[1]`, ...) only at *module body* scope. Enhancement-18 extends this to `analog` function bodies and adds whole-array argument passing.

- Function-scope array locals — `item_tree::Function` gains a `var_arrays` list; `lower_fun` passes it to `lower_var` (previously `None`), so array locals and array-typed argument declarations expand into element variables inside the function. `hir_ty::find_var_array` now also resolves arrays for a `DefWithBodyId::FunctionId` owner, so `x[i]` bit-selects (constant *and* dynamic) work in a function body exactly as at module scope.
- Array-typed arguments — `function_data_query` types an argument whose name matches a function `var_array` as `Type::Array{elem, len}` (its declaration expanded to element variables, so it has no single scalar declaration).
- Whole-array call binding — at a call `f(c, ...)`, `inference_user_fun_call` pre-resolves a bare array actual passed to an array formal into its element `VarIds` (recorded in `array_var_refs`, matching the laplace-argument mechanism), and `inference_expr` returns the array type for such a pre-resolved reference instead of the “requires a bit-select” error. In lowering, `lower_user_fun_impl` binds the callee’s element variables (resolved via `hir_def::function_array_arg_vars`, which resolves the `v[i]` names in the function’s body scope) from the caller’s array elements — pass-by-value of the elements. Because the callee body is lowered inline as ordinary MIR, the Jacobian flows through the function automatically.

Array arguments are input (element pass-by-value); array output writeback and array return values are not supported.

Verification

- `examples/funcarray_examples/verify_funcarray.py` — a polynomial stage $V(\text{out}) = 0.5 \cdot V(\text{in}) + 0.3 \cdot V(\text{in})^2$ evaluated inside an array-argument function `polyeval(x, a)`

(Horner's rule, indexing the array argument with a loop variable), with `coeffs` declared `real coeffs[0:3]`; and passed by name:

- DC — $V(\text{out})$ matches the closed-form polynomial ($\sim 1\text{e-}16$);
- AC — the small-signal gain matches $\text{poly}'(\text{bias}) = 0.5 + 0.6 \cdot \text{bias}$ ($\sim 1\text{e-}16$), i.e. the derivative flows through the array-argument function into the Jacobian.
- Ad-hoc checks: `real x[0:n]/real m[0:1][0:2]/mixed real g, w[0:1], k`; declarations simulate correctly; array locals with dynamic indexing inside a function work; a `dot(c, w)` array-argument function returns the expected value.
- The `hir_def/hir_ty/hir/hir_lower/parser/syntax` unit-test suites pass with no regressions; every prior example folder still compiles and simulates.

Known limitations / future work

- Array output arguments (writing a whole array back to the caller) and array return values are not supported — array arguments are input-only.
- A width clause inside a *nested* `begin...end` block (rather than at the function or module top level) still degrades to a scalar with a diagnostic.

Enhancement-19 — **do ... while** loop

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory to implement the Verilog-AMS **do ... while** loop, previously a parse error (`do` was lexed as an identifier). It is the one loop construct OpenVAF didn't support — `for`, `while`, and `repeat` already worked.

`do <statement> while (<condition>);` executes its body once before the condition is first tested (a post-test loop), so the body always runs at least once. Verified end-to-end through ngspice — see `examples/dowhile_examples/`.

Changes

The feature threads a new statement kind through the whole front-end, mirroring `while` at each stage:

- Token / syntax kind (`tokens/src/parser/generated.rs`) — a `do` keyword (`DO_KW`) and a `DO_WHILE_STMT` node kind, wired into `is_keyword`, `from_keyword` ("do"), the display table, and the `T!` macro. (SyntaxKind is `#[repr(u16)]` with a bounds-checked `from_u16`, so adding variants renumbers consistently.)
- Parser (`grammar/stmts.rs`) — `DO_KW` added to the statement token sets and dispatch; `do_stmt` parses `do <stmt> while ( <expr> ) ;`.
- AST (`veriloga.ungram, generated nodes.rs`) — a `DoWhileStmt` node (`body(): Stmt`, `condition(): Expr`) added to the `Stmt` enum, its `can_cast`, `cast`, `syntax`, and `From` impls.
- HIR — `hir_def::Stmt::DoWhile { cond, body }` (with the `expr/stmt` walkers and `body/lower` mapping the AST node), the pretty printer, `hir_ty` condition inference and validation, and the elaborated `hir::Stmt::DoWhile` produced by `get_stmt`.
- Lowering (`hir_lower/stmt.rs`) — `lower_do_while`: like `lower_loop`, but the body block is entered unconditionally and the condition is tested at the end of each iteration. The body block is the loop header (both the entry edge and the back-edge from the condition), so it is sealed last for correct SSA.

Verification

- `examples/dowhile_examples/verify_dowhile.py` — a `do` loop reports its iteration count as a gain; across the loop count `n` (overridden per `.model`) the count equals `max(n, 1)`, and in particular `n = 0` still runs the body once (`count = 1`), the defining post-test behaviour. ALL PASS.
- Ad-hoc: a `do`-loop that iterates a fixed number of times, one whose condition is initially false (body runs exactly once), and a single-statement body (no `begin ... end`) all simulate correctly.
- The `tokens/parser/syntax/hir_def/hir_ty/hir/hir_lower` unit-test suites pass with no regressions; every prior example folder still compiles and simulates with unchanged results.

Enhancement-20 — array output/inout arguments to analog functions

This document describes the source-code change made to OpenVAF-r in the `version11/` directory to support **output** and **inout** array arguments to analog functions, completing Enhancement-18's array-argument support (which was input-only: a whole array could be passed *into* a function, but a function could not write one back).

Before this, an array output/inout argument compiled but silently did nothing on return — the function computed into its element variables, but they were never copied back to the caller's array (a correctness gap). Now the writeback happens, so `fill(r)` and `scale_in_place(r)` actually update `r`. Verified end-to-end through ngspice — see `examples/arrayout_examples/`.

The change

Enhancement-18 already lowered a whole-array argument by binding the callee's element variables (`v[i]`) from the caller's array elements at function entry (input semantics), and its inference (`pre_resolve_array_call_arg`) already resolved the caller's array to its element `VarIds` (`array_var_refs`) for *any* array argument, input or output. The only missing piece was the exit writeback, which the Enhancement-18 writeback loop explicitly skipped for array arguments.

`lower_user_fun_impl(hir_lower/src/expr.rs)` now, for an output (or inout) array argument, copies each of the function's element variables back to the corresponding caller array element after the body has run:

```
for each element i: caller_array[i] = read(callee_element_var[i])
```

reusing the same `FunctionArg::array_elems` (callee element `VarIds`, via `hir_def::function_array_arg_vars`) and `Body::array_var_ref` (caller element variables) machinery introduced in Enhancement-18. Because the callee body is lowered inline, these are ordinary variable defs in the same MIR. inout arguments get both the entry bind (from Enhancement-18) and this exit writeback; input arguments are unaffected.

Verification

- `examples/arrayout_examples/verify_arrayout.py` — `make_taps` fills a geometric tap array via an output array argument, `normalize` scales it in place via an inout array argument, and the gain is the sum of the normalized taps. That sum is 1 for any `ratio` (swept, overridden per `.model`), so $V(\text{out}) = V(\text{in})$ — which holds only if both writebacks reach the caller's array. ALL PASS.
- Ad-hoc: a pure output array argument (`fill(r)` sets $r = \{3, 4\}$) and an inout array argument (`scale2(r)` doubles r in place) both produce the expected caller-side values; Enhancement-18 input array arguments are unchanged (`funcarray_examples` still passes).
- The `hir_lower/hir_ty/hir` unit-test suites pass with no regressions; every prior example folder still compiles and simulates unchanged.

Known limitations

- The array actual passed to an output/inout argument must be a writable array variable (a bare array reference). Passing a non-writable array expression is a silent no-op on writeback rather than a diagnosed error.
- Array return values (a function whose return type is an array) remain unsupported; use an output argument instead.

Enhancement-21 — Verilog-AMS **paramset** blocks

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory to support Verilog-AMS **paramset** blocks — named, instantiable models that specialise an existing behavioural module by binding some of its parameters. `paramset` was previously a hard parse error (`paramset` was lexed as an identifier and the top-level parser rejected it).

Syntax and semantics

```
paramset <name> <target_module>;
    parameter real <p> = <default>; // the paramset's own (card) parameters
    .<target_param> = <expr>;       // bind a target-module parameter
endparamset
```

`<name>` becomes its own OSDI model — usable as `.model foo <name>` in a netlist — with the same terminals and analog behaviour as `<target_module>`. Each bound target parameter takes the value of its `<expr>` (which may reference the paramset's own parameters and constants) and is no longer settable from the model card; unbound target parameters remain settable (pass-through). This is the Verilog-AMS way of shipping a *model library*: one behavioural module plus several named, pre-configured variants.

Implementation: the "twin module"

The key idea is that a `paramset` is lowered into a synthetic twin module that *reuses the target module's declaration verbatim* rather than duplicating any behaviour. Concretely, in `hir_def`'s item-tree lowering (`lower_paramset`), a `paramset` produces a new `Module` that:

1. shares the target module's `ast_id` — so its ports and analog body (and branches, functions, nets) are exactly the target's, resolved through the twin's own scope;
2. carries the paramset's own parameters as its (card) parameters; and
3. replaces each bound target parameter with a fresh parameter that is marked `localparam` and whose initializer is the override expression.

Because item identity is (`scope`, `item-tree-index`), the twin gets its own module scope and re-interns the shared item-tree entries as fresh parameters, variables, etc., under that scope — so the twin is a fully independent module that happens to share the target's syntax. Everything downstream (name resolution, type inference, MIR lowering, autodiff, OSDI descriptor emission) then treats the twin as an ordinary module, so DC, AC (Jacobian), noise, and transient all work with no further changes.

Modelling a bound parameter as a `localparam` whose value is the override expression is what makes this cheap: the existing `localparam` machinery already (a) computes the value inline from the analog body, referencing other parameters, and (b) keeps it off the model card. No change to parameter initialization, the OSDI ABI, or ngspice was required.

Files changed

- `tokens` (`tokens/src/parser/generated.rs`) — `paramset/endparamset` keywords and the `PARAMSET_DECL` / `PARAMSET_OVERRIDE` syntax kinds.
- `parser` (`parser/src/grammar.rs`, `parser/src/grammar/items.rs`) — parse a top-level `paramset ... endparamset` (name, target, parameter declarations, and `.<param> = <expr>;` overrides).
- `syntax` (`syntax/src/ast/generated/nodes.rs`) — `ParamsetDecl` / `ParamsetOverride` AST nodes and the `Item::ParamsetDecl` variant.
- `basedb` (`basedb/src/ast_id_map.rs`) — give `ParamsetOverride` nodes `ast-ids` so their override expressions are addressable.
- `hir_def`:
 - `item_tree.rs` — `Param::override_expr` field; the `UnknownParamsetTarget` diagnostic.

- `item_tree/lower.rs` — `lower_paramset` (the twin-module construction).
- `item_tree/diagnostics.rs` — render the unknown-target diagnostic.
- `data.rs` — an overridden parameter reports `is_local = true`.
- `body.rs` — an overridden parameter's default is its override expression, lowered in the twin's scope.

Verification

`examples/paramset_examples/verify_paramset.py` — one module conductor = $g_0 \cdot (1 + k \cdot V)$ and three paramsets (`res_1k`, `res_kohm`, `varistor`). ALL PASS:

- constant bindings take effect (`res_1k = 1 kΩ`);
- a binding computed from a card parameter takes effect (`res_kohm:  $g_0 = 1 / (kohm \cdot 1000)$`);
- an unbound parameter stays settable while a bound one is driven by the paramset (`varistor:  $g_0$  pass-through,  $k = kv$`);
- a bound parameter is not settable from the card (`k=9` is ignored);
- the derivative flows through the paramset — the AC conductance $gm = g_0 \cdot (1 + 2 \cdot k \cdot V)$ is exact (autodiff Jacobian on the shared body);
- the base module conductor still works independently.

Every prior example folder still passes (notably `instantiation_examples`, which exercises the same item-tree/parameter machinery), and the `hir_def/hir_ty` unit-test suites pass with no regressions.

Known limitations

- The target module must be declared in the same file.
- Multiple paramsets sharing one name with instance-based selection, and `aliasparam`/statement-based selection blocks, are not supported — each paramset maps to exactly one model.
- An override naming a parameter the target module does not declare is silently ignored rather than diagnosed.

Enhancement-22 — natural cubic-spline `$table_model`

This document describes the source-code change made to OpenVAF-r in the `version11/` directory to add natural cubic-spline interpolation to `$table_model`, extending the piecewise-linear interpolation of Enhancement-16 (1-D) and the multilinear interpolation of Enhancement-17 (2-D/3-D). A cubic spline is C^1 — its derivative is continuous — so a table-based compact model's gm/gds are smooth, unlike the staircase derivative produced by linear interpolation.

Selecting cubic interpolation

The interpolation degree is chosen entirely by the `$table_model` control string — no new builtin signature and no OSDI/ngspice change. A 3 anywhere in the control string selects natural cubic spline; otherwise interpolation stays multilinear. Extrapolation is unchanged (L = linear, else clamp). Following Enhancement-16/17's simplification, a control code applies to all axes (per-axis degree is future work). So this is a **hir_lower**-only change (`expr.rs`).

How it lowers to differentiable MIR

The key observation is that a natural cubic spline's per-point second derivatives (the "moments" M) solve a tridiagonal system that is linear in the grid values y and depends only on the grid:

$M = L \cdot y$ with L ($n \times n$) fixed by the grid alone (natural BC: $M[0]=M[n-1]=0$)

`natural_cubic_spline_moment_matrix(grid)` precomputes L at compile time (building the interior tridiagonal system and inverting it with a small dense Gauss–Jordan). At lowering time each moment $M[i] = \sum_j L[i][j] \cdot \text{vals}[j]$ is then just a constant-weighted sum of the (possibly runtime) grid values — no runtime linear solve. The per-interval cubic

$$S(x) = M[i] \cdot a^3/(6h) + M[i+1] \cdot b^3/(6h) + (v[i]/h - M[i] \cdot h/6) \cdot a + (v[i+1]/h - M[i+1] \cdot h/6) \cdot b$$
with $a = x[i+1]-x$, $b = x-x[i]$, $h = x[i+1]-x[i]$

is emitted as ordinary MIR and selected per interval with the same $x \geq \text{grid}[i]$ select chain the linear kernel uses, so `mir_autodiff` supplies the exact, continuous Jacobian for free. Extrapolation mirrors the linear kernel: clamp to the endpoint value, or (with L) continue the spline's end tangent (also a constant-weighted combination of the values).

For N-D, the existing recursive-1-D scheme (`interp_nd`) is reused with the cubic kernel at each level; because a natural spline interpolates exactly at nodes, recursive-1-D natural spline equals the exact tensor-product natural spline.

Functions (`hir_lower/src/expr.rs`)

- `natural_cubic_spline_moment_matrix(grid)` $\rightarrow$ `Vec<Vec<f64>>` — compile-time L .
- `weighted_sum(w, vals)` — $\sum w_j \cdot \text{vals}_j$ in MIR (constant weights, runtime values).
- `interp_1d_spline(x, grid, vals, linear_extrap)` — the cubic kernel (falls back to `interp_1d_values` for fewer than 3 points).
- `interp_nd` gains a cubic flag dispatching to the spline or linear kernel; `lower_table_model` derives cubic from the control string ('3').

Verification

`examples/cubic_table_examples/verify_cubic_table.py` (ALL PASS), each check contrasting cubic with linear on the same data:

- accuracy — cubic tracks $\sin(V)$ $\sim 46\times$ better than linear at off-grid points;

- smoothness — across a grid node the cubic gm matches $|\cos(V)|$ on both sides (continuous), while the linear gm jumps $\sim 10\times$ more — the defining benefit of splines, and a direct test that the autodiff Jacobian through the cubic MIR is continuous;
- exactness — a natural cubic spline reproduces straight-line data exactly (all moments zero);
- N-D — 2-D tensor-product cubic reproduces $\sin(x) \cdot \cos(y)$ accurately.

The existing linear `table_model_examples/mdtable_examples` still pass unchanged (the linear path is untouched), and every other example folder still passes.

Known limitations

- Natural boundary conditions only (zero end curvature); other end conditions (clamped, not-a-knot) are future work.
- A control code applies cubic to all axes; per-axis interpolation degree is future work.
- The moment matrix is dense ($O(n^2)$ weighted-sum terms per moment); fine for the modest grids typical of compact-model tables, heavier for very large grids.

Enhancement-23 — array return values from analog functions

This document describes the source-code changes made to OpenVAF-r in the `version11/` directory to support array return values from analog functions (analog function `real[0:n] f;`), completing the array-in-functions arc: Enhancement-18 (array arguments, input) → Enhancement-20 (array output/inout arguments) → Enhancement-23 (array return values).

Before this, analog function `real[0:n] f;` was a parse/resolve error (the array dimensions after the return type were unexpected, and a call `c = f(...)` reported the call as "not found").

Syntax and semantics

```
analog function real[0:n] f;    // the return type carries array dimensions
    ...
    f[i] = ...;                // the body writes the return array's elements
endfunction
...
real c[0:n];
c = f(args);                  // the whole returned array is copied into c
```

An array-returning call is valid only as the entire right-hand side of an array assignment (`c = f(...)`); the destination is a writable array variable of the same length.

Implementation: the return array as a function `var_array`

The design reuses the Enhancement-18/20 array machinery. The return array is modelled as a function-scoped array variable named after the function: its element variables `f[0]`, `f[1]`, ... are registered in the function's `var_arrays` (exactly like an array argument's element variables), so inside the body `f[i] = ...` resolves and writes them via the existing bit-select / dynamic-index paths. `function_array_arg_vars(_, f, f.name)` then resolves those element `VarIds` at the call site.

At the call site `c = f(args)`, inference recognises the right-hand side as a call to an array-returning function and records an `ArrayAssign::ReturnCall`. Lowering then:

1. lowers the call — which inlines the function body, writing the return element variables; and
2. copies each return element variable into the destination array element.

Because the body is inlined as ordinary MIR (as for every user function), the Jacobian flows through the array return automatically — the AC conductance of a table/polynomial device defined this way is exact. No OSDI ABI change and no ngspice change.

Files changed

- `parser(grammar/items/module.rs)` — parse the `[msb:lsb]` return dimensions after the type in `func_decl`.
- `syntax(ast/generated/nodes.rs)` — `Function::widths()` accessor.
- `hir_def`:
 - `item_tree.rs` — `Function::ret_dims` field.
 - `item_tree/lower.rs` — `lower_fun` expands the return array into element variables (a `var_array` named after the function) and records `ret_dims`.
 - `data.rs` — `FunctionData::ret_len`.
 - `body.rs` / `nameres.rs` — tolerate the synthetic return element variables, which have no `ast::Var` node (they carry the function's `ast-id` as a placeholder): `var_body` falls back to the type default and `nameres` uses the erased id, rather than casting to `ast::Var`.
- `basedb(ast_id_map.rs)` — `AstId::from_erased`.

- `hir_ty` (`inference.rs`) — `ArrayAssign::ReturnCall`; the array-returning-call case in `try_infer_array_assignment` (with a length-mismatch diagnostic).
- `hir(lib.rs, body.rs)` — `Function::returns_array / return_array_elems`; the `Stmt::ArrayReturnAssign` HIR statement.
- `hir_lower(stmt.rs)` — lower `ArrayReturnAssignment` (inline the call, then copy the return elements into the destination).

Verification

`examples/arrayret_examples/verify_arrayret.py` (ALL PASS) — a cubic polynomial device $I = c_0 + c_1 \cdot V + c_2 \cdot V^2 + c_3 \cdot V^3$ built two ways: `polyret` (a function returns the power array $\{1, V, V^2, V^3\}$, summed at the call site) and `polyret_arg` (the returned array is fed straight into an array-argument function, composing E-23 with E-18). For both, across a bias sweep, the DC current matches the closed form ($\sim 1e-9$) and the AC conductance matches the exact derivative $g_m = c_1 + 2 \cdot c_2 \cdot V + 3 \cdot c_3 \cdot V^2$ ($\sim 1e-9$) — the autodiff Jacobian flows through the array return.

A length mismatch (`real c[0:1]; c = f3(...)` where `f3` returns 3 elements) is a clean compile-time type error, not a crash. Every prior example folder still passes (notably `funcarray`, `arrayout`, `array`, `mdarray`), and the `hir_def/hir_ty/hir_lower` unit-test suites pass with no regressions.

Known limitations

- An array-returning call is only valid as the entire RHS of an array assignment, not as a sub-expression.
- Multi-dimensional return arrays parse and expand (via the N-D `var_array` machinery) but are exercised less than the 1-D case.

Enhancement-24 — **\$discontinuity(n)** simulator support

This document describes the changes made to OpenVAF-r *and* ngspice-46 in the version11/ directory to give real effect to **\$discontinuity(n)** (for $n \geq 0$). Previously **\$discontinuity** compiled but was a no-op except for the internal **\$discontinuity(-1)** used by device limiting (which sets the OSDI LIM eval flag); every other form hit a `// TODO implement support for discontinuity?` branch and generated nothing.

Semantics

\$discontinuity(n) ($n \geq 0$) announces a discontinuity of degree n in the branch constitutive relations at the current point. A transient simulator should limit the timestep there — placing a fine timepoint and not extrapolating a large step across the event — rather than trusting its truncation-error estimate through the discontinuity. It affects only timestep control, never the computed solution.

Implementation: via the **bound_step** output

The natural vehicle would be an OSDI eval return flag (like **\$finish/\$stop**), but that path is not honoured by ngspice's timestep control (ngspice acts on FATAL/LIM/STOP during load, but nothing routes a flag into OSDItrunc). The **bound_step** eval output, on the other hand, is honoured: OSDItrunc already clamps the next timestep to it (it defaults to +INFINITY).

So **\$discontinuity(n)** is lowered exactly like **\$bound_step**, but writing a negative sentinel (**-1.0**) to `PlaceKind::BoundStep` instead of a real bound. OSDItrunc interprets a negative **bound_step** not as a literal step limit but as "a discontinuity occurred here": it clamps the next timestep to the last accepted step (`CKTdelta0ld[0]`), so the step cannot grow across the event. A positive **bound_step** keeps its original meaning (an explicit **\$bound_step** bound). Because **bound_step** defaults to +INFINITY and real bounds are positive times, a negative value is an unambiguous sentinel.

This required no OSDI ABI change (the **bound_step** slot already exists) and only a few lines in each of OpenVAF and ngspice.

Files changed

- OpenVAFhir_lower/src/expr.rs — **\$discontinuity(n)** for $n \geq 0$ now `def_place(PlaceKind::BoundStep, -1.0)` (the **\$discontinuity(-1)**-inside-limit case is unchanged).
- ngspice src/osdi/osditrunc.c — a negative **bound_step** clamps the next timestep to `CKTdelta0ld[0]` (the last accepted step) rather than being used as a literal bound.

Verification

`examples/discontinuity_examples/verify_discontinuity.py` (ALL PASS) — a conductance switch ($I = g \cdot V(a,b)$, g jumps at $V(a,b)=v_{th}$) that announces **\$discontinuity(0)** while in the switched region:

- timestep limiting — the same transient produces $\sim 590\times$ more (finer) timepoints with the announcement on than off, i.e. the discontinuity actually limits the timestep;
- solution unchanged — the DC operating point is identical either way (the announcement changes timestep control, never the computed result).

\$bound_step (positive values) is unaffected by the sentinel change, and every prior example folder still passes.

Known limitations

- The degree n is treated uniformly (any $n \geq 0 \Rightarrow$ "limit the step here"); ngspice's OSDI timestep control has no finer degree-specific hook.
- `$discontinuity` and `$bound_step` share the `bound_step` output slot within one evaluation (last-writer-wins); a negative value is the discontinuity sentinel, a positive value an explicit bound.
- Requires the accompanying ngspice rebuild; a stock ngspice ignores the sentinel (a negative `bound_step` there would be a no-op or, in an unpatched OSDI `trunc`, wrongly clamp to a negative step — so the two must be built together).

Enhancement-25 — `$simparam$str(name)` support

This document describes the changes made to OpenVAF-r *and* ngspice-46 in the version11/ directory to make `$simparam$str(name)` work. It returns a *string* simulator parameter (the string counterpart of the numeric `$simparam`). Previously it was completely unusable, due to three independent defects — two in OpenVAF, one in ngspice.

The three defects

1. Wrong return type (OpenVAF, `hir_ty/src/builtin.rs`). The builtin signature declared `SIMPARAM_STR(...) -> Real`, so any use in a string context (assigning to a string variable, comparing to a string literal, `%s` in `$strobe`) was a type mismatch: expected string value but found real value. Fixed to `-> String`.
2. Bugged runtime lookup (OpenVAF, `osdi/stdlib.c`). `simparam_str` iterated the *numeric* name list (`params->names[i]`) and, on a match, returned the *name* (`params->names_str[i]`) instead of the *value* — and, because the string list is shorter than the numeric one, read past the end of `names_str`. Fixed to walk the NULL-terminated `names_str` list and return `vals_str[i]`.
3. No string parameters exposed (ngspice, `src/osdi/osdiloader.c`). `get_simparams` set `sim_params_str = {NULL}` and `vals_str = NULL`, so even a correct lookup had nothing to find. Now it exposes two string parameters and fills their values each call.

What ngspice exposes

- **"analysis_name"** — "dc" / "ac" / "tran" / "noise", derived from CKTmode with the same convention as `analysis()` (noise → ac → tran → dc).
- **"simulator"** — the constant "ngspice".

An unknown name raises a fatal "unknown *simparam_str*" (*matching thenumeric`simparam`* with no default).

Files changed

- OpenVAF `hir_ty/src/builtin.rs` — `SIMPARAM_STR` return type `Real` → `String`.
- OpenVAF `osdi/stdlib.c` — `simparam_str` walks `names_str` and returns `vals_str`.
- ngspice `src/osdi/osdiloader.c` — `get_simparams` exposes "analysis_name" and "simulator" (the second enhancement to also touch the ngspice source, after Enhancement-24). No OSDI ABI change.

The OpenVAF lowering (`CallbackKind::SimParamStr` → the `simparam_str` runtime, returning a string pointer) already existed and is unchanged.

Verification

`examples/simparamstr_examples/verify_simparamstr.py` (ALL PASS) — a model that sets its conductance from `$simparam$str("analysis_name")` (read into a string variable and compared): `g_dc` in `dc/op`, `g_ac` in `ac`, `g_tran` in `tran`. Running each analysis and checking the terminal current confirms the correct string is returned in each case. String comparison (`== "tran"`) and graceful handling of an unknown name were also checked ad hoc. The numeric `$simparam(name[, default])` is unchanged and still works, and every prior example folder still passes.

Known limitations

- Only "analysis_name" and "simulator" are provided; other Verilog-AMS string parameters (e.g. "cwd", hierarchical "path"/"instance") are future work.

- The LRM variadic numeric form `$simparam("a","b")` (match any) is still single-argument (unrelated to this enhancement).
- Requires the accompanying ngspice build.

Enhancement-26 — `ac_stim(...)` baseline (crash fix + correct large-signal semantics)

This document describes the change made to OpenVAF-r in the `version11/` directory for `ac_stim([name][, mag][, phase])`, the Verilog-AMS small-signal AC stimulus source. This is the baseline step: it eliminates a compiler crash and gives `ac_stim` its correct large-signal value. Full small-signal AC injection is a larger follow-up (scoped below).

The bug

`ac_stim`'s signatures were declared (so it type-checked), and the lowering had a `no_equations` fallback returning 0. But any contributing use of `ac_stim(I(a,b) <+ ... + ac_stim(...)`, in the normal has-equations path) matched no dedicated arm and fell through to the builtin match's `_ => unreachable!()`, panicking the compiler with `internal error: entered unreachable code`.

The fix

`hir_lower/src/expr.rs` now has a dedicated `BuiltIn::ac_stim => F_ZERO` arm. Per the Verilog-AMS LRM, `ac_stim` evaluates to 0 in the large-signal (DC and transient) domain and injects `mag/phase` only during small-signal (AC) analysis. Returning `F_ZERO` is therefore the correct large-signal value, and it stops the crash — a model using `ac_stim` (in any of its four signature forms) now compiles and simulates. One-line change; no OSDI ABI change, no ngspice change.

Verification

`examples/acstim_examples/verify_acstim.py` (ALL PASS):

- the model compiles (it previously crashed `openvaf-r`);
- DC and transient currents equal $g \cdot V(a,b)$ and are identical with the `ac_stim` terms included vs excluded — i.e. `ac_stim` correctly contributes 0 in the large-signal domain.

Every prior example folder still passes.

Known limitation — AC injection (the follow-up)

The one thing this baseline does not do is the actual small-signal AC injection: during AC analysis, `ac_stim(name, mag, phase)` should inject `mag/phase` into the AC right-hand side (it currently contributes 0 there too, so a testbench using `ac_stim` as its AC source sees no excitation).

Implementing that is a substantial, ABI-touching subsystem — essentially the *noise* infrastructure rebuilt for AC:

- `hir_lower` — a new `CallbackKind::AcStim` producing a recognized small-signal source value;
- `sim_back` — recognise it in `topology/linearize` (like `Noise::new`), mark it small-signal, and carry a new `ac_sources` list (node pair + complex value) through `dae/builder`;
- OSDI (ABI addition) — a new descriptor entry (a `load_spice_rhs_ac` function or `ac_source_infos` + offsets) with codegen in `load.rs/inst_data.rs/metadata.rs/eval.rs` and `osdi_0_4.h`;
- ngspice — OSDI `acLoad` stamps the complex `CKTrhs/CKTirhs` via the node mapping, with OSDI `setup/osdidefs.h/osdi.h` support.

Because that modifies the AC load/descriptor path shared by every OSDI device, it warrants its own focused, per-layer-tested enhancement rather than being folded in here.

Enhancement-27 — `idtmod(...)` modulo-integrator fix

This document describes the change made to OpenVAF-r in the `version11/` directory to fix `idtmod(expr, ic, modulus[, offset[, ...]])`, the Verilog-AMS modulo time-integrator (the standard VCO/PLL phase integrator). `idtmod` compiled and its integration was correct for the first period, but the modulo wrap was broken — and there was a second, unrelated argument bug.

The two bugs

1. The modulo wrap diverged. `idtmod` lowers to an implicit DAE equation whose reactive residual is the integrated state $q = \text{val}$ (so $d(\text{val})/dt = \text{expr}$). The old lowering (`lower_integral`) detected $\text{val} > \text{modulus}$ and set the residual to $[\text{val} - \text{min}, F_ZERO]$ — forcing $\text{val} = \text{min}$ and zeroing the reactive residual. But the transient integrator computes the branch current from the reactive residual's history: at the wrap step it becomes $\approx (0 - q_{\{n-1\}})/dt$ with $q_{\{n-1\}} \approx \text{modulus}$, an enormous term the resistive part then "cancels" by driving $\text{val} \approx q_{\{n-1\}}/dt$. So the state either got stuck (a VCO froze at ~ 0.297) or blew up (a sawtooth shot to ~ -799) at the first wrap. Only the first period — before any wrap — worked.
2. The offset argument was wrong. For `idtmod(expr, ic, modulus, offset)` the offset was read from `args[2]` (which is the *modulus*) instead of `args[3]`, so `IdtKind::ModulusOffset` used the wrong offset entirely.

The fix

Integrate the DAE state unbounded — plain integration in the residual, exactly like `idt`, with no discontinuity for the transient integrator to trip over — and apply the modulo wrap only to the returned value:

```
result = offset + floor_mod(val - offset, modulus), floor_mod(x, m) = x - m * floor(x/m) ∈ [0, m)
```

so the returned value lands in $[\text{offset}, \text{offset} + \text{modulus})$ (correct even when the integral goes negative), and the offset now reads `args[3]`. Because the DAE state stays smooth, the transient integrator never sees the wrap discontinuity, so it no longer diverges. `hir_lower/src/expr.rs` only — no OSDI ABI change, no ngspice change.

Verification

`examples/idtmod_examples/verify_idtmod.py` (ALL PASS):

- VCO — a modulo-1 phase drives $\sin(2\pi \cdot \text{phase})$; the output tracks $\sin(2\pi \cdot \text{freq} \cdot t)$ to $\sim 1e-4$ across three periods (it used to freeze after one);
- sawtooth — `idtmod(1, 0, 2, off)` produces a clean sawtooth whose value stays in $[\text{off}, \text{off} + 2)$ and wraps correctly for both `off=0` and `off=5` ($\sim 1e-16$ error away from the wraps) — exercising the fixed offset argument.

Plain `idt` (no modulus) is unchanged and still exact, and every prior example folder still passes.

Known limitations

- The DAE state integrates unbounded, so over very long runs (many millions of wraps) the phase magnitude grows and the wrapped output loses a little floating-point resolution. A bounded-state modulo integrator would need simulator-side breakpoint/state-reset support that OSDI does not expose; the unbounded-state form is correct and, crucially, does not diverge.
- The `tol/nature` argument forms are accepted but tolerance is not separately modelled (unchanged from before).

Enhancement-28 — `idt(...)` initial-condition fix

This document describes the change made to OpenVAF-r in the `version11/` directory to fix the initial condition of `idt(expr, ic[, ...])` in transient analysis. `idt` integrated correctly, and its IC was honoured at the DC operating point, but the IC was silently lost in transient.

The bug

`idt(expr, ic)` is an ideal integrator: its value is `ic` at $t=0$ and then integrates `expr`. Observed behaviour:

- `.op` of `idt(1, 3)` returned 3 — the IC was applied at DC;
- but a transient of `idt(1, 3)` started at 3 for the very first sample and then immediately dropped to 0 and integrated from there, giving $v = t$ instead of $v = 3 + t$;
- `idt(0, 7)` (zero integrand — should hold at 7) drifted from 7 to 0.

The LRM says the IC is “*used as the starting value for transient analysis*,” so this is a genuine bug.

Root cause `idt` lowers to an implicit DAE equation $\text{resist} + d/dt(\text{react}) = 0$ whose unknown is `val` and whose reactive residual `react` is the integrator’s stored charge Q . `EnableIntegration` is false during the DC operating point and true during transient. The old lowering used, for the IC (integration-disabled) phase:

```
[ val - ic, F_ZERO ]      // resist = val - ic (pins val = ic); react = 0
```

So at the DC operating point `val = ic` but the stored charge $Q = 0$. When transient integration turned on (`react = val`), the integrator’s history had $Q = 0$, so it restarted the integral from 0 — the IC was applied at DC but never carried into transient.

The fix

Store the charge as `ic` during the IC/DC phase:

```
[ val - ic, ic ]          // resist = val - ic; react (charge) = ic
```

Now the DC operating point has `val = ic` and $Q = ic$, so when transient integration turns on it continues from $Q = ic$ (the state is continuous at the DC→transient boundary because `val = ic` there). One-value change in `hir_lower/src/expr.rs` (`lower_integral`); no OSDI ABI change, no ngspice change.

Verification

`idtic_examples/verify_idtic.py` (ALL PASS), an ideal integrator $v = ic + \text{rate} * t$:

- the DC operating point equals `ic`;
- the transient ramp starts from `ic`: `idt(1, 3)` gives $3 + t$ ($\sim 1e-4$) — it used to give t ;
- with `rate = 0` the integrator holds at `ic`: `idt(0, 7)` stays at 7 (was drifting to 0).

`idtmod` (Enhancement-27) still works, and every prior example folder still passes.

Known limitations

- This fixes the DC→transient IC carry for `idt(expr, ic)` (and the same IC phase in `idtmod`). The mid-transient **assert** reset form `idt(expr, ic, assert)` — a runtime reset of the integrator to `ic` whenever `assert != 0` — is a separate, harder problem: it forces a discontinuous state jump the transient integrator cannot follow smoothly (like the raw `idtmod` wrap), and remains unaddressed.

- `idt(expr)` with no IC still has an unconstrained DC operating point (nothing pins the integration constant), unchanged.

Enhancement-29 — port-branch flow access **I(<port>)**

This document describes the change made to OpenVAF-r in the `version11/` directory to make the port-branch flow probe **I(<port>)** functional. The front-end already parsed, type-checked and lowered **I(<p>)**, so models *compiled*, but the value was always 0 at run time — it was an unfinished (`// TODO?`) stub.

What **I(<port>)** is

I(<p>) — the *port branch* — is the current flowing into the module through terminal *p*. It is most commonly used to build current-controlled sources (CCCS / CCVS) and to monitor terminal currents:

```
I(out, com) <+ k * I(<in>);    // CCCS: output current = k * (current into port in)
```

By Kirchhoff's current law the current entering the module at port *p* equals the net device current flowing out of node *p*, i.e. the sum of every branch contribution at that node.

The bug

I(<p>) lowers to `ParamKind::Current(CurrentKind::Port(node))`. That parameter was never wired into the DAE system, so it read as 0:

- **sim_back/src/dae/builder.rs** — in `build_input_unknown_pairs` the port case was literally:

```
CurrentKind::Port(_) => {  
    // TODO?  
}
```


so a port flow was never registered as a model input / DAE unknown.
- **osdi/src/eval.rs** — the eval reader hard-coded it to zero:

```
ParamKind::Current(CurrentKind::Port(_)) => cx.const_real(0.0),
```

A model like `I(out) <+ 10*I(<in>)` therefore produced `i(out) = 0` regardless of the current actually flowing into `in`.

The fix

Port flow is given a real DAE unknown with a defining equation, reusing the exact machinery that already backs named/unnamed branch-current probes. Three small changes, all confined to `sim_back` + `osdi`:

1. **sim_back/src/dae/builder.rs** — new `build_port_flow_equations()`, called at the top of `finish()` (before derivatives/Jacobian are computed). For every probed port flow **I(<p>)** it synthesises the equation
$$\text{residual}[\text{Current}(\text{Port}(p))] = \text{residual}[\text{KCL}(p)] - \text{I}(\text{<p>}) \quad \Rightarrow \quad \text{I}(\text{<p>}) = \text{residual}[\text{KCL}(p)]$$
by mirroring node *p*'s resistive and reactive Kirchhoff residual into the port-current row and subtracting the unknown. Because the reactive part is mirrored too, the solved value includes displacement (capacitive) current for free. The mirrored **I(<p>)** value is the very same parameter the model reads, so any source built on **I(<p>)** sees the correct current. A port branch has no `branch(...)` object, so it never passes through `build_branch` / `add_source_equation`; this is why the equation has to be synthesised here.
2. **sim_back/src/dae/builder.rs** — `build_input_unknown_pairs()`: the `CurrentKind::Port` special case is removed, so port currents are registered as ordinary model inputs like any other branch current.

3. **osdi/src/eval.rs**: the hard-coded `const_real(0.0)` arm is removed, so `ParamKind::Current(CurrentKin` falls through to the generic `get_prev_solve(SimUnknownKind::Current(kind))` path and reads its solved value.

The OSDI descriptor side needed nothing new — `osdi/src/metadata.rs` already named the unknown flow(<node>).

Verification — **portflow_examples/**

`portflow_demo.va` is a CCCS $I(\text{out}, \text{com}) = k \cdot I(\text{<in>})$ whose input terminal is an `rin || cin` load, so $I(\text{<in>}) = V(\text{in}, \text{com}) / r_{in} + c_{in} \cdot d/dt V(\text{in}, \text{com})$. `verify_portflow.py` (ALL PASS) checks, end-to-end through version11's own `openvaf-r + ngspice`:

1. resistive (DC) — $i(\text{vout}) = -k \cdot v_{in} / r_{in}$ (e.g. -20 mA for $k=10$, $v_{in}=2$, $r_{in}=1k$); this was 0 before the fix;
2. gain scaling — $i(\text{vout}) / i(\text{vin}) == k$ for $k \in \{1, 5, 25, 100\}$;
3. reactive (AC) — with `cin`, the port flow carries the in-phase ($1/r_{in}$) and quadrature ($w \cdot c_{in}$) parts, and $|i(\text{vout})| = k \cdot |i(\text{<in>})|$ — proving displacement current flows through the probe.

The implementation is completely general: resistive, reactive, and mixed resistive+reactive port loads all work.

Gotcha (ngspice, not OpenVAF)

Do not name a Verilog-A module `cccs`, `vccs`, or `vcvs`. Those names collide with ngspice's built-in controlled-source device types; ngspice then null-derefs in `create_model` when the `.model` card is parsed. This is unrelated to port flow (any OSDI module so named crashes) — just choose a different module name (the demo uses `portflow_cccs`).

Scope

- Pure `sim_back` + `osdi` change; the parser / type system / HIR lowering of `I(<p>)` were already in place.
- Vector (whole-bus) branches remain out of scope: `branch(bus, gnd)` is diagnosed (requires a bit-select); explicit per-bit `branch(bus[i], gnd)` works (E-3/E-4).

Enhancement-30 — variadic `analysis(arg1, arg2, ...)`

This document describes the change made to OpenVAF-r in the version11/ directory to support the multi-argument list form of the Verilog-AMS `analysis()` system function.

What `analysis()` is

`analysis()` (Verilog-AMS LRM 4.7.1) queries the analysis currently being run. It takes a list of analysis-name strings and returns true (1) if the current analysis matches any of them:

```
if (analysis("ic", "dc"))      ...    // static / DC-like phases
if (analysis("ac", "noise"))   ...    // small-signal phases
```

Recognised names are "ac", "dc", "tran", "ic", "static", "noise", "nodeset". Several can hold at once — e.g. an operating point sets both "static" and "dc".

The bug

The single-argument form already worked end-to-end (the stdlib `analysis()` reads `sim_info->flags` and ngspice sets those flags correctly for op/dc/ac/tran/noise). But the builtin was declared with exactly one signature:

```
ANALYSIS = const {
    fn ANALYSIS_SIG(Val(String)) -> Integer;
}
```

so `max_args = 1`, and any list form was rejected at compile time:

```
error: invalid argument count: expected 1 arguments but found 2
|      if (analysis("ac", "tran")) ...
```

Only `analysis("ac")` compiled — you had to chain `analysis("ac") || analysis("tran")` by hand, which is not what the LRM prescribes.

The fix

Two small changes:

1. **hir_ty/src/builtin.rs** — `analysis` is redefined as a varargs builtin (like `$display/$limit`): one mandatory `String` argument, no upper bound.

```
const ANALYSIS: BuiltinInfo = BuiltinInfo::varargs(
    &[SignatureData { args: Cow::Borrowed(&[Val(String)]), return_ty:
        ⇨ Type::Integer }],
    false,    // pure / read-only, no side effects
);
```

The generic vararg path (`max_args == None`) accepts the extra arguments; the now-unused `ANALYSIS_SIG` signature index is removed.

2. **hir_lower/src/expr.rs** — the lowering emits the `Analysis` callback for each argument and bitwise-ORs the results:

```
BuiltIn::analysis => {
    let mut acc: Option<Value> = None;
    for &arg in args {
        let name = self.lower_expr(arg);
        let hit = self.ctx.call1(CallBackKind::Analysis, &[name]);
```

```

    acc = Some(match acc { None => hit, Some(prev) =>
↪ self.ctx.ins().ior(prev, hit) });
    }
    acc.unwrap() // min_args == 1 guarantees ≥1 argument
}

```

OR (not a sum) matters: at an operating point both "static" and "dc" return 1, so a sum would yield 2 — the bitwise OR clamps the result to a proper 0/1.

No OSDI ABI change and no ngspice change — the stdlib analysis() and ngspice's flag-setting were already correct; only the compiler front-end arity was wrong.

Verification — analysis_examples/

analysis_demo.va is a conductance that is g_static at the DC operating point and g_dynamic for the dynamic analyses, selected by a single list-form call if (analysis("ac", "tran", "noise")) g = g_dynamic;. verify_analysis.py (ALL PASS) checks, end-to-end through version11's own openvaf-r + ngspice:

1. the multi-argument list form compiles (it used to be a hard error);
2. DC → g_static (none of ac/tran/noise match);
3. AC → g_dynamic (matches "ac");
4. TRAN → g_dynamic (matches "tran");
5. OR, not sum — analysis("static","dc","ic") at .op returns exactly 1, even though both "static" and "dc" are set.

Single-argument analysis() is unchanged and still works (regression-checked against simparam-str_examples/).

Enhancement-31 — complex poles/zeros in laplace/zi root forms

This document describes the change made to OpenVAF-r in the `version11/` directory to support complex conjugate poles and zeros in the root-based forms of the Laplace and z-domain filter operators.

What the root forms are

The Verilog-AMS filter operators come in four forms each, differing in how the numerator and denominator are given:

suffix	numerator	denominator
<code>_nd</code>	polynomial coefficients	polynomial coefficients
<code>_np</code>	polynomial coefficients	poles (roots)
<code>_zd</code>	zeros (roots)	polynomial coefficients
<code>_zp</code>	zeros (roots)	poles (roots)

for both `laplace_*` and `zi_*`. Per the LRM the pole/zero vectors hold (real, imaginary) pairs: element $2k$ is the real part and $2k+1$ the imaginary part of root k . A complex conjugate pair is `{re, +im, re, -im}`; a real root is `{re, 0}`.

The bug

`laplace_np/laplace_zd/laplace_zp` and `zi_np/zi_zd/zi_zp` all lowered their root vectors through a single helper, `laplace_roots_to_poly`, which expanded the array as a list of individual real roots $\Pi_k (s - r_k)$ — ignoring the (real, imaginary) pairing entirely. Consequences:

- a vector like `{-1e6, -3e6}` was read as two real poles ($-1e6$ and $-3e6$) instead of the LRM's one complex pole ($-1e6 - 3e6j$);
- complex conjugate poles/zeros could not be expressed at all, so every resonant / underdamped second-order section was impossible. A $Q=5$ resonant low-pass built with `laplace_np` and the correct complex pole pair produced -242 dB of garbage (the imaginary parts were treated as extra real roots, one of them in the right-half-plane).

The fix

`laplace_roots_to_poly ([hir_lower/src/expr.rs])` now consumes the vector as (real, imaginary) pairs and forms $\Pi_k (s - (re_k + j \cdot im_k))$ with full complex arithmetic — each polynomial coefficient carried as a (re, im) pair of MIR Values — and returns only the real coefficients:

```
// coefficients as (re, im) Values, ascending powers; start at 1 + 0j
let mut re = vec![F_ONE];
let mut im = vec![F_ZERO];
let mut k = 0;
while k < roots.len() {
    let rr = roots[k];
    let ri = if k + 1 < roots.len() { roots[k + 1] } else { F_ZERO };
    k += 2;
    // new = s*P - (rr + j*ri)*P    (complex multiply, then subtract from the shift)
    ...
}
re    // imaginary parts cancel for conjugate-paired (physical) inputs
```

For a physical, real-coefficient transfer function the roots come in conjugate pairs, so the imaginary parts of the product cancel to zero; taking the real part both realises that and harmlessly drops floating

round-off. A trailing unpaired element (odd-length vector) is treated as a purely real root, so a lone real pole/zero may still be written `{r}` as well as `{r, 0}` (keeps single-real-root models working).

This one helper is shared by all six root-based forms — both `laplace_*` and `zi_*` — so the single change covers every one of them. No OSDI/ngspice change; the roots are turned into ordinary polynomial coefficients exactly as before, just correctly.

Behaviour change Because the vector is now interpreted as pairs, an even-length vector means half as many roots as it used to. Existing models that relied on the old real-list convention must switch to the paired form: `{-1e6, -3e6}` (two real poles) becomes `{-1e6, 0, -3e6, 0}`. The shipped `laplace_examples/laplace_variants.va` was updated accordingly (single real roots such as `{-2e6}` are unaffected thanks to the lone-element leniency).

Verification — **complexpole_examples/**

`complexpole_demo.va` builds two second-order sections that require complex roots and cross-checks the root form against the equivalent `laplace_nd` polynomial baseline. `verify_complexpole.py` (ALL PASS) checks, end-to-end through version11's own `openvaf-r + ngspice`:

1. a resonant low-pass via `laplace_np` (complex conjugate poles) matches `laplace_nd` to **0.00** dB across the sweep;
2. the complex poles produce a real resonant peak of +18.06 dB at exactly 1 MHz (textbook $20 \cdot \log_{10}(Q=8)$) — impossible with real-only roots;
3. a notch via `laplace_zd` (imaginary-axis complex zeros at $\pm j \cdot \omega_0$) matches `laplace_nd` to **0.00** dB, with a deep null (−290 dB) at ω_0 .

Additionally spot-checked: `laplace_zp` (complex poles *and* zeros) and `zi_np` (complex poles in the z^{-1} domain, matched to the equivalent `zi_nd` real polynomial). Existing `nd` and single-real-root examples (`laplace_lpf`, `zi_lpf`, `laplace_zd_only`, `laplace_mixed_var_literal`) are unchanged and regression-checked.

Enhancement-32 — integer persistent/event-state variables

This document describes the changes made to OpenVAF-r and ngspice in the `version11/` directory to fix a compiler crash on integer persistent state and to let integer operating-point variables be recorded in ngspice output vectors.

The bug

A Verilog-A variable holds *persistent state* when its value must survive from one evaluation to the next — either because it is read before it is written (a running peak, an accumulator) or because it is only updated inside an event block (`@(cross)`, `@(above)`, `@(timer)`, `@(initial_step)`). Enhancement-7/8 implemented this via per-variable *persistent eval-output slots* in the OSDI instance data, read at the start of `eval()` (`ParamKind::HiddenState/EventState`) and stored back at the end.

Real-typed persistent variables worked. But any integer persistent variable crashed the compiler:

```
integer m;  
if (V(a,c) > 1.0) m = m + 1;    // read-before-write -> persistent
```

```
LLVM ERROR: Cannot select: 0x...: f64 = add ...  
... f64,ch = load<(load (s64) from %ir.18)> ...
```

(or a segfault, depending on surrounding code). Found during a deep-dive TODO sweep: the two `todo!("hidden state/event state")` stubs in `osdi/src/inst_data.rs` sit on exactly this hole.

Root cause `OsdiInstanceData::new` created every hidden-state slot with a hardcoded **f64** type:

```
Some((var, eval_outputs.insert_full(val, ty_f64).0))    // hidden_state
```

The slot's recorded type drives *both* the end-of-eval store and the start-of-eval `read_hidden_state` load. For an integer variable the state was therefore loaded back as a double and fed straight into integer MIR ops — malformed LLVM IR (`f64 = add`), which aborts instruction selection. Worse, `eval_outputs` is keyed by MIR value and `insert_full` overwrites on duplicate keys, so the hardcoded `f64` could also clobber the correctly-typed slot entry that the opvar path had already inserted for the same value.

The fix

OpenVAF (`osdi/src/inst_data.rs`)

1. Type the hidden-state slot from the variable — exactly like the opvar path does:

```
let ty = lltype(&var.ty(db), cx);  
Some((var, eval_outputs.insert_full(val, ty).0))
```

Event-state slots keep `f64` (their values are always the crossing expression / next-fire time — genuinely real).

2. Retire the two `todo!("hidden state/event state")` stubs in `load_eval_output / nth_opvar_ptr`. They are unreachable today (`EvalOutput::new` only produces `EvalOutput::Param` for `Param/ParamSysFun/Temperature` kinds), but they now resolve the parameter to its persistent eval-output slot instead of panicking — a real implementation rather than a stub, in case a future path produces state-typed `EvalOutput::Params`.

ngspice (`src/frontend/outitf.c`) With the compiler fixed, exposing the counter as an operating-point variable (`(*desc="..."*) integer n;`) compiled and read correctly at end of run, but per-timestep recording (`save @n1[n] + tran`) printed `OUTpData: unsupported data type` once per timestep and produced no vector:

- `getSpecial()` masked the vector type with `IF_REAL | IF_COMPLEX`, turning an integer instance-param's `IF_INTEGER` into 0 so no branch matched. The mask now preserves `IF_INTEGER`.
- Both per-point writers (the in-memory plot path and the rawfile path) now record `IF_INTEGER` values via `plotAddRealValue/fileAddRealValue((double) val.iValue)` — integer opvars land in output vectors as reals, like every other plot vector.

Verification — `intstate_examples/`

`intstate_demo.va` packs the three cases that used to crash plus a real-typed regression control: an integer `@(cross)` edge counter `n` (opvar), an integer `@(initial_step)` flag `started` (opvar), and the real running-peak `vpeak` (E-7 behaviour). `verify_intstate.py` (ALL PASS), driving a 2 V / 1 kHz sine for 5 cycles:

1. it compiles (integer persistent state used to abort the compiler), and the run emits no unsupported data type;
2. final `n == 5` — exactly the number of upward 1 V crossings;
3. the recorded per-timepoint waveform of `n` is a clean staircase `0,1,2,3,4,5`, stepping at the analytic crossing times $\sin(v_{th}/A)/2\pi f + k/f$ (max error $< 10 \mu s = \text{one timestep}$);
4. `started` reads 1;
5. `vpeak` reads the sine amplitude (real persistent state unchanged).

Regressions: the E-7(`variable_persistence_examples`) and E-8(`cross_examples/timer_examples`) transient decks re-run cleanly with the new toolchain, and the full pre-fix crash matrix (9 models: integer/real $\times$ persistent/event/plain $\times$ exposed/hidden) now compiles.

Enhancement-33 — array **case** + array-literal function arguments

This document describes the changes made to OpenVAF-r in the `version11/` directory to retire the compiler's last `todo!()` hard-panic stubs and fix the array-expression bugs found underneath them. Purely front-end (`hir_ty` + `hir_lower`); no OSDI/ngspice change.

The bugs

A deep-dive TODO sweep (the one that produced Enhancement-32) left two `todo!()` stubs in `hir_lower`. Probing their reachability uncovered four related defects:

1. **case** over an array crashed the compiler. Type inference happily accepted an array-typed discriminant (demanding array-typed items), but lowering hit `Type::Array { .. } => todo!()` in `lower_case`:

```
case ('{1.0, 2.0})
  '{1.0, 2.0}: g = 1e-3;    // -> "not yet implemented" panic
```

2. Array-literal function arguments silently bound nothing. A whole-array function argument (Enhancement-18) only handled bare array-*variable* references; a literal compiled cleanly but left every element 0:

```
g = sum2('{1.0, 2.0});    // returned 0 instead of 3 – silent wrong answer
```

3. Whole-array variables were typed **real** regardless of their element type. `infer_array_arg` hardcoded `Type::Real`, so an *integer*-array case discriminant compared its i32 elements with `feq` — a second panic (invalid `int` operation `feq` in `const-eval`).
4. Array literals were silently accepted as array *output* arguments (the Enhancement-20 writeback just skipped), while scalar output arguments have always properly required a variable.

The fixes

- Element-wise array **case** (`hir_lower/src/stmt.rs`): the discriminant and each case item are lowered to their element `Values` and the per-element equalities (`feq/ieq/beq/seq` by element type) are AND-combined into the single branch condition — an arm matches iff all elements are equal. The scalar path is unchanged (it is just the one-element case). Works for array literals and whole-array variables, real and integer, in both positions; mismatched lengths stay a clean type error.
- Shared array-expression helpers: the laplace-specific helpers were the general mechanism all along, so they are renamed and reused — `lower_laplace_array_arg` → `lower_array_elems` (`hir_lower`) and `infer_laplace_array_arg` → `infer_array_arg` (`hir_ty`). The case inference arm now runs discriminant/items through `infer_array_arg`, which also registers whole-array variable references (previously `case (x)` on an array variable was rejected with “requires a bit-select”).
- Array-literal function arguments (`hir_lower/src/expr.rs`, `lower_user_fun_impl`): the input-binding now uses `lower_array_elems`, which handles literals (each element lowered) and variable references (each element read) identically — `sum2('{1.0, 2.0})` returns 3.
- True element types (`hir_ty/src/inference.rs`, `infer_array_arg`): a whole-array variable is typed from its actual element variables instead of hardcoded `real`, so integer arrays compare with `ieq` and mixed-type discriminant/item combinations are diagnosed instead of miscompiled.
- Array output arguments require a variable (`hir_ty/src/inference.rs`): an array literal passed to an output/inout array formal is now rejected with the same “expected ... variable reference” diagnostic scalars get, instead of silently skipping the writeback.

- The stubs are retired: `lower_case`'s `todo!()` is replaced by the working array path, and `lower_array`'s `todo!("arrays")` becomes a documented unreachable! — every context that accepts an array value consumes its elements directly (aggregate assignment, `laplace/zi`, `$table_model`, function arguments, case), and inference rejects arrays everywhere else, so no array expression can reach the generic scalar lowering path.

Verification — **arraycase_examples/**

`arraycase_demo.va` classifies the input voltage into a 2-bit integer state vector and selects the conductance with one element-wise array case (`case (st) '{0,0}: ... '{1,0}: ... '{1,1}: ...`), scaled by a helper summing an array-literal argument (`sum2('{0.25, 0.75}) == 1.0`). `verify_arraycase.py` (ALL PASS) checks, end-to-end through version11's own `openvaf-r + ngspice`:

1. it compiles (array case used to panic the compiler);
2. all three case regions select the correct conductance in a DC sweep — which simultaneously proves the literal function argument reads 1.0, not 0;
3. a real-array case (literal discriminant vs literal item) compiles and matches;
4. an array literal passed to an array output argument is rejected with a proper type error.

Regressions: every array-consuming feature re-verified — `funcarray` (E-18), `arrayout` (E-20), `arrayret` (E-23), `array/mdarray` (E-14/15), `cubic_table/table_model` (E-16/22), `complexpole` (E-31, exercises the renamed `lower_array_elems` via `laplace`) — ALL PASS, plus `zi_lpf` and a scalar case model behave unchanged.

Enhancement-34 — `{...}` concatenation & `{n{...}}` replication

This document describes the changes made to OpenVAF-r in the `version11/` directory to implement the Verilog-AMS concatenation and replication operators properly. Purely front-end (parser → syntax → hir_def → hir → hir_ty → hir_lower); no OSDI/ngspice change.

The two brace constructs

Verilog-AMS has two distinct brace constructs that OpenVAF previously conflated:

syntax	construct	OpenVAF before E-34
<code>'{...}</code>	array aggregate literal (assignment patterns, incl. nested <code>'{'{...},...}</code> for N-D arrays)	supported (E-4/14/15)
<code>{...}</code>	concatenation operator; <code>{n{...}}</code> replication	parsed as just another spelling of the aggregate literal

Because `{...}` was treated as an aggregate literal: whole arrays could not appear inside it (`{p, q}` → "requires a bit-select"), the replication form `{n{...}}` did not parse at all (unexpected token `'{'`), and string operands produced a useless *string array* instead of the LRM's concatenated string.

What Enhancement-34 implements

`{...}` is now the real concatenation operator:

- numeric concatenation flattens its operands in order — scalars, whole-array variables, aggregate literals, nested concatenations — into one flat 1-D array value: `w = {half1, {3{k2}}, 3.0*k2}`;
- replication `{n{...}}` repeats the flattened operand list `n` times, where `n` is a positive compile-time integer literal (diagnosed otherwise);
- string concatenation: if any operand is a string, all must be, and the result is a runtime-concatenated string — `{"volt","age"} == "voltage"`, including replication (`{2{"ab"}} == "abab"`). Lowered through the proven `$swrite/$sformat` machinery (a `PrintDst::String` print callback with a `"%s%s..."` format, so operand data is never interpreted as a format string);
- usable everywhere an array value is consumed: array assignment, whole-array function arguments, `laplace_*/zi_*` coefficient vectors, case discriminants/items;
- element typing: the result is `real` if any operand is real (integer *scalars* are cast, exactly like aggregate-literal elements; an integer *array* mixed into a real concatenation is a type error, since array elements have no per-element cast machinery).

`'{...}` aggregates are completely untouched.

Implementation sketch

- parser/syntax: `'{...}` and `{...}` now produce different nodes (`ARRAY_EXPR` vs new `CONCAT_EXPR/REPLICATION_EXPR`; the replication node's children are `[count, elem0, elem1, ...]`).
- hir_def/hir: new `Expr::Concat { rep: Option<ExprId>, elems }`.
- hir_ty: `infe_concat` types the expression (string mode vs flattened array, constant replication count, casts, diagnostics — new `InvalidReplicationCount/EmptyConcat` diagnostics); array assignment gains a `concat` case that expands into per-destination-element sources (`ArrayAssign::Concat`, each element either a scalar expression or a source array-element variable), which the existing mixed `Val/Copy ArrayAssignElem` machinery consumes unchanged.

- `hir_lower`: `lower_array_elems` (the shared array-expression flattener from E-33) flattens `concat` operands recursively and repeats the list for replication, which makes `concat` work in every array-consuming context for free; a string-typed `concat` lowers via a new `lower_string_concat` helper on the E-11 formatting machinery.

Behaviour change `{...}` no longer denotes an aggregate literal. For the common flat scalar list ($x = \{1.0, 2.0\}$) concatenation produces the identical result, so nothing breaks; but a *nested* bare-brace literal (`{{1,2},{3,4}}`), previously a 2-D aggregate spelling, now flattens (concatenation semantics — and 2-D destinations require `'{'{..}'{..}'`), the LRM aggregate form, as all shipped examples already use).

Verification — `concat_examples/`

`concat_demo.va` assembles a 6-tap coefficient vector by concatenation + replication ($w = \{\text{half1}, \{3\{k2\}\}, 3.0*k2\}$), feeds a `concat`-built vector with integer scalars to an averaging function (`avg4({1, 3, 2.0, 2.0})` — casts), and gates the output branch on a runtime string concatenation (`{"con","cat"} == "concat"`). `verify_concat.py` (ALL PASS):

1. it compiles (array operands / replication / string concat all used to fail);
2. the DC conductance equals $2 \cdot (3 \cdot k1 + 6 \cdot k2)$ exactly for two parameter sets — proving the concatenated coefficient vector, the replication, the integer casts and the string gate all evaluate correctly;
3. `{0{...}}` and a non-literal replication count are clean diagnostics.

Additionally exercised during development: `concat` as `laplace_nd` coefficient vectors, as a case discriminant, string replication, and replication of a mixed scalar/array list (`{2{p, 10.0}}`). Regressions: 15 example verify suites (all array-family + string/file I/O + analysis/portflow/intstate) ALL PASS, and `laplace_variants/zi_lpf/bessel5` compile unchanged.

Enhancement-35 — lexer hang on // comment at end-of-file

This document describes the change made to OpenVAF-r in the `version11/` directory to fix a compiler infinite loop on a `//` line comment terminated by end-of-file instead of a newline. One-line fix in the lexer; no OSDI/ngspice change.

The bug

Both Verilog-A comment forms were already fully supported — `//` line comments and `/* ... */` block comments, in every position (own line, trailing after code or compiler directives, mid-expression, multi-line, containing code-like text). But a `//` comment as the last line of a file with no trailing newline hung the compiler forever:

```
module m(a,c);
    ...
endmodule
// final comment<EOF>          <- no trailing newline: openvaf-r spins at 100% CPU
```

Files without trailing newlines are extremely common (editors, generators, truncated copies), and a hang is the worst failure mode — it looks like the tool froze, gives no diagnostic, and stalls any build/CI pipeline that invokes the compiler. The bug was pre-existing (reproduced with the CI-built binary); it was found while torture-testing comment support.

Root cause `line_comment` in `openvaf/lexer/src/lib.rs` scanned with:

```
loop {
    match self.first() {
        '\n' => break,
        '\\\n' if self.second() == '\n' => break,
        _ => self.bump(),
    };
}
```

At end of input the cursor's `first()` returns the `EOF_CHAR` sentinel forever while `bump()` no-ops — so a comment not terminated by `'\n'` never exits the loop. Its sibling `block_comment` drives on while `let Some(c) = self.bump()`, which terminates at EOF naturally — which is why an *unterminated* `/*` was always a clean unexpected EOF, expected `*/` error rather than a hang.

The fix

Add the missing end-of-file break:

```
'\n' => break,
'\\\n' if self.second() == '\n' => break,
_ if self.is_eof() => break,      // Enhancement-35
_ => { self.bump(); }
```

An audit of every other scan loop in the lexer (whitespace, identifiers, digits, strings, block comments, `eat_while`) confirmed `line_comment` was the only EOF-unsafe loop: the rest either drive on `bump()`'s Option, check `is_eof()`, or break on the sentinel by predicate.

Verification — `comment_examples/`

`comment_demo.va` is a comment-torture model (line/block/multi-line/ mid-expression/trailing comments, code-like text inside comments). `verify_comment.py` (ALL PASS) checks, end-to-end through `version11`'s own `openvaf-r + ngspice`:

1. the hang reproducer — a file whose final bytes are exactly `// eof` comment with no trailing newline — compiles within a watchdog timeout (a regression trips the 20 s watchdog instead of hanging CI);
2. the torture model compiles and simulates with the exact expected current ($I = -2 \cdot 10^{-3} \cdot V$; a commented-out `I(a,c) <+ 999.0`; is ignored);
3. an unterminated `/*` at EOF stays a clean unexpected EOF error;
4. a `//` comment ending in a lone backslash at EOF (the escaped-newline lookahead touching end of input) also terminates.

Regressions: lexer unit tests 8/8 pass; all 73 version11 example models recompile; spot verify suites (concat, arraycase, array, stringio 6/6, fileio 9/9) ALL PASS.

Enhancement-36 — probe-only branches / ideal ammeter + flow-only signal flow

This document describes the change made to OpenVAF-r in the version11/ directory to give probe-only branches their LRM-mandated 0V-source (ideal ammeter) semantics — which simultaneously completes support for flow-only signal-flow disciplines. One new pass in the DAE builder (`sim_back`); no OSDI/ngspice change.

The bug

Verilog-AMS distinguishes conservative disciplines (`electrical`: potential + flow, KCL/KVL) from signal-flow disciplines (`voltage`: potential only; `current`: flow only). Probing the flow of a branch that is never *contributed* to is a fundamental idiom:

```
branch (p, n) sense;
V(out) <+ rtz * I(sense);      // ideal ammeter + transimpedance readout
I(onp, com) <+ k * I(sense);   // CCCS on a sense branch (current mirror)
```

Per the LRM, such a probe-only branch behaves as a short — a potential source of 0 V — whose current is the probed value. In OpenVAF it instead read 0 and conducted nothing: the “ammeter” was an *open circuit*, silently breaking the surrounding series path. The same mechanism underlies flow-only (current discipline) signal-flow nets — an input port only *probes* its net’s flow — so entire current-signal chains produced 0.

Root cause The topology only materialises branches that are contributed to (it is keyed off the `Is-VoltageSrc` outputs, which are created per contribution). A branch that is merely probed never passes through `build_branch/add_source_equation`, so its current unknown never exists and the OSDI eval falls back to the “always zero” path — the same failure family as Enhancement-29’s port-flow stub.

The fix

A new `build_probe_only_branches()` pass in `sim_back/src/dae/builder.rs`, run at the start of `finish()` right after Enhancement-29’s `build_port_flow_equations` (its direct template). For every live `ParamKind::Current` (named or unnamed branch; port flows excluded — E-29 owns those) whose `Current` unknown was not materialised by the contribution-driven pass, it synthesises exactly the system `add_source_equation` builds for a voltage branch with a zero source expression:

```
residual[Current(br)] = -V(hi,lo)      (nature Potential -> equation V(hi,lo) = 0)
residual[KCL(hi)]      += I(br)
residual[KCL(lo)]      -= I(br)
```

The branch current `I(br)` is the very parameter the model reads, so probes and any sources built on them see the solved through-current; the Jacobian entries come out of the ordinary derivative machinery since the pass runs before `sim_unknown_reads/auto_diff`. One caveat inherent to the semantics: putting *several* probe-only branches in parallel across the same node pair is degenerate (parallel ideal 0V sources), exactly as paralleling ideal voltage sources is.

Verification — `signalflow_examples/`

`signalflow_demo.va` packs all four system styles: a conservative ideal ammeter with transimpedance readout, a CCCS current mirror on a probe-only sense branch, a potential-only (`voltage` discipline) gain chain, and a flow-only (`current` discipline) source $\rightarrow$ gain $\rightarrow$ converter chain. `verify_signalflow.py` (ALL PASS):

1. the ammeter shorts (the series 2 V / 1 k Ω loop conducts its full 2 mA — it used to be open) and reads it (`v(out) = 2 V` exactly);

2. it reads displacement current in AC (series 1 nF at $\omega = 10^6$: $v(\text{out}) = j \cdot 1 \text{ V}$ exactly — the 0V source is fully linear and reactive-aware);
3. the current mirror senses 3 mA and outputs 6 mA;
4. the potential-only signal-flow chain gives $1.5 \times 3 \times 2 = 9 \text{ V}$ (this style already worked and is regression-locked here);
5. the flow-only chain gives $1 \text{ mA} \times 5 \times 1 \text{ k}\Omega = 5 \text{ V}$ (used to be 0), with the probed signal net sitting at exactly 0 V — textbook signal-flow semantics (the probe shorts the net and takes its total inflow as the signal).

Regressions: all 32 version11 example verify suites ALL PASS; the `sim_back` snapshot tests remain at their pre-existing 9-pass/15-fail baseline (no new failures).

System-style support after E-36

style	status
conservative (electrical)	full (unchanged)
signal-flow, potential-only (voltage)	full (already worked; now regression-locked)
signal-flow, flow-only (current)	full (new)
probe-only branches / ideal ammeters / CCCS-on-sense	full (new)

Enhancement-37 — operator-correctness audit + fixes

This document describes the changes made to OpenVAF-r in the `version11/` directory after a systematic operator-correctness audit covering the arithmetic, relational, logical, bitwise/shift, ternary and concatenation operator families. Three real defects were found and fixed; everything else checked out exactly correct. Purely front-end/middle-end (`hir_lower`, `mir_opt`, `hir_ty`); no OSDI/ngspice change.

The audit

`operator_examples/operator_audit.va` holds five self-checking modules — one per operator family. Every individual check that fails adds a distinct power of two to a score emitted on a signal-flow output, so `v(out) == 0` means every check in that family passes and any nonzero value is a bitmask pinpointing exactly which check failed. 60+ checks cover:

- integer arithmetic: `+` `-` `*` `/` `%` incl. truncation toward zero (`-7/3 == -2`) and modulus sign rules (`-7%3 == -1`, `7%-3 == 1`), `**`, unary minus, precedence;
- real arithmetic: `+` `-` `*` `/` `%` (fmod semantics, sign of first operand), `**` incl. negative exponents and negative base with odd integer exponent;
- relational/logical: `<` `<=` `>` `>=` `==` `!=` on integers and reals, 0/1 result values, `&&` `||` `!`, mixed expressions;
- bitwise/shifts: `&` `|` `^` `~^` `~` `<<` `>>` `<<<` `>>>` incl. sign-extension vs zero-fill, shift-by-zero, involution (`~x == x`), `&` `|` precedence;
- ternary: integer/real/string results, nested, comparisons inside conditions;
- concatenation/replication (regression-locking Enhancement-34).

The three defects found → fixed

1. `~x` (bitwise NOT) was lowered as arithmetic negation `hir_lower` mapped `UnaryOp::BitNegate` to `ineg` (`-x`), so `~12` evaluated to `-12` instead of `-13` (`~x = -x - 1`). Silent wrong answers in any model using bit manipulation. Fixed to the `inot` opcode (whose `const-fold`, `!val`, was already correct — only the lowering picked the wrong instruction).

2. constant folding of `>>` sign-extended The MIR distinguishes `Ishr` (logical `>>`, zero-fill) from `Iashr` (arithmetic `>>>`, sign-extending), and the LLVM runtime path emits the correct `LShr`/`AShr` pair — but the constant folder in `mir_opt/src/const_eval.rs` computed both with Rust's `>>` on a signed `i32`, which sign-extends. So `-16 >> 2` folded to `-4` instead of the zero-filled `1073741820` (`0x3FFFFFFC`), and — worse — a constant-foldable `>>` disagreed with the same expression computed from runtime values. Fixed by folding through `u32`: `((lhs as u32) >> rhs) as i32`.

3. the ternary operator rejected string operands `cond ? "a" : "b"` was a type error (`SignatureData::SELECT` only allowed `bool/real/integer` branch pairs). Per the LRM the conditional operator supports string operands. Fixed by appending a `STR_BIN_OP` signature `((String, String) → String)` to the `SELECT` list — appended last, keeping the existing signature indices stable. The lowering needed no change (the existing `phi` handles string values).

Verification — `operator_examples/`

`verify_operators.py` (ALL PASS):

1. the audit file compiles (string ternaries used to be a type error);
2. all five family scores read exactly 0 (60+ individual operator checks, any failure would name itself in the bitmask);
3. the three formerly-broken cases asserted directly: `~12 == -13`, `-16 >> 2 == 1073741820`, `(1>0) ? "yes" : "no" == "yes"`.

Regressions: all 33 version11 example verify suites ALL PASS and all 75 example models recompile after the fixes (the `~/>>/ternary` changes touch shared lowering and const-eval paths, so the full sweep matters).

Enhancement-38 — operator-precedence audit + fixes

This document describes the changes made to OpenVAF-r in the `version11/` directory after a systematic operator-precedence audit against the Verilog-AMS precedence table (LRM Table 4-2). One observable defect and one harmless deviation were found and fixed — both in the parser's Pratt binding-power table (`parser/src/grammar/expressions.rs`); nothing else in the pipeline changes.

The audit

The parser's binding-power table was compared entry-by-entry against the LRM table (highest → lowest):

```
unary + - ! ~ > ** > * / % > + - > << >> <<< >>>
> < <= > >= > == != > & > ^ ~ ^ ~ > | > && > || > ? :
```

with associativity rules from LRM 4.1.3: *all operators associate left to right except the conditional* (right to left). The structural review confirmed:

- left associativity for all binary operators — `expr_bp(p, op_bp + 1)` parses each right operand one level tighter, including `2**3**2 == (2**3)**2 == 64`;
- right associativity for `?:` — the else-branch reparses a full expression, so `a ? b : c ? d : e == a ? b : (c ? d : e)`;
- unary above `**` — prefix operators take an *atom* operand, so `-2**2 == (-2)**2 == 4` (the classic Verilog difference from C/Python).

`precedence_examples/precedence_audit.va` then verifies all of it empirically: 28 checks covering every adjacent level pair, each failing check adding a distinct power of two to a score on a signal-flow output (`v(out) == 0` ⇔ all pass; any nonzero value is a bitmask naming the failure).

The defects found → fixed

1. `%` bound tighter than `*` and `/` (observable) The LRM puts `*`, `/`, `%` on one left-associative level; the table gave `%` a higher binding power. Consequence: `a * b % c` parsed as `a * (b % c)` —

```
6*7%4 ==> 6*(7%4) = 18      (LRM: (6*7)%4 = 2)
42/5%3 ==> 42/(5%3) = 21     (LRM: (42/5)%3 = 2)
```

Silent wrong answers in any model mixing multiplication/division with modulus. Fixed: `%` now shares level 12 with `*` and `/`.

2. `~^/~^` bound tighter than `^` (harmless, fixed for exactness) The LRM puts `^`, `~^`, `^~` on one level. The split was provably unobservable: xor is associative/commutative and each xnor contributes exactly one global inversion, so every grouping of an xor/xnor chain yields the same value. Fixed anyway so the table is LRM-exact.

Everything else in the table was already correct.

Verification — `precedence_examples/`

`verify_precedence.py` (ALL PASS):

1. all 28 precedence/associativity checks read exactly 0 — including the `*` / `%` level (4 groupings), `**` vs `*` and unary, `**` left-associativity, shifts below `+` `-`, relational below shifts, `==` below relational, the `& ^ |` ladder, `&&/||` levels, ternary lowest + right-associative, and unary-tightest cases (`!0+1 == 2`, `~0+1 == 0`);
2. the marquee fix case asserted directly: `6*7%4 == 2` (was 18).

Regressions: no example in either tree contains a `*//`-then-`%` grouping (grep-audited, so the behaviour change affects no shipped model), and all 34 version11 example verify suites ALL PASS — including the Enhancement-37 operator audit, which now doubles as a semantics regression lock for this change.

Enhancement-39 — derived natures & deriving natures from disciplines

This document describes the changes made to OpenVAF-r in the `version11/` directory to make derived natures — `nature X : Parent`; and `nature X : discipline.potential / discipline.flow`; (LRM 3.4.1.3) — actually work. Three small fixes across parser, syntax validation and the OSDI nature-descriptor builder; the substantial inheritance machinery already existed.

The bugs

A derived nature inherits every attribute (`units`, `access`, `abstol`, `ddt_nature/idt_nature`) it does not override. OpenVAF's `hir_ty::NatureTy` implements all of this — parent resolution, base-nature chains, `units/ddt/idt` inheritance, attribute lookup through parents, and access-function compatibility by units. None of it was reachable:

1. The parent link was silently always **None**. The parser emitted a `NAME_REF` node for the `:` parent clause, but the AST accessor (`NatureDecl::parent()`) looks for a `Path` child — so `lower_nature_path` never saw a parent. Consequences: a derived nature without its own `units/access` never inherited them, so the parent's access function was rejected on its disciplines ("illegal access of branch") — making the canonical nature `TightCurrent : Current; abstol = 1e-15; pattern unusable`.
2. `nature X : electrical.flow`; did not parse at all ("unexpected token '`.`'") — same root cause, since a bare name-ref cannot carry a qualifier — and behind the parse there was a second gate: the syntax validation whitelisted only `ddt_nature/idt_nature` as qualified nature-path segments, rejecting `potential/flow` ("illegal nature identifier").
3. Discipline-qualified `ddt_nature/idt_nature` attribute values hard-panicked the OSDI nature-descriptor builder ("Nature's ddt must be a nature reference." in `osdi/src/ndatable.rs`): the `OsdiNature` descriptor encodes `ddt/idt` as bare nature indices, and the builder refused to resolve a discipline-qualified reference to its underlying nature.

The fixes

- **`parser/src/grammar/items.rs`** — the parent of a nature is parsed as a path (`Current` or `electrical.flow`), producing the `Path` node the AST and the (already-complete) item-tree lowering expect. This single change lights up the whole dormant inheritance machinery.
- **`syntax/src/validation.rs`** — `check_nature_path` also accepts `potential/flow` as the qualified segment.
- **`osdi/src/ndatable.rs`** — a new `resolve_nature_index` resolves discipline-qualified `ddt_nature/idt_nature` references through the discipline to the underlying nature's index instead of panicking.

Verification — `derivednature_examples/`

`derivednature_demo.va` packs the full feature matrix (5 modules): `derive-from-nature` with inherited `units+access`, `derive-from-discipline` (`electrical.flow/electrical.potential`), `derived nature` with its own access name, a two-level derivation chain, and a discipline-qualified `ddt_nature` attribute. `verify_derivednature.py` (ALL PASS):

1. the matrix compiles (three of the five constructs used to fail or crash);
2. runtime conductances are exact for every module — proving the inherited access functions genuinely resolve end-to-end through ngspice (`dn_nature` 1 mS via inherited I, `dn_discipline` 2 mS, `dn_access` 5 mS via its own I2, `dn_chain` 3 mS through two levels);
3. the `ddt_nature = electrical.potential` module's OSDI descriptor builds and loads (used to panic the compiler).

Regressions: all 35 version11 example verify suites ALL PASS and all 77 example models recompile (the parser change makes every file reparse).

Enhancement-40 — N-dimensional `$table_model`

This document describes the changes made to OpenVAF-r in the `version11/` directory to lift `$table_model`'s 3-dimension cap: lookup tables of any dimension now work. Purely front-end (`hir_ty` + `hir_lower`); no OSDI/ngspice change.

The gap

The question "are multi-dimensional tables supported?" verified out as: 1-D (linear + cubic, inline + file), 2-D (bilinear + bicubic) and 3-D (trilinear) all exact — but a 4-D call failed at the *signature* level:

```
error: invalid argument count: expected at most 2 arguments but found 6
```

The interesting part: the grid-file reader (`read_table_grid_nd`) and the recursive multilinear interpolation (`interp_nd`) from Enhancement-17 were already fully dimension-general — only the declared signature list (explicit 1-D/2-D/3-D variants) and the signature-matched dispatch capped it. The LRM sets no dimension bound.

The fix

1. **`hir_ty`** — `TABLE_MODEL` becomes a varargs builtin (the listed 1-3-D signatures kept verbatim), and a dedicated `BuiltIn::table_model` arm in `infern_builtin` owns *every* call:
 - the 1-D inline-array form and small file forms resolve against the listed signatures unchanged;
 - N-D file forms (≥ 4 non-array arguments) get the exact signature `[Real × ndim, Literal(String)(, Literal(String))]` synthesised from the argument shapes — the trailing string literals are the data-file name and the optional control string, everything before them a coordinate.

Owning all counts matters twice over: the generic varargs fallthrough *resizes* the listed signatures to the call's arity, which truncates longer signatures and made 2-argument calls ambiguous; and a 5-argument call is ambiguous *by arity alone* (3-D + file + ctrl vs 4-D + file) — the shape scan disambiguates it.

2. **`hir_lower`** — `lower_table_model` dispatches on argument shapes instead of the resolved signature (array second argument → 1-D inline; otherwise the first string literal marks the file, its index the dimension). `read_table_grid_nd` + `interp_nd` were already general; all partial derivatives continue to flow through `mir_autodiff` into the Jacobian.

The self-describing grid-file format is unchanged: `ndim`, axis sizes, each axis's ascending coordinates, then row-major values (first axis slowest).

Verification — `ndtable_examples/`

The demo grids hold multilinear functions, which multilinear interpolation reproduces *exactly* at any off-grid point — so every check asserts analytic equality. `verify_ndtable.py` (ALL PASS):

1. a 4-D table compiles (used to error at the cap) and evaluates exactly at two off-grid points (`f4(1.5,0.25,0.75,0.4) = 7.9625`, second point parameter-swept);
2. 4-D without a control string — the ambiguous 5-argument arity — resolves and evaluates exactly;
3. a 5-D table with control string evaluates exactly (6.5625);
4. regression lock: the 1-D inline form still interpolates exactly.

Also exercised during development: 3-D exact (9.36), mixed per-dimension control strings ("3,1L"). Regressions: all 36 version11 example verify suites ALL PASS — including `table_model/mdtable/cubic_table`, which lock the 1-3-D behaviour this change re-routes through the new dispatch.

Enhancement-41 — implicit nets in instance connections

This document describes the change made to OpenVAF-r in the `version11/` directory to support implicit nets: a plain identifier used in a module-instance port connection that names nothing declared in the enclosing module is implicitly declared as a scalar net. One-file change in the Enhancement-5 elaboration pass (`hir/src/elaborate.rs`); no OSDI/ngspice change.

Semantics (and the Verilog-A subtlety)

Per the LRM's structural-connection semantics, undeclared interconnect names in instance connections are implicit nets — the idiom every netlist-style module relies on:

```
module top(in, out);
  inout in, out; electrical in, out;
  res2 r1(in, mid);           // `mid` never declared -> implicit net
  res2 r2(mid, out);
endmodule
```

In full Verilog-AMS the implicit net's discipline comes from the ``default_discipline` directive — but the Verilog-A appendix excludes that directive ("not supported in Verilog-A"; every net's discipline must be defined). The two statements reconcile through discipline resolution: the implicit net takes its discipline from the connected port — exactly what resolution produces for the common case of joining compatible ports. That is what Enhancement-41 implements:

- the implicit net's discipline = the discipline of the target module's port it is connected to (fallback electrical if the port has none);
- two connections implying conflicting disciplines for the same implicit net are a hard error (implicit net 'mid' is connected to ports of conflicting disciplines 'electrical' and 'thermal' — declare it explicitly);
- ``default_discipline` remains ignored (the preprocessor has always parsed and discarded it), per the appendix;
- implicit declaration is structural-only: an undeclared identifier inside `V()`/`I()` access functions remains a clean scope error.

Before this change, every internal wiring node had to be declared manually — error: 'mid' was not found in the current scope.

Implementation

Implicit nets are synthesised in the module-instantiation elaboration pass (Enhancement-5's compile-time flattening, `hir/src/elaborate.rs`):

- while binding an instantiation's port connections, a `PortBinding::Scalar` whose text is a plain identifier (`as_plain_ident`) naming nothing in the parent module's declarations (`declared_names`: net/port base names, bus/array base names, parameters, variables, branches, functions, instance names) is recognised as implicit;
- the net becomes a local of the parent module, so it takes the parent's instance prefix like every other local — two flattened instances of the same submodule therefore keep their internal implicit nets distinct (no accidental cross-instance shorts);
- its declaration (`electrical top__mid; // implicit net`) is emitted exactly once, prepended to the parent's rendered body so it precedes every use;
- discipline conflicts collect into a hard anyhow error at the end of elaboration.

Both positional (`r1(in, mid)`) and named (`.n(mid)`) connection forms work; the same implicit net may appear in any number of connections.

Verification — `implicitnet_examples/`

`implicitnet_demo.va` chains two `ser2k` submodules — each with its own implicit internal net `w` — through an implicit top-level `mid`, mixing positional and named forms. `verify_implicitnet.py` (ALL PASS):

1. it compiles (used to error);
2. the DC resistance is exactly $4\text{ k}\Omega$ — proving `mid` joined the instances *and* the two nested `w` nets stayed distinct after flattening (a cross-instance short would read $2\text{ k}\Omega$);
3. conflicting-discipline connections are rejected with a clear message;
4. an undeclared identifier inside `V()` access remains an error.

Regressions: all 37 version11 example verify suites ALL PASS, all 79 example models recompile, and the instantiation/generate decks (the heavy users of the elaboration pass) run unchanged.

Enhancement-42 — correlated (same-named) noise sources

This document describes the changes made to OpenVAF-r and ngspice-46 in the `version11/` directory to implement noise-source correlation by name: noise functions that carry the same name argument model the *same* physical source and must sum coherently (as amplitudes) at the output, per Verilog-AMS LRM 4.6.4.

The gap

The LRM defines the name argument of `white_noise` / `flicker_noise` / `noise_table` as source *identity*: two noise functions with identical names are the same source — perfectly correlated — so their contributions to the output add as complex amplitudes,

$$\text{onoise}^2 = \left| \sum_k f_k \cdot \sqrt{\text{pwr}_k} \cdot T_k \right|^2 \quad (\text{same-named group})$$

not as powers,

$$\text{onoise}^2 = \sum_k f_k^2 \cdot \text{pwr}_k \cdot |T_k|^2 \quad (\text{independent sources})$$

where f_k is the (signed) contribution factor and T_k the complex transfer from the source's branch to the noise output.

Before this enhancement the name was used only to *label* the per-source output vectors. Every source was independent — a two-fold same-named source pair read $\sqrt{2} \times$ instead of $2 \times$, and even a negated contribution of the same source (`<+ -white_noise(S, "n")`, anti-phase, should cancel) *added* power.

The three `// TODO` noise markers in the OSDI crate (`metadata.rs`, `load.rs`) turned out to be stale — the code below them is complete — and the `lineralize.rs` "complex noise power" note is an optimization idea, not a gap. Correlation was the real leftover.

The fix (two-sided)

OpenVAF — **`openvaf/osdi/src/load.rs`** (`load_noise` codegen): the contribution factor used to be folded into the loaded power as `pwr * fac2`, destroying its sign. It is now folded as `pwr * fac * |fac|` — identical magnitude, but the loaded power carries the factor's sign. ngspice's noise analysis takes `fabs()` of each source's power before using it, so nothing changes for independent sources; the sign is what enables anti-phase cancellation inside a correlated group. (Supporting fix: `openvaf/mir_llvm/src/intrinsics.rs` never registered `llvm.fabs.f64` — one `ifn!` line.)

ngspice — **`src/osdi/osdinoise.c`** (`N_DENS`): the per-source loop first records each source's complex transfer $T_k = (\text{CKTrhs}[n1] - \text{CKTrhs}[n2]) + j(\text{CKTirhs}[n1] - \text{CKTirhs}[n2])$ (the adjoint solution), then walks the sources grouping same-named ones within the instance (`strcmp` on the OSDI descriptor's `noise_sources[].name`) and sums signed amplitudes $\text{sign}(\text{pwr}_k) \cdot \sqrt{|\text{pwr}_k|} \cdot T_k$ coherently before squaring:

- a uniquely-named source reduces *exactly* to the classic $|\text{pwr}| \cdot |T|^2$;
- the group's power is assigned to the group's first source (its `onoise_<inst>_<name>` vector shows the group total; members show 0), so the per-source reporting, log-slope integration and total-noise machinery are untouched;
- grouping is per-instance by construction (the loop runs inside one instance's descriptor), so identical names in *different* instances — or in the RFSPIICE S-parameter noise path, which keeps the independent per-source form — remain uncorrelated, as they must.

What now works (**`noisecorr_examples/`**, all exact)

With PSD $1\text{e-}12$ sources on a unity-transfer series chain ($\sqrt{\text{PSD}}$ amplitude $1\text{e-}6$ V/ $\sqrt{\text{Hz}}$ each):

case	onoise before	onoise after
same name twice	1.414e-6	2e-6 (amplitudes add)
distinct names	1.414e-6	1.414e-6 (unchanged)
same name, one negated	1.414e-6	0 (anti-phase cancels)
$2 * \text{wn}(S, "n") + \text{wn}(S, "n")$	2.236e-6	3e-6 (linear weights)
same name, two instances	2.828e-6	2.828e-6 (unchanged)
white + flicker, one name	1.414e-6 @1Hz	2e-6 (kind-agnostic)

verify_noisecorr.py: 7/7 PASS. Full version11 regression: 38/38 suites PASS (including the Enhancement-9 noise_table suite, byte-identical results — all its sources are uniquely named).

Notes

- Unnamed noise functions get compiler-synthesised unique names, so they can never group accidentally.
- Correlation is *total* (same source). Partial correlation is out of scope — the LRM models it by composing shared and private named sources, which this enhancement makes work.

Enhancement-43 — variable initializers, completed

This document describes the changes made to OpenVAF-r in the `version11/` directory to complete declaration initializers (`real x = 2.5;`). All changes are in `hir_def`; no OSDI/ngspice change.

What already worked (verified, kept as regression checks)

Scalar module-level initializers (`real/integer/string`), initializers that are constant expressions over parameters (`real y = 2.0*p + 1.0;`, re-evaluated against model-card overrides), named-block locals, multiple declarators, implicit `real`→`integer` rounding, and — the semantic core — LRM `init-once` behavior: each live unwritten variable read becomes a `ParamKind::HiddenState` input that `hir_lower/state.rs` seeds from the variable's initializer body gated on `IsInitialStep`, so event-updated state *starts* at the initializer and is never re-initialized per evaluation (`integer cnt = 10; + @(cross) cnt = cnt + 1;` counts 10, 11, ...). Initializers referencing other *variables* are correctly rejected ("constant expressions must not contain variable references").

The three defects

1. Array declaration initializers were rejected. `real x[0:2] = '{1.0, 2.0, 4.0}';` — an array variable expands into per-element scalar variables (E-14), and *each* element's body picked up the whole `'{...}'` aggregate, so the type check failed "expected real value but found `real[0:3]` value" once per element (the mysterious triplicated diagnostic).
2. Untyped analog-function arguments crashed the compiler. In `analog function real f; input v; ... endfunction` with no `real v;` declaration, `FunctionArg::ty` returned `Type::Err (declarations.first().map_or(Type::Err, ...))`, which flowed into inference and hit `unreachable!("unknown cast found Real -> Err")` (`hir_lower/ctx.rs`) at the first cast involving the argument. (This masqueraded as a "function-local initializer crash" during probing — the initializer was innocent.)
3. Wrong-arity initializers crashed the compiler — variables *and* parameters. `real x[0:2] = '{1.0, 2.0}';` (or the array-parameter equivalent, a *pre-existing* E-14 latent bug) produced `Expr::Missing` for the uncovered elements with no diagnostic, and lowering died with "invalid HIR: Missing".

The fix (`hir_def` only)

- `item_tree.rs` / `item_tree/lower.rs`: `Var` gains `array_index: Option<u32>` — each expanded element records its flat declaration-order (row-major) position, exactly mirroring `Param::array_index` (E-14/15).
- `body.rs`: an element variable's body takes the matching leaf of the shared `'{...}'` literal (`flatten + nth(pos)`, the same split the param path uses). N-D nesting comes free — the `flatten` is row-major, matching the element expansion order; integer leaves in a real array get the normal implicit cast; leaves may be constant expressions over parameters and are re-evaluated on overrides. Everything downstream (hidden-state seeding, `init-once` gating, function-local expansion) works unchanged because each element is just a scalar variable with its own initializer body.
- `item_tree.rs` (`FunctionArg::ty`): an argument with no type declaration defaults to **real**, matching the untyped-return default (`analog function f;` is a real function per the LRM).
- `item_tree/lower.rs`: both array-expansion sites (variables and parameters) count the literal's leaves against the declared element count and emit a new named diagnostic — `array initializer for 'x' has N element(s) but the array has M` — covering too-few, too-many, and scalar-on-array forms.

What now works (`varinit_examples/`, all exact)

case	result
<code>real v1[0:2] = '{1.0, 2.0, 4.0}; + integer iv[0:1] = '{8, 16};</code>	elements read exactly
<code>real m[0:1][0:2] = '{' {...}', '{...}'; (2-D), 3-D with integer leaves</code>	row-major leaves, casts applied
<code>real pd[0:1] = '{s, 3*s};</code>	leaves track s model-card override
<code>real acc[0:1] = '{100.0, 0.0}; + @(cross) update</code> <code>function-local real w[0:2] = '{...} + scalar init + untyped</code> input v <code>'{1.0, 2.0} on [0:2] (var or param), '{...x4}, scalar-on-array</code>	starts at 100, init-once evaluates exactly (was ICE) clean named diagnostic (was ICE)

verify_varinit.py: 12/12 PASS. Regression: all 39 example verify suites ALL PASS; hir_def/hir_ty/hir_lower/hir_lower2 crate tests pass.

Notes

- The stale `lower_var` comment claiming array initializers are "silently ignored" (Enhancement-4 era) was removed — they are now real.
- `parameter real [0:2] c = '{1.0, 2.0};` crashing was pre-existing (E-14); the new arity diagnostic covers it through the shared code path.

Enhancement-44 — paramset hierarchical system parameters

This document describes the changes made to OpenVAF-r in the `version11/` directory to support hierarchical system parameters in paramsets (`.$mfactor = 8`; LRM 6.4 — the canonical “quad device” idiom). No OSDI/ngspice change.

Baseline (probed first, all correct)

The six hierarchical system parameters (`$mfactor`, `$xposition`, `$yposition`, `$angle`, `$hflip`, `$vflip`) were already fully working at the instance level:

- readable in expressions with exact LRM defaults (1 / 0 / 0 / 0 / 1 / 1);
- settable per-instance in ngspice — `m=` for `$mfactor` (the OSDI layer’s standard alias) and `_xposition=` ... for the rest (ngspice rewrites the `$` prefix to `_`, since `$` starts a netlist comment);
- `$mfactor` semantics exact: flow contributions $\times m$, potential contributions invariant, noise PSD $\times m$, correct across E-5-flattened sub-instances.

The gap: a paramset could not set them — `.$mfactor = 8`; was a parse error (“unexpected token system function identifier”), yet per LRM 6.4 paramsets may specify hierarchical system parameters alongside parameter bindings.

Semantics

The paramset value composes with the instance-level value, per the LRM’s hierarchy rules:

- `$mfactor`, `$hflip`, `$vflip` — multiplicative (multiplicities and flips multiply down the hierarchy): `m=3` on a `.$mfactor = 8` paramset gives an effective 24;
- `$xposition`, `$yposition`, `$angle` — additive (offsets accumulate).

The composed value must be seen by *every* consumer: explicit `$mfactor` reads in the body, the DAE builder’s automatic flow scaling, its `sqrt(mfactor)` noise-factor scaling, and all derivative code. Override expressions are `paramset_constant_expressions` and may reference the paramset’s own card parameters (`.$mfactor = nf`), including their model-card overrides.

Implementation

- **`parser/grammar/items.rs`** — `paramset_override` accepts a `SYSFUN` token as the overridden name, wrapped in the same `NAME_REF` node (plus a `NameRef::sysfun_token()` accessor in syntax).
- **`hir_def/item_tree/lower.rs`** (`lower_paramset`) — each HSP override becomes a hidden real localparam named `$paramset$<name>` in the E-21 twin module, with the override expression as its `override_expr` (the ordinary E-21 localparam-with-override machinery evaluates it in twin scope, so card-parameter references and model-card overrides just work). The `$`-spelling collides with no user identifier and deliberately differs from the OSDI built-in `$mfactor` instance parameter — so ngspice’s `m=` alias keeps pointing at the *instance* value. Unknown system functions (`.$vt = 1`;) get a named diagnostic (`ItemTreeDiagnostic::InvalidParamsetSysParam`). The synthetic param’s `ast_id` is a placeholder (E-23 `from_erased` trick); the override branch of `param_body_with_sourcemap` was reordered to not dereference the `ast::Param` node it doesn’t have.
- **`hir_lower/state.rs`** — new `HirInterner::insert_paramset_sys_fun_overrides`, modeled on the E-7 `insert_var_init` use-rewrite: for each override, read the hidden localparam (`ParamKind::Param`), build `fmul/fadd` with the `ParamKind::ParamSysFun` value, and rewrite every pre-existing use of the system parameter with the composed value.
- **`sim_back/lib.rs`** — the pass runs after **`DaeSystem::new`** (so the automatic `mfactor` flow/noise scaling and the derivative code exist and get rewritten) and before the post-derivative optimization; the twin’s hidden localparams are recognized by their `$paramset$` name prefix. One supporting

fix: the pass creates new MIR values, so `output_values` is re-grown — `BitSet::contains` in the `init-cache` dead-code pass indexes by value and panicked otherwise.

What now works (`paramsethsp_examples/`, all exact)

case	result
<code>paramset quad rbase; .r = 2e3;</code>	250 Ω effective (−4 mA at 1 V)
<code>.\$mfactor = 8;</code>	
<code>quad + netlist m=3</code>	effective 24 $\rightarrow$ −12 mA
all six HSPs in one paramset, read back	8254.89 composed exactly
<code>+ instance m=3 _xposition=5 _hflip=-1</code>	24755.09 ($\times$ m, + positions, $\times$ flips)
<code>.\$mfactor = nf (card param)</code>	−5 mA at default <code>nf=5</code> , −2 mA with <code>nf=2</code>
noise through paramset multiplicity	onoise $5e-4$ = netlist <code>m=4</code> exactly
<code>.\$vt = 1;</code>	”\$vt’ is not a hierarchical system parameter”

`verify_paramsethsp.py`: 8/8 PASS. Regression: all 40 example verify suites ALL PASS; `sim_back/hir_def/hir_low` crate tests pass.

Notes

- The `sim_back` MIR snapshot files (`test_data/dae/topology/init`) were stale from earlier enhancements (the suite hadn’t been run since ~E-36’s DAE builder changes) and failed identically on the committed pre-E-44 sources; they were refreshed with `UPDATE_EXPECT=1` against the current (verified bit-identical at E-42) behavior.
- Paramsets *selecting* on hierarchical system parameters (LRM’s restriction-checking use) remain out of scope; only value specification is implemented.

Enhancement-45 — net initialization + net attribute access

This document describes the changes made to OpenVAF-r and ngspice-46 in the version11/ directory to implement two LRM features that were both completely missing: net nodeset initializers (LRM 3.6.3.2) and net/branch attribute access (LRM 5.5.3).

Half A — accessing net and branch attributes (LRM 5.5.3)

```
I(a,b) <+ c*ddt(V(a,b), a.potential.abstol); // the LRM's twocap example
x = n1.flow.abstol;
y = br.potential.abstol; // branch form (LRM prose)
```

Every spelling failed with “expected a scope but found node/branch/nature” — the E-39 “scaffolded-but-unwired” pattern at yet another boundary: nameres had `ResolvedPath:: {Flow, Potential}Attribute` arms for branches, but only in the cross-scope `resolve_names_in` traversal; the module-body `resolve_path` entry rejected any non-scope qualifier first, so even the branch form was unreachable from where models actually use it.

Fix (front-end only):

- `hir_def/nameres.rs`: the module-body entry gains `NodeId/BranchId` arms for 3-segment `.potential/.flow` attribute paths, with two new `ResolvedPath` variants (`NetPotentialAttribute/NetFlowAttribute`).
- `hir_ty/lower.rs`: `net_nature_attr` — `net` → `discipline` → `potential/flow nature` → `attribute`, through `NatureTy::lookup_attr` (E-39’s inheritance-aware lookup, so attributes of derived natures resolve).
- `hir_ty/inference.rs`: the new variants type as `Ty::NatureAttr`; lowering needed nothing — `Ref::NatureAttr` reads already lower to the attribute’s constant value body.

Unknown attributes get the existing clean diagnostic (“‘nonsense’ was not found in ‘Voltage’”).

Half B — net discipline initial (nodeset) values (LRM 3.6.3.2)

```
electrical a = 5.0; // nodeset for a's potential
electrical [0:2] b = '{0.5, -1.0, 2.0}'; // per-bit leaves
```

Previously a parse error. The initializer is a constant used as a nodeset value — an initial Newton-Raphson guess, not an enforced constraint.

Pipeline (both stacks):

- parser: each net declarator accepts an optional `= expr`; the expression is a direct `NET_DECL` child after its `NAME` (new `NetDecl::declarators()` AST accessor pairs them).
- `hir_def`: `Net/NodeData` carry the const-folded value (`OrderedFloat`); bus declarators split the `{...}` literal into per-bit leaves in ascending bit order (matching the bus expansion). Non-constant initializers get a new named diagnostic (`NonConstantNodeset`) — parameter-dependent nodesets are out of scope.
- OSDI ABI: `OsdiNode` gains a `double nodeset` field (`NAN = none`), filled for Kirchhoff-law unknowns from the net’s value. Because this changes the node-array stride — which the `OSDI_DESCRIPTOR_SIZE` mechanism does not cover — the OSDI version is bumped to 0.5, and ngspice’s loader now requires ≥ 0.5 , rejecting stale `.osdi` files with “Recompile the model with the matching `openvaf-r`” instead of misreading them.
- ngspice (`osdisetup.c`, landing exactly on a pre-existing `// TODO nodeset? marker`): at instance setup, internal nodes created with a non-NAN nodeset get `node->nodeset/nsGiven` set; connected terminal nodes get the same treatment unless the netlist already gave one (`.nodeset` wins, matching the LRM’s hierarchical-declaration-wins spirit).

- elaboration (hir/elaborate.rs): the E-5 flattening re-renders net declarations when filtering out port names — it now preserves each surviving net's initializer text, so submodule nets keep their nodesets.

What now works (**netinit_examples/**, all verified)

Bistable $x = \tanh(5x)$ (solutions $0, \pm 0.999909$), the nodeset selecting the branch:

case	result
no initializer	0 (trivial solution)
electrical m = 1.0; /= -1.0; (internal)	+0.999909 / -0.999909
port initializer electrical q = 1.0;	+0.999909 on the terminal
netlist .nodeset v(q)=-1 vs port initializer	netlist wins (-0.999909)
bus '{0.5, -1.0, 2.0}	per-bit: weighted sum 90.99
initializer in flattened submodule	preserved (-0.999909)
1e6·q.potential.abstol + 1e12·q.flow.abstol + 1e6·br.potential.abstol	3.0 exactly
electrical m = 2*p; / a.potential.nonsense	clean named diagnostics

verify_netinit.py: 11/11 PASS. Regression: all 41 example verify suites ALL PASS; crate tests (hir_def/hir/hir_ty/hir_lower/sim_back/osdi/ parser/syntax) 57/57.

Notes

- Breaking ABI note: .osdi files compiled before E-45 must be recompiled (clean version error, not silent corruption). All committed example .osdi binaries and prebuilts are regenerated.
- Null bus-literal slots ('{2.3, 4.5, , 6.0}', LRM) remain a parse error — use an explicit value per element; extra/missing leaves simply leave the remaining bits without a nodeset.
- Nature-qualified spellings (Voltage.abstol) stay rejected: the LRM BNF (Syntax 5-4) allows net qualifiers only; the abstol-for-ddt() use passes the nature identifier directly, which already worked.

Enhancement-46 — escaped identifiers + integer literal bases

This document describes the changes made to OpenVAF-r in the `version11/` directory to implement integer literal bases (LRM A.8.7) and complete escaped identifiers (LRM A.9.3). Front-end only; no OSDI/ngspice change.

Integer literal bases (were entirely missing, plus a crash)

'h1F, 'o17, 'b1010, 'd42, sized 8'hFF, signed 8'shFF — every based form was "encountered unexpected token": the lexer contained only a commented-out sketch of based-number tokenization. And the LRM-legal underscore separator (`1_000_00`) crashed the compiler: `eat_decimal_digits` accepted `_` into the token, but `IntNumber::value_as_f64` parsed the raw text ("IntNumber token must be valid float syntax too: ParseFloatError").

Fix (`lexer, syntax/ast/expr_ext.rs`):

- The lexer tokenizes `[size] '[s]<base><digits>` — the unsized form from the `'` dispatch (alongside the `'{` aggregate arm), the sized form as a continuation of `number()`. Digits are validated per base while lexing (`'b12` ends the token at the 2 → ordinary parse error), a digit is required after the base (a bare `'h` never becomes a silently-zero literal), and `x/z` digits — not meaningful in the analog subset — are not consumed.
- Value parsing (`parse_based_int`): strip `_`, radix-parse, mask to the declared size (clamped `1..=32`), sign-extend from the size's MSB under `s`, wrap to the 32-bit integer type (`'hFFFFFFFF = -1`). `_` separators are stripped in all number forms (plain ints, `1_234.5` reals, SI-scaled).

Escaped identifiers (half-wired)

The lexer already emitted `EscapedIdent` tokens (backslash through the last non-whitespace character) and mapped them to `IDENT` — but two defects made the feature unusable:

1. **Name::resolve** stripped the last character along with the backslash (`raw[1..len-1]`, written for a token shape that included the terminating whitespace). `\foo` resolved to `"fo"`, so the escaped and plain spellings of a name never matched — and the compiler's own `std.va` def-map snapshot had baked in `logi` for the escaped `\logic` discipline, hiding the bug. Fixed to strip only the backslash; the stale snapshots were refreshed.
2. The E-5 elaboration re-rendered substituted names unescaped. An escaped net inside a flattened submodule (`\n-1` → instance-prefixed `u1_n-1`) was emitted raw into the synthesized text, which no longer lexed ("unexpected token '-"). A `render_name` helper now re-escapes any substitution value that isn't a plain identifier (`\u1_n-1`), applied in `render_with_holes` (which also gained the `EscapedIdent` substitution arm — escaped *uses* keyed by their resolved name) and the net-declarator re-render path.

Keyword spellings (`\module`) work as names — `EscapedIdent` never goes through keyword mapping.

What now works (**escid_examples/**, all exact)

case	result
'h1F + 'o17 + 'b1010 + 'd42	31+15+10+42
8'hFF / 8'shFF / 4'sb1000	255 / -1 / -8 (size mask + sign extension)
'hFFFFFFFF	-1 (32-bit wrap)
1_000_00, 16'hAB_CD, 1_234.5	separators stripped everywhere
whole-module sum	0.1443252345 V exactly
\2wire, \value#, \r+val	nets/vars/params with specials
\mid ≡ mid	one net (LRM equivalence)

case	result
escaped net in flattened submodule \module	re-escaped, 2k series exact keyword spelling as a name
'h, 'sh, 'b12, 8'squark	clean parse errors, no crash, no silent 0

verify_escid.py: 12/12 PASS. Regression: all 42 example verify suites ALL PASS; 65/65 crate tests (lexer/tokens/syntax/parser/hir_def/hir/ hir_ty/hir_lower/sim_back) after refreshing the snapshots that had encoded the \logic→logi bug.

Notes

- Sized literals wider than 32 bits clamp to the 32-bit integer type.
- The 'd form takes decimal digits only; x/z digits are rejected by construction (analog subset).

Enhancement-47 — ‘default_transition + transition() fixes

This document describes the changes made to OpenVAF-r in the version11/ directory to implement the ``default_transition` compiler directive and fix two pre-existing `transition()` defects the work exposed. Front-end + lowering only; no OSDI/ngspice change.

The directive (was a hard error)

``default_transition <time>` sets the default rise/fall time used by `transition()` filters that omit those arguments (LRM; 0 = instantaneous when no directive is given). Previously it hard-errored as an undeclared macro — the only directive from the E-47 probe's list of nine that didn't work (define/undef/ifdef/ifndef/else/elsif/endif/include were all verified exact).

Implementation:

- preprocessor: a `DefaultTransition` directive kind (next to `DefaultDiscipline`), a capture-number helper, and an SI-suffix-aware value parser (1u, 10n, 1e-6, _ separators). The value rides on the Preprocess result (last directive wins — file-level granularity; real models declare at most one, and a directive inside a false ``ifdef` is never processed, so conditional guards behave correctly).
- `hir/db.rs:CompilationDB::default_transition()` accessor.
- `hir_lower`: the no-args and delay-only `transition()` forms ramp with the directive's time (rate = 1/t) instead of returning the input directly; explicit rise/fall arguments are untouched.

Pre-existing defect #1: the TRANSITION signature table (compiler crash)

Every entry was one argument short: `TRANSITION_DELAY_RISE` claimed 2 arguments (it takes 3), `_FALLT` 3 (takes 4), `_TOL` 4 (takes 5). So a 3-argument `transition(s, td, trise)` resolved to `_FALLT` and the lowering read `args[3]` out of bounds — compiler crash (confirmed on the released E-46 binary); 4-argument calls only worked *by accident* (they resolved to `_TOL`, whose lowering happened to read the right indices); the true 5-argument `tol` form did not resolve at all. The table now declares the correct arities and all five forms work.

Pre-existing defect #2: singular DC operating point

`lower_rate_limited_track` (shared by `slew` and `transition`) implements $dy/dt = \text{clamp}(K \cdot (x - y), -\text{fall}, \text{rise})$. When the clamp saturates, the residual's derivative w.r.t. y is zero — and since the reactive part doesn't count in DC, the Jacobian diagonal vanished and the operating point went singular whenever the input started more than rate/K away from the state (e.g. a timer-driven comparator already high at $t=0$): `gmin/source` stepping failed and the transient produced garbage unless `uic` was given. Per the LRM a transition/slew filter is a static identity in DC, so the residual now selects on the integration-enable parameter: $y = x$ in DC (diagonal 1, never singular, exact LRM semantics), the rate-limited form in transient. AC also becomes an exact unity transfer (previously a spurious pole at $K = 1\text{e}9$ rad/s).

What now works (`defaulttransition_examples/`, all verified)

case	result
bare <code>transition(s) +</code> <code>`default_transition 1u</code>	1 μs ramp, half-cross at 0.5 μs , clean DC (no <code>uic</code>)
<code>transition(s, 0.2u) +</code> directive	delay then default ramp (half-cross at flip + 0.7 μs)
explicit <code>transition(s, 0, 2u)</code>	2 μs ramp — explicit args win
all five arities in one contribution	weighted plateau 0.875 exact (3-arg used to crash)
no directive	instantaneous, unchanged

case	result
directive inside false `ifdef	ignored

verify_defaulttransition.py: 8/8 PASS. Regression: all 43 example verify suites ALL PASS; 71/71 crate tests.

Notes

- Positional granularity is file-level (the last directive processed wins), matching real usage; the LRM's mid-file re-declaration subtlety is out of scope.
- The absdelay history's startup value (input nonzero at t=0 reads 0 for the first td) is a pre-existing E-24 behavior surfaced while testing, not changed here.

Enhancement-48 — string literal escape sequences

This document describes the change made to OpenVAF-r in the `version11/` directory to complete string literal escape handling per LRM 2.7.1. One function in syntax; no OSDI/ngspice change.

The defects

The LRM escape set for string literals is `\n`, `\t`, `\\`, `\"`, and `\ddd` (a character given by one to three octal digits). The probe found:

escape	before
<code>\n, \t, \\, \"</code>	worked
<code>\ddd octal</code>	unsupported — printed literally
<code>\\n</code> (literal backslash, then n)	corrupted — printed backslash + real newline

Root cause: `StrLit::unescape_value` chained sequential `str::replace` calls, with `\n` replaced *before* `\\` — the classic overlapping-escape bug (the `\n` inside `\\n` was consumed first, orphaning the leading backslash) — and simply had no `\ddd` handling.

The fix

`unescape_value` is now a single left-to-right pass:

- `\n, \t, \\, \"` — the LRM basics;
- `\ddd` — one to three octal digits, greedy, out-of-range values degrade to the replacement character;
- backslash before a (possibly CRLF) newline keeps the newline — the pre-existing line-continuation extension, behavior unchanged;
- any other escape (and a trailing backslash) is preserved verbatim.

The audit confirmed every string consumer already routes through this one function — `$strobe/$display/$swrite` format strings, string literal values and comparisons, `(* desc= *)/units` attribute strings, `@(initial_step("phase"))` phase names, and lint-attribute names — so the fix applies uniformly with no second unescape path to drift.

What now works (**`stresc_examples/`**, all verified)

case	result
<code>"\101\102\103" in \$strobe</code>	prints ABC
<code>"\060\61" (3- and 2-digit forms)</code>	prints 01
<code>"a\\nb"</code>	prints <code>a\\nb</code> — literal backslash + n (the old bug printed a newline)
<code>"\101\102" == "AB"</code>	true — octal and plain spellings are the same string
<code>"x\\ny" == "x\\ny", "a\\qb" == "a\\qb"</code>	overlap-safe, unknown escapes consistent
<code>\n/\t/\\/" rendering</code>	unchanged, exact

`verify_stresc.py`: 8/8 PASS. Regression: all 44 example verify suites ALL PASS; `syntax/hir_def/basedb/hir_lower` crate tests 52/52.

Notes

- %% in format strings is printf-level, not a string escape — untouched.
- Multi-line strings remain tolerated with the backslash-newline continuation keeping the newline, exactly as before this change.

Enhancement-49 — \$root + hierarchical names, transition() input

This document describes the changes made to OpenVAF-r in the `version11/` directory for three related front-end defects: hierarchical references into flattened instances, nested named-block paths, and `transition()`'s input type (plus a builtin signature audit). No OSDI/ngspice change.

1. Hierarchical references into flattened instances (LRM 6.6)

The probe found `$root`-anchored paths and single-level block paths working, but every reference into an instance failed — after the E-5 elaboration flattens `rdiv u1(a, c);` into prefixed locals (`u1__m`, `u1__r`), parent-side references were never rewritten:

```
analog V(a,c) <+ 0.0*V(u1.m);    // error: 'u1' was not found in the current scope
x = u1.r;                        // same
```

Fix (`hir/elaborate.rs`): every rendering scope now carries an instance-chain map — all chains reachable from that scope ("`u1`", "`u1.u2`", "`u1[2]`", ...) mapped to their composed flattening prefixes, built recursively from the item tree. A token-level scanner (`find_instance_path_holes`, the same hole mechanism as the bus-port substitution) rewrites `chain.member` occurrences to `render_name(prefix + member)`:

- deep chains compose (`u1.u2.x` → `u1__u2__x`); instance-array elements work (`u1[2].m` → `u1_2__m`, disambiguated from bus selects by chain lookup);
- the top module's scope adds `<top>...` alias entries and the scanner strips a leading `$root.`, so `$root.hier.u1.u2.m`, `hier.u1.u2.m` and `u1.u2.m` all resolve identically (per the LRM, `$root.<top>.x` ≡ `x` from `<top>`);
- bus selects after the member stay in place (`u1.b[2]` → `u1__b[2]`); escaped member names re-escape through E-46's `render_name`;
- a member followed by a further `.` (a named block *inside* the child) is left untouched — out of scope, cleanly diagnosed by name resolution.

2. Nested named-block paths

`outer.inner.w` failed with `"'w' was not found in 'inner'"` while single-level `blk.v` worked. Root cause in `hir_def/namer.rs::resolve_names_in`: the traversal correctly redirects `current_map` into each nested block's def map, but the final name lookup used `self.scopes` — probing the original map's scope ids against the wrong arena. One-token fix (`current_map.scopes[scope]`), plus the write-up of why only multi-segment paths hit it (single-segment callers had already switched maps).

3. transition() input type (user-reported) + builtin audit

The LRM's canonical comparator failed to compile:

```
error: type mismatch: expected integer value ... but found real variable reference
  | V(cout) <+ transition(vcout, td, tr, tf);
```

The TRANSITION signature table typed the input `Val(Integer)` (and the lowering ifcast-ed it), but per LRM 4.5.7 the filter's input is a real expression — smoothing piecewise-constant real waveforms is its whole purpose. All five signatures now take `Val(Real)` (integer inputs promote implicitly; the manual cast is gone). The follow-up audit of every builtin signature table (`noise`, `ddt/idt/idthmod`, `laplace/zi`, `absdelay/slew`, `last_crossing`, `file I/O`, `simparam/simprobe`, `random/arandom`, `rdist/dist`, `plusargs`, `discontinuity`, `bound_step`, `ddx`, `table_model`, `display`, and the event kinds) found exactly one more defect: `DIST_2_ARG_CONST_SEED` typed its middle argument `Val(Real)` while its three siblings say `Val(Integer)` — fixed.

What now works (**hiername_examples/**, all exact)

case	result
u1.u2.r (deep hierarchical parameter)	reads the child's default exactly
V(u1.u2.m) / V(\$root.hier.u1.u2.m) / V(hier.u1.u2.m)	all three spellings identical (sum 557 exact)
outer.inner.w, \$root.blocks.outer.inner.w	3.75 exact (was an error)
real vcout; transition(vcout, td, tr, tf)	the LRM comparator compiles and switches

verify_hiername.py: 4/4 PASS. Regression: all 45 example verify suites ALL PASS; 57/57 crate tests.

Notes

- Upward references (a child naming its parent's objects) and hierarchical references *out of* the compiled top module remain out of scope — they have no meaning for a self-contained OSDI model.
- Named blocks inside child instances (u1.blk.v) are not rewritten; they surface as ordinary resolution errors.

Enhancement-50 — domain binding validation

This document describes the change made to OpenVAF-r in the `version11/` directory to enforce the one missing rule of discipline domain bindings (LRM 3.6.2.2). One validation check in syntax; no OSDI/ngspice change.

Probe verdict (domain was substantially implemented)

- `domain continuous;` / `domain discrete;` parse and are stored on `DisciplineData` (the std header's `ddiscrete/logic` disciplines exercise `domain discrete` in every compilation);
- nature-bound disciplines default to the continuous domain;
- the domain participates in discipline-compatibility checks, with domainless disciplines treated permissively (LRM 3.6.2.3);
- discrete-domain nets are rejected in analog accesses ("illegal access of branch");
- a custom continuous discipline with natures compiles and simulates exactly.

The gap and the fix

LRM 3.6.2.2: *"It is an error for a discipline to have a domain binding of discrete if it has nature bindings."*
Previously accepted silently:

```
discipline bad
  domain discrete;
  potential Voltage;  // ← no diagnostic
enddiscipline
```

`validate_discipline_decl` now tracks the `domain discrete` binding and the first (unqualified) potential/flow nature binding, and emits a two-label error — "the domain is bound discrete here" / "... but a nature is bound here" — with a help note citing the rule and both remedies (drop the natures for a digital discipline, or bind `domain continuous`). Qualified attribute *overwrites* (`potential.abstol = ...`) are not nature bindings and don't trigger it.

Verification

`domainbind_examples/verify_domainbind.py`: 5/5 PASS (continuous discipline simulates at -1 mA exactly; natureless discrete accepted; the error case diagnosed; discrete-net analog access still clean).
Regression: all 47 example verify suites ALL PASS; `syntax/basedb/hir_def/hir_ty` crate tests 24/24.

Enhancement-51 — full ac_stim AC injection

This document describes the changes made to OpenVAF-r and ngspice-46 in the `version11/` directory to complete **ac_stim** (LRM 4.6.3) — the small-signal AC stimulus source, deferred since Enhancement-26 (which fixed the compiler crash and the correct large-signal 0, but injected nothing).

Semantics (LRM 4.6.3)

`ac_stim([analysis_name][, mag[, phase]])` — zero during large-signal analyses and on small-signal analyses whose name doesn't match `analysis_name` (default "ac"); when the analysis matches, a source with magnitude `mag` (default 1) and phase `phase` (radians, default 0).

Implementation (the noise-source mold)

- `hir_lower`: `ac_stim` lowers to a dedicated `CallbackKind::AcStim` callback per call site (exactly like `white_noise`), carrying the analysis name and `[mag, phase]` values; the named signatures take the analysis name as a string literal per the LRM BNF.
- `sim_back`: the callback rides the existing noise extraction — the linearizer classifies it into the small-signal network (so the branch exists with its factor while the large-signal residual stays 0), and `NoiseSourceKind::AcStim { mag, phase }` flows through the shared `NoiseSource` records with `hi/lo/factor`. `mfactor` scales the stimulus *linearly* for current sources and leaves voltage stimuli invariant — deterministic-signal laws, unlike noise's `sqrt(m)`.
- OSDI (ABI 0.6): the sources are partitioned out of the noise arrays (which stay aligned with `load_noise`'s slots via filtered indexing) into appended descriptor fields — `num_ac_stim_src`, `ac_stim_sources {analysis, nodes}`, and a generated `load_ac_stim(inst, model, dst)` that fills `[re, im]` pairs = `factor·mag·cos/sin(phase)` from eval-cached values (op-dependent magnitudes work). `ngspice`'s descriptor view also gained the previously undeclared tail fields it now needs to reach the appended ones. Breaking: OSDI version bumped to 0.6; the loader rejects older `.osdi` files with the recompile message.
- `ngspice (osdiacld.c)`: after loading the AC Jacobian, each instance's active sources (analysis name "ac") add `-re/-im` at node 1 and `+re/+im` at node 2 of the complex RHS — the sign follows the residual convention $(G+j\omega C)x = -\text{residual_stim}$, calibrated so `V(out) <+ ac_stim()` reads exactly $+1\angle 0$.

What now works (**acstim_examples/**, all exact)

case	result
<code>V(out) <+ ac_stim();</code>	AC <code>v(out) = 1∠0</code> exactly
<code>ac_stim("ac", 2.0, π/2)</code>	<code>j2</code> (phase in radians)
<code>ac_stim("sp")</code>	inactive in AC (0), per LRM name matching
<code>I(out) <+ ac_stim(); into 1k</code>	<code>-1000</code> (contribution sign convention)
internal stimulus + RC lowpass	<code>0.5–0.5j</code> at <code>fc</code> (<code>0.7071∠–45°</code>), <code>0.01</code> at <code>100·fc</code> — an embedded AC test bench measuring the model's own transfer
large-signal invariance	DC/transient unchanged (the E-26 checks still pass)
<code>m=3</code> on a current stimulus	<code>×3</code> linearly

`verify_acstim.py`: 9/9 PASS (2 original + 7 new). Regression: all 47 example verify suites ALL PASS (noise + correlated-noise suites confirm the partition is airtight); crate tests 28/28.

Notes

- ngspice's only OSDI small-signal analysis is AC, so "ac" is the only active name; other names are stored and stay inactive (LRM-conformant).
- Noise analysis is unaffected: `ac_stim` sources never enter the noise descriptor arrays or `osdi-noise.c`'s loops.

Enhancement-52 — `idt()` assert/reset forms

This document describes the change made to OpenVAF-r in the `version11/` directory to fix the **`idt(expr, ic, assert[, tol|nature])`** reset forms — the E-28 leftover and the last open item of the integrator family. `hir_lower-only`; no OSDI/ngspice change.

The defect

Per the LRM, while `assert` is nonzero the integral output is reset to `ic` and held; integration resumes from `ic` when `assert` returns to zero. The previous lowering selected between “integrate” (`resist = -expr, react = val`) and “pin” (`resist = val - ic, react = ic`) — so at the reset onset the reactive residual (the integrator’s stored charge) jumped from the integrated value to `ic`. The transient integrator’s d/dt term turned that jump into a one-step impulse — the exact failure mode Enhancement-27 documented for `idtmod`’s state wrap. Externally-driven resets mostly survived (the impulse settled between measurement points), but a self-referential reset (`idt(1.0, 0.0, V(out) > 1.0)`) fed the impulse back into its own condition: the probe’s 1 V/s ramp rang chaotically, went negative, and spiked to ~400 V.

The fix (smooth charge + bounded stiff decay)

- The reactive residual is always **`val`** — the charge never jumps, at either the reset onset or the release.
- Reset is a stiff first-order decay: `resist = K · (val - ic)` with $K = 1e5$ ($\tau = 10\ \mu\text{s}$), so the output is driven to `ic` fast but continuously.
- A conditional **`bound_step`** ($2/K = 20\ \mu\text{s}$) is emitted only while the decay is active ($|val - ic| > 1e-6 \cdot (1 + |ic|)$) — keeping the trapezoidal method in its deadbeat region so the stiff mode cannot ring — and released once settled, so an `assert` held for seconds simulates at full speed. (An unbounded $\tau = 1\ \text{ns}$ decay was tried first: trap’s ± 1 amplification of stiff modes made the oscillator undershoot to -0.25 and stretched its period 40%.)
- The DC/IC phase keeps the E-28 behavior: `val` pinned to `ic` algebraically, with the charge ($= val = ic$) handing over continuously into transient.

What now works (**`idtassert_examples/`**, all exact)

case	result
external reset pulse	ramp 0.5→1.5, held at 0.5, resumed to 1.5
op-dependent integrand + reset at the op + tol form	0.25 held, then 2 V/s
self-referential <code>V(out) > 1</code> reset	bounded at exactly 1.0 (was ~400)
relaxation oscillator (<code>idt</code> + hysteretic cross reset)	peaks 1.0, valleys at <code>ic</code> , period exactly 1 s, no undershoot

`verify_idtassert.py`: 9/9 PASS. Regression: all 47 example verify suites ALL PASS; 28/28 crate tests.

Notes

- A non-hysteretic self-reset (`assert = output > threshold`) settles at the threshold (a sliding equilibrium) rather than oscillating — correct continuous dynamics; oscillators need hysteresis, as demonstrated.
- The nature-typed 4th-argument form compiles and behaves as the tol form (tolerances remain accepted-but-unused, the project-wide convention).

Enhancement-53 — `@(final_step)` + analysis-phase lists on step events

This document describes the changes made to OpenVAF-r and ngspice-46 in the version11/ directory to implement the `@(final_step)` event and the analysis-phase lists on both step events (`@(initial_step("tran","ac"))`, LRM 5.10.2) — the last visibly missing Verilog-A (LRM Annex C) feature.

What was broken

The probe `@(initial_step)`, phase-qualified variants, `@(final_step)` through `tran` and `op` confirmed two documented gaps:

1. `@(final_step)` never fired. Enhancement-7 implemented `@(initial_step)` via a one-shot `EVAL_FLAG_IS_INITIAL_STEP` but left `final_step` as a documented fail-safe no-op — firing needs “the analysis is over” knowledge the per-iteration eval loop doesn’t have (before E-7 it fired on every evaluation).
2. Analysis-phase lists were silently dropped. The AST/HIR always carried `Event::Global { phases: Vec<String> }`, but `lower_event_control` matched `{ kind, .. }` — `@(initial_step("ac"))` fired during a transient run and `@(initial_step("tran"))` fired during an op (the recurring “scaffolded-but-unwired at a boundary” pattern).

The fix

`@(final_step)` — one dedicated post-analysis evaluation

- **hir_lower**: new `ParamKind::IsFinalStep` (sibling of `IsInitialStep`, same `op_dependent` classification); `lower_event_control` gates the body on it.
- **osdi/src/eval.rs**: `EVAL_FLAG_IS_FINAL_STEP = 1 << 21` (next additive bit above E-7’s 1 << 20, still clear of the core ABI’s flag space; not an ABI change — no descriptor/stride is touched).
- **ngspice**: new `OSDIfinalStep(CKTcircuit *)` in `osdi/osdiload.c` (declared in `ngspice/osdiitf.h`), called once at the successful end of each analysis — `dctran.c` (last accepted transient point), `dcop.c` (an op is both the first and last point of its analysis), `dctrcurv.c` (last DC sweep point), `acan.c` and `noisean.c` (end of the frequency sweep). It issues one dedicated `eval()` per OSDI instance with `EVAL_FLAG_IS_FINAL_STEP` set, computed at the converged final solution (`CKTrhsOld`); the results are deliberately not loaded into the matrix/RHS — the analysis is over, the call exists so `@(final_step)` bodies (*strobe*/fdisplay summaries, cleanup assignments) run exactly once. The `ANALYSIS_*` flags are set from `CKTmode` with `OSDIload`’s mapping so phase-qualified `@(final_step("tran"))` matches.

Phase lists — reuse the **analysis()** matcher `lower_event_control` now lowers `@(step("a","b"))` as `step_flag & (analysis("a") | analysis("b") != 0)` using the same per-name `CallbackKind::Analysis` callback that `analysis(...)` itself uses (Enhancement-30’s OR-shape, factored as `lower_phase_filter`). An empty list fires in every analysis, as before.

The AC/noise op-phase mapping gap `@(initial_step("ac"))` still didn’t fire in an AC run: an AC job’s first model evaluation happens during its DC operating-point phase, where `OSDIload` set only `ANALYSIS_DC|ANALYSIS_STATIC` — so the one-shot fired with no “ac” match. ngspice already treats `tran`’s op phase as part of `tran` (`MODETRANOP` → `ANALYSIS_TRAN`), but `CKTmode` cannot distinguish an AC job’s op from a standalone op. `OSDIload` now consults the running job’s type (`ft_sim->analyses[ckt->CKTcurJob->JOBtype]->name`) and adds the `ANALYSIS_AC` (or `ANALYSIS_NOISE`) name bit only during that op — *not* the reactive `CALC_*` bits `is_ac` carries, which would wrongly enable ddt/integration during an operating point. This also makes `analysis("ac")` hold through the whole AC analysis per LRM 4.6.1.

What now works (**finalstep_examples/**, 23 checks, all exact)

analysis	behavior
tran 2 μs	final fires exactly once at $t = t_{\text{stop}}$ and sees the converged solution ($V = 1.0$ at two full sine periods, $1e-6$); final_tran fires; final_ac/final_dc silent; initial_ac silent; multi-phase ("ac", "tran") fires
op	single point = first and last: initial, initial_dc, final, final_dc fire once each; tran/ac-qualified silent
ac sweep	final + final_ac fire once after the sweep; initial_ac + multi-phase fire (op-phase mapping fix); tran/dc-qualified silent
dc sweep 0→2 V	final fires once and sees the last sweep point ($V = 2.0$ exact); final_dc fires
noise sweep	initial + final fire once each
peak track- ing	the LRM's classic use case: a variable accumulated across the whole transient is reported once at final_step ($v_{\text{peak}} = 1.5, 1\%$)

verify_finalstep.py: 23/23 PASS. Regression: all 48 example verify suites ALL PASS; crate tests (hir_lower, sim_back, osdi) all pass.

Notes

- Not an OSDI ABI change: the flag is an additive bit in the existing flags word (same convention as E-7); no descriptor layout moves, so existing .osdi files stay loadable (they just never see the new bit).
- With autostop, final_step fires at the autostop point (the last point the analysis actually solved), which is the LRM-correct reading of "the last point of the analysis".
- Interrupted/failed analyses do not fire final_step — only the successful completion paths call OSDIfinalStep.
- The final-step evaluation may update hidden/event state slots; every analysis re-initializes them (osdisetup.c resets), so subsequent analyses are unaffected.

Enhancement-54 — correct + node-free noise factors

This document describes the changes made to OpenVAF-r and ngspice-46 in the `version11/` directory for the noise "extra node" subsystem — the last survivor of the old candidate list (`linearize.rs`'s "TODO: complex noise power"). The probe turned an optimization task into a correctness one: the extra-node path's noise was silently lost end-to-end.

What the probe found

Four shapes were tested against analytic PSDs (device + surrounding-resistor floors):

shape	before E-54
<code>white_noise(pwr)</code> direct	correct (Linear path)
<code>gm * white_noise(pwr)</code> (op-dependent factor)	extra internal unknown and NO noise output
<code>ddt(cc * white_noise(pwr))</code> (induced-gate idiom)	extra internal unknown and NO noise output
one wave into two branches (correlation network)	extra internal unknown and NO noise output

The onoise spectrum in all three broken cases equaled exactly the surrounding resistors' floor — the device contribution had vanished.

The two correctness defects

1. **build_implicit_equation** never called **add_noise** (`sim_back/src/dae/builder.rs`). Noise attached to an implicit-equation contribution (the `Evaluation::Equation` path: `NoiseSrc` unknowns and `ddt` correlation networks) was dropped before reaching the DAE's `noise_sources` — no OSDI descriptor entry, nothing for the simulator to evaluate. Every other `add_contribution` site pairs with `add_noise`.
2. The late-created `react_optbarrier` was unregistered. When `build_analog_operators` moves a `ddt()` into a contribution's reactive dimension, `update_optbarrier` creates (or rewrites) the `react` barrier — but it was never inserted into `topology.contributes`, so `prune_small_signal`'s `as_contribution` lookup could not find it: the noise wave's replayed coupling twin was built and then dropped, leaving a hole in the Jacobian (zero transferred noise). The refreshed `psp103_topology.snap` shows the impact on a flagship model: its `react_small_signal` couplings went from `F_ZERO` to real values.

With just these two fixes the Equation path produces exact PSDs (verified against closed-form analytics for all shapes above).

The optimization: factors instead of extra unknowns

3. Op-dependent factors stay Linear — `determine_evaluation` barred `fmul/fdiv` with op-dependent operands from the Linear path. For a `ddt` chain that check is correct ($g(v) \cdot ddt(q) \neq ddt(g(v) \cdot q)$), but for a NOISE wave the right question is *wave-derivation*: only a product of two wave-derived values is nonlinear in the wave; an op-dependent factor is replayed into a per-instance value evaluated at the operating point. The check now discriminates by `val_visisted` for noise (`gm * white_noise` → factor `gm`, no extra unknown) and keeps op-dependence for `ddt`.
4. One **ddt()** in a noise chain becomes a $j\omega$ factor (the old TODO's "complex noise power"). The factor generalizes to $re + j\omega \cdot im$:
 - `determine_evaluation` admits `TimeDerivative` calls in noise chains (not for `ac_stim` — its injection is a complex RHS pair, not a power), with a pre-scan rejecting nested `ddt((j\omega)^2`

- needs an ω^2 real part) and post-ddt values feeding phis (replay complexity bound) — those fall back to the (now-correct) Equation path;
 - `create_dimension` runs a parallel react replay (`val_map_react`): `ddt(x)` moves the argument's replayed flat component into the react component; `fadd/fsub/fneg/fmul/fdiv/optbarrier` propagate both;
 - `Noise/NoiseSource` carry `factor_react` through the dae builder (`mfactor` scaling — both components scale identically since they multiply the same wave — and switch-branch `phi` joins);
 - OSDI 0.7 (ABI change): `load_noise(inst, model, freq, dst)` fills `[flat, react]` signed power pairs per source (stride 2): `dst[2i] = fac·|fac|·pwr(f)`, `dst[2i+1] = fac_react·|fac_react|·pwr(f)` — the same E-42 sign-carrying fold, and the frequency shaping (`flicker pwr/f^exp`, tables) applies to both;
 - ngspice **osdinoise.c** groups same-named sources as complex amplitudes $(a + j\omega \cdot b) \cdot T_j$ (T = per-source complex transfer): exact for a single source (the two components are in quadrature: $(a^2 + \omega^2 b^2) |T|^2$) and for coherent groups, including anti-phase cancellation; the RFSPICE SP path uses $|a|^2 + \omega^2 |b|^2$;
 - registry gate raised to ≥ 0.7 .
5. Operator-ordering hazard fixed — `analog_operator_evaluations` visited callbacks in registration order, and `determine_evaluation` mutates the function for Linear results (the dimension replay runs inside it). A shared-`FuncRef` `ddt` evaluated *between* two noise operators detached the second wave's path to its contribution mid-flight, misclassifying it as Dead (source silently lost — caught by the anti-phase cancellation test). All noise operators are now processed before any `ddt` operator: noise replays only zero the waves, which is exactly what the subsequent `ddt` pass should see.

What now works (**noisejw_examples/**, 18 checks, all exact)

See the README: plain control; `gm*white_noise` and `ddt(cc*white_noise)` node-free (were one extra unknown each) with exact flat/ ω^2 -shaped PSDs; `ddt(k*flicker_noise)` composing $\omega^2 \cdot kf/f^{\text{ef}}$; coherent same-named flat+`ddt` mixing ($x^2 + \omega^2 \tau^2$); exact anti-phase cancellation; the formerly-lost two-branch correlation network (coherent cross-branch sum incl. all resistor floors); and `m=4` `mfactor` scaling of the $j\omega$ case.

`verify_noisejw.py`: 18/18 PASS. Regression: all 50 example verify suites ALL PASS; crate tests pass (sim_back topology/dae snapshots refreshed — `factor_react` field + the noise-first ordering + psp103's restored react couplings).

Notes

- OSDI ABI 0.6 $\rightarrow$ 0.7: `load_noise`'s `dst` stride changed; ngspice rejects older `.osdi` files — recompile (committed `.osdi` artifacts must be regenerated at fold time, per the E-45 rule).
- Real models work around the old limitations with manual noise networks (e.g. HiSIM2's internal node `n` with `I(n) <+ V(n) + white_noise(...)` coupled via `ci·V(n)` and `ddt(V(n)·sigrat)`); those still compile unchanged — but the direct idiom (`ddt(sigrat·white_noise(...))`) is now both correct and free.
- `ac_stim` through `ddt` stays on the Equation path (its injection is a complex RHS pair, not a power); nested `ddt(ddt(noise))` and op-dependent conditionals around post-ddt values also fall back — correct, just not node-free.
- The env-gated debug dumps added during this work were kept: `OPENVAF_DAE_DEBUG=1` (openvaf: unknowns/residuals/jacobian/noise of each compiled module) and `OSDI_NOISE_DEBUG=1` (ngspice: per-source loaded powers and complex transfers per frequency).

Enhancement-55 — simulation-control tasks + **\$discontinuity** rejection

This document describes the changes made to OpenVAF-r and ngspice-46 in the `version11/` directory for the remaining simulator-behavior audit items: the simulation-control system tasks (`$finish`, `$stop`, `$fatal`), the `$discontinuity` eval-return-flag path, and two documented decisions (`Opcode::Exit`, `is_voltage_src`).

What the probe found

task	before E-55
<code>\$finish</code> in tran	ignored entirely (ran to tstop; the FINISH return flag was never checked in the load path)
<code>\$stop</code> in tran	timestep collapse: <code>E_PAUSE</code> returned mid-Newton-iteration was treated as a step failure → rejection loop
<code>\$fatal</code> under an op-dependent condition	silently deleted at compile time (never fired at all)
<code>\$fatal</code> 's <code>E_PANIC</code>	swallowed by the transient's nonconvergence retry (step ground down)
<code>\$discontinuity(n>=0)</code>	E-24's sentinel clamps the NEXT step only; the event step itself extrapolates across the jump

The fixes

1. Deferred **\$finish/\$stop** (ngspice) Acting mid-Newton-iteration is what broke `$stop` — the correct point is the accepted-point boundary. `OsdiExtraInstData` gains `point_eval_flags`: the eval-return flags OR-ed over all Newton iterations of the current timepoint attempt (an event may fire on an intermediate iteration only; `eval_flags` holds just the last eval's). Reset on `MODEINITJCT|MODEINITPRED|MODEINITTRAN` — a rejected attempt's requests are discarded with it. A new `OSDIpendingRequests(ckt)` (declared in `osdiitf.h`, codes `OSDI_REQ_FINISH/STOP`) reports them; the mid-NR return `E_PAUSE` on STOP is removed.

- `dctran.c`: once a point is accepted and output, FINISH → Note, fire `@(final_step)` (LRM: `$finish` completes the analysis — E-53 synergy), end the plot, return OK; STOP → Note, `E_PAUSE` (resumable).
- `dctrcurv.c`: same per accepted sweep point (FINISH exits through the normal restore/endplot path via an `osdi_finish` label).

2. **\$fatal** fixes (a) Compile-time silent deletion. `$fatal`'s lowering emits a Fatal print + `SetRetFlag(Abort)` + `exit`. Neither call takes an op-dependent argument, so the init/eval split classified them op-independent and hoisted them to instance-init — where the op-dependent branch is rewritten to its else edge, leaving them in an unreachable block: deleted from both functions. The taint propagation *should* have control-tainted the branch arm, but the shared post-dominator tree roots at the exit sink (`ipdom(branch) = the exit arm itself`), so `taint_block(arm, end=arm)` inserted nothing — and `compute_postdom_frontiers` walks up to the same bogus `ipdom`, so the frontier row was empty too. Rather than re-rooting the shared `pdom` machinery (consumed by ADCE, the topology pass, ...), the fix in `context.rs::refresh_op_dependent_insts` computes the needed control dependence directly: for every op-dependent branch, blocks reachable from exactly one of its two arms are controlled by it (exact for the structured CFGs the lowering emits — and always exact for early-exit arms, which never reconverge). Side-effecting callbacks (`SetRetFlag`, prints) in op-controlled blocks are marked op-dependent and stay in eval. Parameter-only `$fatal` still hoists to init and validates at setup (instance rejected), as designed.

(b) **E_PANIC** swallowed. `NIiter` propagates the load's `E_PANIC`, but `dctran`'s `if (converged != 0)` treated it as nonconvergence and retried with a smaller step. An explicit check now aborts the transient

with a clear error. (dctrcurv/dcop already propagate errors out.)

3. **\$discontinuity(n>=0)** step rejection The lowering additionally raises a new return flag (RetFlag::Discont → stdlib set_ret_flag_discont → EVAL_RET_FLAG_DISCONT = 16, additive — not an OSDI ABI break; both osdi_0_4.h and ngspice's osdi.h define it). OSDItrunc checks the converged attempt's point_eval_flags, edge-triggered and once per onset: only when the flag is NEW versus the last *accepted* point (prev_point_eval_flags, latched in OSDIaccept) and the per-point retry latch is clear (and CKTdelta > 20*CKTdelmin) does it request CKTdelta/8 — the integrator rejects the too-large event step and retries. The edge/one-shot condition matters: a model announcing a discontinuity over a whole REGION (every eval while a condition holds — the E-24 example does exactly this) must not have every step of the region rejected down to the delta floor (the first cut of this fix, without the latch, made the E-24 regression suite crawl indefinitely). The E-24 sentinel (clamp the *next* step) is kept unchanged.

4. Documented decisions

- **Opcode::Exit => todo!()** in mir_llvm/builder.rs was dead code, not a missing feature: InstructionData::Exit is intercepted by build_inst's instruction-data match (which emits the function's ret) before the value-producing opcode dispatch can see it. Replaced with unreachable! and a comment.
- **is_voltage_src** OSDI exposure (the dae-builder TODO for switch branches): the static metadata is already correct (Switch residuals emit NATREF_NONE), ngspice derives nothing from residual natures at runtime, and no OSDI consumer exists for a per-iteration switch-state export. Deferred until a consumer exists — an eval-output + descriptor array would be an ABI change with zero users today.

What now works (**simctrl_examples/**, 17 checks)

See the README: \$finish ends the transient exactly at the requesting point with @(final_step) firing there; \$stop pauses cleanly; \$fatal prints and aborts (tran) or rejects the instance at setup (parameter validation); a DC-sweep \$finish ends the sweep at the requesting value; and the \$discontinuity A/B twins show the event step $\geq 4\times$ smaller with a sharper, no-later jump.

verify_simctrl.py: 17/17 PASS. Regression: all 51 example verify suites ALL PASS; 28/28 crate tests.

Notes

- Requests latch per instance; any OSDI instance requesting FINISH/STOP is honored (multiple instances OR together).
- \$finish in a lone .op has nothing to cut short (the analysis is one point); it completes normally. \$stop there is likewise a no-op.
- With autostop semantics unchanged; \$finish takes the same clean exit path as reaching the stop time.
- The env-gated OPENVAF_TAINT_DEBUG=1 dump (op-dependence statistics at the init/eval split) was kept from the investigation.

Enhancement-56 — VA_TEST end-to-end sweep: CMC default-range idiom + noise crash

This document describes the changes made to OpenVAF-r and ngspice-46 in the version11/ directory as the outcome of the first end-to-end sweep of the VA_TEST corpus: all 92 standalone industry models compiled and run through ngspice op/AC/tran/noise with a generated bias bench, checking for crashes, aborted analyses, and NaNs (the corpus had previously only been compile-tested).

Sweep-harness lesson

ngspice control scripts continue past aborted analyses, so echo markers after an analysis prove nothing — the first sweep's "92/92 clean" was a false positive. Failure detection must be data-based ("No. of Data Rows" per completed analysis, "simulation(s) aborted", return codes).

The fixes

1. Parameter DEFAULTS exempt from range validation (compiler) CMC-standard models declare a default outside the parameter's own range as the "feature disabled" state and expect the range to bind only user-given values:

```
parameter real CORECOVERY = 0.0 from (0.0:1.0];    // diode_cmc
parameter real Fb          = 0.0 from (0.0:inf);    // FBH-HBT
```

insert_param_init (hir_lower/src/parameters.rs) lowered the default and then range-checked it exactly like a given value, so the stock CMC models (diode_cmc, bsimcmg-110, fbh_hbt, psphv fragments, hisim family, ...) were rejected at setup with "Parameter ... is out of bounds". The not-given branch no longer checks; the given branch still validates both from ranges and exclude constraints (verified: the excluded bound, an exclude-list value, and a beyond-range value are all still rejected when given).

2. Setup rejection diagnostics (ngspice) A \$fatal/\$finish raised during setup is a model rejecting its parameters/configuration (HiSIM validates \$port_connected combinations against COSUBNODE/COBCNODE and calls \$finish(0) by design). ngspice surfaced that as E_PANIC's baffling "impossible error - can't occur". osdisetup.c::handle_init_info now reports "*"a Verilog-A device rejected its configuration during setup (*finishraised*)"—rightnexttothemodel' sown`write` message, which was always printed.

3. Noise-analysis singular-matrix crash (ngspice) noisean.c ignored NIacIter's return value in the frequency loop: on a singular AC matrix the factorization fails, and the noise adjoint solve (SMPcaSolveTransposed → spSolveTransposed) then hit Assertion failed: IS_FACTORED(Matrix) — a hard SIGABRT (reproduced with hisimsoi rejecting an all-terminals bench). The return is now checked: "AC solution failed at ... Hz; aborting the noise analysis." The noise analysis additionally honors E-55's deferred \$finish/\$stop raised during its internal operating point (a model that "wanted out" no longer keeps evaluating in a degenerate state).

Sweep verdicts (everything else triaged, not defects)

model	symptom	verdict
hisimhv ×2, hisimsoi- 140	setup rejected	model's own \$finish config guard: 6 nodes connected needs COSUBNODE/COBCNODE=1 — clean diagnostics now
hisimsoi ×3	noise SIGABRT	crash fixed (above); the underlying singularity is the same config guard

model	symptom	verdict
vbic_4T_et_cf	singular cx/si in AC	the model contributes nothing to those nodes at $RCX=0/RS=0$ (defaults) by design; commercial simulators' node-gmin covers it — use <code>.option rshunt=1e12</code>
EPFL_HEM	Top noncon- vergence	bench sensitivity: converges fine at a realistic bias ($V_d=0.5$, $V_g=0.3$: $I_d=127$ mA, all analyses pass)
FBH_HBT	tran "timestep too small"	the model divides by its own disabled-default ($\text{ddt}(V(nii)/(2\pi \cdot F_b))$ with $F_b=0 \rightarrow$ infinite capacitance); give $f_b>0$ — reachable at all only thanks to fix 1

Final sweep result: 83/92 module-runs fully green (op+AC+tran; the setup-rejected CMC models — diode_cmc, bsimcmg-110, psphv, fbh_hbt's op/AC — are all cured); the 9 remaining are exactly the by-design/bench cases tabulated above. All 88 noise runs are crash-free (the three previous SIGABRTs now abort cleanly with diagnostics).

What now works (**paramrange_examples/**, 13 checks)

See the README: out-of-range defaults accepted with exact solutions, given values still validated (three rejection forms), the hisimsoi noise-crash reproducer aborts cleanly, and the stock CMC diode_cmc runs op/AC/noise at defaults with a positive noise spectrum.

verify_paramrange.py: 13/13 PASS. Regression: all 52 example verify suites ALL PASS; 28/28 crate tests.

Notes

- The default-exemption matches industry practice (and the LRM's intent that constraints describe *valid user input*); a model wanting a hard default-check can still assert in its analog block.
- The sweep harness (e56_sweep.py, e56_noise_sweep.py) generates the bench from the OSDI descriptor (terminal count/names via a dlopen dumper); models with thermal terminals get non-sense biases by construction — physics-corrected re-runs were used for the triage verdicts above.

Enhancement-57 — physics-accuracy validation suite

This enhancement adds a permanent, quantitative physics regression suite (`physcheck_examples/`) checking that industry compact models compiled by OpenVAF-r reproduce analytic device laws in ngspice. Unlike E-56's smoke sweep (does it run?), this validates *the numbers*. No toolchain defects were found — the enhancement is the validation deliverable itself, guarding lowering, autodiff, AC, and noise against future regressions.

What is verified (all against closed-form physics)

model	law	result
r2_cmc	thermal noise $\equiv$ built-in ngspice resistor ($4kT/R$)	identical to $< 10^{-6}$
diode_cmc	junction law, 60 mV/decade in the ideal region	$n = 1.004\text{--}1.009$
MEXTRAM bjt505	Gummel slope + β	$n = 1.012\text{--}1.017$, β 73–159
PSP103	AC gm/gds $\equiv$ numeric d/dV of DC (autodiff Jacobian vs residual)	$3\text{--}6 \times 10^{-5}$ relative (finite-difference floor)
JUNCAP200C(V)	grading law self-consistency	1.2×10^{-4}

Notes from the probe

- diode_cmc below ~ 0.9 V is dominated by its recombination/TAT components at default lifetimes (apparent ideality 4–7) — that is the model's physics, not an artifact; the ideal region emerges at 0.96–1.0 V. A naive "check $n \approx 1$ at 0.3 V" would be wrong.
- The gds check in deep saturation is limited by finite-difference noise on a 35 nS conductance (12-digit prints); the triode-region check pins it tightly instead, and the saturation bound is set accordingly.
- The r2_cmc noise identity is constants-free: the same circuit is run with the Verilog-A resistor and ngspice's built-in resistor, and the spectra must be equal — whatever $k \cdot T$ ngspice uses.

`verify_physcheck.py`: 13/13 PASS. `plot_physcheck.py` renders the five laws as PNG plots (`physcheck_examples/plots/`): the diode I–V with its local-ideality panel, the Gummel plot, the PSP g_m AC-vs-numeric overlay, the JUNCAP C(V) fit, and the coinciding thermal-noise spectra. Regression: all 53 example verify suites ALL PASS (no compiler/ngspice source changes in this enhancement).

Enhancement-58 — **defparam** hierarchical parameter override

This document describes the changes made to OpenVAF-r in the `version11/` directory to implement **defparam** (legacy Verilog-2001 compile-time parameter override, LRM 2.6). Front-end only — no OSDI/ngspice change.

What the probe found

defparam did not parse at all. It was listed as a reserved word (`syntax::name`), but had no keyword token and no grammar rule, so `defparam u1.r = 2e3`; tokenised **defparam** as an ordinary identifier and tripped the net-declaration path — surfacing after elaboration as the misleading '**defparam**' was not found in the current scope. The idiomatic instance overrides `#(.r(2e3))` and `#(2e3)` already worked; **defparam** is the deprecated hierarchical form.

The implementation

A **defparam** is a compile-time hierarchical override, so it is handled entirely in the E-5 elaboration pass (the same source-to-source stage that flattens instances) and never reaches the semantic compiler stages.

1. Token (**tokens**) **DEFPARAM_KW** added to the `SyntaxKind` enum, `from_keyword`, `is_keyword`, the `Display` table, and the `T![defparam]` macro; plus a **DEFPARAM** node kind. (**defparam** was already reserved, so making it a keyword breaks no valid model.)
2. Parser (**parser**) A **DEFPARAM_KW** arm in `module_items` dispatches to `defparam_decl`, which parses `defparam <path> = <expr> [, <path> = <expr>]* ;` into a **DEFPARAM** node, reusing the existing `path()` and `expr()` grammar. **DEFPARAM** is deliberately not a member of the typed `ast::ModuleItem` enum — so `module_items()` (the typed iterator every later stage walks) simply skips it, and no `hir_def` / `hir_ty` / lowering change is needed. The node exists only for the elaboration pass to read.
3. Elaboration (**hir/elaborate.rs**)
 - **collect_defparams** runs at the start of `render_items` for every module (top and inlined instances), scanning that module's **DEFPARAM** syntax children. Each target path is resolved to its final flattened name through the very same instance-chain rewrite E-49 uses for hierarchical references (`find_instance_path_holes`): `u1.r` → `u1__r`, `u1.u2.r` → `u1__u2__r`, a single-segment same-module target to itself. The map is keyed by that flattened name (`u1__u2__r` → "4e3"), which is exactly the name the target parameter receives when its instance is inlined, so depth doesn't matter. The value expression is rename-applied (it may reference the enclosing module's own parameters).
 - The **ParamDecl** arm of `render_items`, for each parameter, computes its flattened name and — if a **defparam** targets it — rewrites its default via the existing `render_with_holes` hole mechanism. **defparam** is checked before the instance `#(...)` binding, giving it the higher precedence LRM 2.6 requires.
 - Any **defparam** whose target never matched a rendered parameter is a hard error (**defparam target(s)** did not resolve to any parameter: `u1.typo`), reported with the original source path.

What now works (**defparam_examples/**, 4 checks, all exact)

case	result
<code>defparam u1.r = 2e3</code> (1k default)	2 kΩ → I = 0.5 mA

case	result
deep defparam u1.u2.r = 4e3 + multi-assign defparam up.r=2e3, up.g=1e-3 overriding #(.r(5e3)) defparam u1.r = 2.0*scale (scale = 3k) defparam u1.typo = 5e3	2k (not 5k) + g + 4k → I = 1.75 mA 6 kΩ → I = 1/6 mA compile error naming u1.typo

verify_defparam.py: 4/4 PASS. Regression: all 54 example verify suites ALL PASS; crate tests (parser, syntax, hir, hir_lower, sim_back, osdi) all pass; the VA_TEST corpus still compiles.

Notes

- Machine-portability fallout (found by the pre-fold path check): the elaboration pass named its synthetic virtual file after the VFS's canonicalized ABSOLUTE root path, and that name is embedded in the compiled .osdi as source provenance — any model using instantiation (which defparam requires) leaked the build machine's layout into the artifact. The synthetic name is now /<base-name>__elaborated.va (the VFS requires a leading /). Relatedly, the macOS linker embeds the -o output path AS GIVEN into the dylib, so every verify script now passes a relative -o (they already run with cwd at the example dir).
- Scope: defparam targeting a same-module parameter in a module that contains *no* instantiation is not rewritten (the elaboration pass only runs when the file has instantiations); the parameter's declared default applies there. The hierarchical instance-override use case — the actual reason defparam exists — always involves instantiation and is fully supported.
- Precedence: defparam > instance #(. . .) > declared default, as the LRM specifies. A model-card (SPICE .model) parameter value still overrides all of these at simulation time, unchanged.
- This reuses the E-49 hierarchical-path resolver and the E-21/#() parameter-hole mechanism wholesale; the only genuinely new machinery is the token, the one parser rule, and the collection/application glue — "scaffolded-but-unwired at the node-kind boundary" turned into a small, self-contained enhancement.

Enhancement-59 — LRM-corner probe follow-up: event OR lists, **\$realtime**, port concatenation, recursion diagnostics

This document describes the changes made to OpenVAF-r in the `version11/` directory following a fresh LRM-corner probe battery (16 never-exercised Annex-C constructs). Front-end only — no OSDI/ngspice change.

The probe battery

16 small models covering LRM corners no previous enhancement had exercised. 12 were validated as already correct (several at runtime, exact): away-from-zero real→integer rounding, `$vt(300)`, alias-param + `$param_given` through the alias, string-parameter case + `.model` string override, `above()` in DC, integer min/max/abs, integer function output args, grounded (single-node) branch declarations, parameter-dependent `laplace_nd` coefficients, `$mfactor` reads, `branch.potential.abstol`, and `ddx` w.r.t. a flow probe.

4 gaps were found and fixed:

gap	before
event OR lists <code>@(a or b)</code> (LRM 5.10.3)	parse error at or
<code>\$realtime</code> (LRM 9.7.2)	unknown system function
port-connection net concat <code>u1({a,c})</code> (LRM 6.5)	whole <code>{a,c}</code> text bound to every bit → "expected value but found net reference"
analog-function recursion	direct: misleading "expected a function but found variable"; mutual (f1 → f2 → f1): compiler stack overflow

1. Event OR lists

`@(cross(...) or cross(...)),@(initial_step or timer(t))` — any mix of members in one list.

- tokens: new `OR_KW` keyword (or was already reserved).
- parser (`grammar/stmts.rs`): `event_stmt` loops over or-separated units; each unit is either an `initial_step/final_step` (with optional phase strings) or an event expression.
- `hir_def`: new `Event::Or(Box<[Event]>)` variant; `collect_event_stmt` segments the syntax children on `OR_KW` tokens and builds one `Event` per unit (a malformed unit degrades the whole event to an unconditional body, as before). The child-expr walker recurses through `Or` via a `&mut dyn FnMut` inner `fn` (a generic closure would monomorphize infinitely).
- `hir_lower(stmt.rs)`: `lower_event_fired` lowers each member to its "fired" boolean and folds them with the file's `bool_or` helper (make_select-based). A raw `ior` instruction is wrong here: the members are `i1` values that can const-fold, and MIR const-eval has no `Bool` arm for `ior` — it ICEs (`invalid operation ior Bool(true) Bool(true)`).

Runtime check: with a crossing pair OR'd, the counter equals the sum of the two single-event counters exactly, and `@(initial_step or timer(0.55u))` fires exactly twice in a 1 μ s transient.

2. **\$realtime**

In the analog context `$realtime` is the simulation time in seconds — identical to `$abstime` (the timescale-scaled digital flavor is meaningless in a continuous-time solver). New builtin lowered to the same `ParamKind::Abstime`. Verified `$realtime - $abstime  $\equiv$  0` through a transient. (Gotcha re-confirmed: `hir_ty/src/builtin/generated.rs` holds a `BUILTIN_INFO` array whose length is hardcoded — appending a builtin without bumping `112usize` → `113usize` is an index-out-of-bounds ICE. Signature tables remain the recurring defect source.)

3. Net concatenation in port connections

`pcleaf u1({a, c}); onto inout [1:0] p` — handled entirely in the E-5 elaboration pass. `PortConn::net()` already returned an `ast::Expr`, and E-34 made `{...}` a real `ConcatExpr`, so the pieces existed; new `bind_port_actual` dispatches a `concat actual` to `bind_port_concat`:

- each element contributes one bit (scalar net, bit-select, ...) or — when it names a same-scope bus used whole — all of that bus's bits in *its* declared `msb→lsb` order;
- the flattened bit list maps onto the port in the port's declared `msb→lsb` order (leftmost element = port `msb`), so `[1:0]` and `[0:1]` declaration styles both connect as written;
- a bit-count/width mismatch (or a multi-element concat on a scalar port) is a hard error, collected in a new `port_conn_errors` sink (rendering has no error channel) and bailed after rendering, like `implicit_conflicts`.

Works positionally and named (`.p({b[1], b[0]})`), nested through instance levels. Runtime check: two concat-connected 1 kΩ paths in parallel + 1 kΩ series → exactly 2 V / 1.5 kΩ = 1.3333 mA.

4. Recursion diagnostics

The LRM forbids analog-function recursion; the compiler now says so.

- Direct (`fact` calling `fact`): inside a function its own name resolves to the return variable, so the call landed in the “expected a function but found variable ‘fact’” fallback. `inference_fun_call` now recognises `owner == called name` and emits a dedicated `RecursiveFunctionCall` diagnostic: *“analog function ‘fact’ cannot call itself: recursion is not allowed”* with an LRM 4.7 help note.
- Mutual (`f1→f2→f1`): this crashed the compiler (stack overflow in the recursive inliner) — found by a sanity check while testing the direct case. Fix: a call-graph cycle check in `BodyValidationDiagnostic::collect` for function bodies — DFS from each user-function call through the callees’ own (independently inferred, so salsa-cycle-free) `resolved_calls`; a path back to the owner reports the full chain: `info: call cycle: f1 -> f2 -> f1`. Legitimate diamond call chains (`f→g→h, f→h`) are unaffected.

Examples (`lrmcorner_examples/`, 9 checks, ALL PASS)

`verify_lrmcorner.py`: [1] OR-list counter $\equiv$ sum of single-event counters + `initial_step` or `timer` fires twice; [2] `$realtime` tracks `$abstime` exactly; [3] port-concat op current exact (both concat forms); [4] direct and mutual recursion are clean errors (the mutual one names the cycle); [5] concat width mismatch rejected; [6] `lrmpin_demo.va` — self-checking bitmask module (E-37 technique) pinning 8 runtime-checkable validated corners, score 255/255; [7] compile-only pins (`gnd` branch, `ddx-flow`, above-DC, `laplace-param`, integer fn outputs).

Note: the corner-pin’s `$vt(300)` check uses a 1e-7 tolerance — the compiler’s internal `$vt` uses newer CODATA constants than the LRM-1998 values in the shipped `constants.vams` (difference $\approx 3e-8$). Not a defect.

Regression

All version11 example verify suites pass; crate tests (`tokens`, `parser`, `syntax`, `hir_def`, `hir`, `hir_ty`, `hir_lower`, `sim_back`, `osdi`) pass.

Enhancement-60 — multiple analog blocks: validation deliverable

This document records the Enhancement-60 probe of multiple **analog** / **analog initial** blocks per module (Verilog-AMS LRM 6.2: several blocks “shall behave as if they combine into a single analog block in the order they appear”). No defects were found — the feature is fully supported by construction — so, like Enhancement-57, the deliverable is the validation itself: a probe battery, a pinned example suite, and this write-up. No compiler or ngspice source changes.

Why it works by construction

`hir_def/src/body.rs` collects a module’s behavioural body as

```
body.entry_stmts = if initial {  
    ast.analog_initial_behaviour().map(|stmt| ctx.collect_stmt(stmt)).collect()  
} else {  
    ast.analog_behaviour().map(|stmt| ctx.collect_stmt(stmt)).collect()  
};
```

— an iterator over every analog (respectively analog initial) block of the module, collected into `entry_stmts` in document order. That is literally the LRM’s as-if-concatenated semantics; every downstream stage (type inference, lowering, autodiff, the DAE builder, OSDI) already consumes `entry_stmts` as a list and sees one concatenated body. There is no single-block assumption anywhere to fix.

The probe battery (9 corners, zero defects)

corner	result
contributions to one branch from several blocks	accumulate exactly (1+2 mS → 3 mS)
module variable written in block 1, read in block 3	shared, in order
execution order (<code>\$strobe</code> in consecutive blocks)	source order preserved
<code>analog</code> function declared between two blocks	callable from later blocks
module declarations (parameter/branch/var) after a block that uses them	resolve (module-scope, order-free)
events split across blocks (<code>cross</code> in one, <code>final_step</code> in another; <code>initial_step</code> counters)	all fire, once each
<code>ddt()</code> of a charge computed in an earlier block	correct reactive residual
multi-block module instantiated (E-5 elaboration re-render)	both blocks survive flattening — series current exact to 12 digits
two analog initial blocks	compose in order (<code>g = 1m; g = g + 1m → exactly 2 mS</code>)

Two behaviors verified as *correctly rejected* / *consistent* rather than gaps:

- duplicate named child blocks (`begin : work` in two analog blocks): clean 'work' was already declared in this scope error — named blocks live in the module namespace, so hierarchical references (`inst.work.t`) must stay unambiguous;
- `V(a,c) <+ in one block` and `I(a,c) <+ in another` compiles — identical to the single-block switch-branch behavior (LRM value-retention rules), i.e. multi-block introduces no inconsistency.

Examples (**multianalog_examples/**, 6 checks, ALL PASS)

`verify_multianalog.py`: [1] three-block accumulation to exactly 3 mS + cross event in the middle block fires; [2] strobos print in source order + ordered analog initial composition (2 mS exact); [3]

a multi-block module survives instance flattening (series current exact to 12 digits); [4] the duplicate-named-block diagnostic.

Notes

- Verilog-A 1.0 originally allowed only one analog block per module; Verilog-AMS 2.2+ relaxed this, and openvaf-r follows the relaxed (current LRM) rule. Accepting the multi-block form is a superset of Annex C either way — no legal single-block model changes meaning.
- Regression: no compiler/ngspice source changes in this enhancement; the Enhancement-59 full regression (55 suites, crate tests, 92/92 corpus) stands, plus the new suite's 6 checks.

Enhancement-61 — operator-argument audit: **slew** sign-convention fix

This document describes the changes made to OpenVAF-r in the version11/ directory following a full-argument-form audit of the analog operators (LRM 4.5) and events (LRM 5.10). Front-end only — no OSDI/ngspice change.

The audit

22 probe forms covering every optional-argument spelling: cross 3/4-arg (time_tol, expr_tol), above 2/3-arg, timer 2/3-arg (period + tolerance), absdelay 3-arg (maxdelay), transition 5-arg (trailing tolerance), slew 2/3-arg, ddt 2-arg (abstol), idt 4-arg, idtmod 5-arg, last_crossing 1/2-arg, laplace_*/zi_* trailing tolerance + full zi arg lists (T, τ , t0), \$bound_step, \$limit (built-in "pnjlim" string, user functions, user functions with extra arguments), and ac_stim with magnitude and phase.

One real defect found (and fixed); everything else verified working at runtime, not just parsing:

verified working	evidence
timer(start, period[, tol])	fires exactly 5× at 0.1/0.3/0.5/0.7/0.9 μ s
\$bound_step(5n)	eval count 120 $\rightarrow$ 416 over a 1 μ s transient
\$limit "pnjlim" + user fn (+ extra args)	stiff 5 V/1 Ω diode converges directly (raw diode needs gmin stepping); exact op 0.9345 V
ac_stim("ac", 2.0, $\pi/2$)	V = j1000 exactly (magnitude AND phase honored)
ddt(x, abstol)	$-j2\pi fC$ to 10 digits at AC
idt(x, ic, assert, abstol), idtmod(x, ic, mod, off, abstol)	$+j1e-6$ exactly at $\omega = 1000$
toleranced cross/above	fire correctly (tolerances are step-control hints)
transition 4/5-arg	linear ramp, exact midpoint (first runtime pin ever)
absdelay(x, td, maxdelay)	1.5e-5 max error vs the analytic delayed sine
laplace_*/zi_* trailing ϵ	accepted; realization exact (documented no-op)

(Also confirmed: an empty {} vector for "no zeros" is rejected — correct, Verilog-A has no empty array-literal syntax; E-34's EmptyConcat diagnostic stands.)

The defect: **slew** ignored its input

Before: `slew(V(in), 1e6, -1e6)` — the LRM-conformant spelling (4.5.15: *max_pos_slew_rate shall be greater than zero, max_neg_slew_rate shall be less than zero*) — produced an output that ignored the input entirely: it ramped at +1e6 V/s from $t = 0$ (while the input was still 0) and sailed unboundedly past the target (2.0 V at 2 μ s for a 1.0 V input).

Root cause: `lower_slew` fed the bounds to the shared `lower_rate_limited_track` loop ($dy/dt = \text{clamp}(K \cdot (x-y), lo, hi)$) after `fneg(neg_max)` — assuming a *positive magnitude* third argument. An LRM-conformant negative value was double-negated into a positive lower clamp bound (+1e6), so the clamp forced $dy/dt = +1e6$ regardless of the input: a positive-feedback runaway disguised as a ramp. (transition, which converts rise/fall *times* to always-positive rates before calling the same helper, was unaffected — which is why it worked while `slew` didn't.)

Fix (`hir_lower/src/expr.rs`): bound with $|max_pos| / -|max_neg|$ via a new `lower_fabs` helper (`neg/lt/select` — MIR has no `fabs` instruction). Exact for LRM-conformant inputs and tolerant of the legacy positive-magnitude spelling; the single-rate form keeps its LRM "absolute value bounds both directions" behavior.

After: the output holds at the input, ramps at exactly the bound when the input outruns it (asymmetric rates verified: rise 1e6, fall 0.25e6 — both edges exact), and stops at the target.

Examples (**opargs_examples/**, 16 checks, ALL PASS)

`verify_opargs.py`: [1] the fixed `slew` defect (holds before the step, rate-limited rise, stops at the target, asymmetric fall); [2] toleranced events + timer period (5 fires exact); [3] `$limit` `pnjlim` + user fn converge directly to the exact op with no `gmin` fallback; [4] `$bound_step` honored; [5] `ac_stim` magnitude and phase exact; [6] `ddt/idt/idtmod` trailing tolerances numerically exact at AC; [7] transition ramp semantics. Items [1] and [7] are the first runtime verification the `slew/transition/absdelay` operator family has had (the old `slew_examples/transition_examples/absdelay_examples` folders have no verify scripts).

Regression

All version11 example verify suites pass; crate tests (`hir_lower`, `sim_back`, `osdi`, `mir_autodiff`) pass; VA_TEST corpus compiles 92/92.

Enhancement-62 — ngspice analysis coverage for OSDI devices: **.dc @inst[param]** sweeps + **.disto** warning

This document describes the changes made to ngspice-46 in the version11/ directory following an analysis-coverage probe of OSDI (Verilog-A) devices across every ngspice analysis beyond op/dc/ac/tran/noise. ngspice-only — no compiler/OSDI ABI change.

The probe (built-in-twin comparisons, E-57 technique)

analysis	verdict	evidence
.tf	exact	OSDI divider: $TF = 0.75$, $Z_{out} = 750\ \Omega$, $Z_{in} = 2\ k\Omega$ (with a parallel built-in twin)
.pz (linear)	exact	OSDI RC pole $-1e6\ rad/s$, bit-identical to the built-in RC
.pz (nonlinear bias)	parity	"input signal is shorted" — but the <i>built-in diode circuit fails identically</i> : an ngspice pz quirk, not an OSDI gap
.sens (DC)	exact	dV/dR matches the analytic divider derivative ($-1.875e-4 / +6.25e-5$)
.sens (AC)	exact	$dV/dacmag = 0.5 - 0.5j$ at the pole frequency
.dc temp sweep	exact	\$temperature-dependent R: all points match $1/R(T)$, $^{\circ}C \rightarrow K$ included
alter / altermod / instance-line / print @n1[r]	works	via (* type="instance" *) (the OSDI instance-kind convention)
.dc @n1[r] param sweep	GAP 1	fatal error — sweep code hardcodes Vsource/Isource/Resistor/temp
.disto	GAP 2	silent zeros: OSDI diode measured 0.0 where the identical built-in diode measured $1.8e-6$

Gap 1 fixed: generic **.dc @inst[param]** sweeps

dctrcurv.c recognized only voltage sources, current sources, resistors, and temp as sweep variables. A new **PARAM_CODE** sweep type accepts @inst[param]:

- DCTfindInstParam resolves the instance by case-insensitive name walk (the sweep name is a raw token, not an interned IFuid, so the device hash can't be used) and looks the parameter up in the device's own instanceParms table (settable, real-valued);
- DCTsetInstParam sets each sweep value through the generic DEVparam interface and refreshes with DEVtemperature — for OSDI devices exactly the alter path (setup_model + setup_instance re-run);
- integrated into every arm of the sweep machinery: stop criterion, nested-level reset, per-step increment, plot scale (param-sweep), XSPICE event step, and end-of-sweep restore (the saved value is restored; the parameter necessarily stays marked "given");
- the previous value is captured with DEVask before the sweep.

Works for any device type: OSDI instance-kind parameters (**.dc @n1[r] 1k 4k 1k** — $I = 1/R$ exact at every point), built-in devices (**.dc @r1[resistance]**), and nested with other sweep variables (**.dc @n1[r] 1k 2k 1k V1 1 2 1** — inner level resets correctly).

New struct fields TRCVvParmId / TRCVvNow in trcvdefs.h (devices have no generic readback field to consult mid-sweep).

Gap 2 fixed: **.disto** warns instead of silently lying

Distortion analysis needs per-device Taylor coefficients (DEVdisto); the OSDI ABI only exposes first derivatives, so OSDI nonlinearities are invisible to **.disto** — and ngspice skipped such devices without a word. A **.disto** run over an OSDI diode reported exactly 0.0 distortion while the identical built-in diode circuit reported 1.8e-6.

CKTdisto.c (D_SETUP) now prints a prominent warning for every OSDI device type present in the circuit (recognized by the DEVpublic.registry_entry marker that only OSDI device types carry):

```
Warning: Verilog-A (OSDI) device type 'odio' has no distortion model;  
        .disto results will NOT include its nonlinearities.
```

The analysis still runs (results remain valid for circuits whose nonlinear devices are all built-ins and whose OSDI content is linear). Implementing real OSDI distortion would require higher-order derivatives through the OSDI ABI — an order of magnitude beyond this enhancement's scope, now documented instead of silent.

Examples (**analyses_examples/**, 19 checks, ALL PASS)

verify_analyses.py: [1] **.tf** exact; [2] **.pz** exact + OSDI $\equiv$ built-in; [3] **.sens** DC + AC exact; [4] temp sweep exact; [5] new @inst[param] sweeps (OSDI, built-in, nested); [6] alter/altermod/instance-line/readback (including "altermod must not override a given instance value"); [7] new **.disto** warning + analysis completion.

The folder doubles as a tutorial: nine standalone, commented decks (tf.cir, pz.cir, sens_dc.cir, sens_ac.cir, temp_sweep.cir, param_sweep.cir, nested_sweep.cir, alter.cir, disto.cir — each runnable with ngspice -b <deck>.cir and stating its expected numbers), a walk-through README, and plot_analyses.py, which renders the sweep results to plots/: param_sweep.png (the new @n1[r] sweep vs analytic 1/R), nested_sweep.png (the $I = V/r$ curve family), temp_sweep.png (1/R(T) overlay), and ac_lowpass.png (RC Bode plot with the **.pz** pole at -3 dB and the **.sens ac** point at -45° marked).

Regression

All version11 example verify suites pass (ngspice rebuilt); no compiler change, so crate tests and the corpus stand as of Enhancement-61.

Enhancement-63 — RF analyses with OSDI devices: **.sp** / transient noise / PSS + **span.c** NaN fix

This document describes Enhancement-63: round 2 of the analysis-coverage work (Enhancement-62), probing the RF-flavored ngspice analyses — S-parameters, transient noise, and periodic steady state — with OSDI (Verilog-A) devices against built-in twins. One stock-ngspice defect found and fixed (**span.c**); ngspice-only, no compiler/ABI change.

.sp — S-parameter analysis: exact

- A series 100 Ω OSDI resistor between 50 Ω ports gives the textbook $S_{11} = R/(R+2Z_0) = 0.5$ and $S_{21} = 2Z_0/(R+2Z_0) = 0.5$, exactly.
- A frequency-dependent OSDI R + C shunt two-port is bit-identical to the built-in R/C twin across three decades (1 MHz – 100 MHz).
- Arbitrary port count: **span.c** allocates every matrix $\text{CKTportCount} \times \text{CKTportCount}$, so **.sp** is fully N-port — a 3-port direct junction reproduces the textbook $S_{ii} = -1/3$ / $S_{ij} = +2/3$, and 3-/4-port OSDI resistor stars give the analytic 1/3 and 1/4 exactly (bit-identical to built-in twins). Only the **donoise** noise-parameter block (NF/SOpt/Rn — inherently two-port concepts) is restricted to exactly 2 ports.

.sp ... donoise — noise figure: OSDI exact, and a stock NaN fixed

The OSDI noise pipeline (E-42/E-54) reaches S-parameter noise figures: a Verilog-A resistor with explicit **white_noise(4kT/R)** gives $NF = 10 \cdot \log_{10}(1 + R/Z_0) = 4.7712$ dB exactly.

The defect (stock ngspice, exposed by OSDI parity testing): the same topology with a *built-in* resistor returned NaN for NF/SOpt/NFmin. **span.c**'s noise-parameter extraction computes $Y_{\text{sopt.re}} = \sqrt{SQR(Y_{\text{cor.re}}) + G_u/R_n}$, where G_u — the uncorrelated noise conductance — is analytically zero for a fully-correlated single-noise-source topology. Floating-point rounding can land the **sqrt** argument at $-1e-18$: **sqrt(negative)** → NaN. (The OSDI twin's rounding happened to stay ≥ 0 , which is exactly how the parity test caught it.)

Fix: clamp the argument to its physical range (≥ 0). After the fix the built-in single-R case reads 4.7712125 dB — $10 \cdot \log_{10}(3)$ to eight digits — and the multi-source regression case (series 100 + shunt 200) is unchanged at 7.2016 dB.

Transient noise: correct propagation, documented parity

A **TRN0ISE** source driving an OSDI divider propagates correctly (deterministic mean exact, noise σ as expected). Device-*internal* noise (**white_noise/flicker_noise**) does not enter **.tran** — the same is true of every built-in device's noise model; transient noise in ngspice comes only from **TRN0ISE** sources. Parity, not a gap.

PSS — periodic steady state: OSDI devices are full citizens

.pss is experimental and compile-time optional (**--enable-pss**; the suite auto-detects and SKIPs without it, and the README shows the build recipe — a **build-pss/** tree keeps it out of the default build).

- Linear OSDI RC (1k/1n, driven at 1 MHz): shooting converges (16 iterations), predicted fundamental within 0.1 ppm, and the fundamental harmonic equals the analytic $|H| = 1/\sqrt{1+(\omega RC)^2} = 0.1571767$ — matching the built-in twin to 7 digits.
- Nonlinear OSDI diode (mild drive): converges in 2 shooting iterations — the built-in diode twin actually *wanders longer* (its frequency estimate jumped to ~2 MHz before settling).
- Strongly nonlinear rectifiers defeat the shooting method for built-ins and OSDI alike (frequency-estimation wander) — a stock characteristic of the experimental PSS core, not an OSDI limitation.

Examples (**rfanalyses_examples/**, 15 checks, ALL PASS)

`verify_rfanalyses.py`: [1] `.sp` resistive exact; [2] `.sp` RC bit-identical to built-in; [2b] N-port S-matrices (3-port junction textbook values, 3-/4-port OSDI stars exact + bit-identical to built-in); [3] donoise — OSDI NF exact, built-in NF finite and analytic (the fix), 2-resistor regression unchanged; [4] TRNOISE through OSDI (mean exact, σ in band); [5] PSS — linear exact + twin parity

- nonlinear convergence (SKIPs cleanly without `--enable-pss`).

Regression

All version11 example verify suites pass with the rebuilt ngspice; no compiler change (crate tests / corpus stand as of Enhancement-61/62).

Enhancement-64 — Touchstone export: auto-**Rbase**, N-port **wrsnp**, 1-port **.sp**

This document describes Enhancement-64: making S-parameter results exportable to industry-standard Touchstone v1 files from the **.sp** analysis. Follows directly from Enhancement-63's findings. ngspice-only — no compiler/OSDI change.

What was broken

1. **wrs2p** was unusable out of the box. It required a vector named **Rbase** (the reference resistance for the Touchstone option line `# Hz S RI R <Rbase>`) that no code ever created — every call died with `Error: No Rbase vector given` unless the user knew the undocumented `let Rbase = 50` incantation, and a wrong value silently mislabeled the file header. The reference impedance is *already known* from the ports' `z0`.
2. 2 ports only, though the **.sp** analysis itself is fully N-port (Enhancement-63 verified 3-/4-port S-matrices analytically exact).
3. 1-port **.sp** was rejected outright ("we need at least two!") — and the check was hiding a real crash: with it lifted, ngspice died with `malloc: can't allocate -8 bytes`.

The fixes

Auto-Rbase** (**span.c**, **cktspdum.c**, **postcoms.c**)** The **.sp** analysis now publishes **Rbase** as a vector in its plot — one more UID after the Z-matrix block, with the per-point value read straight from port 1's `VSRCportZ0` (the `refPortY0` global is only set on the noise path, so it is not used). `com_write_sparam` reads it robustly (the **sp** plot is complex data; the old code blind-dereferenced `v_realddata[0]`) and a user-defined `let Rbase = ...` still overrides.

N-port writer + **wrsnp (**postcoms.c**, **commands.c**)** New `spar_write_np()` writes Touchstone v1 for any port count directly from the `S_i_j` vectors: `# Hz S RI R <Rbase>` option line; for $N \geq 3$ the matrix is row-major with at most four complex pairs per data line and every matrix row starting on a new line (per the Touchstone 1.x spec); a 1-port is one pair per line. The port count is auto-detected by probing `S_n_n` vectors. The classic 2-port `S11 S21 S12 S22` column order is preserved through the original `spar_write()` path. A new **wrsnp** command is registered; **wrs2p** transparently dispatches to the N-port writer when the plot isn't 2-port.

1-port **.sp (**span.c**, **maths/dense/dense.c**)** The "at least two ports" hard error was over-strict — a 1-port **.sp** is a plain reflection measurement and the matrix machinery is N-general. The real bug it hid: the complex-matrix `cadjoint()` had no 1×1 base case, so its cofactor loop allocated 0×0 and then negative-sized minors (`cdet` had the base case; `cadjoint` didn't). The adjugate of `[a]` is `[1]` (the empty minor's determinant is 1 by convention), which makes `cinverse` of a 1×1 equal $1/a$. With both fixed, a $100\ \Omega$ load on a $50\ \Omega$ port gives $S11 = 1/3$ exactly in a proper **.s1p**.

Examples (**touchstone_examples/**, 11 checks, ALL PASS)

`verify_touchstone.py`: [1] **wrs2p** with no manual **Rbase** (header `R 50`; the file's `S21` pairs equal the plot's `S_2_1` — also pins the 2-port column order); [1b] **wrsnp** on a 2-port produces a byte-identical file to **wrs2p** (same handler — both commands cover every port count); [2] `let Rbase = 75` override honored; [3] 1-port **.s1p**, $S11 = 1/3$ exactly (pins the `cadjoint` crash fix); [4] **.s3p** — 3 frequency blocks $\times$ 9 pairs of exactly $1/3$ with each matrix row on its own line; [5] **.s5p** — 25 pairs of exactly $1/5$ with rows wrapping at 4 pairs per line.

Notes

- Found while testing: **.sp** `lin 2 fstart fstop` produces only one frequency point in stock ngspice (`lin 3/lin 5` behave); worked around in the suite with `lin 3`, not fixed (separate stock

quirk).

- All values written are from OSDI (Verilog-A) resistor networks with analytically known S-matrices — the star topologies from Enhancement-63's N-port verification.

Regression

All version11 example verify suites pass with the rebuilt ngspice; no compiler change.

Enhancement-65 — preprocessor audit: macro-recursion guard

This document describes the changes made to OpenVAF-r in the `version11/` directory following a systematic audit of the Verilog-A compiler directives — the preprocessor predates every enhancement in this series and had never been probed. Front-end only — no OSDI/ngspice change.

The audit (22 probe forms)

Everything probed works, and the 18 compiling probes were verified numerically exact at runtime (each engineered to produce exactly 1 mA — compiling proves nothing about correct expansion):

feature	status
<code>define</code> (simple, 1-arg, multi-arg with nested parens in actuals)	exact
macro using another macro; macro call as another macro's argument	exact
<code>ifdef/else</code> , <code>ifndef</code> , <code>elsif</code> chains, nested conditionals	exact (right branch, dead branch dead)
conditionals inside a module body	exact
<code>undef</code> + redefinition; <code>resetall</code>	exact
backslash-continued (multi-line) definitions; trailing <code>//</code> comments	exact
macro calls spanning lines	exact
nested <code>include</code> chains (file → file → file)	exact
undefined macro use; unbalanced <code>ifdef</code>	clean, located errors
macro redefinition	warning (macro was overwritten)

One defect: recursive macro expansion crashed the compiler — a stack overflow for both the direct form (``define LOOP (`LOOP + 1)`) and the mutual form (``A uses `B uses `A`).

The fix — the fifth "scaffolded-but-unwired" find

The preprocessor's diagnostic enum already had a `MacroRecursion` variant with a rendered message ("macro 'X' was called recursively") — but nothing ever emitted it: `call_macro` carried a literal `// TODO track recursion`, and the report builder in `basedb/diagnostics/preprocessor_error.rs` was a literal `todo!()` that would have panicked had the diagnostic ever been created. (This is the same defect pattern as E-39 derived natures, E-45 nature attributes, and E-46's based-literal sketch: complete machinery on one side of a boundary, never wired on the other.)

Two changes:

1. **`preprocessor/src/processor.rs`**: an `expansion_stack`: `Vec<&str>` on the `Processor`; `call_macro` reports `MacroRecursion` when the called name is already on the stack. Crucially, the name is pushed around the body expansion only, after arguments are built: a nested call of the same macro inside an *argument* — ``define QUAD(x) (`TWICE(`TWICE(x)))` — is finite and legal (argument tokens belong to the caller's expansion), and the first draft of the guard wrongly rejected exactly that. The final scoping catches direct bodies, mutual cycles through any depth, and recursion smuggled through arguments' *expansions*, while leaving argument-level self-nesting alone.
2. **`basedb/src/diagnostics/preprocessor_error.rs`**: the `todo!()` replaced with a real report — primary label at the recursive call site plus a help note.

Both forms now produce clean, source-located errors; the legitimate QUAD nesting compiles and evaluates exactly.

Examples (**preproc_examples/**, 5 checks, ALL PASS)

`verify_preproc.py`: [1] an 8-way self-checking macro tour (one branch per feature, total exactly 8 mS, with a not-taken `ifdef` that would add 100 S if it leaked); [2] a two-deep `include` chain; [3] direct recursion = clean error naming the macro; [4] mutual recursion likewise; [5] the `QUAD(x) = TWICE(TWICE(x))` false-positive regression pin, exact at runtime.

Regression

All version11 example verify suites pass; crate tests (preprocessor, basedb, parser, syntax, hir, hir_lower, sim_back, osdi) pass; the VA_TEST corpus compiles 92/92.

Enhancement-66 — Monte Carlo with OSDI devices: validation deliverable

This document records the Enhancement-66 probe of Monte Carlo (statistical) simulation over OSDI parameters — the remaining workflow gap after parameter sweeps (E-62) and `alter`. No defects were found — ngspice's statistical machinery fully reaches OSDI parameters — so, like Enhancements 57 and 60, the deliverable is the validation itself: a probe battery, a pinned example suite with distribution plots, and this write-up. No compiler or ngspice source changes.

Both standard MC idioms work

1. The **reset** idiom. `.param rr = agauss(1k, 100, 3)` feeding a `.model` card (`r={rr}`) or an instance line (`N1 a 0 mm r={rr}`, requires the `(* type="instance" *)` param kind from E-62): each reset re-throws the dice and re-runs the OSDI model/instance setup. Verified over 200-run ensembles: parameter readback (`@n1[r]`) gives mean $\approx 1\text{ k}\Omega$ and $\sigma \approx 33.3\ \Omega$ ($= \text{avar}/\text{sig}$), all draws within $\pm 5\sigma$, and the output-current spread matches $\sigma_I \approx \sigma_R/R^2$.
2. The **alter** loop. Control-language random vectors (`sgauss(0)` standard normal, `sunif(0)` uniform on $[-1, 1]$ — not $[0, 1]$) with `alter @n1[r] = value` per run: no netlist re-parse, and `setseed N` makes the entire run sequence bit-reproducible (two seeded 200-run passes produce identical statistics to the last digit).

Also verified: `aunif(nom, avar)` bounds respected with a uniform-like spread ($\sigma \approx 2 \cdot \text{avar} / \sqrt{12}$); single-draw seeded reset reproducibility; and a nonlinear MC — an OSDI diode with `is_={agauss(1e-15, 2e-16, 3)}` whose op-point spread matches the analytic sensitivity $\sigma_V \approx v_t \cdot \sigma_{I_s}/I_s$ (1.54 mV measured vs 1.73 mV analytic, $N = 100$).

The documented gotcha

Every textual occurrence of a random-valued `{param}` draws independently: an OSDI device and a built-in resistor written with the same `{rr}` differ run by run (pinned: $\max |\Delta I| = 9.2\text{e-}5 \neq 0$ over 25 runs). Matched/correlated devices therefore need the `alter` idiom, where one control-language value is explicitly assigned to each instance. (This is stock `.param` semantics, not an OSDI behavior — but it is exactly the kind of trap a mismatch analysis falls into, so the suite pins it.)

Examples (`montecarlo_examples/`, 10 checks, ALL PASS)

`verify_mc.py`: [1] reset-idiom MC on a model-card param (mean and σ vs analytic); [2] instance-line param with `@n1[r]` readback ($\pm 5\sigma$ bounds); [3] seeded `alter+sgauss` loop — σ analytic + two passes bit-identical; [4] `aunif` bounds and spread; [5] seeded single-draw reproducibility; [6] the independent-draws gotcha; [7] nonlinear diode MC vs the analytic sensitivity.

`plot_mc.py` renders `plots/mc_distributions.png`: 500-run gaussian and uniform MC histograms sitting on the analytic transformed densities of $I = 1V/R$ (including the $1/i^2$ tilt of the uniform case).

Notes

- `wrdata` is unusable for control-created vectors: it pairs each vector with the *current plot's* scale, which after the last op has length 1 — a 500-long MC vector writes as one row. The plot script parses `print <vec>`'s indexed table instead.
- Regression: no compiler/ngspice source changes in this enhancement; the Enhancement-65 full regression (61 suites, crate tests, 92/92 corpus) stands, plus this suite's 10 checks.

Enhancement-67 — generate audit: genvar-substitution fix, nested loops, **generate if/case**

This document describes the changes made to OpenVAF-r in the `version11/` directory following a systematic audit of the `generate/genvar` machinery (built in Enhancement-5, never audited since). Front-end only — no OSDI/ngspice change.

The audit (13 probe forms)

Already correct: the basic labelled `generate for` ladder, non-trivial bounds (`start  $\neq$  0`, `step 2`, `<=`), per-iteration net declarations, genvar reuse across regions, bit-select indices with genvar arithmetic (`n[i+1]`), and the descending-loop / non-constant-bound rejections.

One defect and three gaps:

finding	before
DEFFECT: genvar in an ordinary expression (<code>#(.r(1e3*(i+1)))</code>)	substituted through the identifier-renaming path, which re-escaped the numeral into a broken escaped identifier: <code>1e3*(\0 +1) $\rightarrow$ "error: '0' was not found"</code> . Bit-selects only worked because they had a dedicated pre-fold.
nested <code>generate for</code> loops	parse error (the block grammar had no <code>for arm</code>)
anonymous <code>begin</code> (no <code>: label</code>)	parse error — the label was mandatory (1364-2005 allows anonymous blocks)
<code>generate if / generate case</code>	mis-parsed into a broken <code>GENERATE_FOR</code> with misleading errors ("generate for: missing loop condition" for an <code>if</code>)

The implementation

Grammar (**parser**), AST (**syntax**), tokens New `GENERATE_IF / GENERATE_CASE / GENERATE_CASE_ARM` node kinds with typed AST nodes and `ModuleItem` variants (full pipeline threading, the E-34 recipe). After `generate`, the parser dispatches on `for/if/case`; the same tail rules are reused for nested constructs inside a `generate` block (which have no `generate/endgenerate` of their own). `begin's : label` is now optional. `generate if` supports `else` and `else if` chains; `generate case` supports multi-value arms and `default`.

The unelaborated-`generate` safety net in `hir_def`'s item-tree lowering covers the new node kinds too (a `generate` construct that survives to `hir_def` is a diagnostic, never a miscompile).

Elaboration (**hir/elaborate.rs**) — recursive per-item rendering `render_generate_for` now recurses through a shared `render_generate_block(block, env, suffix, scope)`:

- **env** holds *every* genvar in scope (outer loops included), so inner bounds may reference outer genvars and all folds see the full picture;
- **suffix** accumulates per-iteration name disambiguators (`_0_2` two loops deep) — each block suffixes its *own* directly-declared names, so nested declarations flatten collision-free;
- the genvar fix: bit-select indices keep their whole-index constant fold (the bus machinery requires literal indices), and every *remaining* bare genvar identifier becomes a literal-value hole — genvars never pass through identifier renaming (whose escaping was the defect) anymore;
- **generate if/case** fold their condition/discriminant with a new `eval_cond_expr` (comparisons, `&&/||/!`, non-zero test) and emit only the chosen branch. Conditions must be elaboration-time constants (integer literals and genvars) — e.g. triangle structures `if (j <= i)`. A condition on a module parameter is a clear, honest error: parameters bind at *simulation* time under OSDI (model cards!), so they fundamentally cannot shape generated structure. The non-constant-bound message explains the same reasoning.

What now works (all verified numerically exact)

nested 2×3 loops (6 mS), genvar param-override expressions ($1k||2k||3k = 11/6$ mS), triangle generate if on genvars (6 mS), if/else (1.5 mS), generate case with a multi-value arm and default (2.75 mS), anonymous blocks with per-iteration nets (1 mS), $i = 2; i \leq 6; i = i + 2$ (3 mS) — plus the original E-5 ladder pinned bit-identical to its hand-written twin.

Examples (**generate_examples/**, 9 checks, ALL PASS)

The folder finally gets a verify script: `verify_generate.py` — [1] the E-5 ladder twin regression; [2] the seven Enhancement-67 feature checks above; [3] the honest parameter-condition error naming the OSDI reason.

Regression

All version11 example verify suites pass; crate tests pass; the VA_TEST corpus compiles 92/92.

Enhancement-68 — enabling openvaf's own integration test suite

This document describes Enhancement-68: bringing the fork's dormant integration test suite — 28 tests over real compact models (BSIM3/4/6, BSIMBULK, BSIMCMG/IMG/SOI, HiSIM family, MEXTRAM, PSP102/103, HICUM, EKV, ASMHMT, diode_cmc, plus the live `$limit/noise` numeric tests) — to life for the first time in this project. Test-infrastructure only: the shipped compiler binary is unchanged (every edit is in test harness code, test-only loaders, or snapshot data).

Why it never ran

1. The upstream vacask test legs need the **external/vacask** git submodule (codeberg.org/arpadbuermen/VACASK) which was never initialized — and the `mini_harness` panicked on the missing directory, taking the whole suite down ("reading test data must succeed: NotFound").
2. The remaining tests are gated behind `RUN_DEV_TESTS=1`.
3. Once those hurdles were cleared, the suite's own OSDI loader was frozen at ABI 0.4 ("invalid version v0.7") — this project's three ABI bumps (0.5: `0sdiNode.nodeset`, E-45; 0.6: the `ac_stim` descriptor tail, E-51; 0.7: the stride-2 signed-pair `load_noise` convention, E-54) had never been ported to the test-side structs.

The fixes (all test-side)

- **tests/load/osdi_0_4.rs**: synced to the authoritative OSDI 0.7 layout (mirroring ngspice's completed `osdi.h`): `0sdiNode.nodeset`, the new `0sdiAcStimSource` struct, and the descriptor tail (`num_ac_stim_src/ac_stim_sources/load_ac_stim`). **tests/load/mod.rs**: version gate 0.4 → 0.7 (the loader matches exactly that layout).
- **tests/mock_sim/mod.rs**: the noise buffer is stride-2 per source since OSDI 0.7 (`[flat, jw-routed]` signed pairs); `read_noise(i)` reads `dense[2i]`. The noise test's expected values were already correct — the test model's factors are all positive, so the flat densities are numerically identical under the new convention.
- **lib/mini_harness**: a missing test-data directory now skips its tests with a note instead of panicking the harness (general robustness; the suite is fully self-contained after the VACASK removal below).
- 13 snapshot files regenerated (`test_data/osdi/*.snap`) and reviewed line by line: every diff is a known feature of this project — `flow(<port>)` DAE unknowns (E-29 port-flow probes), `flow(a,b)` probe-only branches (E-36), implicit-equation nodes, and their Jacobian entries. No parameter metadata or physics changes.

The VACASK legs were removed outright

VACASK is AGPL-3.0, so its device library cannot be vendored here — and rather than carrying half-alive test legs that depend on cloning an external repository, the 34 upstream `vacask/vacask_spice/vacask_spice_sn` harness entries (and their 34 stale snapshots) were removed. The suite is now fully self-contained: the 26 in-tree `integration_tests/` models plus the two live numeric tests. (During development the VACASK legs were run once against a temporary clone — they passed — before removal.)

Bonus: the whole dormant dev-test surface is green

`RUN_DEV_TESTS=1` also un-ignores long-dormant harness tests in other crates — `parser` (41), `syntax` (40), `hir_lower` (30) — all passing, so the project's regression now runs them too.

Running

```
RUN_DEV_TESTS=1 cargo test --release -p openvaf \
    --features openvaf/llvm18 --test integration
```

28 passed; \$limit and noise are live numeric tests against the mock simulator, the rest are descriptor snapshots + operating-point sanity checks per model.

Regression

All example verify suites pass (the integration suite is now part of the local regression runner); crate tests pass with and without RUN_DEV_TESTS; the VA_TEST corpus compiles 92/92. The compiler binary is byte-unchanged by this enhancement.

Enhancement-69 — operating-point variables end-to-end: validation deliverable

This document records the Enhancement-69 audit of operating-point variable (opvar) access — Verilog-A module variables carrying a (`* desc="..." *`) attribute, exposed through the OSDI descriptor and read back from ngspice as `@instance[variable]`. No defects were found — the surface is fully working — so, like Enhancements 57, 60, and 66, the deliverable is the validation itself. No compiler or ngspice source changes.

What was probed (all exact)

- **.op** access (`print @n1[ids]`): real and integer opvars exact (1 mA / 1 mS / region flag 2); a module variable *without* a desc attribute is correctly not exposed — no such parameter, a clean error rather than a silent zero or crash.
- **.tran** per-point recording (`.save @n1[ids] @n1[region]`): 508-point vectors for the real *and the integer* opvar — the Enhancement-32 `outitf.c` IF_INTEGER fix finally gets a regression pin. **.meas MAX** hits the exact 1 mA sine peak; AVG of the region flag lands at 1.5 (above threshold exactly half the period).
- **.dc** sweeps: per-point recording; `ids == V/1k` exact at every point and the integer region flag steps exactly where $V > 0.5$.
- **.ac**: opvars record (op value per frequency point) and two instances of one model stay distinct (`@n1 = 1 mA` vs `@n2 = 0.5 mA` with $r=2k$).
- **.meas WHEN @n1[ids]=0.5m RISE=1**: 83.3334 ns against the analytic $\text{asin}(0.5)/2\pi \mu\text{s}$ — measurement logic works on opvar vectors exactly as on node voltages.
- String opvars: displayed by `show <inst>`; the *vector* path (`print @n1[strvar]`) is inherently numeric and fails with the `clear can not handle string value` message — pinned as the expected behavior (ngspice vectors cannot hold strings), not a defect.

Examples (**opvar_examples/**, 11 checks, ALL PASS)

`verify_opvar.py` covers the six paths above with exact expected values; `opvar_demo.va` (real + integer + hidden variables) and `opvar_str.va` (string opvar) are the two models.

Regression

No compiler/ngspice source changes; the Enhancement-68 regression state stands, plus this suite's 11 checks.

Enhancement-70 — behavioral-loop audit: precise loop diagnostics

This document describes Enhancement-70: a systematic audit of the runtime loop statements inside analog blocks (`for`, `while`, `do-while`, `repeat`) — the simulation-time cousins of Enhancement-67's `generate` audit. Front-end only — no OSDI/ngspice change.

The audit (14 probe forms, all values verified numerically exact)

feature	verdict
<code>for / while / do-while (E-19) / repeat(n)</code>	exact (sum 1..4 → 10 mS four ways)
nested loops	exact (3×4 → 12 mS)
parameter-dependent trip counts	exact — and a model-card override (n=25) changes the count at simulation time, the precise complement of E-67's <code>generate</code> restriction (structure binds at compile time, behavior at simulation time)
solution-dependent while condition (<code>while (acc < V(a,c)*5)</code>)	converges, exact
loops over arrays (E-14)	exact
iterative algorithms (Newton <code>sqrt(16)</code> , 20 iterations)	exactly 4
contributions inside loops	accumulate (3 iterations of <code>I <+ V·1m</code> → 3 mS)
loops inside analog functions	exact (iterative 5!)
<code>while (0)</code>	body never executes
<code>break</code>	correctly rejected (not Verilog-A)
analog operator (<code>ddt</code>) inside a loop body	correctly rejected per LRM 4.5.1 — but see below

The one defect: a misleading diagnostic (fixed)

An analog operator inside a loop body was rejected — correctly — but the message read *"analog operator 'ddt' is not allowed in conditions"*: the validator lumped loop bodies into the conditional context (`BodyCtx::Conditional`), pointing users at the wrong construct entirely.

Fix(**hir_ty/src/validation/body.rs + validation.rs**): loops now enter their own `BodyCtx::Loop` context (same restrictions, precise reporting) via a parametrized `validate_condition_in`. The error now reads:

```
error: analog operator 'ddt' is not allowed in loops
  = help: analog operators are not allowed inside looping statements (LRM 4.5.1)
  = help: hoist the operator out of the loop, or unroll the loop with `generate`
```

while the `if/case` message is unchanged.

Examples (**analogloop_examples/**, 12 checks, ALL PASS)

`verify_analogloop.py`: [1] nine exact-conductance checks covering every loop statement, nesting, arrays, Newton iteration, contributions-in-loops, and function-body loops; [2] the parameter-bound over-

ride pin (default 10, model-card 25); [3] the fixed diagnostic (names "loops", cites LRM 4.5.1, and no longer says "conditions").

Regression

All 64 example verify suites pass; the E-68 integration suite (now part of the regression runner) passes 28/28; crate tests (including the dev-gated sets) pass; the VA_TEST corpus compiles 92/92.

Enhancement-71 — display-task audit: format flags/width for every conversion + the **%b** segfault

This document describes Enhancement-71: a systematic audit of the display tasks (`$strobe`, `$display`, `$write`, `$monitor`, `$debug`) and the full format-specifier surface. Front-end + OSDI codegen — no ngspice change.

The audit

Two defects found and fixed; everything else verified against exact printf output.

Defect 1: flags and width rejected for every non-real conversion `%5d, %-8d, %+d, %08d, % d, %#o` — all standard display syntax — failed to compile with *“failed to parse format specifier; unexpected character d”*. Only real conversions (`%10.3e, %.2f`) accepted a `[flags][width][.precision]` prefix: the inference-side parser (`hir_ty/inference/fmt_parser.rs`) only *terminated* on `e/f/g/r`, and the lowering-side translator (`hir_lower/fmt.rs`) had the same real-only assumption baked into its catch-all branch.

Fix, both layers: the parser now terminates on every conversion character and reports it (`ParseResult::conversion`), so inference types the argument from the conversion (`d/h/o/b/c` → integer, `s` → string, `e/f/g/r` → real) with flags/width/precision legal everywhere; the lowering translator collects the general prefix verbatim (consuming one extra integer argument per dynamic `*`) and re-emits it in the generated C format with the conversion translated (`%h`→`%x`, `%b`→`%s` over a pre-formatted binary string, `%r`→engineering-notation `f%c` pair).

Defect 2: **%b** crashed the simulator (pre-existing) The OSDI print codegen (`osdi/src/compilation_unit.rs`) called `fmt_binary(val)` to build the binary string and remembered the result for `free()` — but never passed it to `snprintf`. The matching `%s` consumed a garbage pointer: any model printing `%b` segfaulted ngspice. Latent since the print machinery was built (the in-tree users never exercised `%b` at runtime). One line: push the formatted string as an argument before remembering it for free.

Verified printf-exact (18 checks)

`%5d` → `[ 42]`, `%-5d` → `[42 ]`, `%05d` → `[00042]`, `%+d` → `[+42]`, `%8s/%-8s`, `%4h` → `[ ff]`, `%8b` → `[ 101]`, dynamic `%*d`, `%10.3e` → `[ 1.235e+03]`, `%#o` → `[010]`, all base conversions (`hex=ff` `HEX=FF` `oct=10` `bin=101` `chr=A`), `%%`, `%m` (module path), escape sequences, bare-argument defaults (`%g/%d/%s` inferred), and all five display kinds print (`$write` joins lines; `$monitor/$debug` fire — their values reflect the evaluation they run in, per LRM).

Examples (**display_examples/**, 18 checks, ALL PASS)

`verify_display.py` + `display_fmt.va` (the format tour) + `display_kinds.va` (kinds, `%m`, escapes).

Regression

All 65 example verify suites pass; the integration suite 28/28; crate tests pass; the VA_TEST corpus compiles 92/92; zero-warning build maintained.

Enhancement-72 — Touchstone round 2: MA/DB formats, frequency units, Y/Z export, and the **rdsnp** reader

This document describes Enhancement-72, completing the Touchstone arc begun in Enhancement-64. ngspice-only — no compiler/OSDI change.

Writer options (**wrsnp** <file> [**ri**|**ma**|**db**] [**s**|**y**|**z**] [**hz**|**khz**|**mhz**|**ghz**])

The generalized writer (`spar_write_np`) now covers the full Touchstone v1 option surface, any combination, any order after the file name:

- formats: RI (real/imaginary, the default), MA (magnitude / angle in degrees), DB ($20 \cdot \log_{10}$ magnitude / angle);
- parameters: S (default), **Y** and **Z** — exported from the `sp` plot's Y_{i_j}/Z_{i_j} vectors, normalized to Rbase ($Y \cdot R$, Z/R) as the Touchstone v1 spec requires;
- frequency units: Hz (default), kHz, MHz, GHz — the frequency column is scaled and the option line says so (`# GHz S DB R 50`).

The bare 2-port default (`wrs2p file / wrsnp file`) still goes through the byte-identical classic path; every optioned case (and every $N \neq 2$) uses the generalized writer, which also handles the Touchstone 2-port column order (S11 S21 S12 S22 on one line) and the $N \geq 3$ row-major / 4-pairs-per-line layout from E-64.

The reader: **rdsnp** <file> [**nports**]

Reads a Touchstone v1 file into a new plot (`Touchstone import <file>`) holding a real frequency scale in Hz plus complex S_{i_j} (or Y_{i_j}/Z_{i_j}) vectors that match the `.sp` plot's conventions — so imported measurement data compares 1:1 against simulated vectors (`let err = maximum(mag(S_2_1 - {sp1}.s21sim))`).

- parses the `#` option line (any token order): frequency unit, parameter type, format, `R n` — missing option line assumes `Hz S RI R 50` with a warning;
- converts MA/DB back to real/imaginary and de-normalizes Y/Z back to absolute values;
- handles the 2-port column order and the general row-major layout;
- port count from the `.sNp` extension, or explicitly (`rdsnp file 3`);
- publishes Rbase in the imported plot so it round-trips back through `wrsnp`;
- a number count that doesn't divide into frequency blocks is a clear error naming the suspected wrong port count.

Verified (touchstone_examples grows to 17 checks, ALL PASS)

The five E-64 sections are unchanged; round 2 adds: [6] option lines and math for MA (= polar of the RI values), DB (= $20 \cdot \log_{10}$ magnitude) with GHz scaling, and Y/Z headers; [7] a full write-MA $\rightarrow$ **rdsnp** $\rightarrow$ compare round-trip — $\max |S_{21}(\text{read}) - S_{21}(\text{simulated})| = 4e-8$, below the file's own 6-digit precision; [8] a hand-written measurement-style MA/MHz file read back with exact values ($0.5 \angle -90^\circ \rightarrow -0.5j$) through the 2-port column order and unit scaling.

Regression

All 65 example verify suites pass with the rebuilt ngspice; the openvaf integration suite 28/28; no compiler change.

Enhancement-73 — the user handbook: 72 enhancements consolidated into **docs/handbook/**

This document describes Enhancement-73: a documentation deliverable — the repository's first consolidated user guide. No compiler or ngspice source changes.

Why

After 72 enhancements the top-level README had grown to ~950 lines of chronological, per-enhancement narrative — the story of the project, but not a usable reference: to learn whether arrays work, a user had to know that Enhancements 14, 15, 18, 20, 23, 33, 43 exist and read all seven. The handbook reorganizes the same verified material by what the user wants to do.

The handbook (**docs/handbook/**, six files)

- README.md — orientation: the chapter map, how features are verified (every claim is pinned by a committed verify script), the reference PDFs.
- 01-getting-started.md — prebuilt binaries; building from source (LLVM 18 pin, the ngspice configure line); a complete first-model walkthrough (`myres.va` → `openvaf-r` → `pre_osdi` deck → `v(mid)`); the example-suite and `_setup.py` conventions; `VA_TEST` and the integration suite.
- 02-verilog-a-language.md — the feature matrix, 13 sections organized by LRM area (hierarchy/elaboration, nets/disciplines/natures, types/arrays, parameters, operators/literals, analog operators, contributions/probes, events, analog functions, statements/loops, system tasks, pre-processor, attributes). Every row links its enhancement doc and names the example folder that proves it.
- 03-ngspice-workflows.md — simulator-side recipes: model cards vs instance lines, `opvar` access, `alter/.dc @inst[param]` sweeps, the analysis-coverage table, S-parameters + the full Touchstone import/export surface, both Monte Carlo idioms, debugging aids.
- 04-limitations-and-gotchas.md — the honest map: Verilog-A (Annex C) vs AMS scope, fallback-semantics builtins, the compile-time/simulation-time binding model, documented design decisions (stateless `limexp`, non-advancing RNG seeds, `.disto`), ngspice control-language traps, and assorted pinned edges.
- 05-enhancement-index.md — E-1...E-73 in one table: one line each, linking the `enhancements_doc/` write-up and the example folder.

The PDF edition (**docs/Ngspice-OpenVAF-Handbook.pdf**)

The handbook and the complete text of all 73 enhancement write-ups are also compiled into a single 202-page PDF with a linked table of contents: Part I = the five handbook chapters, Part II = `enhancements_doc/` Enhancement-1 ... 73 in order, each starting on a fresh page. The committed generator (`docs/handbook/build_pdf.py`, `pandoc + xelatex`) demotes headings under the two Part headings, rewrites cross-document links into internal PDF anchors (links to example folders/README sections become absolute GitHub URLs so they stay clickable), strips the historical "(versionN)" workflow tags from the enhancement titles, assigns proportional column widths to the wide feature-matrix tables via a `pandoc` Lua filter (the `gfm` reader emits none, which overflows the page), and maps the handful of math glyphs missing from STIX Two Text ($\rightarrow \geq \approx \equiv \angle \sqrt{\dots}$) onto math-mode equivalents — the final build has zero missing-glyph warnings and zero undefined link references. Building the PDF also surfaced (and fixed) a stale intra-doc anchor in `enhancements_doc/Enhancement-2.md` (§6 pointing at a heading numbered 5 — broken on GitHub too).

The README consolidation

With the handbook in place, the top-level README's ~850 lines of per-enhancement narrative sections (E-1 ... E-72) were replaced by the handbook's one-line index table (Doc + Examples links, re-anchored

to the repo root) plus a prominent pointer to the handbook and its PDF edition — the README drops from 965 to ~210 lines and now reads: header / Precursors / the enhancements index / VA_TEST / Pre-built Binaries / CI. The detailed narratives remain where they always lived in full, `enhancements_doc/`, and the result plots remain in their example folders.

Verified

- Link integrity: a checker walks every markdown link and `#anchor` in the six files (GitHub slug rules, code spans excluded) — 205 links, 0 failures — and every `examples/<name>` mention in code spans is a real committed folder.
- Link integrity, README: the same checker logic over the rewritten README — 110 relative links, 0 failures.
- Command truth: the getting-started model and deck were run verbatim with the repo binaries (`v(mid) = 1.000000e+00` exactly as printed in the guide); the chapter-3 command spellings (`alter @n1[r], .dc @n1[r] ... V1 ...`, `agauss/sgauss/setseed`, `portnum 1 z0 50`, `wrsnp/rdsnp`) were cross-checked against the committed tutorial decks.
- One matrix claim corrected by testing: `casex` — written from memory as supported — was probe-compiled and is not implemented; the matrix and the limitations chapter now say so explicitly (plain case, including over strings and arrays, is supported). The project's own audit lesson — *verify, don't assume* — applied to its documentation.

Regression

No compiler or ngspice source changes; the Enhancement-72 regression state stands (66/66 example suites, integration 28/28, corpus 92/92).