## X1 Part List

No.	Picture	Details	Quantity	Check	No.	Picture	Details	Quantity	Check
1-1		Limit switch	3		1-2		DC power jack	1	
1-3		Flat screwdriver	1		1-4	-	Cross screwdriver	1	
1-5		Hex. Wrenches	1		1-6		Binder Clips	2	
1-7		12V 5A adaptor	1		1-8		Bed Frame (Acrylic)	1	
1-9		Fiberglass board	1		1-10		Printing Bed Plate (Acrylic)	1	
1–11	YXNOFIL	Base Frame (Acrylic)	1		1-12	- SANOSHI.	Electronic box top plate (acrylic)	1	

No.	Picture	Details	Quantity	Check	No.	Picture	Details	Quantity	Check
1-13		Electronic box Back plate (acrylic)	1		1-14		Electronic box bottom plate (acrylic)	1	
1-15	- minimum sama	Electronic box front plate (acrylic)	1		1-16		LCD cable	1	
1-17		Electronic box side plate (acrylic)	2		1-18		Z-motor seat	1	
1-19	g Booker	Card reader & Micaro SD card	1		1-20		USB cable	1	
1-21		X-motor mount (acrylic)	1						
2-1	Eq.	Extruded bracket	1		2-2		Screws kits	1	
2-3		Motor wires	4		2-4		Small acrylic kits	1	

No.	Picture	Details	Quantity	Check	No.	Picture	Details	Quantity	Check
2-5		Z-axis motor (with coupling)	1		2-6		X-axis & Y-axis motors (With Pulley)	2	
2-7		Extruder (assembled)	1		2-8		Timing belt x 2pcs Winding pipe Cable ties	1	
2-9		Extrusion kits	1		2-10		Handle	1	
2-11		Wheels x 6pcs 2020 corner bracket x 2pcs Copper nut x 1pcs	1		2-12		power cord	1	
2-13	* =	Belt pulley kits	2		2-14		Mainboard	1	
2-15		LCD display (Assembled)	1		2-16		Aluminum profiles 2020 * 70mm x 1pcs Aluminum profiles 2040 * 285mm x 1pcs Aluminum profiles 2040 * 250mm x 1pcs Aluminum Profile 2020 * 310mm x 1pcs	4	
2-17		Threaded Rod	1		2-18		Extrusion motor(with gear)	1	