

# **Cura Installation and operating instructions**

#### MODEL: T1

### 一、Installation

1) 、Double Click Cura\_15.02.1.exe .













# $\equiv$ operating instructions


1) Open software.



2) 、Setting model,Machine->Machine settings




#### Add new Machine







Select Other, Click next




Select DeltaBot, click next




#### machine paremeters




#### 3) Printer parameters, for reference only







Attention: If the customer need according to his set of nozzle and hot bed temperature printing, please setting following graph (start.gcode)




### Pay special attention to: please delete the following words







#### Load model





5, select model, change model direction, size,






#### 6, viewing model layers





#### 7) Output Gcode file



Thanks you!