## **Notice before Installation**

- 1. Please check the BOM list carefully when unpacking the carton. If any part missing, please contact with your vendor.
- 2. Please tear off the protective paper of acrylic parts before installation, but please keep the masking paper on the hotbed, as the masking paper would help the filament stick onto the hotbed.
- 3. Please pay attention to the positive and negative sequence of the components during the installation process. Do not make mistakes, please install in strict accordance with the assembly video.
- 4. Please pay attention to the labels on the cables in the process of the installation. So as to make sure the cables would be plugged into the right terminals of motherboard.
- 5. If you have any installation or technical question, please do not go it blind, but feel free to contact with your vendor, they would help you out or would report your questions to our engineer team, and then, we would provide the exact solutions.