EE 337: Microprocessors Laboratory (Spring 2021) Section: S1 (Second year UG)

Indian Institute of Technology Bombay

Lab 3: 20 points Date: Feb 8, 2021

- 1. [10 points] In this experiment, you will be demonstrating that your Pt-51 kit works by running the test code for the kit. The test code also checks the peripherals on the kit. By completing this test, you can also verify that the required software is correctly installed. There is no code upload for this experiment. Evaluation will be done by TA during viva.
 - Know more about the Pt-51 kit by going though these slides: https://ee337.github.io/pt51.html#user-manual
 - Install FLIP (on Windows) or DFU Programmer (on Linux/Mac). This software is used to load programs into the 8051 microcontroller on the Pt-51 kit. The steps are here: https://ee337.github.io/tools.html#flip
 - The procedure to load a hex file onto the Pt-51 kit using Flip is shown in the video at the following URL.
 - https://ee337.github.io/pt51.html#programming-and-testing Follow the procedure and load the led.hex file to see that the LEDs on your kit toggle.
 - Download the file pt51_test.hex and load it on your Pt-51 kit, as described at the following URL.
 - https://ee337.github.io/pt51.html#testing-the-peripherals-of-pt-51
 - Follow the steps in the slide deck titled "Pt-51 Test Program" to do the self-test of the kit. Check if all tests run successfully. If there are failed tests, inform us on Moodle/Teams. Also inform the TA during the viva session.
- 2. [10 points] In this experiment, you will write code to read and write values to Port 1, which is abbreviated as P1. Read the ports P1.0 and P1.1 and do the following.
 - If P1.0 is 1, then turn on P1.4 for 1 s and then turn off P1.4 for 3 s. Do this repeatedly.
 - If P1.1 is 1, then turn on P1.6 for 2 s and then turn off P1.6 for 2 s. Do this repeatedly.
 - If both P1.0 and P1.1 are 0, then pins P1.4 and P1.6 should remain off.
 - If both P1.0 and P1.1 are 1, both ports P1.4 and P1.6 have to toggle as mentioned above.

Verify the appropriate toggling of port pins and delays using the logic analyser in Keil.

TA Checkpoints

- 1. For question 1, ask the student to demonstrate the procedure of loading led.hex file onto the Pt-51 kit. Ask the student to demonstrate the toggling of LEDs on the board.
- 2. For question 2, ask the student to set the lower nibble of P1 to 3H and show the waveforms on the pins (mentioned above), in Keil's logic analyser.