
Joshua Clapp Ta: Neha Gupta Section: 506/606


Lab 1

## **Schematics**


Full adder




4 Bit Full Adder



## 4 Bit Register



## 8 Bit Full Adder



**Test Bench** 

Full adder

```
Relinquished control to SimVision...
ncsim>
ncsim> source /opt/coe/cadence/INCISIVE152/tools/inca/files/ncsimrc
ncsim> database -open shmWave -shm -default -into shm.db
Created default SHM database shmWave
ncsim> probe -create -shm test -all -depth 1
Created probe 1
ncsim> run
        0 A=0, B=0, C=0, SUM=0, CARRY=0
        50 A=0, B=0, C=1, SUM=1, CARRY=0
       100 A=0, B=1, C=0, SUM=1, CARRY=0
       150 A=0, B=1, C=1, SUM=0, CARRY=1
       200 A=1, B=0, C=0, SUM=1, CARRY=0
       250 A=1, B=0, C=1, SUM=0, CARRY=1
       300 A=1, B=1, C=0, SUM=0, CARRY=1
       350 A=1, B=1, C=1, SUM=1, CARRY=1
ncsim> run -next
ncsim> ^C
ncsim> exit
        ncxlmode15.20-s078: Exiting on Jan 27, 2023 at 09:21:11 CST (total: 00:07:13)
TOOL:
                                           4_bit_full_adder
Relinquished control to SimVision...
ncsim>
ncsim> source /opt/coe/cadence/INCISIVE152/tools/inca/files/ncsimrc
ncsim> database -open shmWave -shm -default -into shm.db
Created default SHM database shmWave
ncsim> probe -create -shm test -all -depth 1
Created probe 1
ncsim> run
          0 A=0000, B=0000, C=0, SUM=0000, CARRY=0
          50 A=1111, B=1111, C=0, SUM=1110, CARRY=1
         100 A=1010, B=1010, C=1, SUM=0101, CARRY=1
         150 A=0101, B=0101, C=1, SUM=1011, CARRY=0
ncsim> ^C
ncsim> exit
TOOL:
          ncxlmode15.20-s078: Exiting on Jan 27, 2023 at 21:50:47 CST (total: 00:04:30)
```

## 8\_bit\_full\_adder

ncsim> source /opt/coe/cadence/INCISIVE152/tools/inca/files/ncsimrc ncsim> database -open shmWave -shm -default -into shm.db
Created default SHM database shmWave
ncsim> probe -create -shm test -all -depth 1
Created probe 1
ncsim> run

0 A=00000000, B=00000000, Cin=0, Clock=0, SUM=xxxxxxxx, CARRY=x 50 A=00000000, B=00000000, Cin=0, Clock=1, SUM=00000000, CARRY=0 100 A=01111110, B=11100111, Cin=0, Clock=0, SUM=01100101, CARRY=1 150 A=01111111, B=11100111, Cin=0, Clock=1, SUM=01100101, CARRY=1 200 A=11111111, B=00000000, Cin=1, Clock=0, SUM=01100101, CARRY=1 250 A=11111111, B=00000000, Cin=1, Clock=1, SUM=00000000, CARRY=1 300 A=1010101, B=01010101, Cin=0, Clock=0, SUM=00000000, CARRY=1 350 A=10101010, B=01010101, Cin=0, Clock=1, SUM=11111111, CARRY=0 400 A=10101010, B=01010101, Cin=1, Clock=0, SUM=111111111, CARRY=0 450 A=10101010, B=0101011, Cin=1, Clock=1, SUM=00000000, CARRY=1 500 A=11001100, B=00110011, Cin=0, Clock=1, SUM=111111111, CARRY=0 600 A=11001100, B=00110011, Cin=1, Clock=0, SUM=111111111, CARRY=0 650 A=11001100, B=00110011, Cin=1, Clock=1, SUM=111111111, CARRY=0 650 A=11001100, B=00110011, Cin=1, Clock=1, SUM=00000000, CARRY=1

ncsim> ^C ncsim> exit

TOOL: ncxlmode15.20-s078: Exiting on Jan 29, 2023 at 14:19:10 CST (total: 00:04:28)