

EN

User Manual


Model: X2PRO

1 Year Warranty


Support free replacement of damaged products

Key Functions

- 1.Power ON/OFF:** Long press "①" for 3 seconds.
- 2.Reset:** Long press "①" for 8 seconds.
- 3.USB/TF/BT Function Switch:** Click "②".
- 4.Enter/Exit TWS Pairing:** Click "②" twice.
- 5.Play/Pause:** Click "③".
- 6.Answer/End Call:** Click "③".
- 7.Unpair:** Long press "③".
- 8.Next/Previous Track:** Long press "④"/"⑤".
- 9.Volume Increase/Decrease:** Click "④"/"⑤".
- 10.Lighting Mode Switch:** Click "⑥".
- 11.Light ON/OFF:** Long press "⑥".



Connect



1. Turning On the Device Power
 - Long press the Play button for 2 seconds.


※Illustration: A finger long-pressing the central (③) button on the circular panel.

2. Bluetooth Connection [Smartphone Operation]
 - (1) Screen Settings: Go to Settings > Bluetooth.
 - (2) Connection Operation: Select <X2PRO> from Available Devices.

※Illustration: A finger tapping the "X2PRO" device.

Safety Precautions

1. Temperature Environment: Do not place this product in extremely high or low-temperature environments. It may damage the battery and circuit board.
2. No Liquid Immersion: Do not immerse this product in any liquid.
3. No Disassembly: Do not disassemble this product by yourself.
4. Cleaning Method: Avoid cleaning with concentrated chemicals or detergents.
5. Proper Power Source: Use a dedicated 5V=1A/2A power supply. Connecting to a higher voltage may cause serious damage.
6. Disposal & Storage: Strictly prohibit placing or discarding near open flames or high-temperature sources due to risk of explosion.



0.75-5
W

Applicable Power: 0.75 - 5W

•Using within the range of the wireless device's minimum required power (0.75W) to maximum allowable power (5W) will yield optimal charging efficiency.



JP

ユーザーマニュアル


モデル番号: X2PRO

1年間保証


損傷した製品の無償交換をサポートいたします。

キー機能

- 1.電源ON/OFF: “①”を3秒長押し
- 2.リセット: “①”を8秒長押し
- 3.USB/TF/BT機能切替: “②”をクリック
- 4.TWSペアリング入る/終了: “②”2回押す
- 5.再生/一時停止: “③”をクリック
- 6.通話応答/切断: “③”をクリック
- 7.ペアリング解除: “③”を長押し
- 8.次曲/前曲: “④”/“⑤”を長押し
- 9.音量増/減: “④”/“⑤”をクリック
- 10.ライティングモード切替: “⑥”をクリック
- 11.ライトON/OFF: “⑥”を長押し



接続する



1. 〈デバイス電源ON〉

- 再生ボタンを2秒間長押し

※ イラスト: 円形パネル中央の(③)ボタンを人差指で長押し

2. 〈Bluetooth接続〉


[スマートフォン操作]

- (1) 画面設定: 設定 > Bluetooth
- (2) 接続操作: 利用可能なデバイスから<X2PRO>を選択

※ イラスト: 指が“X2PRO”デバイスをタップする描写

安全上のご注意

1. 温度環境: 本品を極端に高温または低温の環境に置かないでください。バッテリーや回路基板に損傷を与えます。
2. 液体浸入の禁止: 本品を液体に浸さないでください。
3. 分解禁止: 本品を自ら分解しないでください。
4. 洗浄方法: 濃縮化学製品や洗剤を使用した清掃は避けてください。
5. 適正電源: 電源は5V = 1A/2A専用。それ以上の電圧を接続すると重大な損傷の原因となります。
6. 廃棄 保管: 火気 高温源の近くへの放置 廃棄は爆発の危険があるため厳禁です。



0.75-5
W

充電器仕様

適用電源: 0.75 - 5W

※ 無線機器の最小必要電力0.75Wから最大許容電力5Wの範囲で使用することで、最適充電効率を得られます

