



Introduction to Slide Set 10

- In prior side sets we explored hardware only approaches to extracting more performance from software.
- In this slide set, we explore simple software approaches to extracting performance from a single thread. We will do this in the context of a single issue pipelined processor with multicycle floating-point operations (e.g., as in Slide Set 6)
- Then we will look at an example of a real processor that uses Tomasulo's algorithm, multiple instruction issue and a reorder buffer—the Pentium 4.
- Finally, we will consider the limits of instruction level parallelism found in software.



Learning Objectives

- After we finish this slide set in lectures you will be able to
 - List two software approaches to enhance instruction level parallelism (scheduling, loop unrolling)
 - Apply loop unrolling to a simple loop for a scalar pipeline.
 - Apply loop unrolling to a simple loop for a VLIW pipeline.
 - Explain why the software based approaches do not completely replace the need for hardware approaches.
 - List one or two details of Pentium 4 microarchitecture.
 Explain how they impact performance of Pentium 4.
 - Explain sources of limits to instruction level parallelism (ILP)



Running Example

This code adds a scalar to a vector:

```
for (i=1000; i>0; i=i-1)
 x[i] = x[i] + s;
```

 Assume a single-issue, in order pipeline with the following latencies in all examples:

Instruction producing result	Instruction using result	Execution in cycles	Latency in cycles
FP ALU op	Another FP ALU op	4	3
FP ALU op	Store double	3	2
Load double	FP ALU op	1	1
Load double	Store double	1	0
Integer op	Integer op	1	0
Integer op	Branch op	1	1



FP Loop: Where are the Hazards?

First translate into MIPS code:

```
Loop: L.D F0,0(R1) ; Regs[F0]=vector element ADD.D F4,F0,F2 ; add scalar from Regs[F2] S.D F4,0(R1) ; store result DADDI R1,R1,#-8 ; decrement pointer 8B (DW) BNE R1,R2,Loop ; branch Regs[R1]!=Regs[R2]
```

1st Question we wish to answer: Where are the stalls? 2nd Question we wish to answer: How to reduce stalls by adjusting the software.



FP Loop: Showing Stalls (in order, single-issue pipeline)

```
1 Loop:
        L.D
                F0,0(R1); Regs[F0]=vector element
2
        stall.
3
        ADD.D F4,F0,F2; add scalar in Regs[F2]
        stall.
4
5
        stall.
6
        S.D F4,0(R1); store result
7
        DADDI R1,R1,#-8; decrement pointer 8B (DW)
        stall.
8
9
        BNE
                R1,R2,Loop; branch Regs[R1]!=Regs[R2]
```

Instruction producing result	Instruction using result	Latency in clock cycles
FP ALU op	Another FP ALU op	3
FP ALU op	Store double	2
Load double	FP ALU op	1
Integer op	Branch op	1

9 clocks: Rewrite code to minimize stalls?



Revised FP Loop Minimizing Stalls

```
Loop: L.D
               F0,0(R1)
        DADDI R1,R1,#-8
2
3
        ADD.D
               F4,F0,F2
4
        stall.
5
       stall
6
        S.D
               F4,8(R1)
7
        BNEZ
               R1,Loop
```

Swap DADDUI and S.D

7 clocks, but just 3 for execution (L.D,ADD.D,S.D), 4 for loop overhead (DADDI, BNE, two stalls);

How to make faster?



Loop Unrolling

- We can reduce loop overhead by making multiple copies of loop body inside loop.
- This is known as loop unrolling.
- In the next few slides we will look at how to apply loop unrolling to the example on the last few slides.

- The steps we will apply are:
 - 1. Make copy of loop body and remove overhead instructions
 - 2. Rename registers in the assembly code to remove name dependencies (unlike Tomasulo's algorithm, this renaming is done in software rather than in hardware)
 - 3. Schedule instructions to reduce stalls ensuring that new code computes same result as original code.



Unroll Loop Four Times (straightforward way)

```
1 cycle stall
                F0,0(R1)
1 Loop: L.D
                                                   Rewrite loop to
2
                F4,F0,F2
                                 2 cycles stall
        ADD.D
                                                     minimize stalls?
3
        S.D
               F4,0(R1)
                               ;drop DADDUI & BNE
4
        L.D
               F0, -8(R1)
5
               F4,F0,F2
        ADD.D
6
        S.D
               F4, -8 (R1)
                               ;drop DADDUI & BNE
        L.D
               F0, -16(R1)
               F4,F0,F2
        ADD.D
        S.D
               F4,-16(R1)
                               ;drop DADDUI & BNE
10
        L.D F0, -24(R1)
11
        ADD.D
               F4,F0,F2
12
        S.D F4, -24(R1)
13
        DADDUI R1,R1,#-32
                               ;alter to -4*8
                RI,R2,LOOP
14
        BNE
                        1 cycle stall
```

 $14 + 4 \times (1+2) + 1 = 27$ clock cycles, or 6.75 cycles per iteration Assumes # of loop iterations is multiple of 4



Where are the name dependencies?

```
Loop:L.D
2
        ADD.D
3
        S.D
                               ;drop DADDUI & BNE
4
        L.D
               FO, 8 (R1)
5
        ADD.D
               F4, F0, F2
6
        S.D
                               ;drop DADDUI & BNE
        L.D
                  ,-16(R1)
8
        ADD.D
              F4,F0,F2
9
        S.D
                               ;drop DADDUI & BNE
10
               F0,-24(R1)
        L.D
11
               F4,F0,F2
        ADD.D
12
                -24(R1), F4
        S.D
        DADDUI R1,R1,#-32
13
                               ;alter to 4*8
14
        BNE
               R1,R2,LOOP
                                                 anti-dependencies on
                                                 R1 omitted for clarity
```

How can we remove them?



Apply Renaming

```
Loop:L.D \mathbf{F0}, 0 (R1)
2
      ADD.D F4,F0,F2
3
      S.D \quad O(R1), F4
                          ;drop DADDUI & BNE
4
      L.D F6, -8(R1)
5
      ADD.D F8, F6, F2
6
      S.D -8 (R1), F8
                          ;drop DADDUI & BNE
7
       L.D F10, -16(R1)
8
      ADD.D F12, F10, F2
9
      S.D -16(R1), F12; drop DADDUI & BNE
10
      L.D F14, -24(R1)
11
      ADD.D F16, F14, F2
12
      S.D -24(R1), F16
13
      DADDUI R1,R1,#-32 ;alter to 4*8
14
       BNE
             R1,R2,LOOP
```



Unrolled Loop That Minimizes Stalls

```
    Assumptions we made:

               F0,0(R1)
 Loop:L.D
                                         OK to move store past
2
        L.D
               F6, -8(R1)
                                           DADDUI even though
               F10,-16(R1)
3
       L.D
                                           DADDUI changes register
4
       L.D
               F14,-24(R1)

    OK to move loads before

5
       ADD.D
               F4,F0,F2
                                           stores: Needed to check if
6
              F8, F6, F2
       ADD.D
                                           we get the right data
       ADD.D F12,F10,F2
                                         - In general, compiler needs to
8
                                           check for both register and
       ADD, D
               F16,F14,F2
9
                                           memory dependencies
       S.D
               0(R1),F4
10
       S.D
               -8(R1),F8
11
       DADDUI R1, R1, #-32
12
        S.D
               16(R1), F12; 16 = -16 + 32
               8(R1), F16 ; 8 = -24 + 32
13
        S.D
14
               R1, R2, LOOP
        BNE
```

14 clock cycles, or 3.5 per iteration



Compiler Based Scheduling (Static Scheduling)

- Compiler analyzes dependencies in program
- Tries to schedule to avoid hazards that cause performance losses
- Easy to determine for registers (fixed names)
- Hard for memory ("memory disambiguation" problem):
 - Example:

```
SD R1, 100(R4)
LD R2, 20(R6)
```

- Is there a data dependence?
- Equivalent question: "Does 100(R4) = 20(R6)"?
- Possible answers: definitely yes, maybe, definitely no
- If "by inspection" we can see the answer is "definitely no", we can move LD before SD. Compilers answer this question using complex algorithms beyond the scope of this course



Compiler Perspectives on Code Movement

Our example required compiler to know that if R1 doesn't change then:

```
0 (R1) \neq -8 (R1) \neq -16 (R1) \neq -24 (R1)
```

There were no dependencies between some loads and stores so they could be moved by each other.



Details Steps to Unroll

- Determine unrolling the loop would be useful by finding that the loop iterations were independent
- Eliminate extra test and branch instructions and adjust the loop termination and iteration code
- Rename registers to avoid name dependencies
- Determine loads and stores in unrolled loop can be interchanged by observing that the loads and stores from different iterations are independent
 - Requires analyzing memory addresses and finding that they do not refer to the same address.
- Schedule the code, preserving any dependences needed to yield same result as the original code



Unknown Loop Bounds

- Do not usually know upper bound of loop
- Suppose it is "n", and we would like to unroll the loop to make "k" copies of the body
- Instead of a single unrolled loop, we generate a pair of consecutive loops:
 - 1st executes (n mod k) times and has a body that is the original loop
 - 2nd is the unrolled body surrounded by an outer loop that iterates (n/k) times
 - For large values of n, most of the execution time will be spent in the unrolled loop



Example

(using C syntax for clarity, not fully optimized)

```
// Original Loop
for(i=0; i < n; i++) {
  A[i] = B[i]
// After applying loop unrolling:
// first loop : original loop body, iterates n mod k times
for(i=0; i < n\%4; i++) {
  A[i]=B[i];
// second loop: unroll original loop 4 times, iterates n/k times
for( i=0; i < n/4; i++ ) {
  A[4*i + n\%4 + 0] = B[4*i + n\%4 + 0];
  A[4*i + n\%4 + 1] = B[4*i + n\%4 + 1];
  A[4*i + n\%4 + 2] = B[4*i + n\%4 + 2];
  A[4*i + n\%4 + 3] = B[4*i + n\%4 + 3];
```



Very Long Instruction Word (VLIW)

VLIW: instructions that "encode" multiple operations.

The hardware executes the entire instruction "at once" on parallel function units in execute stage.

The "long instructions" encode the fact that the operations are <u>independent</u>. So, the hardware does not need to dynamically figure this out. This can save area and power and is now popular in embedded processors (e.g., Texas Instruments C6x series of DSPs).

Inst	N:
Inst	N+1:

ADD.D F1,F1,F4	NOP	L.D F7, 0(R1)	DSUBI R2,R2,#1	NOP
ADD.D F1,F1,F7	MUL.D F4,F5,F6	NOP	DSUBI R2,R2,#1	BEQZ R2, Loop





Loop Unrolling in VLIW

Memory reference 1	Memory reference 2	FP operation 1	FP op. 2	Int. op/ branch	Clock
L.D F <u>0</u> ,0(R1)	L.D F6,-8(R1)				
L.D F10,-16(R1)	L.D F14, 24(R1)				
L.D F18,-32(R1)	L.D F22,-40(R1)	ADD.D F4,F0,F2	ADD.D F8	3,F6,F2	
L.D F26,-48(R1)		ADD.D F12,F10,F2	ADD.D F1	16,F14,F2	
		ADD.D F20,F18,F2	ADD.D F2	4,F22,F2	
S.D 0(R1),F4	S.D -8(R1),F8	ADD.D F28,F26,F2			
S.D -16(R1),F12	S.D -24(R1),F16				
S.D -32(R1),F20	S.D -40(R1),F24			DSUBUI R1,R1,	#48
S.D -0(R1),F28				BNEZ R1,LOOP	

Unrolled 7 times to avoid delays

7 results in 9 clocks, or 1.3 clocks per iteration (~2.7X) 23 ops / 9 cycles = 2.5 ops per clock, 2.5/5 = 50% efficiency

Note: Need more registers in VLIW (15 vs. 6)




Pentium 4 History

- Willamette (Nov 2000)
 - Process technology: 180 nm
 - Pipeline stages: 21
- Northwood (Jan 2002)
 - Process technology: 130 nm
 - Pipeline stages: 21
 - Hyperthreading support added (or finally debugged) for later versions
- Prescott (Feb 2004)
 - Process technology: 90 nm
 - Pipeline stages: 31
 - Hyperthreading
- Cedar Mill (early 2006)
 - Prescott, but in 65 nm
 - End of road for Pentium 4 Microarchitecture... consuming too much power

[source (for dates): Wikipedia]



Pentium 4 ("Prescott") Block Diagram




© 2007 Elsevier, Inc. All rights reserved.



Pentium 4 Pipeline ("Willamette")


Bas	ic Pe	entiu	ım	III F	Proc	ess	sor M	ispre	dictio	n Pip	peli	ne
1 Fetch	2 Fetcl		3 code	4 Decod		5 code		7 ROB Rd	8 Rdy/Sch	9 Dispatcl		0 ec
Bac	ic D	ntii	ım	1 D	rocc		or Mi	cnro	dictio	n Din	alir	•
Bas		entii					or Mi	•	dictio	n Pip		1e



[Source: "The Microarchitecture of the Pentium® 4 Processor", Intel Technology Journal, Vol. 5 Issue 1 (February 2001) special issue on the Pentium® 4 Processor]




Register Renaming



[Source: "The Microarchitecture of the Pentium® 4 Processor", Intel Technology Journal, Vol. 5 Issue 1 (February 2001) special issue on the Pentium® 4 Processor]




Branch Mispredictions



Floating point benchmarks: Less branches, and branches are more predictable.




Instructions "thrown out" due to branch mispredictions (or jump target mispredictions)



Note similarity to branch prediction accuracy




Cache Misses



L2 cache misses more important for performance... why?




Pentium 4 CPI v.s AMD Opteron CPI



Opteron lower average CPI (factor of 1.27)



Pentium 4 Performance v.s AMD Opteron Performance



Opteron slightly faster overall: Higher clock frequency not enough to overcome reduction in CPI due to increased stalls



Limits to ILP (Instruction Level Parallelism)

- How much ILP is available using superscalar OoO mechanisms with increasing HW budgets?
- Do we need to invent new HW/SW mechanisms to keep on processor performance curve?
 - Intel MMX, SSE (Streaming SIMD Extensions): 64 bit ints
 - GPUs/Cell Processor?
 - Other?



Limits to ILP

Initial HW Model here; MIPS.

Assumptions for ideal/perfect machine to start:


- Register renaming infinite virtual registers => all register
 WAW & WAR hazards are avoided
- 2. Branch prediction perfect; no mispredictions
- 3. Jump prediction all jumps perfectly predicted 2 & 3 => machine with perfect speculation & an unbounded buffer of instructions available
- 4. *Memory-address alias analysis* addresses are known & a store can be moved before a load provided addresses not equal

Also:

- unlimited number of instructions issued/clock cycle; perfect caches;
- 1 cycle latency for all instructions




Upper Limit to Instruction Level Parallelism: Ideal Machine





Impact of Instruction Window Size


Instruction window size limits the number of instructions that we can search through while looking for parallelism among instructions.





More Realistic HW: Branch Impact

Change from Infinite window to examine to 2000 and maximum issue of 64 instructions per clock cycle






Beyond Branch Prediction

Control flow very often "re-converges" shortly after a branch.

```
y = lookup(x); // A
if(y > 0) {
    B++;
} else {
    C++;
}
foo(); // D
```




- In 1995-2005 timeframe: much research on "speculative threads". E.g., start short thread at D while executing at A. When original thread reaches D it combines state with speculative thread.
- Huge benefit: reduces sensitivity to branch mispredictions.
- Sun Microsystems "Rock" processor implemented a simple form of this
 and it seem likely Intel or AMD will eventually implement it since
 Amdahl's Law suggests single thread performance still matters.



Impact of Number of Renaming Registers


2000 instruction window, maximum 64 inst/cycle, tournament predictor Floating-point more sensitive to number of rename registers.






Impact of Memory Dependence Prediction

2000 instr window, 64 instr issue, 8K 2 level Prediction, 256 renaming registers (potential impact of memory "dependence prediction")






Virtuous Cycle, circa 1950 – 2005 [Mark Hill, Jim Larus]





Virtuous Cycle, 2005 – ???





Future Microprocessors: What must we do differently to effectively utilize multi-core and many-core chips?

...and what are the implications re: education?

Yale Patt The University of Texas at Austin

World University Presidents' Symposium
University of Belgrade
April 4, 2009




How will we use 50 billion transistors?

How have we used the transistors up to now?




How have we used the available transistors?






Intel Pentium M





Intel Core 2 Duo

- Penryn, 2007
- 45nm, 3MB L2





Why Multi-core chips?

- It is easier than designing a much better uni-core
- It is embarrassing to continue making L2 bigger
- It is the next obvious step
- It is not the Holy Grail



that is...

- In the beginning: a better and better uniprocessor
 - improving performance on the hard problems
- More recently: a uniprocessor with a bigger L2 cache
 - forsaking further improvement on the "hard" problems
 - poorly utilizing the chip area
 - and blaming the processor for not delivering performance
- Today: dual core, quad core
- Tomorrow: ???



The Good News: Lots of cores on the chip

The Bad News: Not much benefit.



Evolution of Thread-Level Parallelism in Desktop Applications


Geoffrey Blake*, Ronald G. Dreslinski*, Trevor Mudge*, Krisztián Flautner†


University of Michigan – Ann Arbor*
ARM †




Introduction

- 2000
 - Single core machines common
 - Clock speed steadily increasing Intel predicts to reach 10GHz by
 2010
- 2005
 - _ C "If you build it, they will come"
 - A -- "Field of Dreams" 1989
- 2010 and ⊢uture
 - Multi-core machines common
 - Core counts steadily increasing










Are threads used?


Benchmark	Threads Created	Avg. Threads Alive
Handbrake 0.9	22511	24
Call of Duty 4	77	44
Photoshop CS4	82	75
Adobe Reader 9	239	24
Quicktime-HD	53	52
Firefox 3.5	522	38

- Many threads created
- Many threads alive and visible to the OS during runtime






TLP vs Time – Atom Windows 7





Overall TLP Results – Xeon Windows 7





Why Instruction Level Parallelism Still Matters (Even With Multicore)

Assuming application is 99% parallelizable, what is better: More simple cores or improve IPC for sequential fraction (e.g., using superscalar or other "cleverness")?

