Dream Maker Overlord 3D printer Mainboard


User Manual V1.0

Version: V1.0

Copy Right: DFRobot

Date: 2016/3/28

Network: http://www.dfrobot.com



| Name | Pin | Function | |
|------|-----|-------------------------------|--------------|
| Tz | D32 | Z axis micro switch | |
| Ту | D28 | Y axis micro switch | |
| Тх | D24 | X axis micro switch | |
| T1 | P13 | Nozzle temperature sensor | |
| T2 | P12 | Nozzle temperature sensor | |
| T3 | P14 | Buildplate temperature sensor | |
| SD | | SD card reader | |
| OLED | | OLED display | |
| X | D27 | Enable | |
| | D25 | Step | X axis motor |
| | D23 | DIR | |
| Υ | D29 | Enable | Y axis motor |
| | D31 | Step | |

| | D33 | DIR | |
|----------|-----|-----------------------|----------------|
| Z | D35 | Enable | Z axis motor |
| | D37 | Step | |
| | D39 | DIR | |
| E1 | D41 | Enable | Extruder motor |
| | D43 | Step | |
| | D45 | DIR | |
| Heater1 | D2 | Heater for Nozzle | |
| Heat bed | D4 | Heater for buildplate | |
| +7.4V | | 7.4V Battery | |