THE FACTORY FLOOR TECHNICAL SPECIFICATIONS

Current as of September 2024

CONTACTS

The Factory Theatre
105 Victoria Road, Marrickville

NSW Australia, 2205
+61 2 9660 9060 (Box Office)

Century Venues

105 Victoria Road, Marrickville
NSW Australia, 2205

+61 2 9519 9231

INDICITIVE CHARGES: FACTORY FLOOR

The below indicative charges are EX GST and should be factored into event budgeting. These costs will be itemised on the venue settlement on completion of the show.

Early / Late Access

Contractual bump in time is from 6.00pm.
A venue hire charge of $50 + GST/hour + staff applies for hours outside of the contractual period.

House Audio Component

House Audio Component (as listed below in this document) is included in your contract

House Lighting Component
House Lighting Component (as listed below in this document) is included in your contract

House Technicians
The House Technicians will operate FOH Audio and Lighting control, Minimum 1 x house technician is required to operate this room.

Additional Production Items
Please contact Event Coordinator for prices and availability of production items outside of the standard as listed in this document.

All technical advancing and prices for hires & staff for all shows to be coordinated through Event Manager / Production Manager.

STAGE DIMENSIONS

Stage Width	4.8m
Stage Depth	4.8m
Height from stage to ceiling	3.8m
Stage Surface	Timber floor, carpet covered.

AUDITORIUM DIMENSIONS

DSE to Audio & Lighting Mix Pos 10.8m

Theatre Floor Width	9.5m

3 x Tiered Platforms

AUDITORIUM CONFIGURATIONS

Concert	250 capacity
Seated	140 capacity

POWER

3 Phase power is not a standard in the Factory Floor. Please contact Event Coordinator for prices on 1 x 32amp wilco install

STAGE FITTINGS

Black Stage curtains

Screen	3.0m x 2.0m

LIGHTING

Control: Grand MA 3 on PC With Fader wing

Additional Lighting Packages Available

Please contact your Event Coordinator for prices and availability.

RIGGING

All rigging and requirements installed and operated by in-house riggers only. The Production Manager must approve additional rigging requirements in advance.

AUDIO

FOH Speaker System

EVX 3 Way (hi, mid, lo)	2
EV 2x18" Sub	2
DBX Drive rack	1
InterM P3200 Amplifier	2

FOH Control

Midas M32 Digital Console	1
Midas Digital Stage Box DL32	1

Monitor System (Mons control from FOH)

RCF ART 912-A	4

System Info

Shure Beta 52	1
Shure Beta 91	1
Shure SM57	6
Shure SM58	4
Sennheiser 604	3
Rode M5	2
Radial Passive Mono D.I.	2
Behringer Ultra-DI	4
Short Booms	6
Tall Booms	7

8 Way Dropbox	1

DRESSING ROOMS & PRODUCTION OFFICES

1 x Dressing rooms available rear of stage

LOADING AREAS

Loading Door located via Victoria road. Please contact Event Coordinator / Audio Tech upon arrival to ensure load in parking.

FACTORY FLOOR HOUSE RULES

BACKLINE SHARING BETWEEN BANDS IS HIGHLY ENCOURAGED
All doors, stage or house must be clear at all times for access.
No Gaff Tape to be used on stage, or curtains.
All stage equipment must enter via Loading Dock.

All FOH equipment must enter via the Foyer Doors.
No seats, armrests, or backrests can be used as a step.

Only house riggers may operate rigging equipment or rig.
Do not adjust stage drapery.

Vehicles may be permitted to enter into front entry for load in with prior consent given however vehicle will need to be removed immediately after load in.

Load out to be carried out safely and immediately after conclusion of performance.
The venue must be cleared of all patrons and the loading passage way cleared of patrons and rubbish before cases can be loaded out.