

NetLink AC1900

User Manual — Dual-Band Wireless Router, Model NL-AC1900

1. Package Contents and Safety

Your NetLink AC1900 package includes: the router unit, a power adapter, one Ethernet cable, and this quick start guide.

***WARNING:** To prevent overheating, ensure adequate ventilation around the router. Do not place the router in an enclosed cabinet or stack other devices on top of it.*

2. Hardware Overview

The front panel has five LED status lights: Power, Internet, 2.4GHz, 5GHz, and Ethernet. The rear panel includes a power port, an Internet (WAN) port, four Ethernet (LAN) ports, a WPS button, and a recessed RESET button.

LED	Solid	Blinking	Off
Power	Router is on	—	Router is off or unplugged
Internet	Connected to the internet	Negotiating connection	No internet connection
2.4GHz / 5GHz	WiFi band active	Data transmitting	Band disabled

3. Connecting the Router

Connect one end of the included Ethernet cable to your modem, and the other end to the WAN port on the router (colored differently from the LAN ports). Plug in the power adapter and wait approximately 60 seconds for the router to fully start up — the Power LED will turn solid green when ready.

For the initial setup, connect a computer to any LAN port using an Ethernet cable, or connect wirelessly using the default network name and password printed on the label on the bottom of the router. Open a web browser and go to netlink.setup to begin the setup wizard.

4. WiFi Configuration

The NetLink AC1900 broadcasts two WiFi networks by default: a 2.4GHz network (better range, slower speed) and a 5GHz network (faster speed, shorter range). Both can be renamed and password-protected from the setup wizard or the admin panel at netlink.setup.

To connect the router to your WiFi network, log into the admin panel and select Internet Setup. Most home internet providers use automatic detection; if your connection is not detected automatically, contact your internet service provider for your connection type (PPPoE, Dynamic IP, or Static IP).

A Guest Network can be enabled separately under Wireless Settings > Guest Access, which gives visitors internet access without exposing your main network's devices.

5. Advanced Settings

- Port Forwarding: Advanced Settings > Port Forwarding, useful for gaming consoles and remote access to home devices.
- Parental Controls: set time limits and content filtering per device under Family Settings.
- Firmware Updates: Advanced Settings > Administration > Firmware Update. The router checks automatically by default.
- Device Priority (QoS): prioritize bandwidth for specific devices under Advanced Settings > QoS.

6. Troubleshooting

Problem	Possible Cause	Solution
Internet LED is off or red	Modem connection issue	Check the WAN cable connection; power-cycle the modem first, then the router.
Cannot connect to WiFi	Incorrect password or band mismatch	Confirm the network name and password on the router label; some devices may not support 5GHz.
Slow WiFi speeds	Interference or distance	Move the router to a central, elevated location away from other electronics.
Forgot admin password	N/A	Press and hold the RESET button on the back panel for 10 seconds.
Router unresponsive / frozen	Temporary software fault	Unplug the router for 10 seconds and plug it back in.

Note: Resetting the router with the RESET button erases all custom settings, including your WiFi name and password, and restores factory defaults.

7. Specifications

Specification	Value
WiFi Standard	802.11ac (WiFi 5)
Max Speed	AC1900 (600 Mbps @ 2.4GHz + 1300 Mbps @ 5GHz)
Ports	4x Gigabit LAN, 1x Gigabit WAN
Dimensions	10.2 in x 7.1 in x 2.1 in
Warranty	1 year limited