		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
Code	Means											
'PWR" - System	n Power Command sets System Standby	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	_
"01"	sets System On	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"QSTN" 'AMT" - Audio N	gets the System Power Status Muting Command	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	_
"00"	sets Audio Muting Off	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"01" "TG"	sets Audio Muting On sets Audio Muting Wrap-Around	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes	
"QSTN"	gets the Audio Muting State	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
'CMT" - Audio N	Muting by Channel Command sets Audio Muting by Channel xx=00 Muting Off xx=01 Muting On xx=TG Muting Wrap-Around for not exist channel is always 00.											
ccddeeffgghhiijjkk	aa:Front Left bb:Front Right cc:Center kli dd:Surround Left ee:Surround Right	No	No	No	No	No	No	No	No	No	No	
	ff:Surround Back Left gg:Surround Back Right hh:Subwoofer 1 ii:Height 1 Left jj:Height 1 Right kk:Height 2 Left li:Height 2 Left li:Height 2 Right mm:Subwoofer 2											
"QSTN"	gets the Audio Muting State	No	No	No	No	No	No	No	No	No	No	
"00"	Speaker A/B Command sets Speaker Off	No	No	No	No	No	No	No	No	No	No	
"01" "UP"	sets Speaker On sets Speaker Switch Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	gets the Speaker State	No	No	No	No	No	No	No	No	No	No	
1:SPA=MAIN A/SI 2:SPA=Front A/SF	SPB=MAIN B SPB=Front B(Exclucive use)											
'SPL" - Speaker	r Layout Command											_
"SB" "FH"	sets SurrBack Speaker sets Front High Speaker / SurrBack+Front High Speakers	No No	No No	No No	No No	No No	No No	No No	No No	Yes No	Yes No	
"FW"	sets Front Wide Speaker / SurrBack+Front Wide Speakers	No	No No	No	No	No	No	No No	No	No No	No	
"HW" "H1"	sets Front High+Front Wide Speakers sets Height1 Speakers	No No	No No	No No	No No	No No	No No	No No	No No	No Yes	No Yes	
"H2"	sets Height2 Speakers	No	No	No	No	No	No	No	No	No	No	
"BH"	sets Back+Height1 Speakers sets Back+Wide Speakers	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"HH"	sets Height1+Height2 Speakers	No	No	No	No	No	No	No	No	No	No	
"A" "B"	sets Speakers A sets Speakers B	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"AB" "UP"	sets Speakers A+B	No No	No No	No No	No No	No No	No No	No No	No No	No Yes	No	
"QSTN"	sets Speaker Switch Wrap-Around gets the Speaker State	No	No	No No	No No	No	No	No No	No	Yes	Yes Yes	
MVL" - Master ' "00"-"C8"	Volume Command	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	
"00"-"64"	Volume Level 0.0 – 100.0 (0.5 Step In hexadecimal representation) Volume Level 0 – 100 (In hexadecimal representation)	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No	
"00"-"50" "UP"	Volume Level 0 – 80 (In hexadecimal representation) sets Volume Level Up	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	
"DOWN"	sets Volume Level Down	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"UP1" "DOWN1"	sets Volume Level Up 1dB Step sets Volume Level Down 1dB Step	No No	No No	No No	No No	No No	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"QSTN"	gets the Volume Level	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
TFR" - Tone(Fr	ront) Command	No	No	No	No	No	No	No	No	No	No	
"Bxx"	Front Bass (xx is "-A""00""+A"[-100+10 2 step] Front Bass (xx is "-A""00""+A"[-100+10 1 step]	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"Txx"	Front Treble (xx is "-A""00""+A"[-100+10 2 step]	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	
"Txx" "BUP"	Front Treble (xx is "-A""00""+A"[-100+10 1 step] sets Front Bass up(2 step)	No	No	No	No	No	No	No	No	No	No	
"BUP" "BDOWN"	sets Front Bass up(1 step) sets Front Bass down(2 step)	Yes	Yes	Yes	Yes	Yes No	Yes	Yes	Yes	Yes No	Yes	
"BDOWN"	sets Front Bass down(1 step)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"TUP" "TUP"	sets Front Treble up(2 step) sets Front Treble up(1 step)	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	-
"TDOWN"	sets Front Treble down(2 step)	No	No	No	No	No	No	No	No	No	No	
"TDOWN" "QSTN"	sets Front Treble down(1 step) gets Front Tone ("BxxTxx")	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	\vdash
TFW" - Tone(Fr	ront Wide) Command											
"Bxx" "Txx"	Front Wide Bass (xx is "-A""00""+A"[-100+10 2 step] Front Wide Treble (xx is "-A""00""+A"[-100+10 2 step]	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"BUP"	sets Front Wide Bass up(2 step)	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"BDOWN" "TUP"	sets Front Wide Bass down(2 step) sets Front Wide Treble up(2 step)	No	No	No	No	No	No	No	No	No	No	L
"TDOWN" "QSTN"	sets Front Wide Treble down(2 step) gets Front Wide Tone ("BxxTxx")	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	1
TFH" - Tone(Fr	ront High) Command											_
"Bxx" "Txx"	Front High Bass (xx is "-A""00""+A"[-100+10 2 step] Front High Treble (xx is "-A""00""+A"[-100+10 2 step]	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	F
	sets Front High Bass up(2 step)	No	No	No	No	No	No	No	No	No	No	
"BUP"	sets Front High Bass down(2 step)	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	-
"BDOWN"	I sets Front High Treble up(2 step)	1	No	No	No	No	No	No	No	No	No	
"BDOWN" "TUP" "TDOWN"	sets Front High Treble up(2 step) sets Front High Treble down(2 step)	No										
"BDOWN" "TUP" "TDOWN" "QSTN"	sets Front High Treble down(2 step) gets Front High Tone ("BxxTxx")	No No	No	No	No	No	No	No	No	No	No	_
"BDOWN" "TUP" "TDOWN" "QSTN" TCT" - Tone(Ce	sets Front High Treble down(2 step) gets Front High Tone ("BxxTxx") enter) Command Center Bass (xx is "A""00""+A"[-100+10 2 step]	No No	No No	No	No	No	No	No	No	No	No	
"BDOWN" "TUP" "TDOWN" "QSTN" "TCT" - Tone(Ce "Bxx" "Txx"	sets Front High Treble down(2 step) gets Front High Tone ("BxxTxx") enter) Command Center Bass (ox is "A*""00""+A"[-100+10 2 step] Center Treble (ox is "A*""00""+A"[-100+10 2 step]	No	No			No No	No No	No No				
"BDOWN" "TUP" "TDOWN" "QSTN" "TCT" - Tone(Ce "Bxx" "Txx" "BUP" "BDOWN"	sets Front High Treble down(2 step) gets Front High Tone ("BxxTxx") enter) Command Center Bass (xx is "-x""0""+A"[-100+10 2 step] Center Treble (xx is "-A""00""+A"[-100+10 2 step] sets Center Bass up(2 step) sets Center Bass down(2 step)	No No No No	No No No No	No No No	No No No	No No No	No No No	No No No	No No No	No No No	No No No	
"BDOWN" "TUP" "TDOWN" "QSTN" "TCT" - Tone(Ce "Bxx" "Txx" "BUP" "BDOWN" "TUP"	sets Front High Treble down(2 step) gets Front High Tone ("Bxx7xx") enter) Command Center Bass (xx is "-x""00""+x"[-100+10 2 step] Center Treble (xx is "-x""00""+x"[-100+10 2 step] sets Center Bass up(2 step) sets Center Bass down(2 step) sets Center Bass (xx is "A""00""+x"[-100+10 2 step] sets Center Bass (xx is "-x""00""+x"[-100+10 2 step] sets Center Bass (xx is "-x""00""+x"[-100+10 2 step]	No No No No No	No No No No No	No No No No	No No No	No No No	No No No	No No No No	No No No No	No No No No	No No No No	
"BDOWN" "TUP" "TDOWN" "QSTN" "QSTN" "TXx" "BUP" "BDOWN" "TUP" "TDOWN" "QSTN"	sets Front High Treble down(2 step) gets Front High Tone ("Bxx7xx") enter) Command Center Bass (xx is "-4""00""+4"[-100+10 2 step] Center Treble (xx is "-4""00""+4"[-100+10 2 step] sets Center Bass up(2 step) sets Center Bass down(2 step) sets Center Treble up(2 step) sets Center Treble up(2 step) sets Center Treble down(2 step) sets Center Treble down(2 step) gets Center Treble down(2 step)	No No No No	No No No No	No No No	No No No No	No No No No	No No No No	No No No	No No No	No No No	No No No	
"BDOWN" "TUP" "TDOWN" "QSTN" TCT" - Tone(Ce "Bxx" "Txx" "BUP" "BDOWN" "TUP" "TDOWN" "QSTN" TSR" - Tone(St	sets Front High Treble down(2 step) gets Front High Tone ("BxxTxx") enter) Command Center Bass (xx is "-A""00""+A"[-100+10 2 step] Center Treble (xx is "-A""00""+A"[-100+10 2 step] sets Center Bass up(2 step) sets Center Bass down(2 step) sets Center Treble down(2 step) gets Center Tone ("BxxTxx") urround) Command	No No No No No No No No	No No No No No No No	No No No No No No	No No No No No No	No No No No No No	No No No No No No	No No No No No No	No No No No No No	No No No No No No	No No No No No No	
"BDOWN" "TUP" "TDOWN" "QSTN" TCT" - Tone(Ce "Bxx" "Txx" "BUP" "BDOWN" "TUP" "TDOWN" "OSTN" TSR" - Tone(St "Txx"	sets Front High Treble down(2 step) gets Front High Tone ("BxxTxx") enter) Command Center Bass (xx is "-A""00""+A"[-100+10 2 step] Center Treble (xx is "-A""00""+A"[-100+10 2 step] sets Center Bass up(2 step) sets Center Bass down(2 step) sets Center Treble down(2 step) sets Center Treble down(2 step) gets Center Treble down(2 step) sets Center Treble down(2 step) sets Center Treble (xx is "-A""00""+A"[-100+10 2 step] urround) Command Surround Bass (xx is "-A""00""+A"[-10+10 2 step] Surround Treble (xx is "-A""00""+A"[-10+10 2 step]	No N	No N	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	
"BDOWN" "TUP" "TDOWN" "QSTN" TCT" - Tone(Ce "Bxx" "Txx" "Txx" "BUP" "BDOWN" "TUP" "TDOWN" "QSTN" TSR" - Tone(St "Bxx" "Txx" "Txx" "FXx" "FXx" "FXx" "BUP"	sets Front High Treble down(2 step) gets Front High Tone ("BxxTxx") enter) Command Center Bass (xx is "-A""00""+A"[-100+10 2 step] Center Treble (xx is "-A""00""+A"[-100+10 2 step] sets Center Bass up(2 step) sets Center Bass up(2 step) sets Center Treble up(2 step) sets Center Treble down(2 step) sets Center Treble down(2 step) gets Cetner Treble down(2 step) sets Center Treble with "GxxTxx") urround Command Surround Bass (xx is "-A""00""+A"[-100+10 2 step] Surround Treble (xx is "-A""0""+A"[-100+10 2 step] sets Surround Bass up(2 step)	No N	No N	No No No No No No No No	No No No No No No No No	No No No No No No No No No	No No No No No No No No No	No No No No No No No No	No No No No No No No No No	No No No No No No No No	No No No No No No No No No	
"BDOWN" "TUP" "TDOWN" "QSTN" "GSTN" TCT" - Tone(Ce "Bxx" "Txx" "BUP" "BDOWN" "TUP" "TDOWN" "QSTN" TSR" - Tone(St "Txx" "Txx"	sets Front High Treble down(2 step) gets Front High Tone ("BxxTxx") enter) Command Center Bass (xx is "-A""00""+A"[-100+10 2 step] Center Treble (xx is "-A""00""+A"[-100+10 2 step] sets Center Bass up(2 step) sets Center Bass down(2 step) sets Center Treble down(2 step) sets Center Treble down(2 step) gets Center Treble down(2 step) sets Center Treble down(2 step) sets Center Treble (xx is "-A""00""+A"[-100+10 2 step] urround) Command Surround Bass (xx is "-A""00""+A"[-10+10 2 step] Surround Treble (xx is "-A""00""+A"[-10+10 2 step]	No N	No N	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	No No No No No No No No	

-	Command Support List											
		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
Code	Means											
	rround Back) Command											
"Bxx" "Txx"	Surround Back Bass (xx is "-A""00""+A"[-100+10 2 step] Surround Back Treble (xx is "-A""00""+A"[-100+10 2 step]	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	H
"BUP"	sets Surround Back Bass up(2 step)	No	No	No	No	No	No	No	No	No	No	
"BDOWN" "TUP"	sets Surround Back Bass down(2 step) sets Surround Back Treble up(2 step)	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"TDOWN"	sets Surround Back Treble down(2 step)	No	No	No	No	No	No	No	No	No	No	
"QSTN"	gets Surround Back Tone ("BxxTxx")	No	No	No	No	No	No	No	No	No	No	L
"Bxx"	Subwoofer Bass (xx is "-A""00""+A"[-100+10 2 step]	No	No	No	No	No	No	No	No	No	No	Т
"BUP"	sets Subwoofer Bass up(2 step) sets Subwoofer Bass down(2 step)	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"BDOWN" "QSTN"	gets Subwoofer Tone ("BxxTxx")	No	No	No	No	No	No	No	No	No	No	H
MP" Phone N	latching Bass Command											
	sets Off	No	No	No	No	No	No	No	No	No	No	Т
"01" "TG"	sets On sets Phase Matching Bass Wrap-Around Up	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	gets Phase Matching Bass	No	No	No	No	No	No	No	No	No	No	
LP" - Sleep Se				Vo.	Voc			V				_
"01"-"5A" "OFF"	sets Sleep Time 1 - 90min (In hexadecimal representation) sets Sleep Time Off	Yes Yes	Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes	\vdash
"UP"	sets Sleep Time Wrap-Around UP	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	gets The Sleep Time Level Calibration Command	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	_
"TEST"	TEST Key	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Γ
"OFF" "CHSEL"	sets TEST TONE OFF CH SEL Key	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	+
"UP"	LEVEL + Key	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	F
	LEVEL – KEY fer (temporary) Level Command	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	_
E"-"000"-"+18"	sets Subwoofer Level -15.0dB - 0.0dB - +12.0dB(0.5dB Step)	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	
F"-"000"-"+0C" -F"-"00"-"+C"	sets Subwoofer Level -15.0dB - 0.0dB - +12.0dB sets Subwoofer Level -15dB - 0dB - +12dB	Yes No	Yes No	Yes No	Yes No	Yes No	No No	No No	No No	No No	No No	F
"UP"	LEVEL + Key	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"DOWN" "QSTN"	LEVEL – KEY gets the Subwoofer Level	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	1
W2" - Subwoo	fer 2 (temporary) Level Command											
	sets Subwoofer 2 Level -15.0dB - 0.0dB - +12.0dB(0.5dB Step) sets Subwoofer Level -15.0dB - 0.0dB - +12.0dB	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	H
-F"-"00"-"+C"	sets Subwoofer 2 Level -15.0dB - 0.0dB - +12.0dB	No	No	No	No	No	No	No	No	No	No	
"UP" "DOWN"	LEVEL + Key	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	\vdash
"QSTN"	LEVEL – KEY gets the Subwoofer Level	No	No No	No No	No No	No	No	No	No	No No	No	L
	emporary) Level Command	No	NI	No.	No.	Ma	V	Van	Ven	Van	Ver	Ξ
8"-"000"-"+18" C"-"000"-"+0C"	sets Center Level -12.0dB - 0.0dB - +12.0dB(0.5dB Step) sets Subwoofer Level -12.0dB - 0.0dB - +12.0dB	No Yes	No Yes	No Yes	No Yes	No Yes	Yes No	Yes No	Yes No	Yes No	Yes No	H
-C"-"00"-"+C"	sets Center Level -12dB - 0dB - +12dB	No	No	No	No	No	No	No	No	No	No	F
"UP" "DOWN"	LEVEL + Key LEVEL – KEY	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	1
"QSTN"	gets the Subwoofer Level ry Channel Level Command	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Г
	Other Ch xxx=-18(-12.0dB)-000(0.0dB)-+18(+12.0dB) for not exist channel is always 000. aaa:Front Left bbb:Front Right ccc:Center ddd:Surround Left							No	No			
eeeπggghhhiijjj	eee:Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left jj:Height 1 Right kkk:Height 2 Left	No	No	No	No	No	No	No	NO	No	No	
	eee:Surround Right fff:Surround Back Left ggg:Surround Back Right hith:Subvoofer 1 iii:Height 1 Left jj:Height 1 Right kkk:Height 2 Left iii:Height2 Right mmm:Subvoofer 2											
"QSTN"	eee:Surround Right fff:Surround Back Left gg;:Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left jjj:Height 1 Right kkk:Height 2 Left lii:Height Right	No	No	No	No	No	No	No	No	No	No No	
"QSTN" IF" - Display Ir "00"	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left jjj:Height 1 Right kkk:Height 2 Left lii:Height 2 Left lii:Height 2 Right fff: ff:Height 2 Right ff:Height 3 R	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN" IF" - Display Ir	eee:Surround Right ff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left iii:Height 1 Left iii:Height 2 Left iii:Height 2 Right hkk:Height 2 Right mmm:Subwoofer 2 gets the Subwoofer Level fformation Command	No	No	No	No	No	No	No	No	No	No	
"QSTN" IF" - Display Ir "00" "01" "02" "03"	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left jjj:Height 1 Right kkk:Height 2 Left lii:Height 2 Right mmm:Subwoofer 2 gets the Subwoofer Level fformation Command Display Porgram Format Display Digital Input Position Display Digital Format Position Display Digital Format Position Display Bost Level	No No No No No	No No No No	No No No No	No No No No	No No No No	No No No No	No No No No No	No No No No	No No No No	No No No No	
"OSTN" IF" - Display II "00" "01" "02" "03" "04"	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 ii:Height 1 Left jj:Height 1 Right kk:Height 2 Left lii:Height 2 Left lii:Height 2 Left lii:Height 2 Left lii:Height 2 Right fromm:Subwoofer 2 gets the Subwoofer Level fformation Command Display Digital Input Position Display Digital Format Position	No No No	No No No No	No No No No	No No No No	No No No	No No No No	No No No	No No No	No No No No	No No No	
"QSTN" IF" - Display Ir "00" "01" "02" "03" "04" IF" - Display N "00"	eee:Surround Right ff:Surround Back Left ggg:Surround Back Right hhrh:Subwoofer 1 iii:Height 1 Left iii:Height 1 Left iii:Height 1 Right kkk:Height 2 Left iii:Height Right kkk:Height 2 Right kkk:Height 2 Right mmrs:Subwoofer 2 gets the Subwoofer Level fformation Command Display Program Format Display Program Format Display Digital Input Position Display Digital Input Position Display Digital Format Position Display Bass Level Display Treble Level Odde Command	No No No No Yes	No No No No No No Yes	No No No No No No Yes	No No No No No Yes	No No No No No No	No No No No No No Yes	No No No No No No Yes	No No No No No No	No No No No No Yes	No No No No No No Yes	
"QSTN" IF" - Display Is "00" "01" "02" "03" "04" IF" - Display Is "00" "01" "	eee-Surround Right fff:Surround Back Left ggg-Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left iii:Height 1 Left iii:Height 2 Left lii:Height 3 Left lii:Height 2 Left lii:Height 3 Left lii:Height 4 Left li	No N	No No No No No No No No	No No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No	No N	No No No No No No No	No N	No No No No No No No	
"QSTN" IF" - Display Ir "00" "01" "02" "03" "04" FF" - Display N "00" "01" "02" "03"	eee-Surround Right fff:Surround Back Left ggg-Surround Back Right hhh:Subvoofer 1 iii:Height I Left iii:Height I Left iii:Height I Right kk:Height J Left iii:Height Z Right iii:Height ii:Height iii:Height iii:Heig	No No No No No No No No Yes Yes Yes	No No No No No No No Yes No Yes Yes	No No No No No No No No Yes No Yes Yes	No No No No No No No Yes Yes Yes	No No No No No No No No Yes Yes	No No No No No No No No Yes Yes Yes	No No No No No No No Yes Yes Yes	No No No No No No No No Yes Yes	No No No No No No No No No Yes No Yes Yes Yes	No No No No No No Yes Yes Yes	
"QSTN" FF" - Display Ir "00" "01" "02" "03" "04" FF" - Display N "00" "01" "02" "03" "70" "70" "70" "70" "70" "70" "70	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left jjj:Height 1 Right kkk:Height 2 Left lii:Height 2 Left lii:Height 2 Left lii:Height 2 Left lii:Height 2 Right lii:Height 2 Right lii:Height 3 Right lii:Height 8 Right lii:Height 9	No No No No No No Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes	No No No No No No No No Yes Yes Yes	No No No No No No No No Yes Yes Yes	No No No No No No No No Yes Yes Yes	No No No No No No No No Yes No Yes Yes	No No No No No No No No No Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes	
"QSTN" F" - Display II "00" "01" "02" "03" "04" "F" - Display II "00" "01" "01" "70" "70" "70" "70" "73" "73" "73" "73	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left jji:Height 1 Right kki:Height 2 Left lii:Height 2 Left lii:Height 2 Left lii:Height 3 Left l	No No No No No No No No Yes Yes Yes	No No No No No No No Yes No Yes Yes	No No No No No No No No Yes No Yes Yes	No No No No No No No Yes Yes Yes	No No No No No No No No Yes Yes	No No No No No No No No Yes Yes Yes	No No No No No No No Yes Yes Yes	No No No No No No No No Yes Yes	No No No No No No No No No Yes No Yes Yes Yes	No No No No No No Yes Yes Yes	
"OSTN" IF" - Display Iv "00" "01" "02" "03" "04" IF" - Display N "00" "01" "02" "03" "TG" "QSTN" Parameter Char IM" - Dimmer I	eee:Surround Right ff:Surround Back Left ggg:Surround Back Right hhrh:Subwoofer 1 iii-Height 1 Left jii-Height 1 Right kKk:Height 2 Left iii-Height Right lii-Height Right kKk:Height 2 Left lii-Height Right kKk:Height 2 Left lii-Height Right kK:Height 2 Left lii-Height Right kK:Height 2 Left lii-Height Right lii-Height Right lii-Height Right lii-Height Right lii-Height lii-	No No No No No No No No Ves Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes	No No No No No No Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes	No No No No No No No Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes	
"OSTN" F" - Display II "00" "01" "02" "03" "04" F" - Display N "00" "01" "02" "03" "TG" "QSTN" Parameter Char M" - Dimmer I	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left jji:Height 1 Right kki:Height 2 Left lii:Height 2 Left lii:Height 2 Left lii:Height 3 Left l	No No No No No No Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes Yes	No No No No No No No No Yes No Yes Yes	No No No No No No No No No Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes Yes	
"QSTN" F" - Display Ir "00" "01" "02" "03" "04" F" - Display N "00" "01" "02" "03" "TG" "0STN" Parameter Char M" - Dimmer I "00" "01" "02"	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hith:Subvoorder 1 iii:Height 1 Left iii:Height 1 Left iii:Height 2 Right iii:Height ii:Height iii:Height ii:Height	No No No No No No No No Yes Yes Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes Yes Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes Yes Yes	No No No No No No No Yes Yes Yes Yes Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes Yes Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes Yes Yes Yes	No No No No No No No Yes Yes Yes Yes Yes Yes Yes	No No No No No No No No No Yes Yes Yes Yes Yes Yes Yes Yes Yes	No No No No No No No No Yes Yes Yes Yes Yes Yes Yes Yes	
"OSTN" F" - Display Is "00" "01" "02" "03" "04" FF" - Display N "00" "01" "02" "03" "TG" "OSTN" Parameter Char M" - Dimmer I "00" "01" "02" "03" "03" "08"	eee:Surround Right ff:Surround Back Left ggg:Surround Back Right hhrh:Subvoorder 1 iii:Height 1 Left iii:Height 1 Left iii:Height 2 Left iii:Height 3 Left iii:Height 4 Left iii:Height 3 Left iii:Height 4 Left i	No No No No No No No No No Yes Yes Yes Yes Yes Yes No	No Yes Yes Yes Yes Yes No	No No No No No No No No No Yes Ves Yes Yes Yes Yos No	No No No No No No No No No Yes Yes Yes Yes Yos No	No No No No No No No No Yes Yes Yes Yes Yes No	No No No No No No No No No Yes Yes Yes Yes Yes Yos No	No No No No No No No No No Yes Yes Yes Yes Yes Yos No	No No No No No No No No Yes Yes Yes Yes Yes No	No No No No No No No No No Yes Yes Yes Yes Yes Yos No	No No No No No No No No No Yes Yes Yes Yes Yes Yes No	
"QSTN" F" - Display II "00" "01" "02" "03" "04" F" - Display N "00" "01" "02" "33" "TG" "05TN" Parameter Char M" - Dimmer "00" "01" "02" "03" "08" "08" "08" "08"	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 lii:Height 1 Left jji:Height 1 Right kkk:Height 2 Left lli:Height 2 Right lli:Height 3 Left lli:Height 4 Left lli:Height 4 Left lli:Height 2 Left lli:Height 3 Left	No No No No No No No No Yes	No No No No No No No Yes Yes Yes Yes No No No Yes Yes Yes Yes No	No No No No No No No No Yes Yes Yes Yes No No No No Yes Yes Yes Yes Yes No	No No No No No No No No Yes Yes Yes Yes No No No No Yes Yes	No No No No No No No No Yes Yes Yes Yes Yos Yes No	No No No No No No No No Yes Yes Yes Yos Yos Yos Yos Yos Yos No Yos No	No No No No No No No Yes Yes Yes Yos Yos No Yes	No No No No No No No No Yes Yes Yes Yes Yos Yes No	No No No No No No No No Yes Yes Yes Yes Yes Yes No	No No No No No No No No No Yes Yes Yes Yes Yes Yes Yes Yes Yes No	
"QSTN" IF" - Display Ir "00" "01" "02" "03" "04" IF" - Display N "00" "01" "02" "03" "TG" "QSTN" Parameter Char M" - Dimmer I "00" "01" "02" "03" "08" "08" "08" "08" "08" "08"	eee-Surround Right Iff-Surround Back Left ggg-Surround Back Right hhrh-Subwoofer 1 iii-Height 1 Left jii-Height 1 Right kkk-Height 2 Left iii-Height 2 Right kkk-Height 2 Left iii-Height 2 Right Moromation Command Display Program Format Display Program Format Display Poigtal Input Position Display Digital Input Position Display Bass Level Display Teble Level Ode Command Sets Selector + Volume Display Mode@1line, Default@2line sets Selector + Usidening Mode Display Mode@1line Display Video Format(temporary display) Display Video Format(temporary display) Display Wideo Format(temporary display) sets Display Mode acter is "UP" Level Command sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright & LED OFF" sets Dimmer Level "Bright & LED OFF" sets Dimmer Level Bright & LED OFF"	No No No No No No No No No Yes Yes Yes Yes Yes Yes No	No Yes Yes Yes Yes Yes No	No No No No No No No No No Yes Ves Yes Yes Yes Yos No	No No No No No No No No No Yes Yes Yes Yes Yos No	No No No No No No No No Yes Yes Yes Yes Yes No	No No No No No No No No No Yes Yes Yes Yes Yes Yos No	No No No No No No No No No Yes Yes Yes Yes Yes Yos No	No No No No No No No No Yes Yes Yes Yes Yes No	No No No No No No No No No Yes Yes Yes Yes Yes Yos No	No No No No No No No No No Yes Yes Yes Yes Yes Yes No	
"QSTN" IF" - Display In "00" "01" "02" "03" "04" IF" - Display N "00" "01" "02" "03" "TG" "QSTN" Parameter Char IM" - Dimmer I "00" "01" "02" "03" "08" "08" "08" "08" "08" "MENU"	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 lii:Height 1 Left jji:Height 1 Right kkk:Height 2 Left lii:Height 2 Left lii:Height 2 Left lii:Height 3 Left lii:Height 3 Left lii:Height 3 Left lii:Height 3 Left lii:Height 4 Left lii:Height 7 Left lii:Height 8 Left l	No Yes	No N	No No No No No No No No No Yes	No No No No No No No No Yes	No N	No No No No No No No No No Yes	No No No No No No No No Yes	No N	No No No No No No No No No Yes	No No No No No No No No Yes	
"OSTN" IF" - Display Is "00" "01" "02" "03" "04" IF" - Display N "00" "01" "02" "03" "03" "05TN" Parameter Char IM" - Dimmer I "02" "03" "01" "02" "03" "08" "01" "08" "08" "08" "08" "08" "08	eee-Surround Right ff:Surround Back Left ggg:Surround Back Right hhrh:Subvoofer 1 iii:Height 1 Left iii:Height 1 Left iii:Height 2 Left iii:Height 2 Left iii:Height 2 Left iii:Height 2 Left iii:Height 3 Left iii:Height 4 Left ii	No Yes	No No No No No No No No No Yes	No No No No No No No No No Yes	No No No No No No No No No Yes	No No No No No No No No No Ves Yes Yes Yes Yes Yes Yes Yes Yes Yes Y	No No No No No No No No No Yes	No No No No No No No No No Yes	No No No No No No No No No Yes	No No No No No No No No No Yes	No No No No No No No No No Yes	
"OSTN" IF" - Display II "00" "01" "02" "03" "04" IF" - Display N "00" "01" "02" "03" "TG" "QSTN" Parameter Char IM" - Dimmer I "00" "01" "02" "03" "08" "08" "08" "08" "08" "08" "08	eee-Surround Right Iff-Surround Back Left ggg-Surround Back Right hhrh-Subwoofer 1 iii-Height 1 Left iii-Height 1 Left iii-Height 2 Left iii-Height 2 Left iii-Height 2 Left iii-Height 2 Left iii-Height 3 Left iii-Height 4 Left iii-Height 4 Left Iii-Height 5 Left Iii-Height 6 Left Ibsplay Togram Format Ibsplay Pogram Format Ibsplay Pogram Format Ibsplay Bass Level Ibsplay Ibsplay Bass Level Ibsplay Ibsplay Bass Level Ibsplay Ibsplay Bass Level Ibsplay Ibsplay Mode Quiline, Default@2line sets Selector + Listening Mode Display Mode@1line Ibsplay Video Format(temporary display) Ibsplay Video Format(temporary display) Ibsplay Video Format(temporary display) sets Display Mode acter is "UP" Level Command sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright & LED OFF"	No No No No No No No No No Yes No Yes	No N	No No No No No No No No No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No No No No No No No No No Yes	No Yes	
"QSTN" F" - Display In "00" "01" "02" "03" "04" F" - Display N "00" "01" "02" "33" "4" "1G" "05TN" Parameter Char M" - Dimmer "00" "01" "02" "03" "08" "08" "08" "08" "08" "08" "08	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 li:Height I Left jj:Height I Right kk:Height I Left jj:Height I Right li:Height Z Left lii:Height Z Right lii:Height Z Left lii:	No No No No No No No No Yes	No No No No No No No No No Yes Ves Yes Yes Yes Yes Yes Yes Yes Yes Yes Y	No No No No No No No No Yes	No No No No No No No Yes	No No No No No No No No No Yes	No No No No No No No Yes	No No No No No No No Yes	No No No No No No No No No Yes	No No No No No No No No Yes	No No No No No No No No Yes	
"OSTN" IF" - Display In "00" "01" "02" "03" "04" IF" - Display N "00" "01" "02" "03" "TG" "GSTN" Parameter Char IM" - Dimmer I "00" "01" "02" "03" "08" "08" "08" "08" "08" "08" "08	eee-Surround Right Iff-Surround Back Left ggg-Surround Back Right hhrh-Subwoofer 1 iii-Height 1 Left iii-Height 1 Left iii-Height 2 Left iii-Height 2 Left iii-Height 2 Left iii-Height 2 Left iii-Height 3 Left iii-Height 4 Left iii-Height 4 Left Iii-Height 5 Left Iii-Height 6 Left Ibsplay Togram Format Ibsplay Pogram Format Ibsplay Pogram Format Ibsplay Bass Level Ibsplay Ibsplay Bass Level Ibsplay Ibsplay Bass Level Ibsplay Ibsplay Bass Level Ibsplay Ibsplay Mode Quiline, Default@2line sets Selector + Listening Mode Display Mode@1line Ibsplay Video Format(temporary display) Ibsplay Video Format(temporary display) Ibsplay Video Format(temporary display) sets Display Mode acter is "UP" Level Command sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright" sets Dimmer Level "Bright & LED OFF"	No No No No No No No No No Yes No Yes	No N	No No No No No No No No No Yes	No Yes	No Yes	No No No No No No No No Yes	No No No No No No No No No Yes	No Yes	No No No No No No No No No Yes	No Yes	
IF" - Display Is "00" "01" "02" "03" "04" IF" - Display N "00" "01" "02" "03" "TG" "STN" Parameter Char IM" - Dimmer Is "00" "01" "02" "03" "08" "08" "08" "O8" "ENTR" "ENTER" "ENTER" "ENTER" "ENTER" "AUDIO"	eee:Surround Right ff:Surround Back Left ggg:Surround Back Right hhh:Subwoofer 1 iii-Height 1 Left jii-Height 1 Right kKk:Height 2 Left iii-Height Right kKk:Height Right kK:Height kK	No N	No N	No Yes	No N	No N	No N	No No No No No No No No No Yes	No N	No Yes	No No No No No No No No No Yes	
"QSTN" IF" - Display Ir "00" "01" "02" "03" "04" IF" - Display N "00" "01" "02" "03" "TG" "0STN" Parameter Char IM" - Dimmer I "00" "011" "02" "03" "08" "08" "08" "08" "08" "08" "08	eee-Surround Right fff:Surround Back Left ggg:Surround Back Right hith:Subvoorder 1 iii:Height 1 Left iii:Height 1 Left iii:Height 2 Left iii:Height 3 Left iii:Height 4 Left	No No No No No No No No No Yes	No N	No No No No No No No No No Yes	No No No No No No No No No Yes	No Yes	No No No No No No No No Yes	No No No No No No No No No Yes	No Yes	No No No No No No No No No Yes	No Yes	

<u>wam-related</u>	Command Support List											
		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
Code	Means											
	stores memory recalls memory	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"LOCK"	locks memory unlocks memory	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"RST" - Reset Co		165	103	165	163	165	168	168	103	163	165	
	Reset All Dimation Command	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	Infomation of Audio(Same Immediate Display ',' is separator of											
"aa,bb,cc,dd ,ee,ff,"	infomations) ae. Audio Input Port bb. Input Signal Format cc. Sampling Frequency dd. Input Signal Channel ee.: Listening Mode	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"aa,bb,cc,dd ,ee,ff,gg,h h,il,jj"	Infomation of Audio(Same Immediate Display ',' is separator of infomations) aa. Audio Input Port bb. Input Signal Format cc. Sampling Frequency dd. Input Signal Channel ee. Listening Mode ff. Output Signal Channel gg. Output Signal Channel	No	No	No	No	No	No	No	No	No	No	
"QSTN"	gets Information of Audio 702", receiver will return this response.	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"IFV" - Video Info "aa,bb,cc,dd ,ee,ff,gg,hh,ii,"	mation Command infomation of Video(Same Immediate Display ',' is separator of infomations) aa. video Input Port bb. Input Resolution, Frame Rate cc. RGB/YCbCr dd. Color Depth ee. Video Output Port ff. Output Resolution, Frame Rate gg. RGB/YCbCr hh. Color Depth hh. Color Depth	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	gets Infomation of Video 703", receiver will return this response.	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"FLD" - FL Displa	ay Infomation Command											
	FL Display Information Character Code for FL Display (UTF-8 encoded)	No	No	No	No	No	No	No	No	No	No	
"QSTN" "SLI" - Input Sele	gets FL Display Information	No	No	No	No	No	No	No	No	No	No	
	sets VIDEO1 VCR/DVR STB/DVR	No	No	No	No	No	No	No	No	No	No	
	sets VIDEO2 CBL/SAT	Yes Yes	Yes	Yes	Yes Yes							
	sets VIDEO3 GAME/TV GAME GAME1 sets VIDEO4 AUX1(AUX)	Yes	Yes Yes	Yes Yes	Yes							
"04" "05"	sets VIDEO5 AUX2 GAME2	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	
	sets VIDEO6 PC sets VIDEO7	No	No	No	No	No	No	No	No	No	No	
	Hidden1 EXTRA1 Hidden2 EXTRA2	No No	Yes Yes	No No	No No	Yes Yes	No No	No No	Yes Yes	No No	Yes Yes	
"09"	Hidden3 EXTRA3	No	Yes	No	No	Yes	No	No	Yes	No	Yes	
	sets DVD BD/DVD sets STRM BOX	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"12"	sets TV	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	sets TAPE(1) TV/TAPE sets TAPE2	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"22"	sets PHONO	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	sets CD TV/CD sets FM	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"25"	sets AM	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	sets TUNER sets MUSIC SERVER P4S DLNA*2	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	
	sets INTERNET RADIO iRadio Favorite*3 sets USB/USB(Front)	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	
"2A"	sets USB(Rear)	No	No	No	No	No	No	No	No	No	No	
	sets NETWORK NET sets USB(toggle)	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"2D"	sets Aiplay	No	No	No	No	No	No	No	No	No	No	
	sets Bluetooth sets Universal PORT	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	No No	Yes No	No No	
"30"	sets MULTI CH	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"32"	sets XM*1 sets SIRIUS*1	No	No	No	No	No	No	No	No	No	No	
"33"	sets DAB *5 sets HDMI 5	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"56"	sets HDMI 6	No	No	No	No	No	No	No	No	No	No	
	sets HDMI 7 sets Selector Position Wrap-Around Up	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	
"DOWN"	sets Selector Position Wrap-Around Down	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"QSTN" *1:Only available XI	gets The Selector Position WSIRIUS Model	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
6:Only AE Model(T	X-NR515AE/616AE/818AE)											
	Selector Command sets VIDEO1	No	No	No	No	No	No	No	No	No	No	
"01"	sets VIDEO2	No	No	No	No	No	No	No	No	No	No	
"03"	sets VIDEO3 sets VIDEO4	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"04"	sets VIDEO5	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"06"	sets VIDEO6 sets VIDEO7	No	No	No	No	No	No	No	No	No	No	
	sets DVD sets TAPE(1)	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"21"	sets TAPE2	No	No	No	No	No	No	No	No	No	No	
"22"	sets PHONO	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"23"	sets CD sets FM	No	No	No	No	No	No	No	No	No	No	
				84.5	No							
"25"	sets AM	No No	No No	No No		No No	No No	No No	No No	No No	No No	
"25" "26" "27"	sets AM sets TUNER sets MUSIC SERVER	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"25" "26" "27" "28"	sets AM sets TUNER	No	No	No	No	No	No	No	No	No	No	

		TX-NR555	DRX-2	TX-NR656	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
		(Ether)		(Ether)								
Code "7F"	Means sets OFF	No	No	No	No							
"80" "QSTN"	sets SOURCE gets The Selector Position	No No	No No	No No	No No	F						
1:REC/ZONE3	Selector Command							· · · · · ·				
"00"	sets AUTO	No	No	No	No							
"01" "02"	sets MULTI-CHANNEL sets ANALOG	No Yes	No Yes	No Yes	No Yes							
"03" "04"	sets iLINK sets HDMI	No Yes	No Yes	No Yes	No Yes							
"05" "06"	sets COAX/OPT sets BALANCE	Yes No	Yes No	Yes No	Yes No	\vdash						
"07"	sets ARC sets None	Yes	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	
"UP"	sets Audio Selector Wrap-Around Up	Yes	Yes	Yes	Yes							
"QSTN" "GA" - 12V Tri	gets The Audio Selector Status gger A Command	Yes	Yes	Yes	Yes							
"00" "01"	sets 12V Trigger A Off sets 12V Trigger A On	No No	No No	No No	No No	H						
"00" "01"	sets 12V Trigger A Off sets 12V Trigger A On	No No	Yes Yes	No No	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"QSTN"	gets 12V Trigger A Status	No	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"00"	gger B Command sets 12V Trigger B Off	No	No	No	No	Τ						
"01" "00"	sets 12V Trigger B On sets 12V Trigger B Off	No No	No Yes	No No	No No	No Yes	No No	No No	No Yes	No No	No Yes	F
"01"	sets 12V Trigger B On gets 12V Trigger B Status	No No	Yes	No No	No No	Yes	No No	No No	Yes	No No	Yes	F
	gger C Command		Yes									_
"00" "01"	sets 12V Trigger C Off sets 12V Trigger C On	No No	No No	No No	No No	F						
"00" "01"	sets 12V Trigger C Off sets 12V Trigger C On	No No	Yes Yes	No No	No No	Yes Yes	No No	No No	Yes Yes	No No	Yes Yes	F
"QSTN"	gets 12V Trigger C Status	No	Yes	No	No	Yes	No	No	Yes	No	Yes	L
OS" - Video (e available,when each 12V Trigger parameter is all "OFF" at Setup Ment Output Selector (Japanese Model Only)						,			,		_
"00" "01"	sets D4 sets Component	No No	No No	No No	No No	F						
"QSTN"	gets The Selector Position Dutput Selector	No	No	No	No	Г						
"00"	sets No Analog	No No	No No	No	No	No Yes	No	No Voc	No	No	No	
"01" "02"	sets Yes/Out Main HDMI Main HDMI sets Out Sub HDMI Sub HDBaseT	No	No	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes	
"03" "04"	sets Both Main+Sub sets Both(Main)	No No	No No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	H
"05" "UP"	sets Both(Sub) sets HDMI Out Selector Wrap-Around Up	No No	No No	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	F
"QSTN" except Americal	gets The HDMI Out Selector	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	L
IAO" -HDMI A	udio Out (Main)		V		V	V.			V.	· ·	V.	_
"00" "01"	sets Off sets On	Yes	Yes	Yes	Yes	Yes	Yes	Yes Yes	Yes	Yes	Yes	
"02" "UP"	sets Auto sets HDMI Audio Out Wrap-Around Up	Yes Yes	Yes Yes	Yes Yes	Yes Yes	F						
"QSTN" IAS" -HDMI A	gets HDMI Audio Out udio Out (Sub)	Yes	Yes	Yes	Yes							
"00" "01"	sets Off sets On	No No	No No	No No	No No	F						
"UP"	sets HDMI Audio Out Wrap-Around Up	No	No	No	No	Ļ						
"QSTN" EC" - HDMI C		No	No	No	No	_						
"00" "01"	sets Off sets On	Yes Yes	Yes Yes	Yes Yes	Yes Yes	F						
"UP" "QSTN"	sets HDMI CEC Wrap-Around Up gets HDMI CEC	Yes Yes	Yes Yes	Yes Yes	Yes Yes	F						
CM" - HDMI C	EC Control Monitor											Ė
"01" "02"	sets Main sets Zone2	No No	No No	No No	No No							
"10" "UP"	sets Sub sets Control Monitor Wrap-Around Up	No No	No No	No No	No No	\vdash						
"QSTN" RES" - Monito	gets Control Monitor r Out Resolution	No	No	No	No							
"00" "01"	sets Through	Yes Yes	Yes Yes	Yes Yes	Yes Yes	F						
"02"	sets Auto(HDMI Output Only) sets 480p	No	No	No	No	t						
"03" "13"	sets 720p sets 1680x720p	No No	No No	No No	No No	H						
"04" "05"	sets 1080i sets 1080p(HDMI Output Only)	No No	No No	No No	No No	F						
"07" "15"	sets 1080p/24fs(HDMI Output Only) sets 2560x1080p	No No	No No	No No	No No	L						
"08"	sets 4K Upcaling(HDMI Output Only) 4K(HDMI Output Only)	No	No	No	No	L						
"06" "UP"	sets Source sets Monitor Out Resolution Wrap-Around Up	No Yes	No Yes	No Yes	No Yes	L						
"QSTN" PR" - Super R	gets The Monitor Out Resolution Resolution	Yes	Yes	Yes	Yes	_						
"00"-"03" "UP"	sets Super Resolution sets Super Resolution Wrap-Around Up	No No	No No	No No	No No							
"DOWN"	sets Super Resolution Wrap-Around DOWN	No	No	No	No	H						
"QSTN"	gets The Super Resolution State	No	No	No	No							
	sets HDMI Information	No	Nia.	No.	Ma	NI.	Ni.	Ma	No	NI.	NI.	Г
ab	a:HDMI Out MAIN 1:for Main Zone b:HDMI Out SUB 0:None,1:for Main Zone,2:for Zone 2		No	No	No	No	No	No		No	No	L
"QSTN" F" - ISF Mode	gets The HDMI Out Information State	No	No	No	No							
"00" "01"	sets ISF Mode Custom sets ISF Mode Day	No No	No No	No No	No No	F						
"02" "UP"	sets ISF Mode Night sets ISF Mode State Wrap-Around Up	No No	No	No	No	No No	No No	No No	No No	No No	No No	L
"QSTN"	gets The ISF Mode State	No No	No No	No No	No No							
/M/M" - Vidoo	Wide Mode											
"00"	sets Auto	No	No	No	No							

		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5
Code	Means										
"03"	sets Zoom sets Wide Zoom	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No
"05"	sets Smart Zoom	No	No	No	No	No	No	No	No	No	No
"UP"	sets Video Zoom Mode Wrap-Around Up	No	No	No	No	No	No	No	No	No	No
"QSTN"	gets Video Zoom Mode Picture Mode	No	No	No	No	No	No	No	No	No	No
"00"	sets Through Standard	No	No	No	No	No	No	No	No	No	No
"01"	sets Custom sets Cinema	No	No	No	No	No	No	No	No	No	No
"02"		No	No	No	No	No	No	No	No	No	No
"03"	sets Game sets ISF Day	No	No	No	No	No	No	No	No	No	No
"05"		No	No	No	No	No	No	No	No	No	No
"06"	sets ISF Night	No	No	No	No	No	No	No	No	No	No
"07"	sets Streaming	No	No	No	No	No	No	No	No	No	No
"08"	sets Direct Bypass	No	No	No	No	No	No	No	No	No	No
"UP"	sets Video Zoom Mode Wrap-Around Up gets Video Zoom Mode	No	No	No	No	No	No	No	No	No	No
"QSTN"		No	No	No	No	No	No	No	No	No	No
D" - Listeni "00"	ng Mode Command sets STEREO	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"01"	sets DIRECT	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"02"	sets SURROUND	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"03"	sets FILM Game-RPG	Yes	Yes	Yes	Yes	Yes	Yes Yes	Yes Yes	Yes	Yes	Yes
"04"	sets THX sets ACTION Game-Action	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"06"	sets MUSICAL Game-Rock sets MONO MOVIE	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"07"		No	No	No	No	No	No	No	No	No	No
"08"	sets ORCHESTRA	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"09"	sets UNPLUGGED	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"0A"	sets STUDIO-MIX	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"0B"	sets TV LOGIC	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"0C"	sets ALL CH STEREO sets THEATER-DIMENSIONAL	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"0E"	sets ENHANCED 7/ENHANCE Game-Sports	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"0F"	sets MONO	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"11"	sets PURE AUDIO	Yes*3	No	Yes*3	Yes*3	No	Yes*3	Yes*3	No	Yes	No
"12"	sets MULTIPLEX sets FULL MONO	No	No	No	No	No	No	No	No	No	No
"13"		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"14"	sets DOLBY VIRTUAL sets DTS Surround Sensation	No	No	No	No	No	No	No	No	No	No
"15"		No	No	No	No	No	No	No	No	No	No
"16"	sets Audyssey DSX	No	No	No	No	No	No	No	No	No	No
"1F"	sets Whole House Mode	No	No	No	No	No	No	No	No	Yes	Yes
"23"	sets Stage (when Genre Control is Enable in Japan Model)	No	No	No	No	No	No	No	No	No	No
"25"	sets Action (when Genre Control is Enable in Japan Model) sets Music (when Genre Contorl is Enable in Japan Model)	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No
"2E"	sets Sports (when Genre Control is Enable in Japan Model) sets 5.1ch Surround	No	No	No	No	No	No	No	No	No	No
"40"		No	No	No	No	No	No	No	No	No	No
"40" "41"	sets Straight Decode*1 sets Dolby EX/DTS ES	Yes	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No
"41"	sets Dolby EX*2	No	No	No	No	No	No	No	No	No	No
"42"	sets THX Cinema	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"43"	sets THX Surround EX sets THX Music	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"44"		No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"45"	sets THX Games	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"50"	sets THX U2/S2/I/S Cinema/Cinema2	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"51"	sets THX MusicMode,THX U2/S2/I/S Music	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"52" "80"	sets THX Games Mode,THX U2/S2/I/S Games sets PLII/PLIIx Movie Dolby Atmos/Dolby Surround	No Yes	No Yes	No Yes	No Yes	No Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes
"81"	sets PLII/PLIIx Music sets Neo:6 Cinema/Neo:X Cinema DTS:X/Neural:X	No	No	No	No	No	No	No	No	No	No
"82"		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"83"	sets Neo:6 Music/Neo:X Music sets PLII/PLIIx THX Cinema Dolby Surround THX Cinema	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"84"		No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"85"	sets Neo:6/Neo:X THX Cinema DTS Neural:X THX Cinema sets PLII/PLIIx Game	No No	No No	No No	No No	No No	Yes No	Yes No	Yes No	Yes No	Yes No
"87"	sets Neural Surr*3	No	No	No	No	No	No	No	No	No	No
"88"	sets Neural THX/Neural Surround sets PLII/PLIIx THX Games Dolby Surround THX Games	No No	No No	No No	No No	No No	No Yes	No Yes	No Yes	No Yes	No Yes
"8A"	sets Neo:6/Neo:X THX Games DTS Neural:X THX Games sets PLII/PLIIX THX Music Dolby Surround THX Music	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"8B"		No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"8C"	sets Neo:6/Neo:X THX Music DTS Neural:X THX Music sets Neural THX Cinema	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
"8D"		No	No	No	No	No	No	No	No	No	No
"8E"	sets Neural THX Music	No	No	No	No	No	No	No	No	No	No
"8F"	sets Neural THX Games	No	No	No	No	No	No	No	No	No	No
"90"	sets PLIIz Height	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No
"92"	sets Neo:6 Cinema DTS Surround Sensation sets Neo:6 Music DTS Surround Sensation	No	No	No	No	No	No	No	No	No	No
"93"	sets Neural Digital Music	No	No	No	No	No	No	No	No	No	No
"94"	sets PLIIz Height + THX Cinema	No	No	No	No	No	No	No	No	No	No
"95"	sets PLIIz Height + THX Music sets PLIIz Height + THX Games	No	No	No	No	No	No	No	No	No	No
"96"		No	No	No	No	No	No	No	No	No	No
"97"	sets PLIIz Height + THX U2/S2 Cinema	No	No	No	No	No	No	No	No	No	No
"98"	sets PLIIz Height + THX U2/S2 Music	No	No	No	No	No	No	No	No	No	No
"99"	sets PLIIz Height + THX U2/S2 Games sets Neo:X Game	No	No	No	No	No	No	No	No	No	No
"9A"		No	No	No	No	No	No	No	No	No	No
"A0"	sets PLIIx/PLII Movie + Audyssey DSX	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No
"A1" "A2"	sets PLIIx/PLII Music + Audyssey DSX sets PLIIx/PLII Game + Audyssey DSX	No	No	No	No	No	No	No	No	No	No
"A3"	sets Neo:6 Cinema + Audyssey DSX	No	No	No	No	No	No	No	No	No	No
"A4"	sets Neo:6 Music + Audyssey DSX	No	No	No	No	No	No	No	No	No	No
"A5"	sets Neural Surround + Audyssey DSX sets Neural Digital Music + Audyssey DSX	No	No	No	No	No	No	No	No	No	No
"A6"		No	No	No	No	No	No	No	No	No	No
"A7"	sets Dolby EX + Audyssey DSX	No	No	No	No	No	No	No	No	No	No
"FF"	sets Auto Surround	No	No	No	No	No	No	No	No	No	No
"UP"	sets Listening Mode Wrap-Around Up	Yes	Yes	Yes	Yes	Yes	Yes Yes	Yes	Yes	Yes	Yes
'DOWN" 'MOVIE"	sets Listening Mode Wrap-Around Down sets Listening Mode Wrap-Around Up	Yes	Yes	Yes Yes	Yes Yes	Yes	Yes	Yes	Yes	Yes Yes	Yes Yes
"MUSIC"	sets Listening Mode Wrap-Around Up sets Listening Mode Wrap-Around Up	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"GAME"		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
"THX"	sets Listening Mode Wrap-Around Up	No	No	No	No	No	No	No	No	No	No
"AUTO"	sets Listening Mode Wrap-Around Up	No	No	No	No	No	No	No	No	No	No
"SURR"	sets Listening Mode Wrap-Around Up sets Listening Mode Wrap-Around Up	No	No	No	No	No	No	No	No	No	No
STEREO"		No	No	No	No	No	No	No	No	No	No
"QSTN"	gets The Listening Mode -SR805:Dolby Digital/DTS/AAC/DTS-ES/DTS 96/24/Dolby Digital Plus.	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
wei man iX	-SR805:Dolby Digital/DTS/AAC/DTS-ES/DTS 96/24/Dolby Digital Plus -SR805:if you want to change Listening Mode to DTS-ES,please use p										

Main-related	Command Support List											
		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
Code	Means sets Late Night Low@DolbyDigital,On@Dolby TrueHD	Var	Voc	Voc	Voc	Yes	Yes	Voc	Voc	Voc	Voc	
"01" "02"	sets Late Night High@DolbyDigital,(On@Dolby TrueHD)	Yes No	Yes No	Yes No	Yes No	No	No	Yes No	Yes No	Yes No	Yes No	
"03" "UP"	sets Late Night Auto@Dolby TrueHD sets Late Night State Wrap-Around Up	Yes Yes	Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"QSTN"	gets The Late Night Level	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"00"	sets Both Off	No No	No	No	No No	No No	No No	No No	No No	No No	No	
"01" "02"	sets Re-EQ On sets Academy On	No	No No	No No	No	No	No	No	No	No	No No	
"UP" "QSTN"	sets Re-EQ/Academy State Wrap-Around Up gets The Re-EQ/Academy State	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"RAS" - Re-EQ (sets Re-EQ Off	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	
"01"	sets Re-EQ On	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	
"UP" "QSTN"	sets Re-EQ State Wrap-Around Up gets The Re-EQ State	No No	No No	No No	No No	No No	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"RAS" - Cinema	Filter Command sets Cinema Filter Off	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No	
"01" "UP"	sets Cinema Filter On sets Cinema Filter State Wrap-Around Up	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	No No	No No	No No	No No	No No	
"QSTN"	gets The Cinema Filter State	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No	
"ADY" - Audyss "00"	ey 2EQ/MultEQ/MultEQ XT sets Audyssey 2EQ/MultEQ/MultEQ XT Off	No	No	No	No	No	No	No	No	No	No	
"01" "02"	sets Audyssey 2EQ/MultEQ/MultEQ XT On/Movie sets Audyssey 2EQ/MultEQ/MultEQ XT Music	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"UP"	sets Audyssey 2EQ/MultEQ/MultEQ XT State Wrap-Around Up	No	No	No	No	No	No	No	No	No	No	
"QSTN" "ADQ" - Audyss		No	No	No	No	No	No	No	No	No	No	
"00" "01"	sets Audyssey Dynamic EQ Off sets Audyssey Dynamic EQ On	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"UP" "QSTN"	sets Audyssey Dynamic EQ State Wrap-Around Up	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"ADV" - Audyss	gets The Audyssey Dynamic EQ State ey Dynamic Volume											
"00" "01"	sets Audyssey Dynamic Volume Off sets Audyssey Dynamic Volume Light	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"02" "03"	sets Audyssey Dynamic Volume Medium sets Audyssey Dynamic Volume Heavy	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"UP"	sets Audyssey Dynamic Volume State Wrap-Around Up	No	No	No	No	No	No	No	No	No	No	
"QSTN" "DVL" - Dolby V	gets The Audyssey Dynamic Volume State	No	No	No	No	No	No	No	No	No	No	
"00" "01"	sets Dolby Volume Off sets Dolby Volume Low/On	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"02"	sets Dolby Volume Mid	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"03" "UP"	sets Dolby Volume High sets Dolby Volume State Wrap-Around Up	No	No	No	No	No	No	No	No	No	No	
"QSTN" "AEQ" - AccuEC	gets The Dolby Volume State	No	No	No	No	No	No	No	No	No	No	
"00" "01"	sets AccuEQ Off sets AccuEQ On On(All Ch)	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"02"	sets AccuEQ On(ex. Front L/R)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"UP" "QSTN"	sets AccuEQ State Wrap-Around Up gets The AccuEQ State	Yes Yes	Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"MCM" - MCACO	sets MCACC MEMORY 1	No	No	No	No	No	No	No	No	No	No	
"02" "03"	sets MCACC MEMORY 2 sets MCACC MEMORY 3	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"04"	sets MCACC MEMORY 4	No	No	No	No	No	No	No	No	No	No	
"05" "06"	sets MCACC MEMORY 5 sets MCACC MEMORY 6	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"UP" "DOWN"	sets MCACC MEMORY Wrap-Around Up sets MCACC MEMORY Wrap-Around Down	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	gets The MCACC MEMORY	No	No	No	No	No	No	No	No	No	No	
"00"	Standing Wave / Standing Wave sets Standing Wave Off	No	No	No	No	No	No	No	No	No	No	
"01" "UP"	sets Standing Wave On sets Standing Wave Wrap-Around Up	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN" "PCT" - Phase C	gets The Standing Wave	No	No	No	No	No	No	No	No	No	No	
"00"	sets Phase Control Off	No	No	No	No	No	No	No	No	No	No	
"01" "02"	sets Phase Control On sets Full Band Phase Control On	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"UP" "QSTN"	sets Phase Control Wrap-Around Up gets The Phase Control	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"PCP" - Phase C	ontrol Plus											
"00"-"10" "AT"	sets Phase Control Plus 0msec - 16msec sets Auto Phase Control Plus	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"UP" "DOWN"	sets Phase Control Plus Up sets Phase Control Plus Down	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	gets The Phase Control Plus el / LFE Mute Level	No	No	No	No	No	No	No	No	No	No	
LIL - LIL LEV	sets LFE Mute Level											
	00:0dB 01:-1dB											
	02:-2dB 03:-3dB											
xx	04:-4dB 05:-5dB	No	No	No	No	No	No	No	No	No	No	
	0A:-10dB 0F:-15dB											
	14:-20dB											
"UP"	FF:-oodB sets LFE Mute Level Up	No	No	No	No	No	No	No	No	No	No	
"DOWN" "QSTN"	sets LFE Mute Level Down gets The LFE Mute Level	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"ACE" - All Char												
	xxx=-18(-12.0dB)~000(0.0dB)~+18(+12.0dB)											
	aaa:63Hz											
hhooddd fffr	bbb:125Hz ccc:250Hz	No	No	No	No	No	No	No	No	No	No	ĺ
bbcccdddeeefffggg	ddd:500Hz eee:1kHz	140	140	140	140	140	140	140	140	140	140	ĺ
	ffi:2kHz ggg:4kHz											
	hhh:8kHz											
	iii:16kHz						L			L		

Main-related	Command Support List											
		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
		. ,		, ,								
Code "QSTN"	Means gets The Phase Control	No	No	No	No	No	No	No	No	No	No	
"MCC" - MCACC	Calibration	No	No	No	No	No	No	No	No	No	No	
"00" "01"	not complete MCACC calibration complete MCACC calibration	No	No	No	No	No	No	No	No	No	No	
"QSTN" "MFB" - Fullbane	gets The MCACC calibration d MCACC Calibration	No	No	No	No	No	No	No	No	No	No	
"00"	not complete Fullband MCACC calibration or not have Fullband MCACC function	No	No	No	No	No	No	No	No	No	No	
"01" "QSTN"	complete Fullband MCACC calibration gets The Fullband MCACC calibration	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"MOT" - Music C	Optimizer / Sound Retriever											
"00" "01"	sets Music Optimizer Off sets Music Optimizer On	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"UP" "QSTN"	sets Music Optimizer State Wrap-Around Up gets The Music Optimizer State	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"AVS" - A/V Syn												
"snnn"	sets AV Sync s: sign ("+" or "-" or "0") If set minus value, s="-". (only HDMI Lipsync is available) If set plus value, s="h-" If set zero value, s="0" nn: value; If set 100msec, nnn="100"	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"UP"	sets A/V Sync is increased (step is depend on model)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"DOWN" "QSTN"	sets A/V Sync is decreased (step is depend on model) gets A/V Sync Value	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"ASC" - Audio S	sets Audio Scalar Auto	No	No	No	No	No	No	No	No	No	No	
"01" "UP"	sets Audio Scalar Manual sets Audio Scalar Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN" "UPS" - Upsamp	gets The Audio Scalar State	No	No	No	No	No	No	No	No	No	No	
"00"	sets Upsampling x1	No	No	No	No	No	No	No	No	No	No	
"01" "02"	sets Upsampling x2 sets Upsampling x4	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"UP" "QSTN"	sets Upsampling Wrap-Around gets The Upscaling State	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"HBT" - Hi-Bit "00"	sets Hi-Bit Off	No	No	No	No	No	No	No	No	No	No	
"01" "UP"	sets Hi-Bit On	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	sets Hi-Bit Wrap-Around Up gets The Hi-Bit State	No	No	No	No	No	No	No	No	No	No	
"DGF" - Digital F	sets Digital Filter Slow	No	No	No	No	No	No	No	No	No	No	
"01" "UP"	sets Digital Filter Sharp sets Digital Filter Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	gets The Digital Filter State Centered Dialog / Dialog Enahncement	No	No	No	No	No	No	No	No	No	No	
"00"	sets Dialog Enhancement Off	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"01" "02"-"05"	sets Dialog Enhancement On sets Dialog Enahncement UP1-UP4	No	No	No	No	No	No	No	No	No	No	
"UP" "QSTN"	sets Dialog Enhancement Wrap-Around gets The Dialog Enhancement State	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"CTS" - Cener S	pread for Dolby Surround sets Center Spread Off	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"01" "TG"	sets Center Spread On sets Center Spread Wrap-Around	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"QSTN"	gets The Center Spread State	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"00"	ma for PLII Music sets Panorama Off	No	No	No	No	No	No	No	No	No	No	
"01" "TG"	sets Panorama On sets Panorama Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN" "DMS" - Dimens	gets The Panorama State ion for PLII Music	No	No	No	No	No	No	No	No	No	No	
"-3"~"00"~"+3" "UP"	sets Dimension	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"DOWN"	sets Dimension Up sets Dimension Down	No	No	No	No	No	No	No	No	No	No	
	gets The Dimension State Width for PLII Music	No	No	No	No	No	No	No	No	No	No	
"00"~"07" "UP"	sets Center Width sets Center Width Up	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"DOWN" "QSTN"	sets Center Width Down gets The Center Width State	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"CTI" - Center In	nage for Neo:6 Music	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	<u> </u>
"00"~"0A" "UP"	sets Center Image sets Center Image Up	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"DOWN" "QSTN"	sets Center Image Down gets The Center Image State	No No	No No	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"DLC" - Dialog C	Control sets Dialog Control	No	No	No	No	No	No	No	No	No	No	
"UP" "DOWN"	sets Dialog Control Up sets Dialog Control Down	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN" "SPI" - Speaker	gets The Dialog Control State	No	No	No	No	No	No	No	No	No	No	
ori - opeaker	sets Speaker Information											
abcdefghhhijk	a:Subwoofer 0:No,1:Yes/1ch,2:2ch b:Front 1:Small,2:Large c:Center 0:None,1:Small,2:Lage d:Surround 0:None,1:Small,2:Lage e:Surround Back 0:None,1:Small,2:Lage f:Height 1 0:None,1:Small,2:Lage g:Height 2 0:None,1:Small,2:Lage hthi:Crossover 50,80,100,150,200 i:Height 1 Position 0:No,1:FH,2:TF,3:TM,4:TR,5:RH,6:DD SP(F),7:DD SP(S),8:DD SP(B) j:Height 2 Position 0:No,1:FH,2:TF,3:TM,4:TR,5:RH,6:DD SP(F),7:DD SP(S),8:DD SP(B) i:Height 0:No,1:F,3:F+C,5:F+S,6:C+S,7:F+C+S	No	No	No	No	No	No	No	No	No	No	
	1											
"QSTN"	gets The Speaker Information	No	No	No	No	No	No	No	No	No	No	

	Command Support List											
		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
Code	Means											
	sets Speaker Distance xxx=001-384 (0.01m - 9.00m unit is meters) xxx=001-12C (0.1ft - 30.0ft unit is feet) xxx=001-2D0 (0'0-1/2' - 30'0' unit is feet/inch) for not exist channel is always 000.											
	M:MCACC Memory 1-6 u:Unit 0:feet,1:meters,2:feet/inch aaa:Front Left bbb:Front Right	No	No	No	No	No	No	No	No	No	No	
	cccCenter dddcSurround Left eee:Surround Right fff:Surround Back Left ggg;Surround Back Right hhh:Subwoofer 1 iii:Height 1 Left jjj:Height 1 Right kkk:Height 2 Left lii:Height Right	No	No	No	No	No	No	No	NO	No	No	
	mmm:Subwoofer 2 gets the Speaker Distance	No	No	No	No	No	No	No	No	No	No	
"DMN" - Input Ch	nannel (Multiplex) / Dual Mono											
	sets DUAL MONO MAIN sets DUAL MONO SUB	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
	sets DUAL MONO MAIN+SUB sets Panorama Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	gets The Panorama State	No	No	No	No	No	No	No	No	No	No	
"LDM" - Loudnes "00"	ss Management sets Loudness Management Off	No	No	No	No	No	No	No	No	No	No	
"01"	sets Loudness management On	No	No	No	No	No	No	No	No	No	No	
"QSTN"	sets Panorama Wrap-Around gets The Panorama State	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"ITV" - IntelliVolu	ime / Input Level Absorber											
"-18"-"00"-"+18" "UP"	sets IntelliVolume -12.0dB~0dB~+12.0dB(0.5dB Step) sets IntelliVolume Up	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
	sets IntelliVolume Down	No	No	No	No	No	No	No	No	No	No	
	gets The IntelliVolume State ector Rename / Input Function Rename	No	No	No	No	No	No	No	No	No	No	
	sets Input Selector Name (10 characters) ii: Selector Number (the same as for SLI command) xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx	No	No	No	No	No	No	No	No	No	No	
"00"	sets PCM Fixed Mode Off	No	No	No	No	No	No	No	No	No	No	
"01" "UP"	sets PCM Fixed Mode On sets PCM Fixed Mode Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	gets The PCM Fixed Mode State	No	No	No	No	No	No	No	No	No	No	
"HST" - HDMI Sta	andby Through sets HDMI Standby Through xx=SLI Number	No	No	No	No	No	No	No	No	No	No	
"OFF"	sets HDMI Standby Through Off	No	No	No	No	No	No	No	No	No	No	
"LAST" "AT"	sets HDMI Standby Through Last sets HDMI Standby Throguh Auto	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"ATE"	sets HDMI Standby Through Auto(Eco)	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	sets HDMI Standby Through Wrap-Around gets The HDMI Standby Through State	No	No	No	No	No	No	No	No	No	No	
"PQL" - PQLS	sets PQLS Off	No	No	No	No	No	No	No	No	No	No	
"01"	sets PQLS On	No	No	No	No	No	No	No	No	No	No	
	sets PQLS Wrap-Around gets The PQLS State	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"ARC" - Audio Re	eturn Channel											
"00" "01"	sets Audio Return Channel Off sets Audio Return Channel Auto	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"UP"	sets Audio Return Channel Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN" "LPS" - Lip Sync	gets The Audio Return Channel State	NO	NO	NO	NO	NO	NO	NO	NO	NO	NO	
"00"	sets Lip Sync Off	No	No	No	No	No	No	No	No No	No	No	
"UP"	sets Lip Sync On sets Lip Sync Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No	No No	No No	
	gets The Lip Sync State	No	No	No	No	No	No	No	No	No	No	
"00"	sets Auto Power Down Off	No	No	No	No	No	No	No	No	No	No	
"01" "UP"	sets Auto Power Down On sets Auto Power Down Wrap-Around	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"QSTN"	gets The Auto Power Down State	No	No	No	No	No	No	No	No	No	No	
	Mode / AMP Mode sets Pre Amp Mode Off	No	No	No	No	No	No	No	No	No	No	
"01"	sets Pre Amp Mode Front	No	No	No	No	No	No	No	No	No	No	
"07"	sets Pre Amp Mode Front+Center sets Pre Amp Mode All	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
	sets Auto Power Down Wrap-Around gets The Auto Power Down State	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"ECO" - for Smar	rt Grid Command											
"01"	sets Volume 1dB down and Dimmer Level "Dark" sets Volume 3dB down and Dimmer Level "Dark"	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"(13")	sets Volume 6dB down and Dimmer Level "Dark"	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"06"				No	No	No	No	No	No	No	No	
"06" "FWV" - Firmwar	e Version	No	No				No	No	No		No	
"FWV" - Firmwar abce-fhik-Imno-qrtu "QSTN"		No No	No No	No	No	No			140	No	NO	
"06" "FWV" - Firmwar abce-fhik-Imno-qrtu "QSTN" "UPD" - Update	e Version sets Firmware Version			No No	No No	No	No	No	No	No	No	
"06" "FWV" - Firmwar abce-fhik-Imno-qrtu "QSTN" "UPD" - Update "NET"	e Version sets Firmware Version gets The Firmware Version State start Device Update via Network start Device Update via USB nn Progress (%) "=DL Downloading "=NT Arm writing	No	No					No No				
"06" "FWV" - Firmwar abce-fhik-Imno-qrtu "QSTN" "UPD" - Update "NET"	e Version sets Firmware Version gets The Firmware Version State start Device Update via Network start Device Update via USB m Progress (%) "=DL Downloading "=NT Arm writing "=D1 DSP1 "=D2 DSP2 "=D3 DSP3 "=VM VMPU "=OS OSD	No No	No No	No	No	No	No		No	No	No	
"06" "FWV" - Firmwar aboe-fliki-lmno-qrlu "0STN" "UPD" - Update "NET" "USB"	e Version sets Firmware Version gets The Firmware Version State start Device Update via Network start Device Update via USB nn Progress (%) "=DL Downloading "=NT Arm writing "=D1 SSP1 "=D2 SSP2 "=D3 SSP3 "=VM VMPU "=OS OSD "=MP MMPU	No No No	No No No	No No	No No	No No	No No	No	No No	No No	No No	
"06" "FWV" - Firmwar aboe-fink-inno-qrtu "0STN" "UPD" - Update "NET" "USB" "D"-nn"	e Version sets Firmware Version gets The Firmware Version State start Device Update via Network start Device Update via USB nn Progress (%) "=DL Downloading "=NT Arm writing "=D1 DSP1 "=D1 DSP1 "=D3 DSP2 "=M VMPU "=O3 DSP3 "=MP MMPU Device Update is completed xx=ErrorCode1	No No No	No No No	No No	No No	No No	No No	No No	No No	No No	No No	
"06" "FWV" - Firmwar abce-flik-Immo-grtu "OSTN" "UPD" - Update "NET" "USB" "D**-nn"	e Version sets Firmware Version gets The Firmware Version State start Device Update via Network start Device Update via USB m Progress (%) "=DL Downloading "=NT Arm writing "=D1 DSP1 "=D2 DSP2 "=D3 DSP3 "=VM VMPU "=OS OSD "=MP MMPU Device Update is completed	No	No N	No N	No No No No	No No No No	No N	No No No No	No No No No	No No No No No	No No No No	
"06" "FWV" - Firmwar aboe-fhik-immo-grlu "0STN" "UPD" - Update "NET" "USB" "D"-nn" "CMP" "Exx-yy" "00" "01"	e Version gets The Firmware Version State start Device Update via Network start Device Update via Network start Device Update via USB nn Progress (%) "=DL Downloading "=D1 DSP1 "=D1 DSP1 "=D2 DSP2 "=D3 DSP3 "=VM VMPU "=OS OSD "=MP MIMPU Device Update is completed xx=ErrorCode1 yx=ErrorCode1	No N	No No No No No No	No No No	No No No	No No No	No No No	No No No	No No No	No No No	No No No	

		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
Code	Means											
"t<>"	t -> message type 'X' : XML > reserved	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	<>: XML data ([CR] and [LF] are removed) U : UI Type											
	0 : List, 1 : Menu, 2 : Playback, 3 : Popup, 4 : Keyboard, 5 : Menu List II -> number of layer (00-FF)											
"Ullt<>"	t : Update Type 0 : All. 1 : Button, 2 : Textbox, 3 : Listbox	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	<> : XML data ([CR] and [LF] are removed)											
	eets of popup xml, custom popup, overlay popup, and disclaimer " (0x20, 0xC2, 0xB7, 0x20) [UTF-8 encoded]											
	Command (Include Tuner Pack Model Only) sets Directly Tuning Frequency (FM nnn.nn MHz / AM nnnnn kHz / SR											
"nnnnn"	nnnn ch) put 0 in the first two digits of nnnn at SR	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"BAND" "DIRECT"	Change BAND starts/restarts Direct Tuning Mode	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"0"	sets 0 in Direct Tuning Mode	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"1" "2"	sets 1 in Direct Tuning Mode sets 2 in Direct Tuning Mode	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"3" "4"	sets 3 in Direct Tuning Mode sets 4 in Direct Tuning Mode	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"5" "6"	sets 5 in Direct Tuning Mode sets 6 in Direct Tuning Mode	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	Yes	Yes Yes	Yes Yes	
"7" "8"	sets 7 in Direct Tuning Mode sets 8 in Direct Tuning Mode	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"9" "UP"	sets 9 in Direct Tuning Mode sets Tuning Frequency Wrap-Around Up	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes	Yes	Yes Yes	Yes Yes	Yes	Yes	
"DOWN" "QSTN"	sets Tuning Frequency Wrap-Around Down gets The Tuning Frequency gets The Tuning Frequency	Yes	Yes	Yes	Yes Yes	Yes	Yes Yes	Yes Yes	Yes	Yes	Yes	
x: FM 100.5 MHz	_gest The Tuning Frequency :(100/200kHz Step)		UN0][!1TU	N5]	100	100	108	100	100	100	100	-
x: FM 90.0 MHz(1 x: FM 90.00 MHz x: AM 1230 kHz(1 x: AM 1341 kHz(9	Izdoni z dep Jinect Tuning is [115LI24][[11TUNDIRECT][[11TUND][[11TUN] (106kHz Step) Direct Tuning is [115LI24][[11TUNDIRECT][[11TUN9][[11TUN] (106kHz Step) Direct Tuning is [115LI25][[11TUNDIRECT][[11TUN1][[11TUN2] (96kHz Step) Direct Tuning is [115LI25][[11TUNDIRECT][[11TUN1][[11TUN3][Command (Include Tuner Pack Model Only))[[1TUN0])][!1TUN0][[!1TUN3]	 !1TUN0]	TTONO								
"01"-"28" "01"-"1E"	sets Preset No. 1 - 40 (In hexadecimal representation) sets Preset No. 1 - 30 (In hexadecimal representation)	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	
"UP" "DOWN"	sets Preset No. Wrap-Around Up sets Preset No. Wrap-Around Down	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"QSTN"	gets The Preset No. Memory Command (Include Tuner Pack Model Only)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"01"-"28"	sets Preset No. 1 - 40 (In hexadecimal representation)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	sets Preset No. 1 - 30 (In hexadecimal representation) formation Command (RDS Model Only)	No	No	No	No	No	No	No	No	No	No	
"00" "01"	Display RT Information*1 Display PTY Information	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	Yes Yes	
"02" "UP"	Display TP Information Display RDS Information Wrap-Around Change	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	No Yes	
PTS" - PTY Sca "01"-"1D"	an Command (RDS Model Only) sets PTY No "1 - 29" (In hexadecimal representation)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
"ENTER"	Finish PTY Scan Command (RDS Model Only)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
are .	Start TP Scan (When Don't Have Parameter)	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"ENTER" XCN" - XM Cha	Finish TP Scan			NO							NO	
"nnnnnnnnnn" "QSTN"	XM Channel Name gets XM Channel Name	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
	st Name Info (XM Model Only) XM Artist Name	No	No	No	No	No	No	No	No	No	No	
"QSTN"	gets XM Artist Name Info (XM Model Only)	No	No	No	No	No	No	No	No	No	No	
"nnnnnnnnn" "QSTN"		No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
XCH" - XM Cha	nnel Number Command (XM Model Only)											
"000"-"255" "UP"	XM Channel Number "000 - 255" sets XM Channel Wrap-Around Up	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
"DOWN" "QSTN"	sets XM Channel Wrap-Around Down gets XM Channel Number	No No	No	No	No No							
"nnnnnnnnnn"	egory Command (XM Model Only)		No	No		140						
"UP"	XM Category Info	No	No	No	No	No	No	No	No	No	No	
"DOWN"							No No No	No No No	No No No	No No No	No No No	
"QSTN"	XM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category	No No	No No	No No	No No	No No	No	No	No	No	No	
"QSTN" SCN" - SIRIUS "nnnnnnnnnn"	XM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name	No No No No	No No No No	No No No No	No No No No	No No No No	No No No	No No No	No No No	No No No	No No No	
"QSTN" SCN" - SIRIUS "nnnnnnnnnn" "QSTN" SAT" - SIRIUS	XM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only)	No No No No No	No No No No									
"QSTN" SCN" - SIRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS "nnnnnnnnn" "QSTN"	IXM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name	No No No No	No No No No	No No No No	No No No No	No No No No	No No No	No No No	No No No	No No No	No No No	
"QSTN" SCN" - SIRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS / "nnnnnnnnnn" "QSTN" STI" - SIRIUS T	XM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name gets SIRIUS Artist Name ittle Info (SIRIUS Model Only) SIRIUS Artist Name SIRIUS Artist Name SIRIUS Artist Name SIRIUS Artist Name	No No No No No No No No	No No No No No No No	No N	No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No No	
"QSTN" SCN" - SIRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS / "nnnnnnnnn" "QSTN" STI" - SIRIUS T "nnnnnnnnnn" "QSTN" SCH" - SIRIUS	XM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name ittel Info (SIRIUS Model Only) SIRIUS Ittel gets SIRIUS Title Channel Namber Command (SIRIUS Model Only)	No N	No No No No No No No	No No No No No No No	No No No No No No	No No No No No No No	No No No No No No	No No No No No No	No No No No No	No No No No No No	No No No No No No	
"QSTN" SCN" - SIRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS / "nnnnnnnnn" "QSTN" STI" - SIRIUS T "nnnnnnnnnn" "QSTN"	IXM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name gets SIRIUS Artist Name ittle Info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title GERIUS Title GERIUS Title GERIUS Title Channel Number Command (SIRIUS Model Only) SIRIUS Channel Number "000 - 255"	No No No No No No No No	No No No No No No No	No N	No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No	No No No No No No No No	
"QSTN" "SRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS / "nnnnnnnnnn" "QSTN" STI" - SIRIUS T "nnnnnnnnnn" "QSTN" STI" - SIRIUS T "nnnnnnnnnn" "QSTN" SCH" - SIRIUS "000"-"255" "UP" "DOWN"	IXM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name gets SIRIUS Artist Name ittle Info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title gets SIRIUS Title SIRIUS Title SIRIUS SIRIUS Title SIRIUS Channel Number "000 - 255" sets SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Down	No N	No N	No N	No N	No N	No N	No N	No N	No N	No N	
"QSTN" SCN" - SIRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS, "nnnnnnnnn" "QSTN" STI" - SIRIUS T "nnnnnnnnnnn" "QSTN" SCH" - SIRIUS "UP" "DOWN" "QSTN" SCF" - SIRIUS "UP" "DOWN" "SCF" - SIRIUS	IXM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name itle Info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title Gets SIRIUS Title Gets SIRIUS Channel Number "000 - 255" sets SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Up gets SIRIUS Channel Wrap-Around Down gets SIRIUS Channel Number "000 - 256" category Command (SIRIUS Model Only) Gets SIRIUS Channel Wrap-Around Down gets SIRIUS Channel Number "000 - 256" category Command (SIRIUS Model Only)	No N	No N	No N	No N	No N	No N	No N	No N	No N	No N	
"QSTN" SCN" - SIRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS , "nnnnnnnnn" "QSTN" SSTI" - SIRIUS , "nnnnnnnnnn" "QSTN" SCH" - SIRIUS "UP" "DOWN" "GSTN" SCT" - SIRIUS "GSTN"	IMA Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name itle Info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title Channel Number Command (SIRIUS Model Only) SIRIUS Channel Number "000 - 255" sets SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Down gets SIRIUS Channel Wrap-Around Down gets SIRIUS Channel Wrap-Around Down SIRIUS Category Info SIRIUS Category Info SIRIUS Category Info sets SIRIUS Category Wrap-Around Up	No N	No N	No N	No N	No N	No N	No N	No N	No N	No N	
"GSTN" SCN" - SIRIUS "nnnnnnnnnn" "GSTN" STRIUS 7 "nnnnnnnnnnn" "GSTN" STN" - SIRIUS 7 "nnnnnnnnnnnn" "GSTN" SCH" - SIRIUS 7 "DOWN" "GSTN"	IMA Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name gets SIRIUS Artist Name gets SIRIUS Artist Name info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title gets SIRIUS Title Ghannel Number Command (SIRIUS Model Only) SIRIUS Channel Number "000 - 255" sets SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Down gets SIRIUS Channel Wrap-Around Up sets SIRIUS Category Wrap-Around Up sets SIRIUS Category Wrap-Around Down gets SIRIUS Category Wrap-Around Down	No N	No N	No N	No N	No N	No N	No N	No N	No N	No N	
"QSTN" SCN" - SIRIUS "nannananan" "QSTN" SAT" - SIRIUS 7 "nannananan" "QSTN" STI" - SIRIUS 7 "nannananananananananananananananananan	IMA Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down qets XM Category Wrap-Around Down qets XM Category Wrap-Around Down qets XM Category Wrap-Around Down SIRIUS Channel Name qets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name gets SIRIUS Artist Name itle Info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title Channel Number Command (SIRIUS Model Only) SIRIUS Channel Number "000 - 255" sets SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Down gets SIRIUS Channel Number Category Command (SIRIUS Model Only) SIRIUS Category Mrap-Around Up sets SIRIUS Category Wrap-Around Down gets SIRIUS Category Mrap-Around Down	No N	No N	No N	No N	No N	No N	No N	No N	No N	No N	
"QSTN" SCN" - SIRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS, "nnnnnnnnnn" "QSTN" ST" - SIRIUS, "nnnnnnnnnnn" "QSTN" SCH" - SIRIUS "DOWN" "QSTN" SCT" - SIRIUS "QUYP" "QSTN" "SCH" - SIRIUS "QSTN" "SCH" - SIRIUS "QSTN" "SCH" - SIRIUS "QSTN" "SCH" - SIRIUS "QSTN" "QSTN" "SCH" - SIRIUS "LOWN" "QSTN" "QSTN" "QSTN"	IXM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name ittle Info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title Gets SIRIUS Title Gets SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Up gets SIRIUS Channel Wrap-Around Up sets SIRIUS Category Wrap-Around Up sets SIRIUS Category Wrap-Around Down gets SIRIUS Category Parental Lock Command (SIRIUS Model Only)	No N	No N	No N	No N	No N	No N	No N	No N	No N	No N	
"GSTN" SCN" - SIRIUS "nnnnnnnnn" "QSTN" SAT" - SIRIUS 7 "nnnnnnnnn" "QSTN" STI" - SIRIUS 7 "nnnnnnnnnn" "QSTN" SCH" - SIRIUS 7 "pown" "QSTN" "GSTN" "IUP" "DOWN" "INPUT" "INPUT" "INPUT" "HRONG"	IXM Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name gets SIRIUS Artist Name gets SIRIUS Artist Name info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title Gets SIRIUS Title Grannel Number Command (SIRIUS Model Only) SIRIUS Channel Number "000 - 255" sets SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Down gets SIRIUS Category Mrap-Around Up sets SIRIUS Category Wrap-Around Up sets SIRIUS Category Wrap-Around Down gets SIRIU	No N	No N	No N	No N	No N	No N	No N	No N	No N	No N	
"QSTN" SCN" - SIRIUS CON" - SIRIUS STN" - SIRIUS ATT - SIRIUS TON	IMA Category Info sets XM Category Wrap-Around Up sets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Wrap-Around Down gets XM Category Channel Name Info (SIRIUS Model Only) SIRIUS Channel Name gets SIRIUS Channel Name Artist Name Info (SIRIUS Model Only) SIRIUS Artist Name gets SIRIUS Artist Name ittle Info (SIRIUS Model Only) SIRIUS Title gets SIRIUS Title Gate SIRIUS Title Grannel Number Command (SIRIUS Model Only) SIRIUS Title Grannel Number Only SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Up sets SIRIUS Channel Wrap-Around Down gets SIRIUS Channel Number Category Command (SIRIUS Model Only) SIRIUS Category Wrap-Around Up sets SIRIUS Category Wrap-Around Up sets SIRIUS Category Wrap-Around Down gets SIRIUS Category Wrap-Around Up	No N	No N	No N	NO N	No N	No N	No N	No N	No N	No N	

Main-related Command Support List

		TX-NR555 (Ether)	DRX-2	TX-NR656 (Ether)	TX-RZ610	DRX-3	TX-NR757	TX-RZ710	DRX-4	TX-RZ810	DRX-5	
Code	Means	No	No				No	No	No	No	No	
"nnnnnnnnnn" "OSTN"	HD Radio Title (variable-length, 64 digits max) gets HD Radio Title	No No	No No	No No	No No	No No	No No	No No	No No	No No	No No	
	lio Detail Info (HD Radio Model Only)	INU	INU	INU	INU	INO	INU	INO	INU	INU	INU	
"nnnnnnnnnn"	HD Radio Title	No	No	No	No	No	No	No	No	No	No	
"OSTN"	gets HD Radio Title	No	No	No	No	No	No	No	No	No	No	
	lio Channel Program Command (HD Radio Model Only)	110	110	140	140	140	140	140	140	140	140	
"01"-"08"	sets directly HD Radio Channel Program	No	No	No	No	No	No	No	No	No	No	
"QSTN"	gets HD Radio Channel Program	No	No	No	No	No	No	No	No	No	No	
	io Blend Mode Command (HD Radio Model Only)									l .		
"00"	sets HD Radio Blend Mode "Auto"	No	No	No	No	No	No	No	No	No	No	
"01"	sets HD Radio Blend Mode "Analog"	No	No	No	No	No	No	No	No	No	No	
"QSTN"	gets the HD Radio Blend Mode Status	No	No	No	No	No	No	No	No	No	No	
'HTS" - HD Rad	io Tuner Status (HD Radio Model Only)											
"mmnnoo"	HD Radio Tuner Status (3 bytes) mm -> "00" not HD, "01" HD nn -> current Program "01"-"08" oo -> receivable Program (8 bits are represented in hexadecimal notati	No	No	No	No	No	No	No	No	No	No	
"OSTN"	gets the HD Radio Tuner Status	No	No	No	No	No	No	No	No	No	No	