

- Treated wastewater effluent is disinfected prior to its discharge into a water body inorder to destroy pathogens primarily to prevent spread of waterborne disease and minimize public health problems
- Disinfection is different from sterilization which is the destruction of all microorganisms
- Fecal coliform, Escherichia coli (E. coli) and Enterococci are used as indicator organisms to test the effectiveness of effluent disinfection in a wastewater treatment plant.

Elements of an "ideal" disinfectant

- Versatile: effective against all types of pathogens
- Fast-acting: effective within short contact times
- Robust: effective in the presence of interfering materials including particulates, suspended solids and other organic and inorganic constituents
- Handy: easy to handle, generate, and apply (nontoxic, soluble, non-flammable, non-explosive)
- Compatible with various materials/surfaces in WTPs (pipes, equipments)
- Economical

23.1 Chlorine disinfection

- · Chlorine is a very effective disinfectant and is the most widely used disinfectant for wastewater
- Chlorine disinfection is a practical and economical means for disinfecting large quantities of wastewaters which have been treated to various degrees.
- However, due to its toxicity, associated risk factors and its rising cost, use of ultraviolet light and ozone for wastewater disinfection is on the rise

23.1.1 Forms of chlorine

- Due to safety issues related to the use of chlorine gas, **hypochlorites** are often used in lieu of chlorine
- Types of hypochlorites
 - Sodium hypochlorite (NaOCl) comes in a liquid form which contains up to 12.5% chlorine
 - Calcium hypochlorite (Ca(OCl)₂), also known as HTH, is a solid which is mixed with water to form a hypochlorite solution. Calcium hypochlorite is 65-70% concentrated.
- Hypochlorites decompose in strength over time while in storage. Temperature, light, and physical energy can all break down hypochlorites before they are able to react with pathogens in water.

23.1.2 Chlorine properties

- Chlorine is a yellowish-green gas at room temperature and atmosphric pressure
- Chlorine gas can be pressurized and cooled to its liquid form for making it easy to ship and store.
- When liquid chlorine is released, it quickly turns into a gas that stays close to the ground (being heavier than air) and spreads rapidly.
- While it is not explosive or flammable, as a liquid or gas it can react violently with many substances
- Chlorine is only slightly soluble in water (0.3 to 0.7% by weight.)
- Chlorine gas has a greenish-yellow color
- It has a characteristic disagreeable and pungent odor, similar to chlorine-based laundry bleaches, and is detectable by smell at concentrations as low as 0.2 to 0.4 ppm
- It is about two and a half times as heavy as air
- One volume of liquid chlorine yields about 460 volumes of chlorine gas.
- · Liquid chlorine is amber in color and is about one and a half times as heavy as water
- Chlorine is an irritant to the eyes, skin, mucous membranes, and the respiratory system

23.1.3 Chlorine storage and safety

- Typically for smaller plants chlorine gas is shipped in pressurized steel cylinders 150 lb or 2000 lb (ton cylinder) size. Larger plants may get their chlorine supply in rail tank cars.
- The daily chlorine usage is typically established based upon the weighing of the chlorine containers.
- The withdrawal rates from a chlorine cylinder is based on the temperature of the liquid in the cylinder, and thus the pressure of the gas.
- As chlorine gas is withdrawn from the cylinder, it absorbs the heat from the surroundings.
- For low withdrawal rates, heat will be able to be transferred from the surrounding air to the container in time so that there is no drop in temperature or pressure,
- If the chlorine withdrawal is larger, the air will not be able to transfer the heat quickly enough and the temperature (and pressure) of the chlorine will drop, thus resulting in a lower feed rate.
- If high enough and prolonged enough, this can even result in ice formation around the outside of the container, further decreasing the withdrawal rate.
- The most effective way to increase withdrawal rate from a single container is to circulate the surrounding air with a fan. Again, never apply heat to the containers.
- If chlorine gas escapes from a container or system, being heavier than air, it will seek the lowest level in the building or area
- Only trained staff with access to proper personal protection equipment (PPE) including selfcontained breathing apparatus, should handle the chlorine cylinders and address chlorine leak issues
- When a leak is suspected, it is recommended that ammonia vapors be used to find the source.
 When ammonia vapor using a rag or brush, is directed at a leak, a white cloud will form. To produce ammonia vapor, a plastic squeeze bottle containing about 5 % ammonia, aqua ammonia (ammonium hydroxide solution) should be used. A weaker solution such as household ammonia may not be concentrated enough to detect minor leaks
- All safety equipment should be located outside of the chlorine room and be easily accessed by all personnel
- Small leaks around valve stems can usually be corrected by tightening the packing nut or closing the valve. A leak can also be reduced by removing the chlorine as rapidly as possible
- If it cannot be added to the process there are several chemicals which can be used to absorb the chlorine gas. For example, chlorine can be absorbed by using 1 frac 14 pounds of caustic soda or hydrated line, or 3 pounds of soda ash per pound of chlorine.
- If the leaking container can be moved, it should be transported to an outdoors area where minimal harm will occur. Keep the leaking part the most elevated so that gaseous chlorine will leak rather than liquid chlorine.
- If the leak is large, all persons in the adjacent area must be warned and evacuated. Only authorized persons equipped with the proper breathing apparatus, and protective measures to the eyes and body should investigate.

- As water is not an efficient absorbent for chlorine and the fact that chlorine reacts with water to form very corrosive hydrochloric acid, never apply water to a leak or consider submerging a chlorine cylinder (for example, in a pond or tank), since it will probably float.
- Remember to keep windward of the leak.
- As chlorine cylinders pressure increases with temperature, as a safety measure the chlorine cylinders are fitted with fusible plug which melts between 158° and 165° F.
- Keep chlorine cylinder or container emergency repair kits available. Be familiar with their use and location
- Leaks at fusible plugs and cylinder valves requires special handling and emergency equipment. The chlorine supplier must be notified immediately
- Pin hole leaks in cylinder walls or ton tanks can usually be stopped by mechanical pressure applications (clamps, turnbuckles, etc.). This only temporary and may require your ingenuity.
- Leaking containers cannot be shipped.
- In general, daily inspection of all chlorine cylinders will avoid major problems

23.1.4 Chlorine reactions related to disinfection

Chlorine reacts with water to form hypochlorous and hydrochloric acids

 Cl_2 + H_2O \iff HOCl + HCl chlorine water hypochlorous acid hydrochloric acid

· Hypochlorous acid dissociates in water to form the hydrogen and hypochlorite ions

- Hypochlorous acid is the most effective form of chlorine available to kill microorganisms
- Hypochlorite ions is much less efficient disinfectant
- The concentration of hypochlorous acid and hypochlorite ions in chlorinated water will depend on the water's pH
 - A higher pH facilitates the formation of more hypochlorite ions and results in less hypochlorous acid in the water
- A significant percentage of the chlorine is still in the form of hypochlorous acid even between pH 8 and pH 9

23.1.5 Chlorine disinfection process

- When chlorine is added to a wastewater flow, it will first react or combine with certain organic and inorganic substances present, prior to acting on pathogens. The amount of chlorine used up as part of these reactions is referred to as the **chlorine demand**
- The **free chlorine** remaining after the chlorine demand is satisfied, is the strongest form of chlorine available for disinfection.
- Chlorine combined with ammonia (as chloramines) and organic compounds (as chloroorganic compounds), known as **combined chlorine** also exhibit disinfecting properties albeit weaker than the free chlorine.
- Total residual chlorine is the sum of free chlorine and combined chlorine and it is the residual chlorine concentration which represents the amount of chlorine available for disinfection

Chlorine Demand = Applied Chlorine Dose - Chlorine Residual

23.1.6 Factors affecting chlorine disinfection

The disinfection efficiency of chlorine depends on the following factors:

- pH: Disinfection is more efficient at a low pH when large quantities of hypochlorous acid are present than at a high pH when hypochlorite ions is the dominant species in the water
- Concentration: Contact Time Ratio (CT): For effective chlorine disinfection both sufficient chlorine dosages concentration (C) as well as contact time (T) are necessary. Generally both of these factors must be worked out experimentally for a given system
- Disinfection activity can be expressed as the product of disinfection concentration (C) and contact time (T) CT

- The same CT values will achieve the same amount of inactivation
- Temperature: Colder temperatures are less favorable for disinfection. Proper contacting or mixing or agitation: This is necessary to make sure that the chlorine applied contacts or reaches the microbial cells
- Organic and inorganic material present: The chlorine used by these organic and inorganic reducing substances including metal ions, organic matter and ammonia, is defined as the chlorine demand.
 So that the amount of chlorine that has to be added to wastewater for different purposes will also vary.

Chlorine dosage is typically established from either bench scale laboratory testing, or actual measurement of field results. Since field conditions, particularly the mixing element, are not as well controlled as laboratory tests, the actual dosage is expected to be generally higher than from that established in the laboratory.

Even though residual chlorine concentration can be used for establishing the effectiveness of disinfection, the ultimate effectiveness of disinfection can be monitored by conducting bacteriological testing. (There may be a substantial residual but if the time (CT factor discussed above, disinfection may not be adequate)

23.1.7 Dechloringtion

Dechlorination is the process of removing residual chlorine from disinfected wastewater prior to discharge into the environment. Dehlorination is necessary to mitigate the toxic effect of chlorine on the receiving waters. Sulfur dioxide is most commonly used for dechlorination. Other chemicals used for sodium bisulfite, sodium sulfite and sodium thiosulfate.

23.2 Ultraviolet (UV) disinfection

- UV Disinfection of wastewater is conducted in specially designed reactors fitted with ultraviolet lamps producing energy in the UV-C range (200-400 nm)
- The UV lamps produce light photons that attack the microorganisms in wastewater as it flows through the reactor.
- Within only a few seconds of exposure to the UV energy, the DNA of the microorganisms is permanently altered and the bacteria can no longer reproduce or infect those coming in contact with the water.
- UV for wastewater disinfection has been in use for more than 50 years
- Increased interest after the discovery in the late 1990's of its remarkable effectiveness against Cryptosporidium parvum and Giardia lamblia - pathogens in surface waters which can find its way into the drinking water supplies
- Chlorine based wastewater disinfection is still most common. However, due to its inherent public and environmental safety issues, UV disinfection is now being adopted more widely
- and environmental safety issues, UV disinfection is now being adopted more widely

 The UV dose expressed as $\frac{mJ-sec}{cm^2}$ or $\frac{\mu W-sec}{cm^2}$ is the product of UV intensity (energy per unit surface area) mJ/cm² or μ W/cm² and residence time sec.


23.2.1 Advantages of UV disinfection

- Very effective against bacteria, fungi, protozoa
- Independent on pH, temperature, and other materials in water
- Smaller reactor size requirement compared to chlorination

23.2.2 Disadvantages of UV disinfection

- Suspended solids, slime growth, turbidity, and color present in wastewater will inhibit the effectiveness of UV
- No lasting residuals
- UV light tends to ionize compounds and break them apart (i.e. nitrate could become nitrite in UV light), causing toxic effects on the effluent.
- Expensive

23.3 Peracetic acid (PAA)



23.3.1 Advantages of peracetic acid

1. ADVANTAGES OF PAA INCLUDE:

- Easy treatment implementation
- Efficacy towards a large spectrum of microorganisms even in the presence of organic matter
- Absence of residual or toxic and/or mutagenic by-products
- Does not require dechlorination
- · Low pH dependence, and
- · Short contact time

23.3.2 Disadvantages of Peracetic acid

- An increase of organic content in the effluent due to acetic acid acetic acid is already present in PAA mixtures and is also formed after PAA decomposition, and
- Increased potential for microbial regrowth due to the presence of easily biodegradable acetic acid

23.4 Ozone

- Ozone (O_3) is the triatomic form of oxygen it is composed of three oxygen atoms.
- Under normal conditions ozone is unstable and quickly decomposes to the more stable gaseous oxygen, O2.
- Because of its instability, ozone cannot be stored and thus generated at the point of application.
- Ozone is generated by passing air or oxygen through an electrical discharge the noticeable clean smell in the air after a thunder and lightning storm is likely due to the formation of ozone due to the lightning bolts passing through the atmosphere.
- Ozone is thirteen times more soluble in water than oxygen.
- As ozone is introduced into wastewater in a specially designed contactor, it is rapidly consumed, satisfying the ozone demand of inorganic salts and organic matter dissolved in the wastewater.
- Ozone disinfects 3100 times faster than chlorine. It has also been found that disinfection occurs within contact times of 3 to 8 seconds.
- Dosages between 5 to 15 mg/L are commonly cited for disinfection of secondary wastewater effluents.
- Viricidal properties of ozone is exhibited at longer contact time of about 5 minutes needed. It has
 also been found that any residual ozone in the effluent of the contactor disappears in a matter of
 seconds outside the contactor.

23.4.1 Advantages of ozonation

The advantages of ozonation include:

- Reduces colors, phenolics, cyanides, oxygen demanding matter, turbidity and surfactants
- Increases dissolved oxygen
- Does not produce any significant toxic by-products
- Increases suspended solids reduction

23.4.2 Disadvantages of ozonation

The disadvantages of ozonation include:

- · High capital cost
- High electric consumption

• Highly corrosive, especially with steel or iron and even oxidizes Neoprene