FICTIONAL - FOR SOFTWARE DEMONSTRATION ONLY - NOT FOR PLANT USE

EDG-1A START AND OUTPUT BREAKER ELEMENTARY



START CIRCUIT: Undervoltage on BUS-1A energizes start relay; EDG-1A to rated speed and voltage in 10 s or less.

52-1A02 CLOSE: permissive when EDG-1A at rated voltage and frequency; load sequencer LS-1A on SAMPLE-E-004 (not in this set).

TITLE	EDG-1A Start and Output Breaker Elementary
SYSTEM	Emergency Diesel Generator 1A
SITE / UNIT	SAMPLE SITE (FICTIONAL) / Unit 1
DRAWN BY	J. Example
DATE	2026-04-14

DWG NO.	REV
SAMPLE-E-003	**B**