HC-SR04 Distance Sensor handling

Masquer l'énoncé

Preparation questions about the HC-SR04 distance sensor low-level handling.

In order to answer this question, you should first read the sensor [datasheet](#).

HC-SR04 Polling Functions

Select **all** the function you will have to use to poll the `HC-SR04` distance sensor.

- ☐ gpio_read
- ☑ busy_wait
- ☑ delay_us
- ☐ gpio_input
- ☐ spin
- ☐ gpio_output
- ☑ gpio_write
- ☑ uptime_us
- ☐ delay_ms

Vous avez atteint la limite de soumission.