
				WORK INS	Effectivity Date:	May 24, 2024					
		Process Name			P ASSEMBLY PRO	CESS		Validity Date:	n/a		
		Model code/Pa	rt number:	240B / 7M0487-7020C	Customer: TRJ	Car Model:	LEXUS-ES	Document No.:	WI-ENG-PDE-822		
		Purpose:		PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	0 Page No.: 1 of 5		
PARTS:		Assy parts; Clamp	y parts; Clamp 82711-52090 (W); Black tape; Violet tape					JIG:	1.Clamp Assembly Jig		
N	Э.	PROCESS N	AME	WORK F	PROCEDURE/ ILLUST	TOOLS/PPE	QUALITY POINTERS				
					Table Lay-out	Safety Instruction  Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)	1. No missing parts/tools 2. No excess parts/tools  Document reference/s:  1. Refer to WI-ENG-PDE-071 for Taping assembly process				
1		SLAMP Table L	ay-out	Assy	parts	SWITCH AND MARKET MARKE					
				Tape Holder/ Black tape  Violet tape/ Tape holder				Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	CLAMP ILLUSTRATION  GOOD  NG  82711-52090 (W)  82711-12A80 (W)		
	,	Revision History						Prepared by	Reviewed by Approved by Noted by		
05/24/24	0 Init	itial issue.					C. A. Arañes	n/a D. Castillo	//orty)/for- E. Villanueva A. A. Arades n/a		
Eff. Date	Rev. No			Details of Change					y 24, 2024		
		•									

			WORK IN	Effectivity Date:	May 24, 2024					
		Process Name/Title:		MP ASSEMBLY PRO	Validity Date:	n/a				
		Model code/Part number:	240B / 7M0487-7020C			LEXUS-ES	Document No.:	WI-ENG-PDE-822		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	LLXOO LO	Revision No.:	0	Page No.:	2 of 5
								<u> </u>		
PARTS:	1. Clamp 2. Black	82711-52090 (W) tape						1. Clamp assembly jig		
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS			
2	CLAMP ASSY	Clamp Setting	1. Get the clamp 82711-520 using both hands.  2. Initially attach Black tape	90 (W) using right hand and		bly jig	n/a	1. No wron	g use of parts. g use of tape  CLAMP ILLUSTRATION  NG  2090(W)  827	

			WORK INS	Effectivity Date:	May 24, 2024 n/a							
		Process Name/Title: CLAMP ASSEMBLY PROCESS						Validity Date:				
		Model code/Part number:	240B / 7M0487-7020C	Customer: TRJ	TRJ	Car Model:	LEXUS-ES	Document No.:	WI-ENG-PDE-822			
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO	)	Revision No.:	0	Page No.:	3 of 5	
PARTS: 1. Ass; 2. Viole								JIG:	1. Clamp A	ssembly jig		
NO.	P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	QUALITY POINTERS			
3	CLAMP	Clamp Assembly	1. Get the harness using both hands a First put the connector into receiver be put the terminal to stopper jig and pull toggle clamp.  2. Check the LED light for POWER, CI SEQUENCE LIGHT is ON. If encounte abnormality, STOP the process, CALL superior and WAIT for instructions.  3. Get the Violet tape and conduct spelocation 1 using both hands. Make 2-3 buzzer will be heard if the Violet tape Press the yellow button after taping. C process if sequence light in location 2	LAMP and ered the immediate of taping on winds. GO we is detected. Continue the	4. Conchands after ta	duct taping on loc	CKING before	n/a	1. No wron 2.No loose 3. No flip- 4. No peel  Impor 1. Must and sto	ng use of tape e tape out tape	2711-12A80 (W)  ote/s:  en terminal	



				Effectivity Date:	May 24, 2024							
			Process Name/Title:	CLAMI	Validity Date:	n/a						
Ш		7	Model code/Part number:	240B / 7M0487-7020C	Customer:	TRJ	Car Model:	LEXUS-ES	Document No.:		WI-ENG-PDE-8	322
L			Purpose:	PROTOTYPE	PRE-LAUNCI	1	MASSPRO	l.	Revision No.:	0	Page No.:	5 of 5
Ē	1								1			

PARTS: 1. Assy parts JIG: n/a

## **VISUAL INSPECTION**

## **CLAMP ASSY**

## 7M0487-7020C



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.