

Process Name/ Title:

PACKING INSTRUCTION

Document No:

WI-QAD-QAC-139

Work INSTRUCTION

Effective Date:

Product Code/Name:

Customer Code:

Rev. No.: 3

Page No.: Page 1 of 1

				75N830	TR	J	Rev. No.:	3	Page No	.: Pag	e 1 of 1
No.	Work Procedure/ Illustration								Records/Remarks/ Quality Pointers		
									Qty/box Mat'l name Partition board	400 Dim. 343*510	100pcs *4bdls Qty.
1	Prepare empty oricon box in the "after inspection area"							Vinyl bag	545*450	4	
2	then pu harness. in same d ID tag insi	at the vinyl (plastic) bag then put the 100 pcs arness. Insert products same direction. Put the tag inside then fold the plastic bag.									
3	Put products on vertical position and partition board vertically & alternately with the products. (100pcs* 4 Bundles with I.D tag inside)							Smaller white connectors must be on top position.			
4	Fold the vinyl sheet. Put NBP Identification tag at the top.Then warehouse Identification tag at lower right side of the box		ion tag	Note: If need to attach 4M tag Put 4M tag at the left side of the box							
									Prepared	Checked	Approved
2/28/2024	3	3		Remove Vinyl Sheet		M. Garcia	D.Dadulla	R.Pascua			, ,
5/9/2023 8/24/2022	2			date quantity per bundle in process no. 2 ate product orientation to vertical position		M. Garcia M. Garcia	R. Alcantara R. Alcantara	A. Arañes A. Arañes	Marin e:	Mus	M/ 1
08/31/2019 Eff. Date	1		•	Initial issue Details of change		C.Dimailig Prepared	.	. Mendoza Approved	/ ·····	D. Dadulla te: August 31	R. Pasqua
		<u> </u>		MPC (Philippines)					LotabiioII Da	ruyusi 31	, 2013

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduc tion in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)

MASTER COPY