
					WORK INS		Effectivity Date:	June 11, 2024				
			Process Name/Title:		OFFLIN	NE ASSEMBLY PROC		Validity Date:	n/a			
			Model code/Part number:	700B /	7N0099-7020	Customer: TRJ	Car Model: Toyota-Land Cruiser	Document No.:		WI-ENG-PDE-7	/33	
			Purpose:	PROTOTYF	E	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	1 of 7	
PARTS: 2. AVSSf 0.3 Y			ector 6098-2220(W) Sf 0.3 Y L=713±3mm Sf 0.3 OR L=713±3mm			Black Corrugated Tul     Black Corrugated Tul	JIG:	1. Insertior 2. Locking	Insertion jig with switch cover     Locking jig			
N			PROCESS NAME		WORK F	PROCEDURE/ ILLUSTRA	ATION	TOOLS/PPE	(	QUALITY POIN	TERS	
1		n/a	Table Lay-out	Connector 60 (W) / Connector	98-2220	TABLE LAY-OUT  ack COT (no slit) 15 L=316±3mm  BI	AVSSf 0.3 wires Y-OR L=713±3mm	Safety Instruction  Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)  Housekeeping  1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.  Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	1. Refer to and Strip	ocument referent to WI-PRO-CNC-to Length Tolerand Length Tolerand ing parts/tools	ce/s: 017 for Wire	
					Revision History		, , , , , , , , , , , , , , , , , , , ,	Prepared by R	eviewed by	Approved by	Noted by	
06/11/24	1	6098-222		notes on page 4 as count	ermeasure for the customer	claim(Broken lock of Connector	A.Hernandez C.Villanueva A. Arañes I	Na Ohomondex	out form			
9/12/23		A.Hernandez J.Loterte C.Villanueva A. Arañes A.Hernandez () C. Villanueva f A. Arañes n/a							n/a			
Eff. Date	Rev. No			Details of 0	Change		Revised Reviewed Approved N	oted Est. Date: Septe	mber 12, 2023	3		



WORK INSTRUCTION Effectivity Date: June 11, 202 Process Name/Title: OFFLINE ASSEMBLY PROCESS Validity Date: n/a Model code/Part number: 700B / 7N0099-7020 Customer: TRJ Car Model: Toyota-Land Cruiser Document No.: WI-ENG-PDE	733
Model code/Part number: 700B / 7N0099-7020 Customer: TRJ Car Model: Toyota-Land Cruiser Document No.: WI-ENG-PDE	'33
Purpose: □PROTOTYPE □ PRE-LAUNCH ■ MASSPRO Revision No.: 1 Page No.:	3 of 7
PARTS: 1. AVSSf 0.3 Y L=713±3mm 2. AVSSf 0.3 OR L=713±3mm 3. AVSSf 0.3	ver
NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE QUALITY POIL	TERS
Wire insertion to connector (6098-2220 (W))  3	te/s: lear Push -029 for

				WORK INS	STRUCTION			Effectivity Date:		June 11, 2024	ļ
		Process Name/Title:		OFFLII	NE ASSEMBLY PRO	CESS		Validity Date:		n/a	
		Model code/Part number:	700B /	7N0099-7020	Customer: TRJ	Car Model:	Toyota-Land Cruiser	Document No.:		WI-ENG-PDE-7	<b>733</b>
		Purpose:	PROTOTY	PE	PRE-LAUNCH	MASSP	PRO	Revision No.:	1	Page No.:	4 of 7
PARTS:	1. Assy	parts						JIG:	1. Locking	jig	
NO.	F	PROCESS NAME		WORK I	PROCEDURE/ ILLUSTF	RATION 1		TOOLS/PPE	11 (	QUALITY POIN	TERS
4	n/a	Connector lock	GOO  2. Hold the assy p connector touch the	NECTOR RETA SIDE	NG RETAINES SENSO	ER R	1.Check the Retainer loc insertion to locking jig. Note: Must be NO half-loc connector locking.	Cocked condition prior  1	1. Please 6 will not tou insertion in connector: 2. Maintain connector: 3. Connector: 4. Make suprocess. 5. No wrong 6. No dam: 7. No unloce    Impo 1. Inconalarm the 2. No reproceed 3. If enconal immof the let	ensure that Connect or hit by any of to locking jig to an a 10mm proper ho or must be fully insolot.  If you have no offset setting a setting of connect or locked/ half-locked or the fully insolot.  If you have no offset setting a setting of connect or locked/ half-locked or the fully insoloted in the full insoloted in th	ctor lock/retainer oject prior roid half-lock dding of wire to serted to g before locking ctor. ck connector.

				WORK INS	TRUCTION			Effectivity Date:		June 11, 2024		
	H	Process Name/Title:		OFFLIN	NE ASSEMBLY PR	ROCESS		Validity Date:		n/a		
		Model code/Part number:	700B /	7N0099-7020	Customer: TRJ	Car Model: Toyota	a-Land Cruiser	Document No.:		WI-ENG-PDE-73	33	
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	5 of 7	
PARTS:	1. Assy	parts						JIG:	1. Locking	jig		
NO.	F	ROCESS NAME		WORK F	PROCEDURE/ ILLUS	TRATION 1		TOOLS/PPE	1 0	QUALITY POINTERS		
4	n/a	Connector lock (Continuation)	HOLD THE HANDL		STEP 2	PULL-DOWN  R  SLIDE	jig using right hai and bring back to locking. Note: Pu  4. Remove the left hand base	ble of the connector locking and then gently pull down to original position after all down one time only.  Be locked connector using don the illustration, action of arrow.  5. Ensure that connector is in locked condition by slide touching the connector lock based on the sequence illustrated.	1. Please 6 will not tou insertion in connector. 2. Maintain connector 3. Connector 4. Make su process. 5. No wrong 6. No dama 7. No unloco Important the 2. No resproceed 3. If encand imm of the le	ensure that Connect ch or hit by any object locking jig to average of connect aged connector locked/ half-locked container in connector locked/ half-locked connector locked/ half-locked/ half-	etor lock/retainer ect prior oid half-lock ding of wire to erted to pefore locking tor. k connector.  Note/s: cess will or cannot e attention orther	

			WORK IN	STRUCTION		Effectivity Date:		June 11, 2024		
		Process Name/Title:	OFFL	Validity Date:	n/a					
		Model code/Part number:	700B / 7N0099-7020	Customer: TRJ	Car Model: Toyota-Land Cruiser	Document No.:	WI-ENG-PDE-733			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	6 of 7	
PARTS:	1. Assy 2.Black	parts Corrugated Tube Ø5 L=316±	3mm (No Slit)	3. Black Corrugated Tul	be Ø5 L=165±3mm (No Slit)	JIG:	n/a			
NO.	P	ROCESS NAME	WORK	PROCEDURE/ ILLUST	RATION	TOOLS/PPE	C	QUALITY POINT	ERS	
5		Wire insertion to Black Corrugated tube Ø5 L=316±3mm (No slit)	1.Get the Black COT Ø5 L=316±3mm (No slit) using right hand and insert Y-OR wires using left hand.		N/A	QUALITY POINTERS  1. No wrong use of parts 2. No deformed terminal				
6	n/a	Wire Insertion to Black Corrugated tube Ø5 L=165±3mm (No Slit)	1.Get the Black Corrugated Tu OR wires using left hand.	be Ø5 L=165±3mm (No Si	R  lit) using right hand then insert Y-			g use of parts med terminal		

		WORK INS	STRUCTION		Effectivity Date:		June 11, 2024	1
Process Na			NE ASSEMBLY PRO	CESS	Validity Date:	n/a WI-ENG-PDE-733		
Model code	/Part number: <b>700B / 7</b>	N0099-7020	Customer: TRJ	Car Model: Toyota-Land Cruiser	Document No.:			
Purpose:	PROTOTYP		PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	7 of 7
PARTS: n/a					JIG:	n/a		
			QUALITY CHE	CKPOINTS		ı		
n/a	1 2		7N00	99-7020		No. of		-
	X		2					
GOOD	GOOD							
	1 2 X							3
NO GOOD	NO GOOD	SO ME				133		
1 No Unlock Connecto (on 2 connecto		2	No Wrong (on 2 connect		No Defor Terminal	med		