

					Effectivity Date:		June 11, 2024								
NB			Process Name/Title: TAPING ASSEMBLY PROCESS							Validity Date:		n/a			
			Model code/Part number:		7R0112-7020	Customer: TRMX	Car Model: TOYOTA	A COROLLA		nent No.:		WI-ENG-PDE-3			
			Purpose:	PROTOTYF	PE	PRE-LAUNCH	MASSPRO		Revision	on No.:	2	Page No.:	1 of 5		
PARTS	:	1. Assy parts; Black SV tube (Vinly) ø4 L=96±3mm; Black tape; Green tape							JIG: n/a						
NO.		PROCESS NAME		✓2 WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE		QUALITY POIN	TERS		
	1	Table Lay-out Table Lay-out Tape holder/ Green tape							I pro (g) 1. M 2. I t pro For the A S Lea	fety Instruction Be sure to wear escribed personal tective equipmed during operation loves, finger cots etc.) Iousekeeping faintain and always practice 5's. Personal things of the workplace is obtained by the workplace is obtained. Keep it your locker. Alert level any trouble, info Assembly Assist upervisor or Line adder for immedia corrective action.	Inport I. Rater Complete proceed 1. No miss 2. No excellent In the proceed proceed In the proceed proceed In the proceed proceed proceed In the proceed	Document References: 1. Refer to WI-ENG-PDE-337 Offline Assembly Process			
					Revision History					Prepared by	Reviewed by	Approved by	Noted by		
06/11/24	2	Change Measure	process sequence due to Process notes and process of Car mode	ocess improvement. In	mproved Tabele lay-out, A"	, Visual inspection and	D.Castillo C.Villanuev a	A. Arañes r	n/a	4	,		,		
03/16/22	1	Change	from Pre-Launch to Masspro	M.Ariola J.Loterte	C. Villanueva A. A	rañes	1	1/4:4	CHARLE						
10/20/21	0	Initial issue. M.Ariola							rañes	D. Castillo	C. Villanueva	A. Aranes	n/a		
Eff. Date	Rev. No			Details of	Change		Revised Reviewed		oted E	,	October 20, 2021	, , .	.,, a		

			WORK INSTRU	Effectivity Date:	June 11, 2024				
	C	Process Name/Title:	TAPING A	Validity Date:	n/a				
		Model code/Part number:	177D / 7R0112-7020	Customer: TRMX	Car Model: TOYOTA COROLLA	Document No.:		WI-ENG-PDE-3	338
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	2	Page No.:	2 of 5
PARTS:	1. Assy 2. Blac	/ parts ck SV tube (Vinly) ø4 L=96:	± 3mm	3. Black tape	JIG:	n/a			
NO.	F	PROCESS NAME	WORK PRO	CEDURE/ ILLUSTRA	ATION	TOOLS/PPE	(QUALITY POIN	TERS
2		Wire insertion to Black SV tube (Vinly) ø4 L=96±3mm		1. Get the SV using right hausing left har	n/a	No wrong usage of parts No deformed terminal			
3	<u>/:</u>	Taping 1 SV tube (Vinyl) to wire near connector	1. Measure from end of SV tube (Vinyl) to connector 25±3mm using both hands. 25 ±3mm 25 ±3mm 25 ±3mm 20 ±3mm	2. Get the Black Tataping process usin	ping, check the measurement and	6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	1. Please measurin measure 1. No flip-c 2. No peel 3. No loose 4. No miss 5. No wron 6. No wron 1. Refer to strip lengt	out tape -off tape e tape ing tape ing dimension ing use of tape ents reference/ o WI-PRO-CNC-01 th tolerance.	rified ing the








	C	WORK INSTRUCTION							Effectivity Date:	June 11, 2024		
		Process Name/Title:	TAPING ASSEMBLY PROCESS						Validity Date:	n/a		
		Model code/Part number:	177D	/ 7R0112	-7020	Customer:	TRMX	Car Model: TOYOTA COROLLA	Document No.:		WI-ENG-PDE-3	338
		Purpose:	PROT	OTYPE		PRE-LAUNCH		MASSPRO	Revision No.:	2	Page No.:	5 of 5
PARTS:	1. Assy	ssy parts							JIG:	n/a		
VISUAL INSPECTION/ QUALITY CHECKPOINTS												

TAPING - P1


7R0112-7020



GOOD



NO GOOD



- **1** No Deformed Terminal
- 2 No Unlocked/Half-locked Connector
- No Missing Tape and No Wrong use of tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.