

Process Name/ Title: **PACKING INSTRUCTION**

WI-QAD-QAC-133 Document No:

WORK INSTRUCTION
Product Code/Name:

Customer Code:

Effective Date:

February 28, 2024

Ш		75N353	TRJ	Rev. No.: 2	Page No	o.: Paç	ge 1 of 1	
No.	Work Procedure/ Illustration					Records/Remarks/ Quality Pointers		
			7		Qty/box Mat'l name	400 Dim.	100pcs *4bdls Qty.	
			1941 1-		Oricon box	386*55* 243	1	
2	Prepare empty				Partition board	343*510	3	
1	oricon box in the "after inspection area"				Vinyl bag	545*450	4	
2	Get the vinyl (plastic) bag then put the 100 pcs harness. Insert products in same direction. Put the ID tag inside then fold the plastic bag.							
3	Put products on standing position and partition board vertically & alternately with the products. (100pcs* 4 Bundles with I.D tag inside)					White connectors must be on top position.		
4	Put NBP Identification tag at the top.Then warehouse Identification tag at lower right side of the box		tag. Put	need to attach 4N 4M tag at the left de of the box				

						i		
						Prepared	Checked	Approved
								. /
2/28/2024	2	Remove Vinyl Sheet	M. Garcia	D.Dadulla	R.Pascua			. [1. /
8/12/2022	1	Update product orientation to standing position	M. Garcia	R. Alcantara	A. Arañes	Menzaito	Mua	MH
7/05/2019	0	Initial issue	C.Dimailig	M.Lumbres	E. Mendoza		D.Dadulla	R.Fascula
Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Establish Date	: July 5, 2019	1

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any informa tion herein is strictly prohibited. **NBC (Philippines) MASTER COPY**