Process Name/ Title: Document No: WI-QAD-QAC-286 **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: September 19, 2024 Product Code/Name: Customer Code/ Customer: Page No.: Page 1 of 1 Rev. No.: 1 7N0070 **TRJ** Records/Remarks/ No. Work Procedure/ Illustration **Quality Pointers** 9pcs\* Qty/box **72** 8bdls Mat'l Dim. Qty. name 386\*55\*2 Oricon 1 box 43 Spread Vinyl sheet inside folding box. (1) Vinyl 1520\* 1 sheet 1500 **Partition** 343\* 1 board 510 Vinyl 300\* 8 200 bag 9pcs/4bundle Note: Plastic vinyl bag of Step 4 is applicable only to QC FG inspection. Put first bundle of products. (9pcs/4bundle) 2 Layout partition board Put the products (9pcs\* 4 bundles) (3) on the 2nd layer 2nd Layer Fold the vinyl sheet. Put NBP Identification tag at the top.Then **(4)** warehouse Identification tag at lower right side of the box. Note : If need to attach 4M tag
Put 4M tag at the left side of the box Prepared by Reviewed by Approved by Noted by -Change document control number from WI-ENG-PDE-501 to WI-QAD-QAC-286 M. Garcia R. Pascua 09/19/24 O. Merin -Change picture for item 2 and 3 05/10/22 Initial Issuance K. Doria J. Loterte C. Villanueva A. Arañes Prepared by Reviewed by Approved by Noted by Eff. Date Rev. No. Details of change

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY