Process Name/ Title: Document No: WI-QAD-QAC-272 **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: October 16, 2024 Product Code/Name: Customer Code/ Customer: Rev. No.: Page No.: Page 1 of 1 **75S321 TRMX** Records/Remarks/ No. Work Procedure/ Illustration **Quality Pointers** 1 100pcs\* Qty/box 400 4bdls Mat'l Dim. Qty. Put Vinyl Sheet name 1250 x 1250) inside TRMX box. **TRMX** 544\*370\* 1 228mm box Vinyl 1250\* 1 sheet 1250 (2) 343\* **Partition** 1 board 510 545\* Vinyl 4 450 bag Put first 2 bundles (100pcs\*2bdls) 3 Put 2nd 2 bundles (100pcs\*2bdls) (4) Lay out partition board vertically (5) Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at Note : If need to attach 4M tag
Put 4M tag at the left side of the box right side of the box. Prepared by Reviewed by Change control no. from WI-ENG-PDE-599 to WI-QAD-QAC-272; R. Pascua 10/16/2024 S. Malabuyoo D. Dadulla mardeyu Change vinyl sheet size to 1250 x 1250 O. Merin 11/17/2022 C. Villanueva J. Loterte A. Arañes Establish Date **NBC (Philippines)** 

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)

MASTER COPY